## Temperature & Humidity

- 1. Connect to the WiFi
- 2. Connect to the MQTT Server
- 3. Read the temperature & humidity
- 4. Write the data to MQTT