MIT OpenCourseWare http://ocw.mit.edu

6.189 Multicore Programming Primer, January (IAP) 2007

Please use the following citation format:

David Zhang, 6.189 Multicore Programming Primer, January (IAP) 2007. (Massachusetts Institute of Technology: MIT OpenCourseWare). http://ocw.mit.edu (accessed MM DD, YYYY). License: Creative Commons Attribution-Noncommercial-Share Alike.

Note: Please use the actual date you accessed this material in your citation.

For more information about citing these materials or our Terms of Use, visit: http://ocw.mit.edu/terms


6.189 IAP 2007

Recitation 1

Getting to Know Cell

Recap

- Cell: 9 cores on single chip
 - 1 PPE
 - 8 SPEs
- PPE is a general-purpose PowerPC processor
 - Runs operating system, controls SPEs
- SPEs optimized for data processing
- Cores are connected to each other and memory through high-bandwidth Element Interconnect Bus



Courtesy of International Business Machines Corporation. Used with permission.

What Makes Cell Different (And Difficult)?

- Multiple programs in one
 - PPU and SPU programs cooperate to carry out computation
- SIMD
 - SPU has 128 128-bit registers
 - All instructions are SIMD instructions
 - Registers are treated as short vectors of 8/16/32-bit integers or single/double-precision floats
- SPE local store
 - 256 KB of low-latency storage on each SPE
 - SPU loads/stores/ifetch can only access local store
 - Accesses to main memory done through DMA engine
 - Allows program to control and schedule memory accesses
 - Something new to worry about, but potential to be much more efficient

What Makes Cell Different (And Difficult)?

- Multiple programs in one
 - PPU and SPU programs cooperate to carry out computation
- SIMD
 - SPU has 128 128-bit registers
 - All instructions are SIMD instructions
 - Registers are treated as short vectors of 8/16/32-bit integers or single/double-precision floats
- SPE local store
 - 256 KB of low-latency storage on each SPE
 - SPU loads/stores/ifetch can only access local store
 - Accesses to main memory done through DMA engine
 - Allows program to control and schedule memory accesses
 - Something new to worry about, but potential to be much more efficient

SPU Programs

- SPU programs are designed and written to work together but are compiled independently
- Separate compiler and toolchain (spuxlc/spu-gcc, etc.)
- Produces small ELF image for each program that can be embedded in PPU program
 - Contains own data, code sections
 - On startup, C runtime (CRT) initializes and provides malloc
 - printf/mmap/some other I/O functions are implemented by calling on the PPU to service the request

A Simple SPU Program

SPU program hello_spu.c

```
#include <stdio.h>
int
main(unsigned long long speid,
         unsigned long long argp,
         unsigned long long envp)
{
   printf("Hello world! (0x%x)\n", (unsigned int)speid);
   return 0;
}
```

Compile and embed hello_spu.o

PPU program

extern spe_program_handle_t hello_spu;

Running SPU Programs

- SPE runtime management library (libspe)
 - Used by PPE only
- Provides interface similar to pthreads
- Run embedded SPU program as abstracted SPE thread
 - No direct access to SPEs
 - Threads can be scheduled, swapped in/out, paused

libspe

spe_create_thread

- spe_wait, spe_kill
- spe_read_out_mbox, spe_write_in_mbox, spe_write_signal
- spe_get_ls
 - Returns memory-mapped address of SPU's local store
 - PPU/other SPUs can DMA using this address
- spe_get_ps_area
 - Returns memory-mapped address of SPU's MMIO registers

#include <stdio.h>

A Simple Cell Program

PPU (hello.c)

```
#include <libspe.h>
extern spe_program_handle_t hello_spu;
int main() {
  speid_t id[8];
  // Create 8 SPU threads
  for (int i = 0; i < 8; i++) {
    id[i] = spe_create_thread(0,
                               &hello spu,
                              NULL,
                                                              SPU (hello spu.c)
                               NULL,
                               -1,
                                           #include <stdio.h>
                               0);
  }
                                           int
                                          main(unsigned long long speid,
  // Wait for all threads to exit
                                                unsigned long long argp,
  for (int i = 0; i < 8; i++) {
                                                unsigned long long envp)
    spe_wait(id[i], NULL, 0);
                                             printf("Hello world! (0x%x)\n", (unsigned int)speid);
                                             return 0;
  return 0;
```

Exercise 1.a (8 minutes)

- Compile and run hello example
 - Fetch tarball
 See example code in recitations section.
 - Unpack tarball tar zxf examples.tar.gz
 - Go to hello example cd examples/hello
 - Compile SPU program
 cd spu
 /opt/ibmcmp/xlc/8.1/bin/spuxlc -o hello_spu hello_spu.c -g -WI,-N
 embedspu -m32 hello_spu hello_spu hello_spu-embed.o
 ar –qcs hello_spu.a hello_spu-embed.o
 - Compile PPU program
 cd ..
 /opt/ibmcmp/xlc/8.1/bin/ppuxlc -o hello hello.c -g -WI,-m,elf32ppc spu/hello_spu.a -lspe
 - Run ./hello

Exercise 1.b (2 minutes)

- Make build system makes the compilation process easier
- Compile using the make build system
 - Set environment variable \$CELL_TOP
 export CELL_TOP=/opt/ibm/cell-sdk/prototype
 - Remove previously compiled code in directory make clean
 - Rebuild the program make
 - Run ./hello

What Makes Cell Different (And Difficult)?

- Multiple programs in one
 - PPU and SPU programs cooperate to carry out computation
- SIMD
 - SPU has 128 128-bit registers
 - All instructions are SIMD instructions
 - Registers are treated as short vectors of 8/16/32-bit integers or single/double-precision floats
- SPE local store
 - 256 KB of low-latency storage on each SPE
 - SPU loads/stores/ifetch can only access local store
 - Accesses to main memory done through DMA engine
 - Allows program to control and schedule memory accesses
 - Something new to worry about, but potential to be much more efficient

SIMD

scalar register


- Single Instruction, Multiple Data
- SIMD registers hold short vectors
- Instruction operates on all elements in SIMD register at once

Scalar code for (int i = 0; i < n; i++) { c[i] = a[i] + b[i]

```
a
b
C
```

Vector code

```
for (int i = 0; i < n; i += 4) {
  c[i:i+3] = a[i:i+3] + b[i:i+3]
```



SIMD

- Can offer high performance
 - Single-precision multiply-add instruction: 8 flops per cycle per SPE
- Scalar code works fine but only uses 1 element in vector
- SPU loads/stores on qword granularity only
 - Can be an issue if the SPU and other processors (via DMA) try to update different variables in the same qword
- For scalar code, compiler generates additional instructions to rotate scalar elements to the same slot and update a single element in a qword
- SIMDizing code is important
 - Auto SIMDization (compiler optimization)
 - Intrinsics (manual optimization)


SPU Intrinsics


- Vector data types
 - vector signed/unsigned char/short/int/long long
 - vector float/double
 - 16-byte vectors
- Intrinsics that wrap SPU instructions
- e.g. vector integer multiply-add instruction/intrinsic

What Makes Cell Different (And Difficult)?


- Multiple programs in one
 - PPU and SPU programs cooperate to carry out computation
- SIMD
 - SPU has 128 128-bit registers
 - All instructions are SIMD instructions
 - Registers are treated as short vectors of 8/16/32-bit integers or single/double-precision floats
- SPE local store
 - 256 KB of low-latency storage on each SPE
 - SPU loads/stores/ifetch can only access local store
 - Accesses to main memory done through DMA engine
 - Allows program to control and schedule memory accesses
 - Something new to worry about, but potential to be much more efficient

- SPU needs data
- 1. SPU initiates DMA request for data







- SPU needs data
- 1. SPU initiates DMA request for data
- 2. DMA requests data from memory




- SPU needs data
- 1. SPU initiates DMA request for data
- 2. DMA requests data from memory
- 3. Data is **copied** to local store



- SPU needs data
- 1. SPU initiates DMA request for data
- 2. DMA requests data from memory
- 3. Data is copied to local store
- 4. SPU can access data from local store



- SPU needs data
- 1. SPU initiates DMA request for data
- 2. DMA requests data from memory
- 3. Data is copied to local store
- 4. SPU can access data from local store
- SPU operates on data then copies data from local store back to memory in a similar process



DMA and SPEs

- 1 Memory Flow Controller (MFC) per SPE
- High bandwidth 16 bytes/cycle
- DMA transfers initiated using special channel instructions
- DMA transfers between virtual address space and local store
 - SPE uses PPE address translation machinery
 - Each SPE local store is mapped in virtual address space
 - Allows direct local store to local store transfers
 - Completely on chip, very fast
- Once DMA commands are issued, MFC processes them independently
 - SPU continues executing/accessing local store
 - Communication-computation concurrency/multibuffering essential for performance

DMA and SPEs

- Each MFC can service up to 24 outstanding DMA commands
 - 16 transfers initiated by SPU
 - 8 additional transfers initiated by PPU
 - PPU initiates transfers by accessing MFC through MMIO registers
- Each DMA transfer is tagged with 5-bit program-specified tag
 - Multiple DMAs can have same tag
 - SPU/PPU can wait or poll for DMA completion by tag mask
 - Can enforce ordering among DMAs with same tag

DMA Alignment

- 1/2/4/8/16-byte transfers that are naturally aligned
- Multiples of 16 bytes up to 16 KB per transfer
- DMA transfers of 16 bytes or less are atomic, no guarantee for anything else
- Memory and local store addresses must have same offset within a qword (16 bytes)
- DMA list commands
 - SPU can generate list of accesses in local store
 - Transfers between discontinuous segments in virtual address space to contiguous segment in local store
 - MFC processes list as single command

Mailboxes and Signals

- Facility for SPE to exchange small messages with PPE/other SPEs
 - e.g. memory address, "data ready" message
- From perspective of SPE
 - 1 inbound mailbox (4-entry FIFO) send messages to this SPE
 - 1 outbound mailbox (1-entry) send messages from this SPE
 - 1 outbound mailbox (1-entry) that interrupts PPE send messages from this SPE to PPE
 - 2 signal notification registers send messages to this SPE
 - Act as 1 entry or 32 independent bits
 - 32 bits
- SPU accesses its own mailboxes/signals by reading/writing to channels with special instructions
 - Read from inbound mailbox, signals
 - Write to outbound mailboxes
 - Accesses will stall if empty/full

Mailboxes and Signals

- SPE/PPE accesses another SPE mailboxes/signals through MMIO registers
 - Accesses do not stall
 - Read outbound mailboxes
 - Write inbound mailbox, signals
 - Accesses by multiple processors must be synchronized
 - If inbound mailbox overflows, last item is overwritten
 - Reading outbound mailbox when no data may return garbage

DMA

From SPU

- Also list commands: mfc_getl, mfc_putl
- mfc_stat_cmd_queue
 - Queries number of free DMA command slots
 - Similar functions to query available mailbox/signal entries

From PPU (libspe)

- spe_mfc_get, spe_mfc_put
- No list commands

DMA Example

- Array of integers in memory that we want to process on SPU
- Need to tell SPU program
 - Location (address) of array
 - Size of array
 - Additional parameters?
- Approach
 - Fill in control block in main memory
 - Pass address of control block to SPU
 - Have SPU DMA control block to local store

Generic C code

```
for (int i = 0; i < NUM_ELEMENTS; i++) {
  data[i] = data[i] * MUL_FACTOR + ADD_FACTOR;
}</pre>
```

```
typedef struct {
  uintptr32_t data_addr;
  uint32_t num_elements;
  ...
} CONTROL_BLOCK;
```

Generic C code

DMA Example

```
for (int i = 0; i < NUM_ELEMENTS; i++) {
  data[i] = data[i] * MUL_FACTOR + ADD_FACTOR;
}</pre>
```

PPU

SPU

```
CONTROL_BLOCK cb __attribute__((aligned(16)));
int *data;
int main(speid, argp, envp) {
  // DMA over control block
 mfc_get(&cb, argp, sizeof(cb), 5, ...);
  // Mask out tag we're interested in
 mfc_write_tag_mask(1 << 5);</pre>
  // Wait for DMA completion
 mfc_read_tag_status_all();
  // Compare mfc_read_tag_status_any/immediate
  // Allocate 128-byte aligned buffer
 data = malloc align(data size, 7);
  // DMA over actual data
 mfc_get(data, cb.data_addr, data_size, 5, ...);
 // Wait for DMA completion
 mfc_read_tag_status_all();
```

Generic C code

DMA Example

```
for (int i = 0; i < NUM_ELEMENTS; i++) {
  data[i] = data[i] * MUL_FACTOR + ADD_FACTOR;
}</pre>
```

PPU

```
// Wait for mailbox message from SPU
while (spe_stat_out_mbox(id) == 0);

// Drain mailbox
spe_read_out_mbox(id);

// Done!
...
```

SPU

```
// Process the data
for (int i = 0; i < cb.num_elements; i++) {
   data[i] = data[i] * MUL_FACTOR + ADD_FACTOR;
}

// DMA back results
mfc_put(data, cb.data_addr, data_size, 5, ...);

// Wait for DMA completion
mfc_read_tag_status_all();

// Notify PPU using outbound mailbox
spu_write_out_mbox(0);
return 0;
}</pre>
```

- Assumed entire array fits in one DMA command (16 KB)
- Assumed array size is multiple of 16 bytes

DMA Example 2

- Add 2 arrays of integers and store result in 3rd array
- Same approach
 - Fill in control block in main memory
 - Pass address of control block to SPU
 - SPU DMAs control block to LS
 - SPU DMAs both input arrays to LS
 - SPU DMAs result back to memory

```
typedef struct {
  uintptr32_t data1_addr;
  uintptr32_t data2_addr;
  uintptr32_t result_addr;
  uint32_t num_elements;
  ...
} CONTROL_BLOCK;
```

Generic C code

```
for (int i = 0; i < NUM_ELEMENTS; i++) {
  result[i] = data1[i] + data2[i];
}</pre>
```

// Data and result arrays

Generic C code

DMA Example 2

for (int i = 0; i < NUM_ELEMENTS; i++) {</pre> result[i] = data1[i] + data2[i];

PPU

```
int data1[NUM ELEMENTS] attribute ((aligned(128)));
int data2[NUM_ELEMENTS] __attribute__((aligned(128)));
int result[NUM_ELEMENTS] __attribute__((aligned(128)));
int main() {
  // Fill in control block
  cb.data1_addr = data1;
  cb.data2 addr = data2;
  cb.result addr = result;
  cb.num_elements = NUM_ELEMENTS;
  // Create SPU thread
  id = spe_create_thread(0, &dma_spu, &cb,
                         NULL, ...);
```

SPU

```
CONTROL_BLOCK cb __attribute__((aligned(16))); CONTROL_BLOCK cb __attribute__((aligned(16)));
                                                int *data1, *data2, *result;
                                                int main(speid, argp, envp) {
                                                  // DMA over control block
                                                  mfc_get(&cb, argp, sizeof(cb), 5, ...);
                                                  // Mask out tag we're interested in
                                                  mfc write tag mask(1 << 5);</pre>
                                                  // Wait for DMA completion
                                                  mfc_read_tag_status_all();
                                                  // Allocate 128-byte aligned buffers for data
                                                  // and results
                                                  // Start DMA for both input arrays with same tag
                                                  mfc_get(data1, cb.data1_addr, data_size, 5, ...);
                                                  mfc_get(data2, cb.data2_addr, data_size, 5, ...);
                                                  // Wait for completion of both transfers
                                                  mfc read tag status all();
```

DMA Example 2

for (int i = 0; i < NUM_ELEMENTS; i++) {
 result[i] = data1[i] + data2[i];
}</pre>

PPU

SPU

```
// Wait for mailbox message from SPU
while (spe_stat_out_mbox(id) == 0);

// Drain mailbox
spe_read_out_mbox(id);

// Done!
...
```

Same assumptions

- Each array fits in one DMA command (16 KB)
- Array sizes are multiples of 16 bytes

- Streaming data from SPE to SPE
- Distribute computation so one SPE does multiplication, another does addition

```
for (int i = 0; i < cb.num_elements; i++) {
  data[i] = data[i] * MUL_FACTOR + ADD_FACTOR;
}</pre>
```

- Keep actual data transfer local store to local store
- Communication?
 - PPE orchestrates all communication
 - SPEs talk to each other via mailboxes/signals


- SPEs that communicate with each other need to know:
 - Addresses of local stores
 - Addresses of MMIO registers
- Only PPU program (via libspe) has access to this information
 - PPU creates SPE threads, gathers address information, informs SPEs

PPU

PPU

SPU 0

SPU 1



PPU

```
typedef struct {
  uintptr32_t spu_ls[2];
  uintptr32_t spu_control[2];
  ...
} CONTROL_BLOCK;

// Fill in control block
for (int i = 0; i < 2; i++) {
  cb.spu_ls[i] = spe_get_ls(id[i]);
  cb.spu_control[i] =
    spe_get_ps_area(id[i], SPE_CONTROL_AREA);
}


...

// Send control block address to all SPUs
for (int i = 0; i < 2; i++) {
  spe_write_in_mbox(id[i], &cb);
}</pre>
```

Both SPUs

```
// Wait for control block address from PPU
cb_addr = spu_read_in_mbox();

// DMA over control block and wait until done
mfc_get(&cb, cb_addr, sizeof(cb), 5, ...);
mfc_write_tag_mask(1 << 5);
mfc_read_tag_status_all();</pre>
```





Data

SPU 0

```
// DMA in data from memory and wait until
// complete
mfc_get(data, cb.data_addr, data_size, ...);
mfc_read_tag_status_all();
```

David Zhang, MIT 38 6.189 IAP 2007 MIT






SPU 0

SPU₁

```
// Wait for mailbox message from SPU 0
// indicating data is ready.
data_addr = spu_read_in_mbox();
```




Data

Mailbox

SPU₁


```
// DMA in data from SPU 0 local store and
// wait until complete.
mfc_get(data, data_addr, data_size, ...);
mfc_read_tag_status_all();
```



SPU₁

SPU₀

```
// Wait for acknowledgement from SPU 1.
spu_read_in_mbox();
return 0;
```




Data

Mailbox

SPU₁

```
// DMA processed data back to memory and wait
// until complete
mfc_put(data, cb.data_addr, data_size, ...);
mfc_read_tag_status_all();
```



SPU₁

```
// Notify PPU.
spu_write_out_mbox(0);
return 0;
```



Documentation

- Cell Broadband Engine resource center
 - http://www-128.ibm.com/developerworks/power/cell
 - Tutorial (very useful)
 - Documentation for:
 - SPE runtime management library (libspe)
 - SPU C language extension (intrinsics)
 - Programmer's Handbook (more detailed information)
 - PowerPC architecture books (SIMD on PPU)
- Samples and library source in SDK directory
 - /opt/ibm/cell-sdk/prototype/src