

OS-65D V3.2

DISASSEMBLY

MANUAL

**SOFTWARE
CONSULTANTS**

7053 ROSE TRAIL / MEMPHIS, TENN. 38134 / (901) 377-3503

OS-65D VERSION 3.2 DISASSEMBLY

by

Software Consultants
7053 Rose Trail
Memphis, TN 38134
(901) 377-3503

This document is not from any official source, but was done using the "brute force method". That is, starting with the small amount of data released by OSI, each routine was painstakingly traced and decoded by hand. Great care was taken to insure accuracy throughout, however, if you do find any errors or omissions, please let us know. We will then forward all such corrections to all purchasers.

In several places within this listing you will find comments which are less than complimentary to OSI. This was not done with the intent of belittling the original authors of OS-65D, but strictly to inform all readers of the shortcomings as well as the virtues of this operating system. If anyone feels we have been overly critical, we apologize.

If any of your friends asks you to allow them to make a copy of this document, please ask them to first read the following.

Software Consultants is a professional software house specializing in OSI compatible products. We are in business to make a profit, just as all businesses are. The OS-65D disassembly represents over 500 manhours of research, compilation, and editing. The price was set as low as was possible while still allowing us a reasonable profit. If we are denied this reasonable profit by large numbers of people making pirate copies then we will not be able to continue working on other products for OSI equipment. You may save yourself a few dollars, but you will also be jeopardizing one of the very limited number of sources of high quality products for the OSI community.

COPYRIGHT 1980 by Software Consultants. All rights reserved.

GENERAL INFORMATION

One of the most frustrating features of using Ohio Scientific equipment is the almost total lack of useable documentation. OS-65D is supposed to be a "developmental" operating system, which implies that the user can develop his own machine language programs and tie them into the OS. Obviously this is not the case or this document would never have come into existence.

We originally broke the OS not as a money making project, but to enable us to tie our own machine language programs into the OS, and to give us the information necessary to make modifications that suit our needs. Once completed, we felt others attempting to use this OS could use this information to the same advantage that we have. Of course, the profit motive was also a deciding factor.

We assume that anyone using this document is thoroughly familiar with the workings of OS-65D V3.2 and is also a competent 6502 assembler programmer. Every effort has been made to make each routine within the OS as clear as possible. However, this is a reference manual, not a textbook.

We suggest that upon first reading this document you simply scan through and read all comments rather than attempt to absorb the entire thing at one reading. Then you may go back and read the actual code after first getting a feel for the contents and flow of the OS.

This manual was intentionally printed on just one side of the paper to allow you to put your own notes on the facing pages. In particular, if you make changes to the OS, note each change in the listing along with its purpose and the date made. If you will do your documentation as if you were going to be struck with amnesia tomorrow, it will truly make your life easier.

Following the listing of the OS itself is a complete cross reference showing the locations where each label is used. The location where the label is defined is marked with an asterisk. This should prove invaluable in both tracing logic and in assuring yourself that any changes made will not have any undesired side effects.

Our intention in the preparation of this manual was to make it as useful as possible to you, the purchaser. If after careful study of the listing, you still have unanswered questions about the workings of OS-65D, write us and we will attempt to answer your questions.

Happy computing!

DOS from Track 2+R0

; INITIALIZATION ROUTINE

; THIS IS THE ENTRY POINT WHEN THE SYSTEM IS BOOTTED.
; THE CODE FROM \$2200 TO \$22FF IS OVERLAYED BY BASIC WHEN IT IS CALLED.

2200 A9 01	LDA #1	
2202 20 B6 22	JSR PATCH0	SET SECTOR # AND STEP RATE
2205 20 BC 26	JSR SETTK	MOVE TO TRACK 1
2208 A9 2A	LDA #\$2A	
220A 85 FF	STA MEMHI	SET HI MEM ADDR
220C 20 54 27	JSR LDHEAD	LOAD HEAD
220F 86 FE	STX MEMLO	SET LOW MEM ADDR TO 0
2211 20 67 29	JSR READDK	READ TK 1 INTO \$2A00
2214 20 61 27	JSR UNLDHD	UNLOAD HEAD
2217 8E 01 F4	STX PTRPIA+1	
221A 8E 00 F4	STX PTRPIA	CLEAR PRINTER PIA (X=0)
221D 8E 03 F4	STX PTRPIA+3	
2220 CA	DEX	X=FF
2221 8E 01 DF	STX KPORT+1	SET KEYBOARD SOUND GENERATOR TO LOWEST FREQUENCY (192.753 HZ) THEN TURN IT OFF @ \$228F!!!
;		SET PRINTER PIA
;		
2224 8E 02 F4	STX PTRPIA+2	
2227 AD 06 FB	LDA UART+6	SET SERIAL PORT
222A 8E 05 FB	STX UART+5	
222D A9 04	LDA #4	PRINTER AGAIN
222F 8D 01 F4	STA PTRPIA+1	
2232 8D 03 F4	STA PTRPIA+3	RESET DISK (Y=0)
2235 8C 01 C0	STY FLOPIN+1	
2238 A0 40	LDY #\$40	SET TO DRIVE 1
223A 8C 00 C0	STY FLOPIN	RESET TERMINAL ACIA
223D 8D 01 C0	STA FLOPIN+1	SET TERMINAL ACIA
2240 A9 01	LDA #1	
2242 20 C6 29	JSR SETDRV	SET CA-10X 16 WAY SERIAL BOARD (IF ADDRESSED @ \$CF00)
2245 A9 03	LDA #3	
2247 8D 00 FC	STA TERMAC	
224A A0 11	LDY #\$11	
224C 8C 00 FC	STY TERMAC	
224F A2 1E	LDX #\$1E	
2251 9D 00 CF CLRX16	STA X16ACI,X	
2254 98	TYA	
2255 9D 00 CF	STA X16ACI,X	
2258 A9 03	LDA #3	
225A CA	DEX	
225B CA	DEX	
225C 10 F3	BPL CLRX16	CLEAR VIDEO SCREEN
225E A2 08	LDX #8	
2260 A9 D0	LDA #\$D0	
2262 85 FF	STA MEMHI	
2264 A0 00	LDY #0	
2266 84 FE	STY MEMLO	
2268 A9 20	LDA #\$20	
226A 91 FE	CLRVID STA (MEMLO),Y	
226C C8	INY	

```

226D D0 FB      BNE CLRVID
226F E6 FF      INC MEMHI
2271 CA          DEX
2272 D0 F6      BNE CLRVID
2274 86 00      STX PAGE0      X = 0
;
```

; WE ORIGINALLY THOUGHT THE ABOVE INSTRUCTION WAS USED FOR A
; FOR A PURPOSE WE HAVE NEVER SEEN DOCUMENTED. WHEN BASIC IS RUN
; IT PUTS A JUMP AT \$0000 TO \$0474 (4C 74 04). THIS JUMP WILL TAKE
; YOU TO THE COMMAND MODE. IF YOU RESET THE SYSTEM WHILE BASIC
; IS RUNNING AND DO NOT WISH TO LOSE THE PROGRAM IN MEMORY, ALL YOU
; HAVE TO DO IS TO JUMP TO \$0000 FROM THE MONITOR. I.E. TYPE M THEN
; L012E0000RG FOR A SERIAL SYSTEM OR .0000G FOR A VIDEO SYSTEM.
; ANOTHER TIME WHEN THIS IS USEFUL IS WHEN BASIC IS AT AN INPUT
; STATEMENT AND YOU DO NOT WANT TO CONTINUE THE PROGRAM. SINCE YOU
; CANNOT USE CONTROL C AT AN INPUT STATEMENT, JUST RESET AND DO THE
; ABOVE. WE SUSPECTED THE PURPOSE OF THIS INSTRUCTION WAS TO
; PREVENT DOING JUST THIS IF THE RESET IS HIT, THEN D, THEN RESET
; AGAIN BEFORE BASIC HAS BOOTTED. ACTUALLY THAT IS NOT THE REASON,
; BUT SINCE THIS IS A USEFUL PIECE OF INFORMATION, WE PUT IT IN
; ANYWAY. THE REASON \$00 IS SET TO 0 IS AS A FLAG FOR BASIC TO
; KNOW WHETHER OR NOT TO SWAP PAGE 0 AND 1 (SEE \$2D50).

; ; MEMTST : HIGHEST MEMORY TEST ROUTINE

; ; THIS ROUTINE CHECKS FOR THE HIGHEST AVAILABLE MEMORY PAGE.
; IT STARTS WITH THE PAGE @ \$BF00 AND MOVES DOWN IN STEPS OF ONE
; PAGE UNTIL IT FINDS MEMORY. A WORD OF CAUTION. IF YOU HAVE LESS
; THAN 48K AND INTEND TO USE SOME OF THE UPPER ADDRESS SPACE FOR
; HARDWARE, THEN THE STARTING PAGE ADDRESS @ \$2277 SHOULD BE MODIFIED
; OR THE MEMORY TEST MAY DO STRANGE THINGS TO YOUR DEVICE.

2276 A9 BF	MEMTST	LDY #\$BF	START TEST @ \$BF00
2278 20 EC 22		JSR MEMCHK	TEST THIS PAGE
227B F0 03		BEQ HMFND	IF SO, FOUND MEMORY
227D 88		DEY	TRY NEXT PAGE
227E D0 F8		BNE MEMTST+2	ALWAYS JUMP BACK
2280 8C 00 23	HMFND	STY HIMEM	STORE HIGHEST MEMORY PAGE
2283 A2 01		LDX #1	CHECK FOR SERIAL OR VIDEO
2285 AD 01 FE		LDA \$FE01	(EITHER 65-A OR 65-V PROM)
2288 F0 01		BEQ *+1	
228A E8		INX	IF VIDEO SET X=2
228B 8E C6 2A		STX DEFDEV	STORE DEFAULT DEVICE
; THE DEFAULT DEVICE ABOVE IS PICKED UP BY BEXEC* AND PUT INTO THE			
; INPUT & OUTPUT DISTRIBUTOR BYTES. THIS IS THE REASON THAT THE			
; BASIC STARTUP MESSAGE IS NOT PRINTED ON BOOTING THE SYSTEM, SINCE			
; THE OUTPUT DISTRIBUTOR ON DISK IS \$00, WHICH DOES NOT OUTPUT TO			
; ANYTHING.			
228E EA		NOP	
228F A2 01		LDX #1	SET VIDEO TO 64 CHAR/LINE
; TURN OFF SOUND GENERATOR, COLOR			
2291 8E 00 DE		STX VIDSIZ	

```

2294 4C B3 22      JMP GOBAS      SKIP OVER UNUSED CODE!
;
; $2297-$22B2 IS UNUSED CODE
;
2297 EC 22 F0      CPX $F022      2294 A0 DB LDY #$DB
229A 18             CLR             2296 20 EC22 JSR 22EC
229B A0 D7      LDY #$D7        2299 F019 BEQ 22B3
229D 20 EC 22      JSR MEMCHK
22A0 D0 11      BNE $22B3
22A2 A0 00      LDY #0
22A4 BE C7 22      LDX $22C7,Y
22A7 F0 0A      BEQ $22B3
22A9 C8      INY
22AA B9 C7 22      LDA $22C7,Y
22AD 9D 99 25      STA VIDOUT,X
22B0 C8      INY
22B1 D0 F1      BNE $22A4
;
22B3 4C E6 2A GOBAS JMP BASIC      LOAD AND EXECUTE BASIC
;
; THE JUMP ABOVE IS TO THE SAME ROUTINE USED WITH THE 'BA'
; COMMAND. YET 'BEXEC*' IS RUN ONLY WHEN THE SYSTEM IS BOOTED.
; THE METHOD USED TO DO THIS IS REALLY QUITE ELEGANT. THE INPUT
; DISTRIBUTOR ON DISK IS SET FOR MEMORY INPUT, WHILE THE MEMORY
; INPUT POINTER ON DISK POINTS TO $2E25. THIS IS WITHIN THE OS
; INPUT BUFFER. AND WHAT IS AT $2E25 ON DISK? WHY, 'RUN BEXEC* (CR)', 
; OF COURSE. THEN WHEN 'BEXEC*' RUNS, IT SETS THE INPUT AND OUTPUT
; DISTRIBUTORS FROM THE DEFAULT DEVICE (SEE NOTE @ $228B), SO THE
; NEXT TIME THE 'BA' COMMAND IS EXECUTED, 'BEXEC*' IS NOT RUN.
;
; THIS PATCH ADDED FOR ADAPTIVE STEP RATE
;
22B6 8D 5E 26 PATCH0 STA SECTNM      SET SECTOR TO 1
22B9 A2 08          LDX #$08
22B8 86 EF          STX STEPRT      STEP RATE
22BD 60          RTS
;
; $22C7 THRU $22EB IS A TABLE USED BY THE UNUSED ROUTINE @$2297.
;
; MEMCHK : MEMORY CHECK SUBROUTINE. CALLED @ $2278
;
; THERE MUST BE SOME REASON TO ONLY CHECK THE LOWEST SIX BITS OF
; THE BYTE UNDER TEST, BUT WE SURE CAN'T THINK OF ONE!
;
22EC 84 FF      MEMCHK STY MEMHI      POINT TO PAGE UNDER TEST
22EE B1 FE      LDA (MEMLO),Y      GET A BYTE FROM THAT PAGE
22F0 29 3F      AND #$3F        KILL HIGHEST 2 BITS (?!)
22F2 49 3F      EOR #$3F        INVERT ALL REMAINING BITS
22F4 91 FE      STA (MEMLO),Y      PUT HASHED BYTE BACK
22F6 85 FD      STA TS2         AND SAVE IT
22F8 B1 FE      LDA (MEMLO),Y      GET BYTE BACK FROM MEMORY
22FA 29 3F      AND #$3F        KILL HIGHEST 2 BITS
22FC C5 FD      CMP TS2         IS IT THE SAME?

```

) 22FE 60

RTS

EXIT WITH EQL FLAG SET

```

; OS-65D V3.2 (NMHZ)

; ZERO PAGE LOCATIONS USED BY OS

;      PAGE0 = $0000      BASE OF PAGE ZERO
00E0      TS1    = $00E0      TEMPORARY STORAGE
00E1      OSIBAD = $00E1      OS INPUT BUFFER ADDRESS
00E3      STROAD = $00E3      ADDRESS USED BY STROUT ROUTINE
00E5      HSTTK  = $00E5      HIGHEST TRACK NUMBER OF FILE
00EE      TKNHLD = $00EE      TRACK NUMBER HOLD
00EF      STEPRT = $00EF      STEP RATE FOR DISK
00F5      SCTRTRY = $00F5     SECTOR RETRY COUNT
00F6      WRTRTRY = $00F6     WRITE RETRY COUNT
00F7      RDRTYN = $00F7     READ VERIFICATION RETRY COUNT
;          NOT USED ON      AFTER MOVING HEAD (3)
00F8      RDRTYN = $00F8     VERIFY AFTER DISK WRITE
;          NOT USED ON      READ VERIFICATION RETRY COUNT
;          WITHOUT MOVING HEAD (7)
; ON READ, TOTAL RETRIES BEFORE AN ERROR = RDRTYN * RDRTYM (21)
00F9      SCTBYP = $00F9      SECTORS BYPASSED COUNTER
00FA      SCTLEN = $00FA      SECTOR LENGTH IN PAGES
00FB      SCTNUM = $00FB      SECTOR NUMBER
00FC      STKADR = $00FC      STACK ADDRESS
00FD      TS2    = $00FD      TEMPORARY STORAGE
00FE      MEMLO  = $00FE      INDIRECT MEMORY ADDRESS, LOW
00FF      MEMHI  = $00FF      "           "           "           , HI

; OTHER MEMORY ADDRESSES REFERRED TO BY THE OS
; ALL EXCEPT THOSE MARKED WITH AN ASTERISK ARE PART OF AN INSTRUCTION
; AND THEREFORE ARE CASES OF SELF-MODIFYING CODE.
; DURING THE LISTING, ANY ADDRESS WHICH IS MODIFIED IS DENOTED BY
; TWO ASTERISKS (**) IN THE PLACE OF AN ADDRESS.

;      STACK  = $0100      * BASE OF STACK (PAGE 1)
0100      SWAP4A = $0213      * 4 BYTES SWAPPED DURING POLLED
;          KEYBOARD ROUTINE
1300      STASM  = $1300      * COLD START FOR ASSEMBLER
1303      RTASM  = $1303      * RESTART ASSEMBLER ENTRY POINT
1700      STEM   = $1700      * COLD START FOR EXTENDED MONITOR
;          THERE IS NO RESTART POINT
20C4      RTBAS  = $20C4      * RESTART BASIC ENTRY POINT
20E4      STBAS  = $20E4      * COLD START FOR BASIC
235F      X.HOLD = $235F      X REGISTER HOLD
2361      Y.HOLD = $2361      Y REGISTER HOLD
2363      A.HOLD = $2363      ACCUMULATOR HOLD
2378      IOOFS = $2378      VECTORED I/O OFFSET
238A      MINADR = $238A     MEMORY INPUT ADDRESS
2391      MOTADR = $2391     "      OUTPUT "
23AC      D1IADR = $23AC     DISK 1 BUFFER INPUT ADDRESS
23C3      D1OADR = $23C3     "      "      OUTPUT "
23FD      D2IADR = $23FD     "      2      "      INPUT "
2416      D2OADR = $2416     "      "      "      OUTPUT "
25A4      VOTOFS = $25A4     VIDEO OUTPUT LINE OFFSET

```

262B VLP1 = \$262B VIDEO LINE POINTER DURING SCROLL
 262E VLP2 = \$262E " " " "
 2639 VLOSAV = \$2639 " " OFFSET SAVE
 267B NMHZ = \$267B NMHZ VARIABLE
 ;
 ;
 ;

2AC6 DEFDEV = \$2AC6 DEFAULT I/O DEVICE (SET @ \$228B)
 2CE5 BUFOFS = \$2CE5 OS BUFFER OFFSET
 2CED MAXBUF = \$2CED MAXIMUM SIZE OF OS BUFFER
 D700 PLINE = \$D700 * PRINT LINE FOR 540 VIDEO

; FLOPPY DISK PIA (MC6821)

C000 FLOPIN = \$C000 FLOPPY DISK STATUS PORT

; BIT FUNCTION

; ---
 ; 0 DRIVE 0 READY (0 IF READY)
 ; 1 TRACK 0 (0 IF AT TRACK 0)
 ; 2 FAULT (0 IF FAULT)
 ; 4 DRIVE 1 READY (0 IF READY)
 ; 5 WRITE PROTECT (0 IF WRITE PROTECT)
 ; 6 DRIVE SELECT (1 = A OR C, 0 = B OR D)
 ; 7 INDEX (0 IF AT INDEX HOLE)

C002 FLOPOT = \$C002 FLOPPY DISK CONTROL PORT

; BIT FUNCTION

; ---
 ; 0 WRITE ENABLE (0 ALLOWS WRITING)
 ; 1 ERASE ENABLE (0 ALLOWS ERASING)
 ; ERASE ENABLE IS ON 200us AFTER WRITE IS ON
 ; ERASE ENABLE IS OFF 530us AFTER WRITE IS OFF
 ; 2 STEP BIT : INDICATES DIRECTION OF STEP (WAIT 10 us FIRST)
 ; 0 INDICATES STEP TOWARD 76
 ; 1 INDICATES STEP TOWARD 0
 ; 3 STEP (TRANSITION FROM 1 TO 0)
 ; MUST HOLD AT LEAST 10 us, MIN 8us BETWEEN
 ; 4 FAULT RESET (0 RESETS)
 ; 5 SIDE SELECT (1 = A OR B, 0 = C OR D)
 ; 6 LOW CURRENT (0 FOR TRKS 43-76, 1 FOR TRKS 0-42)
 ; 7 HEAD LOAD (0 TO LOAD : MUST WAIT 40ms AFTER)

; FLOPPY DISK ACIA (MC6850)

C010 ACIA = \$C010 DISK CONTROLLER ACIA STATUS PORT
 C011 ACIAIO = \$C011 " " " I/O "

; OTHER HARDWARE ADDRESSES

CF00 X16ACI = \$CF00 NORMAL BASE ADDRESS OF CA10X BOARD
 DE00 VIDSIZE = \$DE00 VIDEO SIZE (1 = 64 CHAR, 0 = 32)

DF00	KPORT = \$DF00	POLLED KEYBOARD PORT
F400	PTRPIA = \$F400	PARALLEL PRINTER PIA (MC6821)
FB00	UART = \$FB00	430 BOARD SERIAL PORT (S1883)
FC00	TERMAC = \$FC00	SERIAL TERMINAL ACIA STATUS PORT
FC01	TERMIO = \$FC01	" " " I/O "
FD00	KPOLL = \$FD00	POLLED KEYBOARD ROUTINE (ROM)

;
; THE ACIAS AT \$CFXX AND \$FC00 ARE ALL MC6850'S

; START OF RESIDENT OS MEMORY AREA

2300 HIMEM = \$2300 HIGHEST MEMORY PAGE ADDRESS
SET @ \$2280

; I/O DISPATCH TABLE (ADDRESS = ACTUAL ADDRESS - 1)
; ROUTINES ARE CALLED BY PUSHING THE ADDRESS ON
; THE STACK AND DOING AN RTS.

; INPUT DISPATCH TABLE

2301 F5 24	IOTABL .WORD TERMIN-1	TERMINAL (ACIA): BASIC DEVICE 1
2303 2A 25	.WORD KBINP-1	POLLED KEYBOARD: BASIC DEVICE 2
2305 17 25	.WORD SERINP-1	SERIAL (UART): BASIC DEVICE 3
2307 85 23	.WORD NULLIN-1	NULL: BASIC DEVICE 4
2309 88 23	.WORD MEMIN-1	MEMORY: BASIC DEVICE 5
230B A0 23	.WORD DK1IN-1	DISK1: BASIC DEVICE 6
230D EF 23	.WORD DK2IN-1	DISK2: BASIC DEVICE 7
230F AF 24	.WORD X16INP-1	CA10X: BASIC DEVICE 8

; OUTPUT DISPATCH TABLE

2311 CC 24	.WORD TERMOT-1	TERMINAL (ACIA): BASIC DEVICE 1
2313 98 25	.WORD VIDOUT-1	540 VIDEO: BASIC DEVICE 2
2315 0C 25	.WORD SEROUT-1	SERIAL (UART): BASIC DEVICE 3
2317 9E 24	.WORD PTROUT-1	PARALLEL PRINTER: BASIC DEVICE 4
2319 8F 23	.WORD MEMOT-1	MEMORY: BASIC DEVICE 5
231B B1 23	.WORD DK1OUT-1	DISK1: BASIC DEVICE 6
231D 02 24	.WORD DK2OUT-1	DISK2: BASIC DEVICE 7
231F BC 24	.WORD X16OUT-1	CA10X: BASIC DEVICE 8

; GENERAL STORAGE AREA

2321 01	INDST = *	INPUT DISTRIBUTOR
2322 01	OUTDST = *	OUTPUT DISTRIBUTOR
2323 00	X16DEV = *	CA10X DEVICE # * 2 (0-1E)
2324 D4	RNDSED = *	RANDOM NUMBER SEED
2325 00	KPDO = *	KEY PRESSED DURING OUTPUT
2326 7E	D1BFLO = *+2	DISK1 BUFFER LOW ADDRESS
2327 31		
2328 7E	D1BFHI = *+2	DISK1 BUFFER HI ADDRESS
2329 3D		
232A 50	D1FRST = *	DISK1 FIRST TRACK
232B 51	D1LAST = *	DISK1 LAST TRACK
232C 50	D1CRTK = *	DISK1 CURRENT TRACK
232D 00	D1BFDR = *	DISK1 BUFFER 'DIRTY' FLAG
232E 7E	D2BFLO = *+2	DISK2 BUFFER LOW ADDRESS
232F 3D		
2330 7E	D2BFHI = *+2	DISK2 BUFFER HI ADDRESS
2331 49		
2332 50	D2FRST = *	DISK2 FIRST TRACK
2333 51	D2LAST = *	DISK2 LAST TRACK
2334 50	D2CRTK = *	DISK2 CURRENT TRACK

```

2335 00      D2BFDR = *          DISK2 BUFFER 'DIRTY' FLAG
;
; START OF ACTUAL CODE
;
; INPUT/OUTPUT ROUTINES
;
2336 4C D6 2C IN1    JMP INPUT      USED BY INECHO @\$2340
;
; DOINP : DO VECTORED INPUT BASED ON VALUE IN INDST
;
; (SEE NOTE AT \$2CD6)
; THE OS-65D MANUAL SAYS THAT INPUT IS DONE FROM THE LOWEST SET
; DEVICE & ALL OTHERS ARE IGNORED. WRONG!!! IF MORE THAN ONE BIT
; IS SET IN INDST, THINGS REALLY GO CRAZY. TRY ENTERING "IO 11"
; (OR "IO 12" FOR A VIDEO SYSTEM) AT "A*" AND WATCH THE RESULTS.
;
2339 A0 00      DOINP LDY #$00      SET FOR INPUT
233B AD 21 23    LDA INDST      GET INPUT DISTRIBUTOR
233E D0 0B      BNE DOIO      GO DO INPUT
;
; INECHO : INPUT & ECHO. ALSO CHECKS FOR CONTROL CHARACTERS.
;
2340 20 36 23 INECHO JSR IN1      INPUT AND ECHO
;
; THIS SHOULD HAVE BEEN
; JSR INPUT. WHY THEY DID IT
; THIS WAY WE DON'T KNOW.
;
; PRINT ROUTINE : OUTPUT TO ALL ACTIVE DEVICES
; OUTPUT CHARACTER IN A
;
2343 20 67 23 PRINT   JSR SAVAXY    SAVE ALL REGISTERS
2346 AD 22 23    LDA OUTDST    GET OUTPUT DISTRIBUTOR
2349 A0 10      LDY #$10      DENOTES OUTPUT
;
; DO I/O, EITHER INPUT OR OUTPUT BASED ON VALUE IN Y
;
234B A2 FF      DOIO   LDX #$FF      SET INDEX TO DETERMINE DEVICE
234D D0 22      DOIO   BNE PATCH1 ($2371) GO TO PATCH FOR I/O OFFSET
234F E8      INX
2350 4A      LSR A      CHECK FOR I/O BIT ON
2351 90 09      BCC DONXIO    ($235C) BRANCH IF NOT
2353 48      PHA      SAVE REST OF I/O DIST BYTE
2354 8A      TXA      AND DEVICE NUMBER FOUND
2355 48      PHA      I/O DEVICE NOW IN A
2356 20 76 23    JSR IODISP    GO DO I/O
2359 68      PLA      RESTORE A AND X
235A AA      TAX
235B 68      PLA
235C D0 F1      DONXIO BNE DOIO+4    ($234F) IF ANY BITS STILL ON
;
; RSTAXY : RESTORE A,X,Y (USED AFTER SAVAXY)
; WARNING! THIS ROUTINE MASKS OUT THE UPPER BIT IN A
;
```

```

235E A2 00 RSTAXY LDX **      RESET X
2360 A0 00 LDY **           RESET Y
2362 A9 00 LDA **           RESET A
2364 29 7F AND #$7F        KILL UPPER BIT IN A
2366 60 RTS                 BACK WE GO
;
; SAVAXY : SAVE A,X,Y FOR LATER
;
2367 8D 63 23 SAVAXY STA A.HOLD   SAVE A
236A 8C 61 23 STY Y.HOLD       SAVE Y
236D 8E 5F 23 STX X.HOLD       SAVE X
2370 60 RTS
;
; PATCH TO SET I/O OFFSET
;
2371 8C 78 23 PATCH1 STY IOOFS    STORE I/O OFFSET
2374 D0 D9 BNE DOIO+4          ($234F) GO BACK
;
; IODISP : I/O DISPATCH ROUTINE
;
2376 0A IODISP ASL A          MULTIPLY I/O DEVICE BY 2
2377 69 00 ADC **             I/O OFFSET (0=INPUT $10=OUTPUT)
2379 AA TAX                  GET SET TO GET I/O ADDRESS
237A BD 02 23 LDA IOTABL+1,X   GET HI BYTE
237D 48 PHA                 PUSH ON STACK
237E BD 01 23 LDA IOTABL,X    GET THE LOW BYTE
2381 48 PHA                 PUSH ON STACK
2382 AD 63 23 LDA A.HOLD     RESTORE A FOR OUTPUT
2385 60 RTS                 JUMP TO ROUTINE
;
; NULLIN : NULL INPUT ROUTINE (BASIC DEVICE 4)
;
; WHILE THE NULL INPUT ROUTINE IN ITSELF IS NOT THAT USEFUL,
; SINCE IT IS 3 BYTES LONG IT COULD BE USED AS A JUMP TO A
; USER DEFINED INPUT ROUTINE.
;
2386 A9 00 NULLIN LDA #$00
2388 60 RTS
;
; MEMIN : INPUT FROM MEMORY ROUTINE (BASIC DEVICE 5)
; THIS ROUTINE IS ALSO USED FOR THE INDIRECT FILE FUNCTION
;
2389 AD 00 00 MEMIN LDA **      GET BYTE FROM MEMORY
;                               MODIFIED BY COMINC
238C A2 00 LDX #$00           SET OFFSET
238E F0 05 BEQ COMINC         GO TO COMMON INCREMENT ROUTINE
;
; MEMOT : MEMORY OUTPUT ROUTINE (BASIC DEVICE 5)
; THIS ROUTINE IS ALSO USED BY THE INDIRECT FILE FUNCTION.
;
2390 8D 00 00 MEMOT STA **      PUT BYTE IN MEMORY
;                               MODIFIED BY COMINC
2393 A2 07 LDX #$07           SET OFFSET

```

; COMINC : COMMON INCREMENT ROUTINE
; THE FOLLOWING ROUTINE IS USED BY THE DISK 1 AND 2 INPUT
; AND OUTPUT ROUTINES AS WELL AS THE MEMORY INPUT AND OUTPUT
; ROUTINES. THIS IS AN EXTREME CASE OF SELF MODIFING CODE WHICH
; SHOULD NORMALLY BE AVOIDED. X IS USED AS THE INDEX
; AND IS SET BY EACH INDIVIDUAL ROUTINE BEFORE CALLING THIS ROUTINE.
;

```
2395 8D 63 23 COMINC STA A.HOLD      SAVE A
2398 FE 8A 23           INC MINADR,X   INCREMENT MEMORY ADDRESS
239B D0 03             BNE *+5       ($23A0)
239D FE 8B 23           INC MINADR+1,X
23A0 60               RTS
```

; DK1IN : DISK 1 INPUT ROUTINE (BASIC DEVICE 6)
;

```
23A1 A0 00   DK1IN LDY #$00      SET Y OFFSET
23A3 20 66 24           JSR CKBFEN-2  CHECK FOR END OF BUFFER
23A6 D0 03             BNE *+5       ($23AB) IF NOT END OF BUFFER, CONT
23A8 20 CC 23           JSR DK1NXT   READ NEXT TRACK
23AB AD 7E 31           LDA **
23AE A2 22             LDX #$22      LOAD BYTE (MODIFIED BY COMINC)
23B0 D0 E3             BNE COMINC   SET THE OFFSET
                                GO USE COMMON INCREMENT ROUTINE
```

; DK1OUT : DISK 1 OUTPUT ROUTINE (BASIC DEVICE 6)
;

; THIS ROUTINE WILL ALLOW YOU TO PRINT ANY CHARACTERS TO DISK EXCEPT
; A LINE FEED (\$0A). SOMETIMES IT IS USEFUL TO BE ABLE TO WRITE A
; LINE FEED TO DISK, I.E. CREATING A WORD PROCESSOR OR ASSEMBLER
; FILE WITH BASIC. IF YOU WISH TO DO SO, YOU CAN CHANGE THE FOURTH
; BYTE OF EITHER DISK OUTPUT ROUTINE TO A NULL (HEX 0). JUST BE SURE
; YOU DON'T DO A "NORMAL" WRITE TO DISK WHILE THE CHANGE IS IN EFFECT
; OR THE CARRIAGE RETURN WILL BE FOLLOWED BY A LINE FEED.

```
23B2 C9 0A   DK1OUT CMP #$0A      IF LINE FEED THEN RETURN
23B4 F0 EA   BEQ DK1IN-1   ($23A0)
23B6 48         PHA          SAVE BYTE TO BE WRITTEN
23B7 A0 17         LDY #$17      SET Y FOR OFFSET
23B9 20 66 24           JSR CKBFEN-2  CHECK FOR END OF BUFFER
23BC D0 03             BNE *+5       ($23C1) CONTINUE IF NOT AT END
23BE 20 CC 23           JSR DK1NXT   WRITE THIS TRACK, READ NEXT
23C1 68             PLA          RESTORE THE OUTPUT BYTE
23C2 8D 7E 31           STA **      PUT IN BUFFER (MODIFIED BY COMINC)
23C5 A2 39             LDX #$39      SET OFFSET FOR COMMON INCREMENT
23C7 8E 2D 23           STX D1BFDR   SET BUFFER DIRTY FLAG
23CA D0 C9             BNE COMINC  BRANCH TO COMMON INCREMENT
```

; DK1NXT : DISK 1 NEXT TRACK READ, USED BY DK1IN AND DK1OUT
;

```
23CC AD 2D 23 DK1NXT LDA D1BFDR   GET BUFFER 'DIRTY' FLAG
23CF F0 05           BEQ *+7       ($23D6) IF NOT 'DIRTY' CONTINUE
23D1 A2 00             LDX #$00      SET OFFSET
```

```

) 23D3 20 77 24      JSR WTDKBF      GOSUB TO WRITE DISK BUFFER
23D6 AD 26 23      LDA D1BFLO      RESET READ/WRITE ADDRESS
23D9 8D AC 23      STA D1IADR      AND MEMORY ADDRESS TO START
23DC 8D C3 23      STA D1OADR      OF DISK BUFFER
23DF 85 FE          STA MEMLO
23E1 AD 27 23      LDA D1BFLO+1
23E4 8D AD 23      STA D1IADR+1
23E7 8D C4 23      STA D1OADR+1
23EA 85 FF          STA MEMHI
23EC A2 00          LDX #$00      SET OFFSET
23EE F0 52          BEQ BDRDNX    ALWAYS BRANCH
;
; DK2IN : DISK 2 INPUT ROUTINE (BASIC DEVICE 7)
;
23F0 A2 08          DK2IN     LDX #$08      SET OFFSETS
23F2 A0 51          LDY #$51
23F4 20 68 24      JSR CKBFEN
23F7 D0 03          BNE *+5
23F9 20 20 24      JSR DK2NXT
23FC AD 7E 3D      LDA **
;
23FF A2 73          LDX #$73
2401 D0 92          BNE COMINC   BRANCH TO COMMON INCREMENT
;
; DK2OUT : DISK 2 OUTPUT ROUTINE (BASIC DEVICE 7)
; SEE NOTE @\$23B2 ABOUT LINE FEED
;
2403 C9 0A          DK2OUT    CMP #$0A      IF LINE FEED THEN RETURN
2405 F0 6F          BEQ $2476
2407 48              PHA
2408 A2 08          LDX #$08      SAVE BYTE TO BE WRITTEN
240A A0 6A          LDY #$6A      SET OFFSETS
240C 20 68 24      JSR CKBFEN
240F D0 03          BNE *+5
2411 20 20 24      JSR DK2NXT
2414 68              PLA
2415 8D 7E 3D      STA **
2418 A2 8C          LDX #$8C
241A 8E 35 23      STX D2BFDR
241D 4C 95 23      JMP COMINC   SET BUFFER 'DIRTY' FLAG
;
; DK2NXT : DISK 2 NEXT TRACK READ, USED BY DK2IN AND DK2OUT
;
2420 AD 35 23      DK2NXT    LDA D2BFDR
2423 F0 05          BEQ *+7      GET BUFFER 'DIRTY' FLAG
2425 A2 08          LDX #$08      ($242A) CONTINUE IF NOT 'DIRTY'
2427 20 77 24      JSR WTDKBF
242A AD 2E 23      LDA D2BFLO
242D 8D FD 23      STA D2IADR
2430 8D 16 24      STA D2OADR
2433 85 FE          STA MEMLO
2435 AD 2F 23      LDA D2BFLO+1
2438 8D FE 23      STA D2IADR+1

```

```

) 243B 8D 17 24      STA D2OADR+1
243E 85 FF          STA MEMHI
2440 A2 08          LDX #$08      SET OFFSET
;
;
; THE NEXT GROUP OF ROUTINES ARE USED BY BOTH DISK 1 & DISK 2
; X IS SET TO 0 FOR DISK 1 AND TO 8 FOR DISK 2.
;
; BDRDNX : BUFFERED DISK I/O READ NEXT TRACK
;
2442 BD 2C 23 BDRDNX LDA DICRTK,X   GET CURRENT TRACK NUMBER
2445 18             CLC           GET SET TO ADD 1 TO CURRENT TRACK
2446 F8             SED           SET DECIMAL (TRACK# IN BCD)
2447 69 01          ADC #$01     DO THE ADD
2449 D8             CLD           CLEAR DECIMAL MODE
244A 9D 2C 23       STA D1CRTK,X  SAVE THE TRACK NUMBER
244D 20 53 24       JSR BDMHTK   MOVE HEAD TO TRACK
2450 4C 1D 2B       JMP CALL+12  ($2B1D) READ DISK, UNLOAD HEAD
;
;
; BDMHTK : BUFFERED DISK I/O MOVE HEAD TO TRACK
;
2453 A9 00          BDMHTK LDA #$00    CLEAR BUFFER 'DIRTY' FLAG
2455 9D 2D 23       STA D1BFDR,X
2458 BD 2C 23       LDA D1CRTK,X   COMPARE CURRENT TRACK
245B DD 2B 23       CMP D1LAST,X  WITH LAST TRACK
245E 20 8D 2C       JSR INCTKN+10 ($2C8D) MOVE HEAD TO TRACK, IF
;
;                               INY           PAST END OF FILE, ERROR D
2461 C8             BNE PATCH2   SET Y TO 1
2462 D0 2D           BRK           ALWAYS BRANCH TO PATCH2
2464 00             BRK           (NOT USED)
2465 00             BRK           (NOT USED)
;
2466 A2 00          LDX #$00    SET OFFSET
;
;
; CKBFEN : CHECK FOR END OF BUFFER
;
2468 B9 AC 23 CKBFEN LDA D1IADR,Y  LOW ADDRESS OF BYTE TO BE READ
246B DD 28 23       CMP D1BFHI,X  LOW ADDRESS OF END OF BUFFER
246E D0 06          BNE *+8     ($2476) IF NOT THE SAME THEN RETURN
2470 B9 AD 23       LDA D1IADR+1,Y HI ADDRESS OF BYTE TO BE READ
2473 DD 29 23       CMP D1BFHI+1,X HI ADDRESS OF END OF BUFFER
2476 60             RTS          RETURN WITH Z FLAG SET IF END
;
;
; WTDKBF : WRITE DISK BUFFER
;
2477 BD 29 23 WTDKBF LDA D1BFHI+1,X HI ADDR OF BUFFER HI ADDR
247A 38             SEC           SEC
247B FD 27 23       SBC D1BFLO+1,X HI ADDR OF BUFFER LOW ADDR
247E 8D 5F 26       STA PGCNT   NUMBER OF PAGES
2481 BD 26 23       LDA D1BFLO,X SET MEMORY ADDRESS TO LOW
2484 85 FE          STA MEMLO  BUFFER ADDRESS

```

```

2486 BD 27 23      LDA D1BFLO+1,X
2489 85 FF          STA MEMHI
248B 20 53 24      JSR BDMHTK      MOVE HEAD TO TRACK
248E 4C E1 27      JMP DSKWRT     WRITE TO DISK AND RETURN
;
; PATCH2 (FROM $2462)
;
2491 8C 5E 26 PATCH2 STY SECTNM      SET SECTOR NUMBER TO 1
2494 4C 54 27      JMP LDHEAD     LOAD HEAD AND RETURN
;
; MODMIN : MODIFY MEMORY INPUT ADDRESS
;
; THIS ROUTINE IS USED ONLY BY THE INPUT FROM INDIRECT FILE
; FUNCTION (CTRL X). IF YOU WANT TO CHANGE THE LOCATION OF
; THE INDIRECT FILE, YOU MUST CHANGE THE ADDRESS HERE AND IN
; THE ROUTINE @S2551.
;
2497 A9 80      MODMIN LDA #$80      HIGH ADDRESS FOR INDIRECT FILE
2499 8D 88 23      STA MINADR+1    SAVE IT
249C A9 00      LDA #$00      LOW ADDRESS OF INDIRECT FILE
249E 60      RTS
;
; PTROUT : PARALLEL PRINTER OUTPUT DEVICE (BASIC DEVICE 4)
;
; NOTE: SOME OF THE NEWER PRINTERS ON THE MARKET ARE EQUIPPED WITH
; GRAPHICS AND NEED THE FULL 8 BITS OF AN OUTPUT BYTE TO USE
; THIS FEATURE. CHANGING THE INSTRUCTION AT $24A7 AND $24A8 TO
; NOP'S ($EA) WILL ALLOW THIS.
;
249F 48      PTROUT PHA      SAVE BYTE TO BE PRINTED
24A0 AD 00 F4      LDA PTRPIA     CHECK PIA STATUS REGISTER
24A3 4A      LSR A
24A4 B0 FA      BCS PTROUT+1   ($24A0) NOT CLEAR, KEEP WAITING
24A6 68      PLA           RESTORE THE OUTPUT BYTE
24A7 29 7F      AND #$7F      KILL THE UPPER BIT
24A9 8D 02 F4      STA PTRPIA+2  OUTPUT THE BYTE
24AC AD 20 F4      LDA PTRPIA+$20  STROBE THE BYTE TO THE PRINTER
24AF 60      RTS
;
; BEFORE USING EITHER OF THE CA10X ROUTINES, THE PORT NUMBER MUST
; BE SET IN X16DEV ($2323)
;
; X16INP : CA10X INPUT ROUTINE (BASIC DEVICE 8)
;
24B0 AE 23 23 X16INP LDX X16DEV      GET ACIA DEVICE#
24B3 BD 00 CF      LDA X16ACI,X     GET ACIA STATUS REGISTER
24B6 4A      LSR A      SHIFT STATUS BIT TO CARRY
24B7 90 F7      BCC X16INP     TRY AGAIN IF NOT READY
24B9 B0 4D      BCS PATCH3     ($2508) GO TO PATCH3 TO INPUT
24BB 00      BRK        (NOT USED)
24BC 00      BRK        (NOT USED)
;
; X16OUT : CA10X OUTPUT ROUTINE (BASIC DEVICE 8)

```

```

;          X16OUT PHA      SAVE THE OUTPUT BYTE
24BD 48      LDX X16DEV    GET THE CURRENT DEVICE NUMBER
24BE AE 23 23 LDA X16ACI,X  GET THE STATUS REGISTER
24C1 BD 00 CF LSR A
24C4 4A       LSR A
24C5 4A       BCC X16OUT+1 ($24BE) IF NOT READY, TRY AGAIN
24C6 90 F6     PLA        GET THE BYTE TO BE OUTPUT
24C8 68       STA X16ACI+1,X WRITE IT
24C9 9D 01 CF RTS
24CC 60
;
```

; TERMOT : TERMINAL OUTPUT ROUTINE (BASIC DEVICE 1)

```

;          TERMOT PHA      SAVE THE BYTE TO OUTPUT
24CD 48      LDA TERMAC   GET THE ACIA STATUS
24CE AD 00 FC LSR A
24D1 4A       LSR A
24D2 4A       BCC TERMOT+1 ($24CE) IF NOT READY, TRY AGAIN
24D3 90 F9     PLA        GET THE BYTE TO PRINT
24D5 68       STA TERMIO   OUTPUT IT
24D6 8D 01 FC  PHA        SAVE IT AGAIN
24D9 48       LDA TERMAC   GET THE STATUS AGAIN
24DA AD 00 FC  LSR A     CHECK FOR INPUT READY
24DD 4A       BCC TORTN    NO KEY PRESSED, GO BACK
24DE 90 11     JSR TERMIN   INPUT A CHARACTER
24E0 20 F6 24  STA KPDO    SAVE IT
24E3 8D 25 23  CMP #$13   CONTROL S?
24E6 C9 13     BNE TORTN   NO, GO BACK
24E8 D0 07     JSR TERMIN   YES, INPUT A BYTE
24EA 20 F6 24  CMP #$11   CONTROL Q?
24ED C9 11     BNE *-5    ($24EA) NO, TRY AGAIN
24EF D0 F9     PLA        RESTORE THE OUTPUT BYTE
24F1 68       STA A.HOLD   SAVE IT
24F2 8D 63 23  RTS
24F5 60
;
```

; TERMIN : SERIAL TERMINAL INPUT ROUTINE (BASIC DEVICE 1)

```

;          TERMIN LDA TERMAC   GET ACIA STATUS
24F6 AD 00 FC  INC RNDSED  BUMP THE RANDOM SEED
24F9 EE 24 23  LSR A      CHECK RCV READY
24FC 4A       BCC TERMIN   IF NOT TRY AGAIN
24FD 90 F7     LDA TERMIO  INPUT THE BYTE
24FF AD 01 FC  AND #$7F   KILL THE UPPER BIT
2502 29 7F     STA A.HOLD  SAVE THE CHARACTER
2504 8D 63 23  RTS
2507 60
;
```

; PATCH3 : ADDED TO X16INP ROUTINE (FROM \$24B9)

```

;          PATCH3 LDA X16ACI+1,X GET BYTE FROM ACIA
2508 BD 01 CF  BCS TIRTN   PUT IN A.HOLD AND RETURN
250B B0 F7
;
```

; SEROUT : 430 BOARD UART OUTPUT (BASIC DEVICE 3)

```
) 250D 48      SEROUT PHA      SAVE THE BYTE TO OUTPUT
250E AD 05 FB  LDA UART+5    GET UART STATUS
2511 10 FB    BPL SEROUT+1  ($250E) NOT READY, TRY AGAIN
2513 68      PLA          RESTORE THE OUTPUT CHARACTER
2514 8D 04 FB  STA UART+4    AND OUTPUT IT
2517 60      RTS         

;
; SERINP : 430 BOARD UART INPUT (BASIC DEVICE 3)
;

2518 AD 05 FB SERINP LDA UART+5.    GET THE UART STATUS
251B 4A      LSR A        NOT READY, TRY AGAIN
251C 90 FA    BCC SERINP   INPUT A BYTE
251E AD 03 FB  LDA UART+3    ACKNOWLEDGE INPUT
2521 8D 07 FB  STA UART+7    SAVE THE BYTE
2524 8D 63 23  STA A.HOLD
2527 60      RTS         

;
; THE FOLLOWING IS A "WHO KNOWS" INSTRUCTION
; THIS IS ANOTHER CASE OF HOW TO USE UP COMPUTER TIME
;

2528 20 3F 25  JSR KIRTN     JUMP SUBROUTINE TO RTS
;

;
; KBINP : POLLED KEYBOARD INPUT ROUTINE (BASIC DEVICE 2)
;

;
; THIS ROUTINE USES THE SAME ROUTINE AS THE ROM BASED MACHINES.
; UNFORTUNATELY, THE DISK BASIC USES SOME OF THE SAME MEMORY
; LOCATIONS AS THE ROUTINE AT $FD00. INSTEAD OF DOING THE CORRECT
; THING, WRITING A NEW ROUTINE FOR THE DOS, OSI MADE ANOTHER PATCH.
; EVERY TIME YOU INPUT FROM THE 540 KEYBOARD YOU MUST FIRST SWAP
; OUT 4 BYTES, CALL THE ROUTINE IN ROM @$FD00, AND THEN RESTORE
; THE 4 BYTES. HIGHLY INEFFICIENT!
;

252B 20 44 26 KBINP  JSR SWAP4    SAVE $213-$216
252E EE 24 23      INC RNDSED   BUMP THE RANDOM SEED
2531 20 00 FD      JSR KPOLL    CALL THE ROUTINE IN ROM
2534 F0 F8      BEQ KBINP+3  ($252E) IF NULL THEN TRY AGAIN
;

;
; THIS IS ANOTHER STRANGE INSTRUCTION. THE PRESENT KEYBOARD ROUTINE
; WAITS UNTIL A KEY IS PRESSED AND THEN RETURNS IT'S ASCII VALUE.
; A NULL IS NEVER RETURNED FROM THE PRESENT KEYBOARD ROUTINE SO
; IT MAKES NO SENSE TO CHECK FOR IT.
;

2536 8D 63 23  STA A.HOLD    SAVE THE INPUT CHARACTER
2539 20 44 26  JSR SWAP4    RESTORE $213-$215
253C AD 63 23  LDA A.HOLD    GET THE INPUT CHARACTER
253F 60      KIRTN      RTS

;
; PATCH4 : USED BY 540 VIDEO DRIVER FOR KEY PRESSED DURING OUTPUT
; (FROM $25F2)
;

2540 8D 25 23 PATCH4 STA KPDO    SAVE THE CHARACTER
2543 68      PLA          SAVE A AND RETURN
2544 4C 04 25  JMP TIRTN
```

; THIS IS AN UNDOCUMENTED RE-ENTRY POINT TO THE OS. ON VIDEO SYSTEMS
; WHEN YOU EXIT TO THE MONITOR AND THEN RE-ENTER THE OS AT \$2A51, YOU
; WILL NORMALLY HAVE PROBLEMS WITH THE POLLED KEYBOARD ROUTINE. BY
; ENTERING AT \$2547, THE 4 BYTES FROM \$0213-\$0216 ARE RESTORED AND THE
; KEYBOARD ROUTINE WILL WORK CORRECTLY.

2547 20 44 26 JSR SWAP4 SWAP THE 4 BYTES
254A 4C 51 2A JMP OS65D3 JUMP TO THE OS

; CKINP : CHECK INPUT FOR INDIRECT FILE COMMANDS AND CONTROL P.
;

; THE CONTROL P IS A NICE FEATURE THAT WE HAVE NEVER SEEN DOCUMENTED
; BY OSI. UNDER VERSION 3.0 IT WAS A CONTROL T, WHILE UNDER
; VERSION 3.2 IT HAS BEEN CHANGED TO A CONTROL P. THIS CONTROL
; CHARACTER, WHICH EVER ONE IT IS, FLIP-FLOPS A FLAG THAT CONTROLS
; PRINTER OUTPUT. THE FIRST TIME THE CONTROL CHARACTER IS ENCOUNTERED
; IT TURNS ON THE PRINTER DEVICE AND THE NEXT TIME IT TURNS IT OFF.
; WARNING! SOME OF THE SOFTWARE PROVIDED ON THE SYSTEM USES THIS
; FUNCTION. WHEN USING WP2 IF YOU USE THIS FEATURE DURING OUTPUT
; THE WORD PROCESSOR TURNS IT OFF WHEN DONE. HOWEVER THE ASSEMBLER
; DOES NOT AFFECT IT AND IT REMAINS ON UNTIL THERE IS ANOTHER
; CONTROL (T/P) INPUT FROM THE KEYBOARD. THE PRINTER DEVICE BIT
; IS AT LOCATION \$2592.

254D C9 5B	CKINP	CMP #\$5B	(1) START INDIRECT FILE?
254F D0 11		BNE CKIFND	NO, CONTINUE
2551 A9 80		LDA #\$80	SET UPPER ADDRESS FOR INDIRECT
2553 8D 92 23		STA MOTADR+1	MODIFY MEMORY OUTPUT ROUTINE
2556 A9 00		LDA #\$00	SET LOWER ADDRESS FOR INDIRECT
2558 8D 91 23		STA MOTADR	MODIFY MEMORY OUTPUT ROUTINE
255B AD 22 23		LDA OUTDST	
255E 09 10		ORA #\$10	SET MEMORY OUTPUT
2560 D0 31		BNE CKIRTN	ALWAYS BRANCH TO EXIT
2562 C9 5D	CKIFND	CMP #5D	(1) CLOSE INDIRECT FILE?
2564 D0 13		BNE CKCTLX	NO, CONTINUE
2566 20 46 23		JSR PRINT+3	PRINT ']', BYPASS SAVAXY
2569 AD C6 2A		LDA DEFDEV	I/O DEFAULT DEVICE
256C 8D 21 23		STA INDST	RESET INPUT POINTER
256F AD 22 23		LDA OUTDST	GET THE PRESENT OUTPUT DEVICE(S)
2572 29 EF		AND #\$EF	TURN OFF MEMORY OUTPUT
2574 8D 22 23		STA OUTDST	SAVE THE OUTPUT DISTRIBUTOR
2577 A9 5D		LDA #\$5D	PUT ']' BACK IN A
2579 C9 18	CKCTLX	CMP #\$18	CONTROL X? (LOAD INDIRECT FILE)
257B D0 0D		BNE CKCTLP	NO, CONTINUE
257D A9 10		LDA #\$10	
257F 8D 21 23		STA INDST	SET FOR MEMORY INPUT
2582 20 97 24		JSR MODMIN	GOSUB TO SET INPUT HIGH ADDRESS
2585 8D 8A 23		STA MINADR	SET INPUT LOW ADDRESS
2588 B0 0C		BCS CKIRTN+3	(\$2596) ALWAYS BRANCH TO EXIT
258A C9 10	CKCTLP	CMP #\$10	IS IT CONTROL P
258C D0 0A		BNE CKIRTN+5	(\$2598) NO, JUMP TO EXIT
258E AD 22 23		LDA OUTDST	GET THE OUTPUT DISTRIBUTOR

2591 49 08	EOR #\$08	FLIP-FLOP THE PRINTER OUTPUT
2593 8D 22 23 CKIRTN	STA OUTDST	SAVE THE DISTRIBUTOR
2596 A9 00	LDA #\$00	DENOTES CONTROL CHARACTER FOUND
2598 60	RTS	
;		
; VIDOUT : 540 VIDEO OUTPUT ROUTINE (BASIC DEVICE 2)		
;		
; AS DELIVERED WITH THE SYSTEM THE 540 VIDEO DRIVER IS NOTHING		
; MORE THAN A "GLASS TELETYPE" WITH NON-DESTRUCTIVE BACKSPACE		
; AND FORWARD SPACE. CONSIDERING THE SOFTWARE SUPPLIED WITH OTHER		
; COMPARABLE SYSTEMS, THIS IS RIDICULOUS. THE ROUTINE WILL NOT EVEN		
; ALLOW YOU TO PRINT ANY OF THE OSI GRAPHICS CHARACTERS AND		
; FORCES YOU TO "POKE" THEM TO THE SCREEN. ONE CHANGE THAT YOU		
; COULD MAKE WOULD BE TO CHANGE THE INSTRUCTIONS FROM \$25B9 TO		
; \$25C0 AND \$25A1,\$25A2 TO NOP'S. THIS WILL ALLOW YOU TO PRINT SOME		
; GRAPHICS CHARACTERS. WARNING! THIS ROUTINE IS BAD ABOUT USING		
; SELF MODIFYING CODE.		
;		
2599 98	VIDOUT TYA	SAVE Y FOR LATER
259A 48	PHA	
2598 AC 3C 26	LDY LCHAR	GET CHARACTER 'UNDER' CURSOR
259E AD 63 23	LDA A.HOLD	GET OUPUT CHARACTER
25A1 29 7F	AND #\$7F	STRIP TO 7 BIT ASCII
25A3 A2 00	LDX **	GET OFFSET IN PRINT LINE
25A5 C9 0D	CMP #\$0D	IS IT A 'CR'
25A7 F0 5A	BEQ CR	YES, DO IT
25A9 C9 0A	CMP #\$0A	IF IT A 'LF'
25AB F0 62	BEQ LF	YES, DO IT
25AD C9 08	CMP #\$08	BACKSPACE? (non dest cut H)
25AF F0 44	BEQ BSPACE	YES, DO IT
25B1 C9 10	CMP #\$10	IS IT CNTRL P
25B3 F0 47	BEQ CNTLP	YES, DO IT
25B5 C9 0C	CMP #\$0C	IS IT CNTRL L (forward space non dest)
25B7 F0 43	BEQ CNTLP	YES, DO IT
25B9 C9 20	CMP #\$20	IS IT < 'SPACE'
25BB 30 1A	BMI EXIT	YES, INVALID CHARACTER
25BD C9 7B	CMP #\$7B	IS IT > '{'
25BF 10 16	BPL EXIT	YES, INVALID CHARACTER
25C1 9D 00 D7	STA PLINE,X	OUTPUT CHARACTER TO SCREEN
25C4 E8	INX	BUMP LINE POINTER
25C5 E0 80	CPX #\$80	LAST CHARACTER ON LINE
25C7 F0 42	BEQ SCROLL	YES, DO SCROLL
25C9 BC 00 D7 EXIT	LDY PLINE,X	GET CHAR. 'UNDER' NEW CURSOR
25CC 8C 3C 26	STY LCHAR	SAVE IT
25CF A9 5F	LDA #\$5F	GET CURSOR CHARACTER
25D1 9D 00 D7	STA PLINE,X	OUTPUT IT
25D4 8E A4 25	STX VOTOF	SAVE OFFSET
25D7 68	PLA	RESTORE Y
25D8 A8	TAY	
25D9 A9 01	LDA #\$01	CHECK FOR 'CNTRL'
25DB 20 3D 26	JSR KEYTST	
25DE 50 63	BVS KTRTN	NO, WE ARE DONE
25E0 A9 08	LDA #\$08	CHECK FOR 'S'

25E2 20 3D 26		JSR KEYTST	
25E5 10 5C		BPL KTRTN	NO, WE ARE DONE
25E7 AD 63 23		LDA A.HOLD	RESTORE OUTPUT CHARACTER
25EA 48		PHA	AND SAVE
25EB 20 2B 25		JSR KBINP	INPUT FROM POLLED KEYBOARD
25EE C9 13		CMP #\$13	CNTRL S?
25F0 F0 F9		BEQ *-5	(\$25EB) YES, KEEP LOOPING
25F2 4C 40 25		JMP PATCH4	EXIT THE ROUTINE
25F5 98	BSPACE	TYA	RESTORE CHAR. 'UNDER' CURSOR
25F6 9D 00 D7		STA PLINE,X	PRINT IT
25F9 CA		DEX	BUMP LINE POINTER BACK 1
25FA B0 CD		BCS EXIT	GO BACK
25FC 98	CNTLP	TYA	RESTORE CHAR. 'UNDER' CURSOR
25FD 9D 00 D7		STA PLINE,X	
2600 E8		INX	BUMP LINE POINTER
2601 B0 C6		BCS EXIT	EXIT THIS ROUTINE
2603 98	CR	TYA	RESTORE CHAR. 'UNDER' CURSOR
2604 9D 00 D7		STA PLINE,X	
2607 A2 40		LDX #\$40	RESET LINE POINTER
2609 D0 BE		BNE EXIT	JUMP TO EXIT
260B A2 40	SCROLL	LDX #\$40	RESET LINE POINTER
260D D0 04		BNE *+6	(\$2613) JUMP A LITTLE
260F 98	LF	TYA	RESTORE CHAR. 'UNDER' CURSOR
2610 9D 00 D7		STA PLINE,X	
2613 8E 39 26		STX VLOSAV	SAVE LINE OFFSET
2616 A9 20		LDA #\$20	SET TO CLEAR LOWER LINE
2618 A2 80		LDX #\$80	SET OFFSET
261A 9D 00 D7		STA PLINE,X	OUTPUT IT
261D E8		INX	BUMP THE OFFSET
261E D0 FA		BNE *-4	(\$261A) LOOP UNTIL DONE
2620 A0 CF		LDY #\$CF	GET SET TO SCROLL
2622 C8	SETNXT	INY	FIRST TIME THROUGH Y = \$D0
2623 8C 2B 26		STY VLP1	ADJUST LINE POINTER
2626 8C 2E 26		STY VLP2	ADJUST LINE POINTER
2629 BD 40 D0 MOVE		LDA **,X	MOVE UP 1 LINE AT A TIME
262C 9D 00 D0		STA **,X	
262F E8		INX	BUMP THE LINE POINTER
2630 F0 F0		BEQ SETNXT	IF MOVED LINE, SET FOR NEXT
2632 10 F5		BPL MOVE	KEEP LOOPING
2634 C0 D7		CPY #\$D7	HAVE WE DONE THEM ALL
2636 90 F1		BCC MOVE	NO, KEEP LOOPING
2638 A2 00		LDX **	RESTORE LINE OFFSET
263A D0 8D		BNE EXIT	JUMP TO EXIT
263C	LCHAR	= *	CHARACTER 'UNDER' CURSOR

;
; KEYTST : TEST POLLED KEYBOARD FOR KEYDOWN IN ROW IN ACCUM

;
263D 8D 00 DF KEYTST STA KPORT
2640 2C 00 DF BIT KPORT
2643 60 KTRTN RTS
;

; SWAP4 : PATCH ADDED TO ENABLE USE OF POLLED KEYBOARD ROUTINE
; @\$FD00. SWAPS OUT 4 BYTES FROM \$213-\$216 TO \$2657-\$265A

ENABLE THE ROW
CHECK FOR KEYDOWN

```
;  
2644 A2 03    SWAP4   LDX #$03      SET INDEX FOR 4 BYTES  
2646 BD 13 02          LDA SWAP4A,X  SWAP A BYTE  
2649 BC 57 26          LDY SWAP4B,X  
264C 9D 57 26          STA SWAP4B,X  
264F 98          TYA  
2650 9D 13 02          STA SWAP4A,X  
2653 CA          DEX  
2654 10 F0          BPL SWAP4+2      ($2646) IF ANOTHER CONTINUE  
2656 60          RTS  
;  
2657          SWAP4B = *+4      SWAP AREA FOR $0213-$0216
```

; DISK DRIVER ROUTINES AND STORAGE

265B 20	.BYTE \$20	(UNKNOWN USAGE, IF ANY)
265C 01	DSKDR = *	PRESENT DISK DRIVE
265D 67	TKNUM = *	CURRENT TRACK NUMBER
265E 01	SECTNM = *	PRESENT SECTOR NUMBER
265F 07	PGCNT = *	PAGE COUNT
2660 00	LAMB = *	LOW ADDRESS OF MEMORY BLOCK
2661 00	HAMB = *	HI ADDRESS OF MEMORY BLOCK
2662 00	TRKNM = *	HEX TRACK NUMBER NOT USED, SEE NOTE @ \$26A6

; HOME : HOMES HEAD TO TRACK 0 ON CURRENT DISK DRIVE

2663 20 8A 26	HOME	JSR STEPOT	STEP HEAD OUT
2666 20 78 26		JSR TENMS	DELAY 10 MS
2669 8C 5D 26		STY TKNUM	SET TRACK# TO 0
266C A9 02	HOLOOP	LDA #\$02	CHECK FOR TRACK 0
266E 2C 00 C0		BIT FLOPIN	
2671 F0 05		BEQ TENMS	DELAY 10MS AND RETURN IF TR 0
2673 20 83 26		JSR STEPIN	STEP HEAD IN
2676 F0 F4		BEQ HOLOOP	LOOP BACK AND TRY AGAIN

; TENMS : 10 MS DELAY. ACTUALLY @ 1MHZ THE DELAY IS CLOSER TO 11 MS

2678 A2 0C	TENMS	LDX #\$0C	<i>NMHZ</i>
267A A0 31		LDY #\$31	<i>62 = 2 MHZ</i>
267C 20 00 27		JSR DELAY	LOOP COUNT FOR DELAY
267F CA		DEX	DO 1 MS DELAY
2680 D0 F8		BNE TENMS+2	(\$267A) NOT DONE, KEEP ON
2682 60		RTS	

; STEPIN : STEP TOWARDS TRACK 0
; MOVES HEAD ONE TRACK

2683 AD 02 C0	STEPIN	LDA FLOPOT	TURN ON STEPIN BIT
2686 09 04		ORA #\$04	
2688 D0 05		BNE STEP	GO STEP IN

; STEPOT : STEP HEAD AWAY FROM TRACK 0
; MOVES HEAD ONE TRACK.

268A A9 FB	STEPOT	LDA #\$FB	TURN OFF STEP IN BIT
268C 2D 02 C0		AND FLOPOT	
268F 8D 02 C0	STEP	STA FLOPOT	
2692 20 82 26		JSR STEPIN-1	(\$2682) KILLS 12 CLOCK CYCLES
2695 29 F7		AND #\$F7	TURN OFF STEP BIT
2697 20 19 27		JSR SETFLO	STA @ \$C002 AND RETURN
269A 20 06 27		JSR DELAY+6	(\$2706) KILL 14 CYCLES
269D 09 08		ORA #\$08	TURN ON STEP BIT
269F 20 19 27		JSR SETFLO	STA @ \$C002 AND RETURN
26A2 A6 EF		LDX STEPRT	GET STEP RATE
26A4 D0 D4		BNE TENMS+2	(\$267A) DELAY STEP RATE MS

```

;
; (ROUTINE @ $26A6) THIS ROUTINE CONVERTS A HEX TRACK NUMBER
; AT $2662 TO BCD AND STORES IT AT $EE, THEN FALLS INTO THE SET
; TRACK ROUTINE. THE ROUTINE IS NOT USED BY THE OS, SO EITHER
; IT IS USED BY BASIC, OR IT'S LEFT OVER FROM AN OLDER VERSION.
;

26A6 AD 62 26 CNVHTN LDA TRKNM
26A9 38 SEC
26AA A2 FF LDX #$FF . INIT X TO COUNT 10'S
26AC E8 INX
26AD E9 0A SBC #10 SUBTRACT 10 FROM TRACK#
26AF B0 FB BCS *-3 ($26AC) IF >=0 BUMP X AND DO AGAIN
26B1 69 0A ADC #10 ADD BACK LAST 10 FOR REMAINDER
26B3 85 EE STA TKNHLD SAVE REMAINDER
26B5B 8A TXA GET NUMBER OF TENS
26B6 0A ASL A SHIFT TO HIGH NIBBLE
26B7 0A ASL A
26B8 0A ASL A
26B9 0A ASL A
26BA 05 EE ORA TKNHLD COMBINE WITH REMAINDER
;

; SETTK : CHECK FOR VALID TRACK NUMBER AND MOVE HEAD THERE
; TRACK NUMBER IN ACCUMULATOR

26BC 85 EE SETTK STA TKNHLD SAVE TRACK NUMBER
26BE 48 PHA
26BF 2C 9E 26 BIT $269E CHECK FOR 8 BIT
26C2 F0 04 BEQ ERR8-2 ($26CB) IF NOT, CONTINUE
26C4 29 06 AND #$06 CHECK FOR 4 BIT OR 2 BIT
26C6 D0 05 BNE ERR8 YES, LOW NIBBLE > 9 : ERROR 8
26C8 68 PLA RESTORE TRACK NUMBER
26C9 C9 77 CMP #$77 TRACK < 77?
26CB 90 04 BCC MOVEHD YES, CONTINUE
26CD A9 08 ERR8 LDA #$08 ERROR 8, BAD TRACK NUMBER
26CF D0 0D BNE ERR5+2 ($26DE) JUMP TO ERROR HANDLER
26D1 AD 5C 26 MOVEHD LDA DSKDR GET DISK DRIVE
26D4 29 01 AND #$01 TOP DRIVE=1, BOTTOM DRIVE=0
26D6 A8 TAY
26D7 20 DA 29 JSR CKRDY SEE IF DRIVE IS READY
26DA 90 05 BCC CKTK YES, CONTINUE
26DC A9 06 ERR6 LDA #$06 DRIVE NOT READY : ERROR 6
26DE 4C 48 2A JMP ERRENT JUMP TO OS ERROR ROUTINE
26E1 A5 EE CKTK LDA TKNHLD RETRIEVE TRACK NUMBER
26E3 CD 5D 26 CMP TKNUM SAME AS PRESENT TRACK NUMBER?
26E6 F0 20 BEQ STCCNT($2708) YES, DON'T MOVE THE HEAD
26E8 B0 07 BCS *+9 ($26F1) BRANCH IF > PRESENT TRACK
26EA 20 83 26 JSR STEPIN STEP HEAD IN ONE TRACK
26ED A9 99 LDA #$99 SET TO SUBTRACT 1 FROM TKNUM
26EF 90 04 BCC *+6 ($26F5) JUMP
26F1 20 8A 26 JSR STEPOT MOVE HEAD OUT 1 TRACK
26F4 8A TXA X=1 : SET TO ADD 1 TO TKNUM
26F5 F3 SED
26F6 6D 5D 26 ADC TKNUM ADD OR SUBTRACT 1 FROM TKNUM

```

```

) -----
26F9 8D 5D 26      STA TKNUM      AND SAVE
26FC D8            CLD
26FD 4C E1 26      JMP CKTK       GO SEE IF WE ARE DONE
;
; DELAY : DELAY=18*Y+14 CYCLES (DELAY=896us IF Y=$C1)
;
2700 20 9B 23 DELAY JSR COMINC+6 ($239B) BNE AND RTS : 14 CYCLES
2703 88            DEY
2704 D0 FA          BNE DELAY     IF NOT DONE DO IT AGAIN
2706 EA            NOP
2707 60            RTS
;
; SET TRACK CODE CONTINUED FROM $26E6
;
2708 C9 43      STCCNT CMP #$43   ARE WE PAST TRACK 42
270A AD 02 C0      LDA FLOPOT
270D 29 BF      AND #$BF   RESET LOW CURRENT BIT
270F A0 00      LDY #$00   WHO KNOWS?
2711 EA            NOP
2712 B0 05      BCS SETFLO  IF PAST TRACK 42, CONTINUE
2714 A9 40      LDA #$40
2716 0D 02 C0      ORA FLOPOT (PIA2) SET LOW CURRENT BIT
2719 8D 02 C0 SETFLO STA FLOPOT STORE IT
271C 60            RTS
;
; WAITIH : WAIT FOR INDEX HOLE
;
271D AD 00 C0 WAITIH LDA FLOPIN GET DISK STATUS
2720 30 FB          BMI WAITIH IF BIT 7 ON, GO TEST AGAIN
2722 AD 00 C0      LDA FLOPIN GET DISK STATUS
2725 10 FB          BPL *-3   ($2722) IF BIT 7 OFF, TRY AGAIN
2727 60            RTS
;
; LDHDWI : LOAD HEAD AND WAIT FOR INDEX HOLE
;
2728 20 54 27 LDHDWI JSR LDHEAD LOAD HEAD
;
; RSACIA : RESET DISK ACIA, WAIT FOR INDEX HOLE
;
272B 20 1D 27 RSACIA JSR WAITIH WAIT FOR THE INDEX HOLE
272E A9 03          LDA #$03
2730 8D 10 C0      STA ACIA    MASTER RESET FOR ACIA
2733 A9 58          LDA #$58    SET FOR /1, RTS=1, NO INTERRUPT
2735 8D 10 C0      STA ACIA
2738 60            RTS
;
; EXAMCN : EXAM COMMAND CONTINUED , FIRST SECTION AT $2B37
;
2739 20 28 27 EXAMCN JSR LDHDWI LOAD HEAD, WAIT FOR INDEX HOLE
273C A9 00 C0      LDA FLOPIN GET THE STATUS
273F 10 20          BPL UNLDHD IF AT INDEX HOLE, UNLOAD HEAD
2741 AD 10 C0      LDA ACIA  GET ACIA STATUS
2744 4A            LSR A

```

```

2745 90 F5      BCC EXAMCN+3      ($273C) NOT READY, WAIT FOR INDEX
2747 AD 11 C0      LDA ACIAIO
274A 91 FE      STA (MEMLO),Y    READ A BYTE
274C C8      INY
274D D0 ED      BNE EXAMCN+3      ($273C) IF MORE IN THIS PAGE
274F E6 FF      INC MEMHI
2751 4C 3C 27      JMP EXAMCN+3    BUMP MEMORY ADDRESS
; ($273C) CONTINUE

; LDHEAD : LOAD HEAD TO DISK
;
2754 A9 7F      LDHEAD LDA #$7F
2756 2D 02 C0      AND FLOPOT    SET BIT 7 TO 0
2759 8D 02 C0      STA FLOPOT
275C A2 28      LDX #$28
275E 4C 7A 26      JMP TENMS+2    SET FOR 32 ms DELAY

; UNLDHD : UNLOAD HEAD FROM DISK
;
2761 A9 80      UNLDHD LDA #$80
2763 0D 02 C0      ORA FLOPOT    SET BIT 7 TO 1
2766 D0 F1      BNE LDHEAD+5    ($2759) JUMP

; INITIAL : INITIALIZE ALL TRACKS (EXCEPT ZERO) ON CURRENT DRIVE
;
2768 A9 76      INITIAL LDA #$76      SET HIGHEST TRACK NUMBER
276A 85 E5      STA HSTTK
276C 20 63 26      JSR HOME
276F 20 83 2C      JSR INCTKN
2772 20 7D 27      JSR INITTK
2775 AD 5D 26      LDA TKNUM
2778 C9 76      CMP #$76
277A D0 F3      BNE INITIAL+7    GET CURRENT TRACK NUMBER
277C 60      RTS          AT 76 YET?
; ($276F) NO, KEEP ON

; INITTK : INITIALIZE TRACK
;
277D A9 02      INITTK LDA #$02
277F 2C 00 C0      BIT FLOPIN    CHECK FOR TRACK 0
2782 D0 04      BNE *+6        ($2788) NO, CONTINUE
2784 A9 03      ERR3 LDA #$03
2786 D0 09      BNE ERR4+2    DO ERROR #3
2788 A9 20      LDA #$20
278A 2C 00 C0      BIT FLOPIN    JUMP TO ERROR HANDLER
278D D0 05      BNE ERR4+5
278F A9 04      ERR4 LDA #$04
2791 4C 4B 2A      JMP ERRENT
2794 20 28 27      JSR LDHDWI
2797 A9 FC      LDA #$FC
2799 2D 02 C0      AND FLOPOT
279C 8D 02 C0      STA FLOPOT
279F A2 01      LDX #$01
27A1 20 7A 26      JSR TENMS+2    WRITE ENABLE AND ERASE ENABLE
27A4 A2 43      LDX #$43          DO 1 ms DELAY

; TRACK START CODE BYTE1

```

```

) 27A6 20 C2 27      JSR DKWTX      WRITE IT
27A9 A2 57          LDX #$57       TRACK START CODE BYTE2
27AB 20 C2 27      JSR DKWTX      WRITE IT
27AE AE 5D 26      LDX TKNUM     GET THE TRACK NUMBER
27B1 20 C2 27      JSR DKWTX      WRITE IT
27B4 A2 58          LDX #$58       TRACK TYPE CODE
27B6 20 C2 27      JSR DKWTX      WRITE IT
27B9 AD 00 C0      LDA FLOPIN    WAIT FOR INDEX, ERASE IS ON
27BC 30 FB          BMI *-3       ($27B9) NOT YET, TRY AGAIN
27BE A9 83          LDA #$83      TURN OFF WRITE ENABLE, ERASE
27C0 D0 A1          BNE UNLDHD+2  ($2763) ENABLE, UNLOAD HEAD & RET
;
; DKWTX : WRITE X TO DISK
;
27C2 AD 10 C0 DKWTX  LDA ACIA      GET ACIA STATUS
27C5 4A             LSR A
27C6 4A             LSR A
27C7 90 F9          BCC DKWTX    NOT READY, TRY AGAIN
27C9 8E 11 C0      STX ACIAIO   WRITE X TO DISK
27CC 60             RTS
;
; DSKBYT : GET BYTE FROM DISK
;
27CD AD 10 C0 DSKBYT  LDA ACIA      GET ACIA STATUS
27D0 4A             LSR A
27D1 90 FA          BCC DSKBYT    NOT READY, TRY AGAIN
27D3 AD 11 C0      LDA ACIAIO   READ THE BYTE
27D6 60             RTS
;
; THE FOLLOWING IS NOT USED BY THE OS. MAY BE USED BY BASIC
;
27D7 AD 60 26      LDA LAMB      GET LOW ADDRESS OF MEMORY BLOCK
27DA 85 FE          STA MEMLO    SAVE AT MEMORY ADDRESS
27DC AD 61 26      LDA HAMB      GET HIGH ADDRESS
27DF 85 FF          STA MEMHI    AND SAVE
;
; DSKWRT : WRITE SECTOR TO DISK ROUTINE
;
; TO USE THIS ROUTINE THE HEAD MUST ALREADY BE POSITIONED TO THE
; PROPER TRACK, THE NUMBER OF PAGES TO WRITE IN PGCNT ($265F), AND
; THE SECTOR NUMBER TO WRITE IN SECTNM ($265E). STARTING
; ADDRESS OF DATA MUST BE IN MEMLO, MEMHI ($FE,$FF).
;
27E1 AD 5F 26 DSKWRT LDA PGCNT    GET NUMBER OF PAGES
27E4 F0 02          BEQ ERRB      IF 0 DO ERROR B
27E6 10 04          BPL *+6      ($27EC) IF BIT 7 IS ON DO ERROR B
27E8 A9 0B          ERRB        ERROR B ROUTINE
27EA D0 A5          BNE ERR4+2  ($2791) JUMP
27EC C9 0E          CMP #$0E     IF>D, THEN ERROR B
27EE 10 F8          BPL ERRB    TEST FOR TRACK 0
27F0 A9 02          LDA #$02
27F2 2C 00 C0      BIT FLOPIN   ($27D6) IF TRACK 0 THEN RETURN
27F5 F0 DF          BEQ DSKBYT+9

```

27F7 4A	LSR A	
27F8 85 FA	STA SCTLEN	PUT 1 IN SECTOR LENGTH
27FA A9 20	LDA #\$20	TEST FOR WRITE PROTECT
27FC 2C 00 C0	BIT FLOPIN	
27FF D0 04	BNE *+6	(\$2805) NOT WRITE PROTECT, CONTINUE
2801 A9 04	LDA #\$04	WRITE PROTECT IS ON, ERROR 4
2803 D0 E5	BNE DSKWRT+8	(\$27EA) JUMP
2805 A9 01	LDA #\$01	
2807 85 F6	STA WRTRTY	
2809 A9 03	LDA #\$03	SET RETRY COUNT
280B 85 F8	STA RDRTYN	
280D 20 C4 28	JSR SETSCT	READ VERIFICATION RETRY COUNT
2810 20 9F 28	JSR DLYFA	POSITION TO START OF SECTOR
2813 A9 FE	LDA #\$FE	DO 800us DELAY (SCTLEN = 1)
2815 2D 02 C0	AND FLOPOT	SET WRITE ENABLE
2818 8D 02 C0	STA FLOPOT	
281B A2 02	LDX #\$02	DELAY 200us
281D 20 A2 28	JSR HUNDUS	
2820 A9 FD	LDA #\$FD	TURN ON ERASE ENABLE
2822 2D 02 C0	AND FLOPOT	
2825 8D 02 C0	STA FLOPOT	
2828 20 9F 28	JSR DLYFA	ANOTHER 800us DELAY
282B A2 76	LDX #76	
282D 20 C2 27	JSR DKWTX	WRITE SECTOR START CODE
2830 AE 5E 26	LDX SECTNM	GET SECTOR NUMBER
2833 20 C2 27	JSR DKWTX	WRITE IT
2836 AE 5F 26	LDX PGCNT	GET THE PAGE COUNT
2839 86 FD	STX TS2	SAVE IT
283B 20 C2 27	JSR DKWTX	WRITE PAGE COUNT
283E A0 00	LDY #\$00	SET INDEX
2840 B1 FE	LDA MEMLO,Y	WRITE PAGE OF MEMORY TO DISK
2842 AA	TAX	
2843 20 C2 27	JSR DKWTX	WRITE TO DISK
2846 C8	INY	
2847 D0 F7	BNE WRTPG	(\$2840) NOT DONE, LOOP BACK
2849 E6 FF	INC MEMHI	BUMP HIGH MEMORY ADDRESS
284B C6 FD	DEC TS2	DROP PAGE COUNT
284D D0 F1	BNE WRTPG	IF ANOTHER PAGE THEN CONTINUE
284F A2 47	LDX #47	WRITE 'G' TO DISK
;		(SECTOR START CODE)
2851 20 C2 27	JSR DKWTX	
2854 A2 53	LDX #53	WRITE 'S' TO DISK
;		(SECTOR START CODE)
2856 20 C2 27	JSR DKWTX	
2859 AD 5F 26	LDA PGCNT	GET PAGE COUNT
285C 0A	ASL A	MULTIPLY BY 2
285D 85 FD	STA TS2	SAVE IT
285F 0A	ASL A	MULTIPLY BY 2 AGAIN
2860 65 FD	ADC TS2	ADD TOGETHER, = 6*PAGE COUNT
2862 AA	TAX	
2863 20 A2 28	JSR HUNDUS	100us DELAY*PAGE COUNT
2866 AD 02 C0	LDA FLOPOT	
2869 09 01	ORA #\$01	TURN OFF WRITE ENABLE

```

) 286B 8D 02 C0      STA FLOPOT
286E A2 05          LDX #$05
2870 20 A2 28      JSR HUNDUS      500us DELAY
2873 A9 02          LDA #$02
2875 20 16 27      JSR SETFLO-3   ($2716) TURN OFF ERASE ENABLE
2878 18             RTYCMP CLC
2879 8A             TXA           ADD X TO HIGH MEMORY ADDRESS
287A 65 FF          ADC MEMHI    X=0 FIRST TIME WE COMPARE
287C 38             SEC           X=# OF SECTORS NOT COMPARED
;
; 287D ED 5F 26      SBC PGCNT    IF THIS IS A RETRY
2880 85 FF          STA MEMHI    RESET HIGH MEMORY ADDRESS
2882 20 07 29      JSR RDCDSK   COMPARE DATA WRITTEN TO DISK
;
; WARNING! IF WRITE STARTED FROM PAGE 0, ABOVE ROUTINE WILL
; READ FROM DISK INSTEAD OF COMPARE.
;
2885 B0 28          BCS DKBT9-1   ($28AF) NO FAULT SO RETURN
2887 C6 F8          DEC RDRTYN   DROP COMPARE RETRY COUNT
2889 D0 ED          BNE RTYCMP   IF NOT 0 THEN TRY AGAIN
288B C6 F6          DEC WRTRTY   DROP WRITE RETRY COUNT
288D 30 0C          BMI ERR2    IF DONE THEN ERROR #2
288F 8A             TXA
2890 65 FF          ADC MEMHI   RESET MEMORY ADDRESS
2892 38             SEC
;
2893 ED 5F 26      SBC PGCNT    WRITE TO DISK AGAIN
2896 85 FF          STA MEMHI   ERROR #2
2898 4C 09 28      JMP REWRT   ($28C1) ALWAYS JUMP
289B A9 02          ERR2       LDA #$02
289D D0 22          BNE ERR9+2
;
; DLYFA : 800us DELAY TIMES VALUE IN SCTLEN ($FA)
;
289F 20 56 29 DLYFA  JSR DLYFA1   GO COMPUTE VALUE FOR X
;
; HUNDUS : APPROXIMATELY 100us DELAY PER X
;
28A2 AD 7B 26 HUNDUS LDA NMHZ    GET DELAY COUNT
28A5 24 00          BIT PAGE0   KILL 3 CYCLES
28A7 38             SEC
28A8 E9 05          SBC #$05    SUBTRACT 5 FROM DELAY COUNT
28AA B0 F9          BCS HUNDUS+3 ($28A5) IF >=0 THEN DO AGAIN
28AC CA             DEX
28AD D0 F3          BNE HUNDUS  DO X TIMES
28AF 60             RTS
;
; DKBT9 : GET BYTE FROM DISK, ERROR #9 IF INDEX HOLE
;
28B0 AD 00 C0 DKBT9  LDA FLOPIN  GET DISK STATUS
28B3 10 0A          BPL ERR9    IF INDEX HOLE THEN ERROR #9
;
; WARNING: $28B4 IS MODIFIED BY THE D9 COMMAND @ $2823
;
```

```

28B5 AD 10 C0      LDA ACIA          CHECK ACIA STATUS
28B8 4A            LSR A
28B9 90 F5          BCC DKBT9        NOT READY, KEEP LOOKING
28BB AD 11 C0      LDA ACIAIO       GET BYTE FROM DISK
28BE 60            RTS
28BF A9 09      ERR9    LDA #$09        ERROR #9, CAN'T FIND SECTOR
28C1 4C 4B 2A      JMP ERRENT

; SETSCT : SETUP FOR SECTOR IN SECTNM

; 28C4 A9 05      SETSCT LDA #$05
; 28C6 85 F5          STA SCTRTRY      SET RETRY COUNT
; 28C8 20 2B 27      JSR RSACIA       WAIT FOR INDEX HOLE
; 28CB 20 B0 28      JSR DKBT9        GET FIRST BYTE FROM DISK
; 28CE C9 43          CMP #'C' 43      CHECK FOR TRACK START CODE
; 28D0 D0 F9          BNE *-5         ($28CB) IF NOT 'C' TRY AGAIN
; 28D2 20 B0 28      JSR DKBT9        GET SECOND BYTE FROM DISK
; 28D5 C9 57          CMP #'W' 57      CHECK FOR TRACK START CODE
; 28D7 D0 F5          BNE *-9         ($28CE) IF NOT 'W' THEN CHECK FOR 'C'
; 28D9 20 B0 28      JSR DKBT9        GET ANOTHER BYTE FROM DISK
; 28DC 45 EE          EOR TKNHLD      IS THIS THE RIGHT TRACK?
; 28DE F0 0B          BEQ SSOK         YES, CONTINUE
; 28E0 A9 05      ERR5    LDA #$05        SET FOR ERROR #5, SEEK ERROR
; 28E2 C6 F5          DEC SCTRTRY      BUT FIRST CHECK RETRY COUNT
; 28E4 10 61          BPL SEEKRT      FLIP SEEK RATE AND TRY AGAIN
; 28E6 CD A9 0A ERRA    CMP $0AA9

; THE INSTRUCTION AT $28E6 IS AN OLD ASSEMBLER PROGRAMMING TRICK
; THAT SHOULD NORMALLY BE AVOIDED BECAUSE OF THE DANGERS INVOLVED.
; THIS IS A PRIME EXAMPLE OF MISUSE. THE TRICK IS TO TAKE A TWO
; BYTE INSTRUCTION; IN THIS CASE, LDA #$0A (A9 0A); AND ADD A BYTE
; TO THE FRONT WHICH CREATES A "HARMLESS" THREE BYTE INSTRUCTION.
; THEN YOU CAN FALL THROUGH FROM PRECEDING CODE WITH NO EFFECT, OR
; BRANCH TO THE SECOND BYTE OF THIS INSTRUCTION FOR A DIFFERENT
; EFFECT, AS IS DONE AT $28FC. THIS ALLOWS REPORTING AN ERROR #5
; ON FALL THROUGH, OR ERROR A WHEN ENTERING AT $28E7. THE RATIONALE
; FOR USING THIS TRICK IS TO SAVE ONE LOUSY BYTE OF CODE. THE DANGER
; IS THAT QUITE OFTEN THE "HARMLESS" THREE BYTE INSTRUCTION CAN CAUSE
; CONSIDERABLE HARM. SUCH IS THE CASE HERE. SINCE OSI CHOSE TO USE A
; CMP INSTRUCTION, IF THE VALUE AT $0AA9 IS EQUAL TO 5, THE TEST AT
; $28E9 WILL FAIL AND THE PROGRAM WILL FALL INTO THE CODE USED WHEN
; THERE IS NO SEEK ERROR. ALSO $F9 WILL BE INITIALIZED TO 5 INSTEAD
; OF 0. ANOTHER ERROR, SUCH AS ERROR A, WILL PROBABLY OCCUR, BUT TO
; US PROBABLY IS NOT NEARLY GOOD ENOUGH.

; 28E9 D0 D6          BNE ERR9+2      ($28C1) GO REPORT ERROR 5 (OR A)
; 28EB 85 F9      SSOK    STA SCTBYP      SET SECTORS BYPASSED TO 0
; 28ED 20 B0 28      JSR DKBT9        GET FIRST BYTE FROM SECTOR
; 28F0 AD 5E 26      LDA SECTNM       GET SECTOR NUMBER
; 28F3 E9 01          SBC #$01         SUBTRACT 1
; 28F5 F0 0F          BEQ RDCDSK-1    ($2906) RETURN IF WANT SECTOR 1
; 28F7 48            PHA
; 28F8 20 98 29      JSR BPSECT      SAVE SECTORS TO SKIP
;                               SKIP A SECTOR

```

```

) 28FB 68      PLA           GET BACK SECTORS TO SKIP
28FC 90 E9    BCC $28E7     IF CARRY CLEAR, ERROR A
28FE C5 F9    CMP SCTBYP   HAVE WE SKIPPED ENOUGH?
2900 D0 F5    BNE *-9      ($28F7) NO, CONTINUE
2902 C5 FB    CMP SCTNUM  SECTOR NUMBER JUST SKIPPED
;
2904 D0 E1    BNE $28E7   SET @$29A4
2906 60      RTS          IF NOT RIGHT ONE, ERROR A
;
; RDCDSK : READ (OR COMPARE) FROM DISK, THIS TRACK INTO MEMORY @($FE)
;
2907 48      RDCDSK PHA   SAVE READ/COMPARE FLAG
;          (0=READ)
2908 20 C4 28  JSR SETSCT  POSITION HEAD
290B 20 B0 28  JSR DKBT9   GET BYTE FROM DISK
290E C9 76    CMP #$76    IS IT A SECTOR START CODE?
2910 D0 F9    BNE *-5     ($290B) NO, TRY AGAIN
2912 20 B0 28  JSR DKBT9   GET ANOTHER BYTE
2915 CD 5E 26  CMP SECTNM  IS THIS THE RIGHT SECTOR?
2918 F0 03    BEQ *+5    ($291D) YES, CONTINUE
291A 68      PLA          IF NOT, RETURN WITH CARRY
;
291B 18      SETFF CLC   CLEAR AS FAULT FLAG
291C 60      RTS
;
) 291D 20 B0 28  JSR DKBT9  GET SECTOR LENGTH FROM DISK
2920 AA        TAX          PUT PAGE COUNT IN X
2921 8D 5F 26  STA PGCNT   STORE SECTOR LENGTH
2924 A0 00    LDY #$00    SET Y FOR INDEXING
2926 68        PLA          RESTORE READ/COMPARE FLAG
2927 69 FE    ADC #$FE   FORCE CARRY FLAG IF COMPARE
2929 A9 01      RDCONT LDA #$01
292B 2C 10 C0   BIT ACIA   CHECK ACIA READY AND PARITY
292E F0 FB    BEQ *-3     ($292B) IF NOT, TRY AGAIN
2930 AD 11 C0   LDA ACIAIO  GET BYTE FROM ACIA
2933 70 E6    BVS SETFF   PARITY ERROR, RETURN
2935 90 04    BCC *+6     ($293B) CARRY CLEAR, THIS IS A READ
2937 D1 FE    CMP (MEMLO),Y  COMPARE TO BYTE IN MEMORY
2939 D0 E0    BNE SETFF   IF NOT THE SAME, ERROR
293B 91 FE    STA (MEMLO),Y  STORE BYTE IN MEMORY
293D C8       INY          BUMP THE INDEX
293E D0 E9    BNE RDCONT  IF MORE THIS PAGE, CONTINUE
2940 E6 FF    INC MEMHI   SET ADDRESS FOR NEXT PAGE
2942 CA        DEX          DROP PAGE COUNT
2943 D0 E4    BNE RDCONT  IF ANOTHER PAGE, CONTINUE
2945 38        SEC          SET CARRY AS NO FAULT FLAG
2946 60      RTS
;
; SEEKRT : SEEK RETRY ROUTINE FOR ADAPTIVE STEP RATE
;
) 2947 A5 EF      SEEKRT LDA STEPRT   GET CURRENT STEP RATE
2949 49 0E      EOR #$0E    CHANGE 8 TO 6 OR 6 TO 8
294B 85 EF      STA STEPRT  STORE NEW STEP RATE

```

```

) 294D 20 63 26      JSR HOME      MOVE HEAD TO TRACK 0
2950 20 D1 26      JSR MOVEHD    GO MOVE HEAD TO PROPER TRACK
2953 4C C8 28      JMP SETSCT+4 AND TRY FOR SECTOR AGAIN
;
; DLYFA1 : COMPUTE 8 TIMES VALUE IN SCTLEN. USED BY DLYFA @ $289F
;
2956 A5 FA      DLYFA1 LDA SCTLEN   GET SECTOR LENGTH
2958 0A           ASL A        MULTIPLY BY EIGHT
2959 0A           ASL A
295A 0A           ASL A
295B AA           TAX         PUT IN X (FOR HUNDUS)
295C 60           RTS
;
; SET MEMORY ADDRESS POINTER TO DISK BUFFER ADDRESS
; NOT USED BY OS.
;
295D AD 60 26      LDA LAMB
2960 85 FE      STA MEMLO
2962 AD 61 26      LDA HAMB
2965 85 FF      STA MEMHI
;
; READDK : READ DISK, THIS TRACK INTO MEMORY @($FE)
;
2967 A9 03      READDK LDA #$03     SET RETRY COUNT WHEN HEAD MOVED
2969 85 F7      STA RDRTYM
296B A9 07      LDA #$07     SET RETRY COUNT W/O MOVING HEAD
296D 85 F8      STA RDRTYN
296F A9 00      RTYRD  LDA #$00     DENOTES READ
2971 20 07 29      JSR RDCKSK   READ SECTOR INTO MEMORY
2974 90 04      BCC DKRDRY+3 ($297A) IF FAULT OCCURED, RETRY
2976 60           RTS
;
; DKRDRY : DISK READ RETRY
;
2977 C6 FF      DKRDRY DEC MEMHI  RESET MEMORY ADDRESS
2979 E8           INX
297A EC 5F 26      CPX PGCNT
297D D0 F8      BNE DKRDRY  NOT DONE, CONTINUE
297F C6 F8      DEC RDRTYN
2981 D0 EC      BNE RTYRD  DROP RETRY COUNT
2983 20 83 26      JSR STEPIN  NOT 0, TRY AGAIN W/O MOVING HEAD
2986 20 78 26      JSR TENMS  STEP HEAD IN
2989 20 8A 26      JSR STEPOT  10ms DELAY
298C 20 78 26      JSR TENMS  STEP HEAD OUT
298F C6 F7      DEC RDRTYM  DROP RETRY COUNT
2991 10 D8      BPL READDK+4 ($296B) IF >=0 THEN TRY AGAIN
2993 A9 01      ERRI   LDA #$01  ALL RETRIES FAILED, ERROR #1
2995 4C 4B 2A      JMP ERRENT
;
; BPSECT : BYPASS SECTOR
;
2998 20 B6 29  BPSECT JSR DKBTCI  GET BYTE FROM DISK
299B C9 76          CMP #$76  SECTOR START CODE?

```

```

299D D0 F9      BNE BPSECT    NO, TRY AGAIN
299F A2 02      LDX #$02      SET TO READ 2 BYTES
29A1 20 B6 29    JSR DKBTCI   GET BYTE FROM DISK
29A4 95 F9      STA SCTNUM-2,X STORE SECTOR NUMBER IN $FB
;                   STORE SECTOR LENGTH IN $FA (PAGES)
29A6 CA          DEX          ($29A1) BACK FOR SECOND BYTE
29A7 D0 F8      BNE *-6      BUMP SECTORS BYPASSED
29A9 E6 F9      INC SCTBYP   SECTOR LENGTH IN PAGES
29AB A8          TAY          GET ANOTHER BYTE FROM DISK
29AC 20 B6 29    JSR DKBTCI
29AF CA          DEX          ($29AC) IF NOT END OF PAGE, CONTINU
29B0 D0 FA      BNE *-4      ($29AC) IF MORE PAGES TO GO, CONTIN
29B2 88          DEY          ;
29B3 D0 F7      BNE *-7      ;
29B5 60          RTS          ;

; DKBTCI : GET BYTE FROM DISK, IF INDEX HOLE SEEN POP STACK AND RETURN
;
29B6 AD 10 C0 DKBTCI LDA ACIA     GET ACIA STATUS
29B9 4A          LSR A        ($29C3) ACIA READY, GO AHEAD
29BA B0 07      BCS SETDRV-3  TEST FOR INDEX HOLE
29BC AD 00 C0    LDA FLOPIN   NO, TRY AGAIN
29BF 30 F5      BMI DKBTCI
29C1 68          PLA          PULL LAST KNOWN RETURN ADDRESS
29C2 68          PLA          OFF OF STACK AND RETURN
29C3 4C BB 28    JMP DKBTCI+11 ($28BB) LOAD BYTE AND RETURN
;
; SETDRV : SET FOR DRIVE IN ACCUMULATOR
;
29C6 8D 5C 26 SETDRV STA TKNUM   SET TRACK NUMBER
29C9 0A          ASL A        MULTI BY 2 : A=2,B=4,C=6,D=8
29CA AA          TAX          ($29C9)
29CB 29 02      AND #$02     ISOLATE DRIVE : A=1,B=0,C=1,D=0
29CD A8          TAY          ;
29CE BD E9 29    LDA DKINIT-2,X INITIALIZE PIA FROM INIT TABLE
29D1 8D 00 C0    STA FLOPIN
29D4 BD EA 29    LDA DKINIT-1,X
29D7 8D 02 C0    STA FLOPOT
;
; CKRDY : CHECK FOR DRIVE READY, RETURNS WITH CARRY CLEAR IF READY
;
29DA AD 00 C0 CKRDY  LDA FLOPIN  PUT READY BIT IN CARRY FLAG
29DD 4A          LSR A        SAVE CARRY STATUS
29DE 08          PHP          IF TOP DRIVE THEN RETURN
29DF C0 00      CPY #$00
29E1 D0 06      BNE DKINIT-2 ($29E9)
29E3 28          PLP          RESTORE STATUS
29E4 4A          LSR A        PUT BIT 4 IN CARRY
29E5 4A          LSR A
29E6 4A          LSR A
29E7 4A          LSR A
29E8 60          RTS          ;
29E9 28          PLP          RESTORE STATUS

```

29EA 60 RTS

;

;

DISK INITIALIZATION TABLE

;

29EB 40	DKINIT	.BYTE \$40	DRIVE A
29EC FF		.BYTE \$FF	
29ED 00		.BYTE \$00	DRIVE B
29EE FF		.BYTE \$FF	
29EF 40		.BYTE \$40	DRIVE C
29F0 DF		.BYTE \$DF	
29F1 00		.BYTE \$00	DRIVE D
29F2 DF		.BYTE \$DF	

;

DIRCNT : DIR COMMAND CONTINUED (FROM \$2B2C)

;

29F3 AA	DIRCNT	TAX	PUT TRACK NUMBER IN X
29F4 F0 F1		BEQ DKINIT-4	(\$29E7) IF 0 THEN RETURN
29F6 48		PHA	SAVE TRACK NUMBER
29F7 20 BC 26		JSR SETTK	MOVE HEAD TO TRACK
29FA 20 73 2D		JSR STROUT	PRINT THE FOLLOWING MESSAGE
29FD 0D 0A 54		.BYTE \$0D,\$0A,"TRACK ",0	
2A00 52 41 43			
2A03 4B 20 00			
2A06 68		PLA	RESTORE THE TRACK NUMBER
2A07 20 92 2D		JSR PRT2HX	PRINT TRACK NUMBER
2A0A BA		TSX	SAVE STACK ADDRESS
2A0B 86 FC		STX STKADR	
2A0D 20 54 27		JSR LDHEAD	LOAD HEAD TO DISK
2A10 E8		INX	
2A11 8E 5E 26		STX SECTNM	PUT 1 IN SECTOR NUMBER
2A14 20 C4 28		JSR SETSCT	POSITION FOR SECTOR 1
2A17 A9 00		LDA #\$00	CLEAR SECTORS BYPASSED COUNT
2A19 85 F9		STA SCTBYP	
2A1B 20 98 29		JSR BPSECT	BYPASS THIS SECTOR
2A1E A5 FB		LDA SCTNUM	
2A20 48		PHA	SAVE SECTOR NUMBER
2A21 A5 FA		LDA SCTLEN	
2A23 48		PHA	SAVE SECTOR LENGTH
2A24 B0 F5		BCS *-9	(\$2A1B) IF WE DIDN'T HIT THE INDEX HOLE, TRY AGAIN
;		LDX STKADR	GET ORIGINAL STACK ADDRESS
2A26 A6 FC		BCC *+15	(\$2A37) AND JUMP
2A28 90 0D		JSR CRLF	PRINT CR/LF
2A2A 20 6A 2D		LDA #\$20	PRINT SPACE AND SECTOR NUMBER
2A2D A9 20		JSR DCPRNT	
2A2F 20 41 2A		LDA #\$2D	PRINT - AND SECTOR LENGTH
2A32 A9 2D		JSR DCPRNT	
2A34 20 41 2A		DEC SCTBYP	DROP SECTORS BYPASSED COUNT
2A37 C6 F9		BPL *-15	(\$2A2A) IF MORE TO DO, CONTINUE
2A39 10 EF		LDX STKADR	RESET STACK ADDRESS
2A3B A6 FC		TXS	
2A3D 9A		JMP UNLDHD	UNLOAD HEAD AND RETURN
2A3E 4C 61 27		JSR PRINT	PRINT ACCUMULATOR
2A41 20 43 23	DCPRNT		

2A44 BD 00 01 LDA STACK,X GET NEXT BYTE OFF STACK
2A47 CA DEX GET SET FOR THE NEXT ONE
2A48 4C 92 2D JSR PRT2HX PRINT AS 2 HEX CHAR. AND RETURN

```
; ** KERNEL **  
;  
; ERRENT : OS ERROR ENTRY. ERROR # IN ACCUMULATOR  
;  
2A4B 20 C4 2A ERRENT JSR OSERR ($2A4C)  
2A4E 4C 51 2A JMP **  
;  
; WHILE IT MAKES LITTLE SENSE TO DO A DIRECT JUMP TO THE NEXT  
; MEMORY LOCATION, THIS MAKES IT POSSIBLE TO ALTER THE EXIT  
; FROM THE OS ERROR ROUTINE SO THAT IT WILL RETURN TO ANOTHER  
; PLACE OTHER THAN THE OS. THIS CAN BE DONE WITH THE SETERR  
; ROUTINE @ $2A7D. IF YOU ARE USING THE OS FROM YOUR OWN PROGRAM,  
; YOU MAY ALSO WISH TO MODIFY THE OSERR ROUTINE TO NOT PRINT THE  
; ERROR MESSAGE, IN WHICH CASE YOU WOULD NEED TO SET A FLAG TO INFORM  
; YOUR PROGRAM THAT AN ERROR HAD OCCURED.  
;  
; OS65D3 : ENTRY POINT FOR OS65D MAIN LOOP  
;  
2A51 A2 28 OS65D3 LDX #$28  
2A53 9A TXS SET STACK  
;  
; THE TOP OF STACK IS SET TO $28 SINCE THE NON-MASKABLE INTERRUPT  
; VECTOR IS SET TO $0130. WE WON'T EVEN COMMENT ON HOW ASININE IT  
; IS TO PUT THE INTERRUPT VECTORS IN THE STACK AREA.  
;  
2A54 A9 51 LDA #$51 SET OS ERROR RETURN TO OS  
2A56 A0 2A LDY #$2A  
2A58 20 7D 2A JSR SETERR  
2A5B 20 6A 2D JSR CRLF  
2A5E AD 5C 26 LDA DSKDR GET PRESENT DISK DRIVE  
2A61 18 CLC  
2A62 69 40 ADC #$40 ACCUM NOW HAS LETTER OF  
;  
2A64 20 43 23 JSR PRINT PRESENT DISK DRIVE  
2A67 A9 2A LDA #'* PRINT IT  
2A69 20 43 23 JSR PRINT PRINT '**  
2A6C 20 9B 2C JSR OSINP DO INPUT TO OS BUFFER  
2A6F A9 2E LDA #$2E OS INPUT BUFFER HI ADDRESS  
2A71 85 E2 STA OSIBAD+1  
2A73 A9 1E LDA #$1E OS INPUT BUFFER LOW ADDRESS  
2A75 85 E1 STA OSIBAD  
2A77 20 84 2A JSR EXCOM GO EXECUTE COMMAND  
2A7A 4C 51 2A JMP OS65D3 LOOP BACK FOR ANOTHER COMMAND  
;  
; SETERR : SET OS ERROR RETURN, LOW ADDRESS IN A  
; HIGH ADDRESS IN Y  
;  
2A7D 8D 4F 2A SETERR STA ERRENT+4 ($2A4F)  
2A80 8C 50 2A STY ERRENT+5 ($2A50)  
2A83 60 RTS  
;  
; EXCOM : EXECUTE OS COMMAND SUBROUTINE  
;
```

; TO EXECUTE OS COMMANDS FROM OTHER PROGRAMS EITHER PLACE THE COMMAND
; IN THE OS BUFFER (@\$2E1E) AND DO A JSR TO EXCOM, OR PUT THE COMMAND
; IN MEMORY, SET THE BUFFER POINTER (\$E1,E2) TO YOUR BUFFER. THEN DO
; A JSR TO EXCOM. YOU WOULD PROBABLY ALSO WANT TO SET THE OS ERROR
; RETURN TO YOUR OWN PROGRAM.

2A84 A2 00	EXCOM	LDX #\$00	X=OFFSET INTO DISPATCH TABLE
2A86 8E E5 2C		STX BUFOFS	CLEAR BUFFER OFFSET
;			USED BY BUFBYT
2A89 A0 00		LDY #\$00	Y=OFFSET INTO BUFFER
2A8B BD 30 2E		LDA DSPTBL,X	FIRST CHARACTER IN DISPATCH
;			TABLE ENTRY
2A8E F0 30		BEQ ERR7	IF 0 THEN DO ERROR #7
2A90 D1 E1		CMP (OSIBAD),Y	COMPARE TO BUFFER
2A92 D0 26		BNE NXTENT	IF NOT GO CHECK NEXT ENTRY
2A94 C8		INY	BUMP BUFFER INDEX
2A95 BD 31 2E		LDA DSPTBL+1,X	SECOND CHAR. IN TABLE ENTRY
2A98 D1 E1		CMP (OSIBAD),Y	COMPARE TO BUFFER
2A9A D0 1E		BNE NXTENT	IF NOT CHECK NEXT ENTRY
2A9C BD 33 2E		LDA DSPTBL+3,X	GET HIGH ADDRESS FROM TABLE
2A9F 48		PHA	
2AA0 BD 32 2E		LDA DSPTBL+2,X	GET LOW ADDRESS
2AA3 48		PHA	
2AA4 20 E4 2C		JSR BUFBYT	GET BYTE FROM BUFFER
2AA7 C9 0D		CMP #\$0D	CHECK FOR 'CR'
2AA9 F0 0E		BEQ NXTENT-1	(\$2A89) IF IT IS, EXECUTE COMMAND
2AAB C9 20		CMP #\$20	CHECK FOR A 'SPACE'
2AAD D0 F5		BNE *-9	(\$2AA4) IF NOT, TRY AGAIN
2AAF 20 E4 2C		JSR BUFBYT	GET BYTE FROM BUFFER
2AB2 C9 20		CMP #\$20	CHECK FOR A 'SPACE'
2AB4 F0 F9		BEQ *-5	(\$2AAF) IF SO, LOOK AGAIN
2AB6 CE E5 2C		DEC BUFOFS	POINT TO FIRST NONSPACE
2AB9 60		RTS	JUMP TO ADDRESS FROM TABLE
2ABA E8	NXTENT	INX	INCREMENT TO NEXT TABLE ENTRY
2ABB E8		INX	EACH ENTRY IS 4 BYTES
2ABC E8		INX	
2ABD E8		INX	
2ABE D0 C9		BNE EXCOM+5	(\$2A89) GO BACK IF MORE TABLE
2AC0 A9 07	ERR7	LDA #\$07	SYNTAX ERROR #7
2AC2 D0 87		BNE ERRENT	JUMP TO OS ERROR ENTRY (2A4B)
;			
; OSERR : OS ERROR ROUTINE, ERROR # IN ACCUMULATOR			
;			
; ALWAYS CALLED FROM \$2A4B. NOTE THAT THE I/O DISTRIBUTORS ARE			
; RESET TO THE DEFAULT DEVICE ON ANY ERROR.			
;			
2AC4 48	OSERR	PHA	
2AC5 A9 01		LDA #\$01	GET DEFAULT I/O DISTRIBUTOR
2AC7 8D 21 23		STA INDST	AND RESET
2ACA 8D 22 23		STA OUTDST	
2ACD 20 73 2D		JSR STROUT	PRINT THE FOLLOWING
2AD0 20 45 52		.BYTE 'ERR # ',0	
2AD3 52 20			

```

2AD5 23 00
2AD7 68          PLA
2AD8 20 9B 2D    JSR PRTHEX   PRINT THE ERROR NUMBER
2ADB 4C 61 27    JMP UNLDHD   UNLOAD HEAD AND RETURN
;
; ASM : ASSEMBLER COMMAND
;
2ADE A9 05      ASM     LDA #$05    FIRST TRACK NUMBER
2AE0 20 EE 2A    JSR LDCMN    COMMON CODE
2AE3 4C 00 13    JMP STASM    JUMP TO START OF ASSEMBLER
;
; BASIC : BASIC COMMAND
;
2AE6 A9 02      BASIC   LDA #$02    FIRST TRACK NUMBER
2AE8 20 EE 2A    JSR LDCMN    COMMON CODE
2AE8 4C E4 20    JMP STBAS    JUMP TO START OF BASIC
;
; LDCMN : LOAD LANGUAGE COMMON ROUTINE
; LOADS 3 TRACKS STARTING WITH TRACK IN ACCUM INTO MEMORY @ $0200 & UP
;
2AEE 20 BC 26 LDCMN  JSR SETTK    POSITION HEAD TO FIRST TRACK
2AF1 A2 02        LDX #$02
2AF3 86 E0        STX TS1      # OF TRACKS-1 TO READ
2AF5 86 FF        STX MEMHI   MEMORY ADDRESS HIGH=2
2AF7 CA           DEX
2AF8 8E 5E 26     STX SECTNM  SET SECTOR TO 1
2AFB CA           DEX
2AFC 86 FE        STX MEMLO   MEMORY ADDRESS LOW=0
2AFE CA           DEX
2AFF 86 E5        STX HSTTK   HIGHEST TRACK = $FF
2B01 20 54 27    JSR LDHEAD  LOAD HEAD TO DISK
2B04 20 67 29    JSR READDK  READ TRACK INTO MEMORY
2B07 C6 E0        DEC TS1
2B09 30 15        BMI D9-3   ($2B20) IF NO MORE TRACKS, DONE
2B0B 20 83 2C    JSR INCTKN  BUMP TRACK NUMBER AND SET HEAD
2B0E 4C 04 2B    JMP *-10    ($2B04) CONTINUE
;
; CALL : CALL COMMAND, READ SECTOR INTO MEMORY
;
2B11 20 23 2D CALL   JSR GETADR  MEMORY ADDRESS @$FE,FF
2B14 20 58 2D       JSR CKEQL   LOOK FOR = SIGN
2B17 20 60 2C       JSR GETTK   GET TRACK # AND SECTOR
2B1A 20 54 27       JSR LDHEAD  LOAD HEAD TO DISK
2B1D 20 67 29       JSR READDK  READ DISK INTO MEMORY
2B20 4C 61 27       JMP UNLDHD UNLOAD HEAD AND RETURN
;
; D9 : DISABLE ERROR 9
;
2B23 A9 00      D9     LDA #$00
2B25 8D B4 28    STA DKBT9+4  ($28B4) CHANGE DKBT9 ROUTINE
2B28 60           RTS
;
; DIR : DIRECTORY COMMAND, PRINT SECTOR MAP OF TRACK

```

```

);
; 2B29 20 2E 2D DIR      JSR BLDHEX      GET TRACK NUMBER FROM BUFFER
2B2C 4C F3 29          JMP DIRCNT       GOTO ACTUAL CODE
;
; EM : CALL AND ENABLE EXTENDED MONITOR
;
2B2F A9 05   EM      LDA #$05        GET FIRST TRACK NUMBER
2B31 20 EE 2A          JSR LDCMN       COMMON CODE
2B34 4C 00 17          JMP STEM        GOTO START OF EXTENDED MONITOR
;
; EXAM : EXAM TRACK INCLUDING FORMATTING INFORMATION
;
; THIS IS A REALLY NICE COMMAND, EXCEPT THEY DON'T GIVE YOU ANY
; EASY WAY TO PUT THE DATA BACK ONTO THE DISK.
;
2B37 20 23 2D EXAM    JSR GETADR      MEMORY ADDRESS @$FE,FF
2B3A 20 58 2D          JSR CKEQL       LOOK FOR EQUAL SIGN
2B3D 20 2E 2D          JSR BLDHEX     GET TRACK NUMBER
2B40 20 BC 26          JSR SETTK       MOVE HEAD TO TRACK
2B43 4C 39 27          JMP EXAMCN     JUMP TO REST OF CODE
;
; GO : GO COMMAND
;
2B46 20 2E 2D GO      JSR BLDHEX      GET HIGH ORDER ADDRESS
2B49 8D 54 2B          STA GOADR+2    ($2B54) SAVE IT
2B4C 20 2E 2D          JSR BLDHEX      GET LOW ORDER ADDRESS
2B4F 8D 53 2B          STA GOADR+1    ($2B53) SAVE IT
2B52 4C 00 00 GOADR   JMP **         GO TO ADDRESS ENTERED
;
; INIT : INITIALIZATION COMMAND
;
2B55 20 E4 2C INIT    JSR BUFBYT     GET BYTE FROM BUFFER
2B58 C9 0D             CMP #$0D        IF 'CR' THEN DO ENTIRE DISK
2B5A F0 0C             BEQ FULINT     OTHERWISE, DO ONE TRACK
;
2B5C CE E5 2C          DEC BUFOFS     RESET BUFFER POINTER
2B5F 20 2E 2D          JSR BLDHEX     GET TRACK NUMBER
2B62 20 BC 26          JSR SETTK      MOVE HEAD TO TRACK
2B65 4C 7D 27          JMP INITTK     INITIALIZE TRACK AND RETURN
2B68 20 73 2D FULINT  JSR STROUT     PRINT THE MESSAGE
2B6B 41 52 45          .BYTE 'ARE YOU SURE?',0
2B6F 20 59 4F
2B71 55 20 53 55
2B75 52 45 3F
2B78 00
2B79 20 40 23          JSR INECHO     INPUT AND ECHO 1 CHARACTER
2B7C C9 59             CMP #'Y'
2B7E D0 26             BNE LOAD-1    ($2BA6) IF NOT 'Y' THEN RETURN
2B80 4C 68 27          JMP INITAL    DO REST OF CODE
;
; IO : I/O COMMAND (SEE NOTE AT $2339)
;
2B83 20 E4 2C IO      JSR BUFBYT     GET BYTE FROM BUFFER

```

```

) 2B86 C9 2C      CMP #' ,
2B88 F0 16      BEQ ONLYO    IF ',' DO OUTPUT ONLY
2B8A CE E5 2C      DEC BUFOFS   RESET BUFFER POINTER
2B8D 20 2E 2D      JSR BLDHEX  GET INPUT FLAG
2B90 8D 21 23      STA INDST   SAVE IT
2B93 20 E4 2C      JSR BUFBYT  GET BYTE FROM BUFFER
2B96 C9 0D      CMP #$0D
2B98 F0 0C      BEQ LOAD-1   ($2BA6) IF 'CR' THEN RETURN
2B9A CE E5 2C      DEC BUFOFS   RESET BUFFER POINTER
2B9D 20 5B 2D      JSR CKEQL+3 CHECK FOR COMMA
2BA0 20 2E 2D ONLYO  JSR BLDHEX  GET OUTPUT FLAG
2BA3 8D 22 23      STA OUTDST  STORE IT
2BA6 60      RTS
;
```

; LOAD : LOAD COMMAND

```

; 2BA7 20 A6 2D LOAD      JSR FNDFL   FIND FILE NAME IN DIRECTORY
2BAA 20 70 2C      JSR SETPGM  SET MEMORY ADDRESS & LOAD HEAD
2BAD 86 E0      STX TS1    X=0 USED AS # OF TRACKS READ
2BAF F0 03      BEQ *+5    ($2BB4) SKIP NEXT INSTR 1ST TIME
2BB1 20 83 2C      JSR INCTKN  BUMP TRACK NUMBER
2BB4 20 67 29      JSR READDK  READ TRACK INTO MEMORY
2BB7 E6 E0      INC TS1    BUMP TRACKS READ
2BB9 CE 7D 31      DEC $317D  DROP NUMBER OF TRACKS TO READ
2BBC D0 F3      BNE *-11   ($2BB1) IF MORE TRACKS, CONTINUE
2BBE A5 E0      LDA TS1    RESET NUMBER OF TRACKS IN FILE
2BC0 8D 7D 31      STA $317D  UNLOAD HEAD AND RETURN
2BC3 4C 61 27      JMP UNLDHD
;
```

; MEM : MEMORY COMMAND

```

; 2BC6 A2 00      MEM      LDX #$00  SET OFFSET FOR INPUT ADDRESS
2BC8 20 D0 2B      JSR *+8   ($2BD0) GET FROM BUFFER AND SAVE IT
2BCB 20 5B 2D      JSR CKCOMA  CHECK FOR COMMA
2BCE A2 07      LDX #$07  SET OFFSET FOR OUTPUT ADDRESS
2BD0 20 2E 2D      JSR BLDHEX  GET HIGH ORDER ADDRESS
2BD3 9D 8B 23      STA MINADR+1,X  SAVE IT
2BD6 20 2E 2D      JSR BLDHEX  GET LOW ORDER ADDRESS
2BD9 9D 8A 23      STA MINADR,X  SAVE IT
2BDC 60      RTS
;
```

; PUT : PUT COMMAND

```

; THERE IS A SERIOUS FLAW IN THE PUT COMMAND. IT ALWAYS WRITES WHOLE
; TRACKS STARTING @ $3179. IF YOU HAVE A VERY LARGE FILE IN MEMORY,
; SUCH AS A WORD PROCESSOR FILE, AND IT GOES BEYOND $B578 THEN THE
; LANGUAGES (BASIC, ASSEMBLER, WORD PROCESSOR) WILL COMPUTE 13
; TRACKS TO BE PUT TO DISK. UNFORTUNATELY, ATTEMPTING TO PUT OUT
; 13 TRACKS WILL CAUSE THE SYSTEM TO WRITE THE DISK CONTROLLER
; MEMORY TO DISK!!! THE READ AFTER WRITE CHECK WILL FAIL AND YOU
; WILL GET AN ERROR 2. IF YOU DON'T SEE THE ERROR WHEN IT OCCURS,
; AND ATTEMPT TO LOAD THE FILE LATER, VERY CURIOUS ERRORS HAPPEN.
; THE SIMPLEST FIX FOR THIS PROBLEM IS TO LIMIT THE AMOUNT OF MEMORY
;
```

```

; THE COMPUTER THINKS YOU HAVE BY CHANGING HIMEM @ $2300 TO $B4.
;
2BDD 20 A6 2D PUT      JSR FNDFL      FIND FILE NAME IN DIRECTORY
2BE0 20 70 2C          JSR SETPGM     SET MEMORY ADDRESS, LOAD HEAD
2BE3 AD 7D 31          LDA $317D      CFT NUMBER OF TRACKS
2BE6 85 E0              STA TS1       SAVE IT
2BE8 A9 0B              LDA #$0B      NUMBER OF PAGES
;

; YET ANOTHER EXAMPLE OF AN OSI BLUNDER. EACH TRACK ON THE DISK
; IS CAPABLE OF HOLDING 13 SECTORS BUT THE PROGRAMMERS AT OSI
; ONLY USE 11 IN THE PUT COMMAND. THERE IS NO LOGICAL REASON
; TO DO THIS, MAYBE THEY THOUGHT THAT THIS WOULD HELP THEM TO
; SELL MORE DISKS. YOU MAY CHANGE THIS, AS WE HAVE, TO USE 12
; OR 13 SECTORS PER TRACK BY CHANGING THE PREVIOUS LDA #$0B TO
; LDA #$0C OR $0D. IF YOU DO DECIDE TO UTILIZE THE WASTED
; SECTORS WE WOULD ADVISE YOU TO GO TO A 12 SECTOR PER TRACK
; FORMAT AS THIS IS THE MOST THAT BASIC WILL RECOGNIZE.
; THIS WILL NOT HELP YOU WHEN SAVING BASIC OR ASSEMBLER PROGRAMS
; OR WORD PROCESSOR FILES AS ALL OF THESE LANGUAGES CALCULATE
; THE NUMBER OF TRACKS TO BE WRITTEN TO DISK BASED ON 11
; SECTORS PER TRACK. HOWEVER, IF YOU ARE DOING DISK I/O FROM
; YOUR OWN MACHINE LANGUAGE PROGRAMS, SUCH AS THE TEXT EDITOR
; USED TO PREPARE THIS DOCUMENT, YOU CAN USE 12 SECTORS PER TRACK
; WITHOUT ANY PROBLEM.
;
2BEA 8D 5F 26          STA PGCNT      SAVE IT
2BED 20 E1 27          JSR DSKWRT     WRITE TO DISK
2BF0 C6 E0              DEC TS1       DROP TRACK COUNT
2BF2 F0 06              BEQ *+8      ($2BFA) IF NO MORE THEN DONE
2BF4 20 83 2C          JSR INCTKN    BUMP TRACK NUMBER AND STEP HEAD
2BF7 4C ED 2B          JMP *-10     ($2BED) LOOP BACK & WRITE THIS TRACK
2BFA 4C 61 27          JMP UNLDHD    UNLOAD HEAD AND RETURN
;

; RET : RESTART COMMAND
;

; (*) NOTE, NOT ALL OF THESE WILL BE SET AT THE SAME TIME.
; EACH LANGUAGE SETS IT'S OWN RESTART ADDRESS AND SETS THE
; OTHERS TO REPORT AN ERROR. OF COURSE, THE ASSEMBLER/EXTENDED MONITOR
; SETS BOTH RETURN ADDRESSES.
;

2BFD 20 E4 2C RET      JSR BUFBYT    GET BYTE FROM BUFFER
2C00 C9 41              CMP #'A       ($2C07) NOT 'A' THEN CONTINUE
2C02 D9 03              BNE *+5      REENTER ASSEMBLER (*)
2C04 4C 03 13          JMP RTASM    ($2C0E) NOT 'B' THEN CONTINUE
2C07 C9 42              CMP #'B       REENTER BASIC (*)
2C09 D0 03              BNE *+5
2C0B 4C C4 20          JMP RTBAS    ($2C15) NOT 'E' THEN CONTINUE
2C0E C9 45              CMP #'E       ENTER EXTENDED MONITOR (*)
2C10 D0 03              BNE *+5
2C12 4C 00 17          JMP STEM     ($2C1F) NOT 'M' THEN ERROR #7
2C15 C9 4D              CMP #'M
2C17 D0 06              BNE *+8
2C19 20 44 26          JSR SWAP4    SWAP 4 BYTES FOR VIDEO ROUTINE

```

```

2C1C 6C FC FE      JMP ($FEFC)      JUMP TO RESET VECTOR
2C1F 4C C0 2A      JMP ERR7        DO ERROR #7
;
; XQT : LOAD FILE AND GO @$317E
;
; ONE USEFUL CHANGE TO THIS ROUTINE IS TO MAKE THE JUMP AT $2C25
; INTO AN INDIRECT JUMP TO $3179 (6C 79 31). SINCE THE PROGRAM MUST
; BE IN LOAD FORMAT ANYWAY, THIS WOULD ALLOW YOU TO HAVE A DISK
; BUFFER OR TWO AT THE FRONT OF THE WORKSPACE AND USE THE BASIC
; DISK I/O ROUTINES IN A STRAIGHTFORWARD FASHION.
;
2C22 20 A7 2B XQT   JSR LOAD       DO LOAD
2C25 4C 7E 31       JMP $317E     JUMP TO START OF PROGRAM
;
; SAVE : SAVE COMMAND, WRITE SECTOR TO DISK
;
2C28 20 60 2C SAVE   JSR GETTK      GET TRACK# AND POSITION HEAD
2C2B 20 58 2D       JSR CKEQL     CHECK FOR =
2C2E 20 23 2D       JSR GETADR    GET MEMORY ADDRESS AND PUT @$FE,FF
2C31 20 5E 2D       JSR CKEQL+6   CHECK FOR '/'
2C34 20 3D 2D       JSR GETHEX    GET NUMBER OF PAGES FROM BUFFER
2C37 8D 5F 26       STA PGCNT    SAVE IT
2C3A 20 54 27       JSR LDHEAD    LOAD HEAD
2C3D 20 E1 27       JSR DSKWRT   WRITE TO DISK
2C40 4C 61 27       JMP UNLDHD   UNLOAD HEAD AND RETURN
)
;
; SELECT : SELECT DISK DRIVE
; SETS PARAMETERS FOR DRIVE AND HOMES HEAD
;
2C43 20 E4 2C SELECT JSR BUFBYT   GET BYTE FROM BUFFER
2C46 C9 41           CMP #'A      CHECK FOR A-D
2C48 30 0E           BMI ERR6-3   ($2C48) LESS THAN 'A', ERROR #7
2C4A C9 45           CMP #'E      ($2C58) >= 'E', ERROR #7
2C4C 10 0A           BPL ERR6-3   KILL UPPER 4 BITS : A=1,D=4
2C4E 29 0F           AND #$0F     SET FOR DRIVE
2C50 20 C6 29       JSR SETDRV   ERROR #6 IF DRIVE NOT READY
2C53 B0 06           BCS ERR6     HOME HEAD AND RETURN
2C55 4C 63 26       JMP HOME     DO ERROR #7
2C58 4C C0 2A       JMP ERR7     DO ERROR #6
2C5B A9 06           ERR6       LDA #$06
2C5D 4C 4B 2A       JMP ERRENT

```

```

) ; COMMON ROUTINES USED BY KERNEL
;
; GETTK : GET TRACK NUMBER & SECTOR FROM BUFFER & POSITION HEAD
;
2C60 20 2E 2D GETTK  JSR BLDHEX      GET TRACK NUMBER
2C63 20 BC 26        JSR SETTK       CHECK TRACK AND MOVE HEAD THERE
2C66 20 5B 2D        JSR CKCOMA     CHECK FOR COMMA
2C69 20 3D 2D        JSR GETHEX     GET SECTOR NUMBER
2C6C 8D 5E 26        STA SECTNM    SAVE IT
2C6F 60              RTS
;
; SETPGM : SET UP FOR PROGRAM
;
2C70 20 BC 26 SETPGM JSR SETTK      SET HEAD TO TRACK
2C73 A9 31           LDA #$31       SET MEMORY ADDRESS TO $3179
2C75 85 FF           STA MEMHI
2C77 A9 79           LDA #$79
2C79 85 FE           STA MEMLO
2C7B A9 01           LDA #$01
2C7D 8D 5E 26        STA SECTNM    SET SECTOR NUMBER TO 1
2C80 4C 54 27        JMP LDHEAD    LOAD HEAD AND RETURN
;
; INCTKN : INCREMENT TRACK NUMBER
;
2C83 AD 5D 26 INCTKN LDA TKNUM    GET TRACK NUMBER
2C86 18              CLC
2C87 F8              SED
2C88 69 01           ADC #$01     ADD 1 IN DECIMAL
2C8A D8              CLD
2C8B C5 E5           CMP HSTTK    IS THIS HIGHEST TRACK NUMBER?
2C8D F0 02           BEQ *+4     ($2C91) YES, LET'S CONTINUE
2C8F B0 03           BCS *+5     $ (2C94) HIGHER, DO ERROR D
2C91 4C BC 26        JMP SETTK    SET HEAD AT TRACK AND RETURN
2C94 A9 0D           ERRD       LDA #$0D    ERROR D
2C96 D0 C5           BNE ERR6+2   ($2C5D) JUMP TO ERROR
;
2C98 20 6A 2D NXTOSN JSR CRLF     SET FOR NEXT OS INPUT
;
; OSINP : OS INPUT ROUTINE
;
; NOTE: THIS ROUTINE DOES NOT TRAP ILLEGAL CONTROL CHARACTERS.
; IF YOU PRESS 'BACKSPACE' ($08), THE PREVIOUS CHARACTER WILL
; BE ERASED, BUT BOTH THE 'BACKSPACE' AND THE CHARACTER WILL
; STILL BE IN THE BUFFER AND YOU WILL GET AN ERROR #7 EVEN
; THOUGH THE INPUT COMMAND LOOKS CORRECT.
;
2C9B A9 11           OSINP      LDA #$11    SET BUFFER SIZE
2C9D 8D ED 2C         STA MAXBUF
2CA0 A2 00           LDX #$00    X=CHARACTER COUNT
2CA2 20 40 23 NXTOSI JSR INECHO   GET A CHARACTER
2CA5 C9 5F           CMP #$5F    IS IT THE 'UNDERLINE'
2CA7 D0 13           BNE OSIOK   CONTINUE IF NOT
2CA9 CA              DEX        MOVE BACK ONE CHARACTER

```

```

2CAA 30 EC      BMI NXTOSN      TRY AGAIN
;
2CAC 9D 1E 2E    STA OSBUF,X    BACKSPACED AT FIRST CHARACTER
2CAF 20 73 2D    JSR STROUT     PUT IT IN BUFFER
;
; THIS PRINT FIRST DOES 2 BACKSPACES TO POSITION THE CURSOR
; AT THE CHARACTER TO BE DELETED. THE FIRST IS NECESSARY TO GET
; PAST THE UNDERLINE OR LEFT ARROW AND THE SECOND TO GET TO THE
; CHARACTER THAT WAS INPUT. THE ROUTINE THEN PRINTS 2 SPACES, 1
; TO ELIMINATE THE CHARACTER THAT WAS ENTERED AND ANOTHER TO
; ELIMINATE THE UNDERLINE OR LEFT ARROW. THE CURSOR IS THEN
; BACKSPACED TWICE TO REPOSITION IT SO YOU ARE READY TO
; ENTER THE CORRECT CHARACTER.
;
2CB2 08 08 20    .BYTE 8,8,' ',8,8,0
2CB5 20 08 08
2CB8 00
2CB9 4C A2 2C    JMP NXTOSI     CONTINUE
2CBC C9 15  OSIOK   CMP #$15      CHECK FOR CONTROL U
2CBE F0 D8      BEQ NXTOSN     IF SO IGNORE INPUT UP TO NOW
2CC0 9D 1E 2E    STA OSBUF,X    PUT IN BUFFER
2CC3 C9 0D      CMP #$0D      CHECK FOR 'CR'
2CC5 F0 09      BEQ *+11      ($2CD0) IF SO THEN WE ARE DONE
2CC7 E8          INX          BUMP INDEX
2CC8 E0 11      CPX #$11      CHECK FOR MAXIMUM LENGTH
2CCA D0 D6      BNE NXTOSI     NOT DONE SO CONTINUE
2CCC A9 0D      LDA #$0D      BUFFER FULL, STOP INPUT AND PROCESS
2CCE D0 F0      BNE OSIOK+4   ($2CC0) JUMP
2CD0 4C 6A 2D    JMP CRLF
2CD3 00          BRK          (UNUSED)
2CD4 00          BRK          (UNUSED)
2CD5 00          BRK          (UNUSED)
;
; INPUT : INPUT ROUTINE. CHECKS FOR CONTROL CHARACTERS.
;
; (SEE NOTE AT $2339)
; WHEN WRITING YOUR OWN INPUT ROUTINES TO BE USED WITH THE OS
; YOU SHOULD STORE THE INPUT CHARACTER IN A.HOLD BEFORE RETURNING
; FROM YOUR ROUTINE SINCE THE INPUT ROUTINE RESTORES A,X,Y
; WHEN IT RETURNS. IF YOU DO NOT DO THIS YOUR INPUT WILL BE THE
; CHARACTER IN A WHEN THE ROUTINE WAS CALLED.
;
2CD6 20 67 23 INPUT  JSR SAVAXY
2CD9 20 39 23      JSR DOINP      GO DO INPUT
2CDC 20 4D 25      JSR CKINP     CHECK FOR CONTROL CHARACTERS
2CDF F0 F8          BEQ INPUT+3   ($2CDF) IF SO CONTINUE INPUT
2CE1 4C 5E 23      JMP RSTAXY    RESTORE REGISTERS AND GO BACK
;
; BUFBYT : GET BYTE FROM BUFFER
;
2CE4 A0 07      BUFBYT LDY #BUFOFS  GET OFFSET INTO BUFFER
;
2CE6 B1 E1      LDA (OSIBAD),Y  MORE SELF MODIFYING CODE
                                         LOAD BYTE

```

```

) 2CE8 C9 0D      CMP #$0D      CHECK FOR 'CR'
2CEA F0 07      BEQ *+9       ($2CF3) IF SO WE ARE DONE
2CEC C0 11      CPY #$11      CHECK FOR END OF BUFFER
2CEE F0 04      BEQ *+6       ($2CF4) IF SO THEN RETURN
2CF0 EE E5 2C      INC BUPOFS   BUMP THE OFFSET
2CF3 60      RTS
2CF4 A9 0D      LDA #$0D      LOAD A 'CR'
2CF6 60      RTS           RETURN, BUFFER IS FULL
;
; SWAP : SWAP PAGE 0 AND 1 WITH $2F79 AND UP (USED BY BASIC)
; THIS ROUTINE IS NOT CALLED ANYWHERE BY THE OS
;
2CF7 68      SWAP     PLA      CHANGE RETURN ADDRESS
2CF8 18      CLC      CLC      INTO JUMP @$2D20
2CF9 69 01      ADC #$01      ($2D21)
2CFB 8D 21 2D      STA GETADR-2   ($2D22)
2CFE 68      PLA
2CFF 69 00      ADC #$00
2D01 8D 22 2D      STA GETADR-1   ($2D23)
2D02 A2 00      LDX #$00      SET THE OFFSET
2D06 BD 00 01 SWAPLP  LDA STACK,X  GET BYTE FROM PAGE 1
2D09 BC 79 30      LDY SWAP1,X  GET BYTE FROM SWAP AREA
2D0C 9D 79 30      STA SWAP1,X  SAVE THE BYTE FROM PAGE 1
2D0F 98      TYA
2D10 9D 00 01      STA STACK,X  SAVE THE BYTE FROM SWAP AREA
2D13 B5 00      LDA PAGE0,X  GET BYTE FROM PAGE 0
2D15 BC 79 2F      LDY SWAP0,X  GET BYTE FROM SWAP AREA
2D18 9D 79 2F      STA SWAP0,X  SAVE BYTE FROM PAGE 0
2D1B 94 00      STY PAGE0,X  SAVE BYTE FROM SWAP AREA
2D1D E8      INX      INX      BUMP THE OFFSET
2D1E D0 E6      BNE SWAPLP  NOT DONE, KEEP ON
2D20 4C C7 14      JMP **      ADDRESS FOR JUMP IS CHANGED ABOVE
;
; GETADR : GET MEMORY ADDRESS FROM BUFFER
;
2D23 20 2E 2D GETADR JSR BLDHEX
2D26 85 FF      STA MEMHI      HIGH ORDER BYTE
2D28 20 2E 2D      JSR BLDHEX
2D2B 85 FE      STA MEMLO      LOW ORDER BYTE
2D2D 60      RTS
;
; BLDHEX : BUILD HEX BYTE FROM BUFFER
; RESULT IS IN ACCUM
;
2D2E 20 3D 2D BLDHEX JSR GETHEX      GET BYTE FROM BUFFER
2D31 0A      ASL A
2D32 0A      ASL A
2D33 0A      ASL A
2D34 0A      ASL A
2D35 85 E0      STA TS1      SAVE UPPER FOUR BITS
2D37 20 3D 2D      JSR GETHEX  GET SECOND BYTE
2D3A 05 E0      ORA TS1      COMBINE WITH FIRST BYTE
2D3C 60      RTS

```

```

);
; GETHEX : GET 1 HEX DIGIT FROM BUFFER
;
2D3D 20 E4 2C GETHEX JSR BUFBYT      GET BYTE FROM BUFFER
2D40 38           SEC
2D41 E9 30        SBC #$30
2D43 C9 0A        CMP #$0A
2D45 90 08        BCC *+10      ($2D4F) IF <10 THEN RETURN
2D47 E9 11        SBC #$11
2D49 C9 06        CMP #$06
2D4B B0 08        BCS *+10      ($2D55) IF > F THEN ERROR
2D4D 69 0A        ADC #$0A
2D4F 60           RTS

;
; THIS CODE USED BY BASIC AND POSSIBLY THE OTHER LANGUAGES
;
2D50 A5 00        LDA PAGE0      DO WE NEED TO SWAP PAGES 0/1
2D52 F0 A3        BEQ SWAP       YES, GO DO IT
2D54 60           RTS

;
2D55 4C C0 2A      JMP ERR7      GOT HERE FROM $2D4B

;
; CKEQL ; CHECK FOR '=' OR ',' OR '/'
;

;
; THREE ENTRY POINTS -> CKEQL=$2D58 : CKCOMA=$2D5B : CKSLSH=$2D5E
; ANOTHER EXAMPLE OF TURNING A TWO BYTE INSTRUCTION INTO A THREE
; BYTE 'HARMLESS' INSTRUCTION. (SEE NOTE @ $28E6)
; FORTUNATELY, THIS TIME THEY ARE HARMLESS.
;

2D58 A9 3D      CKEQL  LDA #'=
2D5A 2C A9 2C      BIT $2CA9
2D5D 2C A9 2F      BIT $2FA9
2D60 85 E0        STA TS1       SAVE CHARACTER TO TEST
2D62 20 E4 2C      JSR BUFBYT   GET BYTE FROM BUFFER
2D65 C5 E0        CMP TS1
2D67 D0 EC        BNE CKEQL-3   ($2D55) IF NOT THEN ERROR #7
2D69 60           RTS

;
; CRLF : PRINT CR,LF TO ALL ACTIVE DEVICES
;
2D6A A9 0D      CRLF   LDA #$0D      DO 'CR'
2D6C 20 43 23      JSR PRINT
2D6F A9 0A        LDA #$0A      DO 'LF'
2D71 D0 30        BNE FNDFL-3   ($2DA3) JUMP TO PRINT

;
; STROUT : PRINT STRING FOLLOWING JSR THAT GOT US HERE
;
; THE STRING CAN BE ANYTHING, BUT MUST BE TERMINATED BY A NULL.
; STRING LENGTH IS LIMITED TO 255 CHARACTERS.
; THIS IS A VERY USEFUL ROUTINE, BUT BE WARNED THAT IT CAN REALLY
; PLAY HAVOC WITH YOUR PROGRAM IF YOU FORGET TO PUT THE NULL
; DELIMITER ON YOUR STRING.
;
```

```

) 2D73 68      STROUT PLA          PULL RETURN ADDRESS OFF STACK
2D74 85 E3     STA STROAD        STORE LOW ADDRESS
2D76 68      PLA
2D77 85 E4      STA STROAD+1    STORE HIGH ADDRESS
2D79 A0 01      LDY #$01        SET TO INDEX THROUGH STRING
2D7B B1 E3      LDA (STROAD),Y  GET BYTE FROM STRING
2D7D F0 06      BEQ *+8         ($2D85) IF NULL THEN WE ARE DONE
2D7F 20 43 23    JSR PRINT       PRINT IT IF NOT
2D82 C8      INY
2D83 D0 F6      BNE *-8         GET SET FOR NEXT CHARACTER
2D85 98      TYA
2D86 38      SEC
2D87 65 E3      ADC STROAD      GET SET TO FIND RETURN ADDRESS
2D89 85 E3      STA STROAD      ADD LENGTH OF STRING TO ADDRESS
2D88 90 02      BCC *+4         SAVE IT
2D8D E6 E4      INC STROAD+1    ($2D8F) NO CARRY SO UPPER BYTE IS ON
2D8F 6C E3 00    JMP (STROAD)   BUMP THE UPPER BYTE
;                JUMP PAST PRINTED STRING
;
; PRT2HX : PRINT 2 HEX CHARACTERS OF ACCUMULATOR
;
2D92 48      PRT2HX PHA        SAVE THE CHARACTER
2D93 4A      LSR A           PUT UPPER NIBBLE IN LOWER NIBBLE
2D94 4A      LSR A
2D95 4A      LSR A
2D96 4A      LSR A
2D97 20 9B 2D    JSR PRTHEX     PRINT THE UPPER 4 BITS
2D9A 68      PLA            RESTORE THE CHARACTER
;
; PRTHEX : PRINT HEX OF LOW NIBBLE IN ACCUMULATOR
; GOOD HEX TO ASCII CONVERSION
;
2D9B 29 0F      PRTHEX AND #$0F  MASK UPPER 4 BITS
2D9D C9 0A      CMP #$0A        SET CARRY IF >9 AND CLEAR
;                CARRY IF <10
2D9F F8      SED
2DA0 69 30      ADC #$30        IF CARRY SET THEN A=$41
;                IF CARRY CLEAR 9=$39
2DA2 D8      CLD
2DA3 4C 43 23    JMP PRINT      ; FNDFL : FIND FILE NAME IN DIRECTORY
;
; ONE OF THE MOST USEFUL ROUTINES IN THE OS IF YOU ARE WRITTING
; YOUR OWN MACHINE LANGUAGE PROGRAMS. PUT THE NAME OF THE FILE YOU ARE
; LOOKING FOR IN A BUFFER, EITHER THE OS BUFFER @ $2E1E OR YOUR OWN.
; THE FILE NAME SHOULD BE DELIMITED BY A CR IF IT IS SHORTER THAN
; SIX CHARACTERS. IF YOU ARE USING YOUR OWN BUFFER, IT'S ADDRESS
; SHOULD BE PUT IN $E1,$E2. THE BUFFER OFFSET @ $2CE5 MUST BE
; SET, EITHER TO ZERO IF THE FILE NAME IS AT THE BEGINNING OF THE
; BUFFER, OR TO WHATEVER OFFSET IN THE BUFFER THE FIRST CHARACTER
; OF THE FILE NAME IS AT. THEN CALL THIS ROUTINE.
; RETURNS WITH STARTING TRACK IN A, LAST TRACK @ $E5.
;
```

```

2DA6 A9 76      FNDFL   LDA #$76
2DA8 85 E5      STA HSTTK  SET HIGHEST TRACK NUMBER
2DAA 20 E4 2C   JSR BUFBYT GET BYTE FROM BUFFER
2DAD CE E5 2C   DEC BUFOFS SET POINTER BACK
2DB0 C9 41      CMP #$41
2DB2 10 0A      BPL *+12   ($2DBE) IF ALPHA THEN LOOK FOR NAME
2DB4 A2 00      LDX #$00   HERE IF TRACK NUMBER ENTERED.
2DB6 A9 76      LDA #$76
2DB8 9D 7A 2E   STA SCRBUF+1,X
2DBB 4C 2E 2D   JMP BLDHEX GET TRACK# IN A AND RETURN
;
; LOAD BY NAME
;
2DBE AD E5 2C   LDA BUFOFS GET POINTER
2DC1 85 E0      STA TS1    SAVE IT
2DC3 A9 08      LDA #$08  TRACK NUMBER FOR DIRECTORY
2DC5 20 BC 26   JSR SETTK MOVE TO TRACK 8
2DC8 8C 5E 26   STY SECTNM SECTNM=0
2DCB 4C 00 2E   JMP NEWDS JUMP AROUND A LITTLE
2DCE A2 00      LDX #$00
2DD0 20 E4 2C NXTCHR JSR BUFBYT GET BYTE FROM BUFFER
2DD3 C9 0D      CMP #$0D
2DD5 D0 02      BNE *+4   ($2DD9) IF NOT 'CR' THEN CONTINUE
2DD7 A9 20      LDA #$20   IF 'CR' USE 'SPACE' FOR COMPARE
2DD9 DD 79 2E   CMP SCRBUF,X COMPARE TO DIRECTORY ENTRY
2DDC D0 11      BNE NXTDE IF NOT = TRY NEXT ENTRY
2DDE E8        INX      BUMP OFFSET
2DDF 8A        TXA
2DE0 29 07      AND #$07
2DE2 C9 06      CMP #$06
2DE4 D0 EA      BNE NXTCHR IF WE HAVEN'T LOOKED AT ALL
;                                6 CHARACTERS THEN CONTINUE
2DE6 BD 7A 2E   LDA SCRBUF+1,X MATCH! GET LAST TRACK#
2DE9 85 E5      STA HSTTK  SAVE IT
2DEB BD 79 2E   LDA SCRBUF,X GET STARTING TRACK#
2DEE 60        RTS
2DEF 8A        NXTDE  TXA  NEXT DIR ENTRY SETUP
2DF0 29 F8      AND #$F8  KILL LOWER 3 BITS IN OFFSET
2DF2 18        CLC
2DF3 69 08      ADC #$08  SET TO NEXT DIR ENTRY
2DF5 AA        TAX
2DF6 F0 08      BEQ NEWDS IF END OF SECTOR GET NEXT
2DF8 A5 E0      NXTDS  LDA TS1  RESTORE BUFFER OFFSET
2DFA 8D E5 2C   STA BUFOFS
2DFD 4C D0 2D   JMP NXTCHR JUMP BACK AND TRY AGAIN
2E00 EE 5E 26   NEWDS  INC SECTNM BUMP SECTOR NUMBER
2E03 AD 5E 26   LDA SECTNM
2E06 C9 03      CMP #$03
2E08 30 05      BMI *+7   ($2E0F) IF < 3 THEN CONTINUE
2E0A A9 0C      LDA #$0C  ERROR C, FILE NOT FOUND
2E0C 4C 4B 2A   ERRC   JMP ERRENT
2E0F A9 79      LDA #$79  SET MEMORY ADDRESS TO $2E79
2E11 85 FE      STA MEMLO (SCRATCH BUFFER, 256 BYTES)

```

2E13 A9 2E	LDA #\$2E	
2E15 85 FF	STA MEMHI	
2E17 20 1A 2B	JSR CALL+9	(\$2B1A) LOAD HEAD, READ DISK, UNLOAD HEAD
i		BUFFER OFFSET
2E1A A2 00	LDX #\$00	
2E1C F0 DA	BEQ NXTDS	SEARCH THIS DIRECTORY SECTOR

```
; TABLES AND STORAGE FOR OS65D
; OS65D INPUT BUFFER @$2E1E TO $2E2F
;
2E1E          OSBUF = *+17
;
; OS65D DISPATCH TABLE
;
; ADDRESS IN TABLE = ACTUAL ADDRESS OF ROUTINE - 1
; ADDRESS IN TABLE IS PUSHED ON STACK AND THEN CALLED
; BY DOING AN RTS.
;
2E30 41 53    DSPTBL .BYTE 'AS'
2E32 DD 2A      .WORD ASM-1
2E34 42 41      .BYTE 'BA'
2E36 E5 2A      .WORD BASIC-1
2E38 43 41      .BYTE 'CA'
2E3A 10 2B      .WORD CALL-1
2E3C 44 39      .BYTE 'D9'
2E3E 22 2B      .WORD D9-1
2E40 44 49      .BYTE 'DI'
2E42 28 2B      .WORD DIR-1
2E44 45 4D      .BYTE 'EM'
2E46 2E 2B      .WORD EM-1
2E48 45 58      .BYTE 'EX'
2E4A 36 2B      .WORD EXAM-1
2E4C 47 4F      .BYTE 'GO'
2E4E 45 2B      .WORD GO-1
2E50 48 4F      .BYTE 'HO'
2E52 62 26      .WORD HOME-1
2E54 49 4E      .BYTE 'IN'
2E56 54 2B      .WORD INIT-1
2E58 49 4F      .BYTE 'IO'
2E5A 82 2B      .WORD IO-1
2E5C 4C 4F      .BYTE 'LO'
2E5E A6 2B      .WORD LOAD-1
2E60 4D 45      .BYTE 'ME'
2E62 C5 2B      .WORD MEM-1
2E64 50 55      .BYTE 'PU'
2E66 DC 2B      .WORD PUT-1
2E68 52 45      .BYTE 'RE'
2E6A FC 2B      .WORD RET-1
2E6C 58 51      .BYTE 'XQ'
2E6E 21 2C      .WORD XQT-1
2E70 53 41      .BYTE 'SA'
2E72 27 2C      .WORD SAVE-1
2E74 53 45      .BYTE 'SE'
2E76 42 2C      .WORD SELECT-1
2E78 00          .BYTE Ø
;
; THE REST OF THE OS MEMORY AREA IS WORKING STORAGE LOCATIONS
;
2E79          SCRBUF = *+256           SCRATCH BUFFER FOR DIRECTORY
```

```
; THIS AREA IS ALSO USED BY THE BASIC GET/PUT LOGIC.  
; YOU CAN USE THIS PAGE FOR TRANSIENT CODE BY CALLING IT HERE.  
; JUST BE SURE THAT YOU DON'T DO A DIRECTORY SEARCH OR USE BASIC'S  
; RANDOM DISK I/O. A GOOD PLACE TO PUT SUCH CODE IS ON TRACK 8  
; IN SECTORS 6 & UP SINCE THIS AREA IS NOT USED FOR ANY OTHER  
; PURPOSE.  
;  
2F79      SWAP0  = *+256      PAGE 0 HOLD AREA (USED BY BASIC)  
3079      SWAP1  = *+256      STACK    "    "    "    "    "  
;  
; AND THAT (FINALLY!) BRINGS US UP TO THE START OF THE BASIC WORKSPACE.
```


)	\$0AA9	28E6
)	\$22A4	22B1
)	\$22B3	22A0 22A7
)	\$22C7	22A4 22AA
)	\$2476	2405
)	\$269E	26BF
)	\$28E7	28FC 2904
)	\$2CA9	2D5A
)	\$2FA9	2D5D
)	\$317D	2BB9 2BC0 2BE3
)	\$317E	2C25
)	\$F022	2297
)	\$FE01	2285
)	\$FEFC	2C1C
	**	235E 2360 2362 2377 2389 2390 23AB 23C2 23FC 2415 25A3 2629 262C 2638 2A4E 2B52 2D20
	A.HOLD	*2363 2367 2382 2395 24F2 2504 2524 2536 253C 259E 25E7
	ACIA	*C010 2730 2735 2741 27C2 27CD 28B5 292B 29B6
	ACIAIO	*C011 2747 27C9 27D3 28BB 2930
	ASM	*2ADE 2E32
	BASIC	*2AE6 22B3 2E36
	BDMHTK	*2453 244D 248B
	BDRDNX	*2442 23EE
	BLDHEX	*2D2E 2B29 2B3D 2B46 2B4C 2B5F 2B8D 2BA0 2BD0 2BD6 2C60 2D23 2D28 2DBB
	BPSECT	*2998 28F8 299D 2A1B
)	BSPACE	*25F5 25AF
	BUFBYT	*2CE4 2AA4 2AAF 2B55 2B83 2B93 2BFD 2C43 2D3D 2D62 2DAA

OS-65D V3.2 CROSS REFERENCE

PAGE 2

2 DDDG

D10ADR *23C3 23DC 23E7
D2BFDR *2335 241A 2420
D2BFHI *2330
D2BFLO *232E 242A 2435
D2CRTK *2334
D2FRST *2332
D2IADR *23FD 242D 2438
D2LAST *2333
D2OADR *2416 2430 243B
D9 *2B23 2B09 2E3E
DCPRNT *2A41 2A2F 2A34
DEFDEV *2AC6 228B 2569
DELAY *2700 267C 269A 2704
DIR *2B29 2E42
DIRCNT *29F3 2B2C
DK1IN *23A1 230B 23B4
DK1NXT *23CC 23A8 23BE
DK1OUT *23B2 231B
DK2IN *23F0 230D
DK2NXT *2420 23F9 2411
DK2OUT *2403 231D
DKBT9 *28B0 2885 28B9 28CB 28D2 28D9 28ED 290B 2912 291D 29C3
2B25
DKBTCI *29B6 2998 29A1 29AC 29BF
DKINIT *29EB 29CE 29D4 29E1 29F4
DKRDY *2977 2974 297D
DKWTX *27C2 2856 27A6 27AB 27B1 27B6 27C7 282D 2833 283B 2843 2851

DLYFA *289F 2810 2828
DLYFA1 *2956 289F
DOINP *2339 2CD9
DOIO *234B 233E 235C 2374
DONXIO *235C 2351
DSKBYT *27CD 27D1 27F5
DSKDR *265C 26D1 2A5E
DSKWRT *27E1 248E 2803 2BED 2C3D
DSPTBL *2E30 2A88 2A95 2A9C 2AA0
EM *2B2F 2E46
ERR1 *2993
ERR2 *289B 288D
ERR3 *2784
ERR4 *278F 2786 278D 27EA
ERR5 *28E0
ERR6 *26DC *2C5B 26CF 2C48 2C4C 2C53 2C96
ERR7 *2AC0 2A8E 2C1F 2C58 2D55
ERR8 *26CD 26C2 26C6
ERR9 *28BF 289D 28B3 28E9
ERRA *28E6
ERRB *27E8 27E4 27EE
ERRC *2E0A
ERRD *2C94
ERRENT *2A4B 26DE 2791 28C1 2995 2A7D 2A80 2AC2 2C5D 2E0C
EXAM *2B37 2E4A
EXAMCN *2739 2745 274D 2751 2B43
EXCOM *2A84 2A77 2ABE

OS-65D V3.2 CROSS REFERENCE

PAGE 5

IO	*2B83	2E5A									
IODISP	*2376	2356									
IOOFS	*2378	2371									
IOTABL	*2301	237A	237E								
KBINP	*2528	2303	2534	25EB							
KEYTST	*263D	25DB	25E2								
KIRTN	*253F	2528									
KPDO	*2325	24E3	2540								
KPOLL	*FD00	2531									
KPORT	*DF00	2221	263D	2640							
KTRTN	*2643	25DE	25E5								
LAMB	*2660	27D7	295D								
LCHAR	*263C	259B	25CC								
LDCMN	*2AEE	2AE0	2AE8	2B31							
LDHDWI	*2728	2739	2794								
LDHEAD	*2754	220C	2494	2728	2766	2A0D	2B01	2B1A	2C3A	2C80	
LF	*260F	25AB									
LOAD	*2BA7	2B7E	2B98	2C22	2E5E						
MAXBUF	*2CED	2C9D									
MEM	*2BC6	2E62									
MEMCHK	*22EC	2278	229D								
MEMHI	*00FF 287A	220A 2880	2262 2890	226F 2896	22EC 2940	23EA 2965	243E 2977	2489 2AF5	274F 2C75	27DF 2D26	2849 2E15
MEMIN	*2389	2309									
MEMLO	*00FE 27DA	220F 2840	2266 2937	226A 293B	22EE 2960	22F4 2AFC	22F8 2C79	23DF 2D2B	2433 2E11	2484	274A
MEMOT	*2390	2319									
MEMTST	*2276	227E									

MINADR	*238A	2398	239D	2499	2585	2BD3	2BD9		
MODMIN	*2497	2582							
MOTADDR	*2391	2553	2558						
MOVE	*2629	2632	2636						
MOVEHD	*26D1	26CB	2950						
NEWDS	*2E00	2DCB	2DF6						
NMHZ	*267B	28A2							
NULLIN	*2386	2307							
NXTCHR	*2DD0	2DE4	2DFD						
NXTDE	*2DEF	2DDC							
NXTDS	*2DF8	2E1C							
NXTENT	*2ABA	2A92	2A9A	2AA9					
) NXTOSI	*2CA2	2CB9	2CCA						
NXTOSN	*2C98	2CAA	2CBE						
ONLYO	*2BA0	2B88							
OS65D3	*2A51	254A	2A7A						
OSBUF	*2E1E	2CAC	2CC0						
OSERR	*2AC4	2A4B							
OSIBAD	*00E1	2A71	2A75	2A90	2A98	2CE6			
OSINP	*2C9B	2A6C							
OSIOK	*2CBC	2CA7	2CCE						
OUTDST	*2322	2346	255B	256F	2574	258E	2593	2ACA	2BA3
PAGE0	*0000	2274	28A5	2D13	2D1B	2D50			
PATCH0	*22B6	2202							
PATCH1	*2371	234D							
) PATCH2	*2491	2462							
PATCH3	*2508	24B9							

OS-65D V3.2 CROSS REFERENCE

PAGE 8

OS-65D V3.2 CROSS REFERENCE

PAGE 10

) VIDSIZE *DE00 2291
VLOSAV *2639 2613
VLPI *262B 2623
VLP2 *262E 2626
VOTOF5 *25A4 25D4
WAITIH *271D 2720 272B
WRTPG *2840 2847 284D
WRTRTY *00F6 2807 288B
WTDKBF *2477 23D3 2427
X.HOLD *235F 236D
X16ACI *CF00 2251 2255 24B3 24C1 24C9 2508
X16DEV *2323 24B0 24BE
) X16INP *24B0 230F 24B7
X16OUT *24BD 231F 24C6
XQT *2C22 2E6E
Y.HOLD *2361 236A

ASCII Key Board

Does NOT leave
value in "A"

```

2528 204425 JSR $2544 delay
→252B EE2423 INC $2324 wait seed
252E AD01DF LDA $DFF1
2531 30F5 BMI $2528
2533 8D6323 STA $2363
2536 EA NOP 44 PHa
2537 EA NOP
2538 EA NOP
2539 EA NOP
253A EA NOP
253B 204425 JSR $2544 delay
253E AD01DF LDA $DFF1 wait key-up
2541 10F8 BPL $253B C8 pha
2543 60 RTS
2544 A276 LDX *$76 } delay
2546 CA DEX
2547 204C25 JSR $254C } delay
254A D0FA BNE $2546
254C 60 RTS
→254D C95B CMP *$5B " [ start indirect file
254F D011 BNE $2562
2551 A980 LDA *$80
2553 8D9223 STA $2392

```

```

2556 A980 LDA *$80
2558 8D9123 STA $2391
255B AD2223 LDA $2322
255E 0910 ORA *$10
2560 D031 BNE $2593
2562 C95D CMP *$5D
2564 D013 BNE $2579
2566 204623 JSR $2346
2569 ADC62A LDA $2AC6
256C 8D2123 STA $2321
256F AD2223 LDA $2322
2572 29EF AND *$EF
2574 8D2223 STA $2322
2577 A95D LDA *$5D
2579 C918 CMP *$18
257B D0ED BNE $258A
257D A910 LDA *$10
257F 8D2123 STA $2321
2582 209724 JSR $2497
2585 8D8A23 STA $238A
2588 B00C BCS $2596

```

540 video

2599 98	TYA	
259A 48	PHA	
259B A05B26	LDY \$265B	under cursor
259E AD6323	LDA \$2363	A. Hold
25A1 297F	AND #\$7F	strip bit ? - EA EA
25A3 A247	LDX #\$52	
25A5 C90D	CMP #\$0D	cr
25A7 F078	BEQ \$2621	
25A9 C908	CMP #\$08	back up
25AB F066	BEQ \$2613	
25AD C910	CMP #\$10	contrl P - printer on/off
25AF F069	BEQ \$261A	
25B1 C90C	CMP #\$0C	control L
25B3 F065	BEQ \$261A	
25B5 C90A	CMP #\$0A	LF
25B7 F074	BEQ \$262D	
25B9 C920	CMP #\$20	< space EA
25BB 301C	BMI \$25D9	exit EA
25BD C97B	CMP #\$7B	> { EA
25BF 1018	BPL \$25D9	exit EA
25C1 9D00D7	STA \$D700,X	To Screen
25C4 E8	INX	
25C5 E682	CPX #\$00	

25C7 F060	BEQ \$2629	SCROLL
25C9 D028	BNE \$25CB	
25CB BC00D7	LDY \$D700,X	
25CE 8C5B26	STY \$265B	under cursor
25D1 A95F	LDA #\$5F	cursor
25D3 9D00D7	STA \$D700,X	
25D6 3EA425	STX \$25A4	
25D9 68	PLA	
25DA A8	TAY	
25DB AD6323	LDA \$2363	A. Hold
25DE 48	PHA	
25DF AD01DF	LDA \$DF01	
25E2 3011	BMI \$25F5	
25E4 8D2523	STA \$2325	
25E7 C913	CMP #\$13	control S
25E9 D00A	BNE \$25F5	— save keypressed for cc check 60819
25EB 204425	JSR \$2544	delay
25EE AD01DF	LDA \$DF01	
25F1 C911	CMP #\$11	
25F3 D0F9	BNE \$25EE	
25F5 4CF124	JMP \$24F1	Restore A + RTS
25F8 68	RTS	
25F9 8A	TXA	