Rigaku XtaLAB Mini II SC-XRD

v20211208

Overview

The XtaLAB Mini II is a desktop single-crystal X-ray diffractometer (SC-XRD) with an enclosed beam that is completely shielded. *Any individual who wishes to use the XRD must:*

- Participate in training that demonstrates all safety issues including possible radiation hazards and biological effects of radiation associated with the instrument.
- · Receive training in proper operating procedures for the instrument.
- · Agree to document that training has been completed.
- · Record their time on the log sheet.
- · Operate the instrument only according to the manner specified in the SOP.
- · Never bypass the instrument safety devices.
- Read, understand, and abide by the contents of this binder (tabs 1-5).
- Abide by all other policies pertaining to WCU's shared instrumentation.

Emergency Contacts

Contact	Role	Office	Email	Phone
Matt Burleson	Instrumentation Specialist, XRD Authorized User	AP 346	mburleson@wcu.edu	828-227- 2239
Wes Bintz	Research Operations Manager, Arts & Sciences	AP 221	wwbintz@wcu.edu	828-227- 2270
Jamie Wallen	Department Head, CHPH	AP 112	jamiewallen@wcu.edu	828-227- 3667
Jon Maddy	Director, Safety and Risk Management	-	jmaddy@wcu.edu	828-227- 7442
Amanda Lytle	Lab Safety Officer, Safety and Risk Management	-	alafferty@wcu.edu	828-227- 3645
Campus Police	Non-emergency/after hours contact	-	-	828-227- 730
Campus Dispatch	Fire/Medical/Police Emergency Response	-	-	828-227- 8911
NC Radiation Protection Section	State Emergency Center	-	-	800-858- 0368

Safety

- Please see the "Safety Overview" tab for safety information specific to the XRD.
- Please see the "Safety Overview" tab for the Notice to Employees.
- In an emergency, press the Red Stop Button on the front of the instrument. If you believe you have been exposed to X-rays, report it immediately
 to one of the contacts listed above!

Remember to document your time on the log sheet!