
Communication Protocols

UART

UART Protocol


Universal Asynchronous Receiver and Transmitter



Drive Mode of Pins?

IC-A to IC-B Pin Connections?


The Protocol



Ref: https://www.electronicwings.com/arm7/lpc2148-uart0

*Mode = 8bit Data Transfer, Parity = None, Stop-Bit=1

The Protocol




Data byte transferred?

Why LSB first?


Ref: https://www.electronicwings.com/arm7/lpc2148-uart0

Questions.




- Significance of baudrate ?
- Need for Start/Stop bit
- How Rx decodes data?
- Why asynchronous?
- UART pros/cons?

Ref: https://www.electronicwings.com/arm7/lpc2148-uart0




Baudrate?

Ref - RIPYL Library (Python)




Ref – RIPYL Library (Python)



Prof. Kurian Polachan, IIIT-Bangalore

Question.




Baudrate ?

Data Byte ?

Ref – RIPYL Library (Python)


Answer




Ref – RIPYL Library (Python)


SPI


SPI Protocol





SPI Protocol






- The clock signal is in the low state when idle.
- The data is changed on the leading edge of the clock
- The data is sampled on the falling edge of the clock

*SPI Mode = 1 (CPOL = 0, CPHA = 1), LSB First Transfer


Multi-Byte Transfer



Better than UART

- No Start/Stop Bit Requirement
- Header/Footer Not Required.
- Synchronized. Bits Change with Clock.
 Transfer starts with SS
- High Speed

Multi-Slave Comm.




 How many slave select lines are required for interfacing 8 SPI-Slave devices with SPI-Master

 Can UART be used for Multi-Slave Communications?


https://en.wikipedia.org/wiki/Chip_select

Questions.


- Significance of SPI Clock Speed ?
- Algorithm for SPI Transmit and SPI Receive ?
- Is SPI Synchronous or Asynchronous ?
- SPI Pros/ Cons. (SPI require more pins?)



Clock Speed?




Ref – RIPYL Library (Python)



Ref – RIPYL Library (Python)

Question.




Baudrate?

Data Byte ?


Ref – RIPYL Library (Python)

Answer



Ref - RIPYL Library (Python)

Question.




Baudrate?

Data Byte ?

Ref – RIPYL Library (Python)


Answer




Ref – RIPYL Library (Python)

12C


12C Protocol





Drive Mode of Pins?
How to decide Pull-Up Value?


Questions




https://electrosome.com/i2c/


- How to Address a Slave ?
- How to transfer data?
- Why SCL/SDA has pull-up?


Addressing, Data Tx-Rx





Start/ Stop






Ref: Understanding the I2C Bus, Texas Instruments





Byte Transfer






Master expects an acknowledgment from slave after every byte transfer!






Ref – RIPYL Library (Python)




Ref – RIPYL Library (Python)




Ref – RIPYL Library (Python)

Question



Ref – RIPYL Library (Python)

Answer



Ref – RIPYL Library (Python)

SPI, I2C and UART

- Simplest Protocol?
- Slowest Protocol?
- Multi-Master?

Multi-Slave?

- Detect Presence of Slave ?
- Header/Footer Requirement ?
- Full-Duplex ?
- Synchronous?