

Arduino BiCMOS Curve Tracer



The curves above can be done with a Arduino board, a solderless breadboard, a dual Rail to Rail Input/Output Op amp, a few resistors and capacitors, and some free software. Everything needed is shown below.

The graphs above are produced by either Scilab or Octave. The curves are also viewed when using the Processing application.


ARDUINO BICMOS CURVE TRACER 5V X 5mA



This is a circuit which may want to be used more than once. Solderless bread boards are not usually meant for long term use. An easy alternative is to build up a CardBoard printed circuit board. This involves printing out a layout. Gluing the printout to cardboard. Hot gluing all the components in place. Then wire wrap up this simple circuit.

Optional Cardboard PCB

(Hot glue components then wire wrap)



A hand wire wrap tool and wire wrap wire are needed to do this. After the circuit is completely working, solder can be added to all the wire wrap points. As long as only one lead of a component is soldered at a time, melting the hot glue does not seem to be much of a problem.

Optional Tools Needed




Can solder wire wrap leads one lead at a time after everything is working (yes it works)


The layout for the CardBoard printed circuit board is below.

(for optional Cardboard PDB)

Print Out This and Mount On Cardboard



NMOS and PMOS transistors are hooked up the same as NPNs and PNPs. Usually the bulk to CMOS transistors are connected to the source. A Bulk terminal is provided otherwise. The same NPN/PNP polarity switch provides the proper Bulk voltage.






Open this application, then paste in the code below.

```
===Curve Tracer Arduino Code Below===============
                                                // TriAngle Wave
 int tri =
                                                                     at D5
 int vq =
                    3;
                                                // Voltage step port at D3
                                               // Tri value
 int j =
 int k =
                                               // Step Value
 int slope =
 int
                    incomingByte;
                                                // read incoming serial data into
                    setup()
 void
{ Serial.begin(
                    9600);
                                                // initialize serial communication:
                    tri, OUTPUT);
 pinMode(
 pinMode (
                    vg, OUTPUT);
                    // setup
 void
                    loop()
                     (Serial.available() > 0)
{ if
                                               // see if incoming serial data:
{ incomingByte =
                    Serial.read();
                                               // read oldest byte in serial buffer:
                    if (Serial.available() > 0)
 if
                     (incomingByte == 'H')
                                               // if H (ASCII 72), printoutput
{ delay(
                    10);
 j =
                    j+slope;
                                                // will be PWM 488 Hz
 analogWrite(
                    tri, j);
                    vg, k);
 analogWrite(
                                               // will be PWM 488 Hz
 Serial.print(
                    analogRead(0));
                                               // read current
                                                                      at A0
 Serial.print(
                    " ");
 Serial.println(
                    analogRead(1));
                                               // read tri voltage
                                                                      at A1
                                                // to stabilize adc:
 delay(
                    10);
 if
                     (j > 251) slope = -4;
```

```
{ slope = 4 ;
  k = k + int(255/5);
} // if (j > 251) slope = -4 ;
  if (k > 255) k = 0;
} // if (incomingByte == 'H')
} // loop()
```

Then it is a simple matter of compiling the code and uploading it to the hardware.

Compile and Load into Arduino



The same thing is true for Processing code. But this processing code is also set up to be able to control the Arduino hardware.



Open this application, then paste in the code below.

=========Curve Tracer Processing Code=================

```
processing.serial.*;
import
                                                                   // output file
PrintWriter
                      output;
Serial
                      myPort;
                                                                   // The serial port
                      xPos = 1;
                                                                   // hor position graph
int
                      setup ()
 void
                      300, 300);
                                                                   // set the window size:
{ size(
 println(
                      Serial.list());
                                                                   // List serial ports
                      new Serial(this, Serial.list()[0], 9600 ); // initialize to 9600 baud
 myPort =
 myPort.bufferUntil('\n');
                                                                   // serialEvent() @ \n:
                                                                   // set inital background:
 background(
 println(
                      "Click on image and hit s to start");
                                                                   // will start serial data
                      "Hit w to write to file");
                                                                   // dump to file ad stop
 println(
  String file =
                      String.valueOf(year());
                      file +"."+String.valueOf(month());
  file =
```


```
file =
                     file +"."+String.valueOf(day());
 file =
                     file +"."+String.valueOf(hour());
 file =
                     file +"."+String.valueOf(minute());
 file =
                     file +"."+String.valueOf(second())+".mat";
 println(
                     file):
 output =
                     createWriter(file);
                                                                 // Sketch->Show Sketch fie
                     // setup
 void
                     draw ()
{ if(
                     keyPressed)
{ if
                     (key == 's' || key == 'S')
                      "H");
{ myPort.write(
                      //if (key == 's' || key == 'S')
                      (key == 'w' || key == 'W')
{ output.flush();
                     // Writes the remaining data to the file
 output.close();
                     // Finishes the file
                     // Stops the program
 exit();
                     // if (key == 'w' || key == 'W')
}
                     // if( keyPressed)
}
                     // draw ()
                     serialEvent (Serial myPort)
 void
{ String inString = myPort.readStringUntil('\n');
                                                                 // get the ASCII string:
                     (inString != null)
{ inString =
                     trim(inString);
                                                                  // trim whitespace:
                     int(split(inString, ' '));
 int[] vv =
 // println(
                     inString );
 output.println(
                     inString );
 float val0 =
                     float(vv[0]);
 float val1 =
                     float(vv[1]);
 val0 =
                     map(val0, 0, 1023, 0, height*.95);
                     map(val1, 0, 1023, 0, height*.95);
 val1 =
                     127,34,255);
                                                                      // color to draw
 stroke(
                     val1, height - val0-1, val1+1, height - val0); // draw the line:
 line(
 if
                     (xPos >= 6*width)
                     0;
{ xPos =
                                                                      // auto redraw
 background(
                     // if (xPos >= 2*width)
 else
{ xPos=
                     xPos+1;
                     // else
                     // if (inString != null)
}
}
                     // serialEvent (Serial myPort)
```

After the code is pasted into the Processing window, hit the run button. At first a list of serial ports gets printed out. The Arduino board and the Processing application should be using the same port be default. The available serial ports are listed the the array Serial.list()[0]. The number 0 can be changed to match the arduino port to the Processing port if there is a problem.

It takes a while for the graph window to come up. When it does, the curve tracing is started by first clicking the graph window, and then typing "s".

The tracing of the transistor is a little slow because the analog outputs of a Arduino are really low pass filter PWM digital outputs at 488Hz.

Processing Code will start by typing S Write Data to file by typing W



The Processing Code also writes the curve tracer data to a text file. The Sketch/Show_Sketch_Folder menu will open up the proper folder. The file initially gets named the exact time the data was taken. Not a bad idea to rename that file.

The following are template text that can be copied and pasted into a Scilab window to generate the plots. Scilab will need

to know where the data files are located. So the paths shown below in light blue need to be set to the correct path.




Open this application, then paste in code below.

```
======Copy Paste Into SciLab Window==========================
z1 = read( '/Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/NPN.mat', -1, 2);
v =
          4.88e-3*z1(:, 2);
I =
          4.88e-3*z1(:, 1);
          V, I );
plot(
xgrid();
xtitle( "NPN Ib equal 5 5uA steps", "Collector Voltage V", "Collector Current mA");
======Copy Paste Into SciLab Window==========================
z1 = read( '/Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/PNP.mat', -1, 2);
\mathbf{v} = 5
         -4.88e-3*z1(:, 2);
I = 5
          -4.88e-3*z1(:, 1);
          V, I );
plot(
xgrid();
xtitle(
         "PNP Ib equal 5 5uA steps", "Collector Voltage V", "Collector Current mA");
======Copy Paste Into SciLab Window======================
z1 = read( '/Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/NMOS.mat', -1, 2);
          4.88e-3*z1(:, 2);
\mathbf{v} =
I =
          4.88e-3*z1(:,1);
plot(
          V, I );
xgrid();
         "NMOS VG equals 5 1Vsteps", "Drain Voltage V", "Drain Current mA");
xtitle(
======Copy Paste Into SciLab Window==========================
z1 = read( '/Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/PMOS.mat', -1, 2);
          -4.88e-3*z1(:, 2);
\mathbf{v} = 5
I = 5
          -4.88e-3*z1(:, 1);
          v, I );
plot(
xgrid();
          "PMOS VG equals 5 1Vsteps", "Drain Voltage V", "Drain Current mA");
xtitle(
```

The templates are set up to translate the data into voltages and currents. There are four templates for each type of transistor. They produce the curves show below.

Rename to your path for NPN.mat



The templates for Octave are almost the same and are given below.

They produce the same curves.



Open this application, then paste in code below.


```
========Cut Paste Into Octave Window========================
             /Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/NPN.mat
load -ascii
v =
             4.88e-3* NPN(:, 2);
I =
             4.88e-3* NPN(:, 1);
             V, I );
plot(
grid
title (
             "NPN Ib equal 5 5uA steps")
xlabel (
            "Collector Voltage V")
             "Collector Current mA")
ylabel (
========Cut Paste Into Octave Window========================
             /Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/PNP.mat
load -ascii
\mathbf{v} = 5
             -4.88e-3*PNP(:, 2);
I = 5
             -4.88e-3*PNP(:, 1);
             V, I );
plot(
grid
title (
             "PNP Ib equal 5 5uA steps")
xlabel (
             "Collector Voltage V")
             "Collector Current mA")
ylabel (
======Cut Paste Into Octave Window=====
      -ascii /Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/NMOS.mat
v =
            4.88e-3*NMOS(:, 2);
            4.88e-3*NMOS(:, 1);
I =
            V, I );
plot(
grid;
title (
            "NMOS Vg equal 5 1V steps");
xlabel (
           "Drain Voltage V");
           "Drain Current mA");
ylabel (
========Cut Paste Into Octave Window========================
load -ascii /Users/donsauer/Downloads/REF SOURCE/WORK/curvetrace2/PMOS.mat
\mathbf{v} = 5
            -4.88e-3*PMOS(:, 2);
            -4.88e-3*PMOS(:, 1);
I = 5
plot(
            V, I );
grid
title (
            "PMOS Vg equal 5 1V steps")
xlabel (
            "Drain Voltage V")
ylabel (
             "Drain Current mA")
```

There is a free feature to the hardware. The curve tracer can be converted into a dual trace oscilloscope by loading in some different Processing code. The analog inputs AO and A1 will act like scope probes. These probes can be placed at different

places in the circuit to things like view things like triangle and step waveforms. Simply copy and paste the following Processing code. It starts up the same as the curve tracer.

Load Scope Processing Code

(can look at waverforms)



==========Dual Scope Processing Code===================== import processing.serial.*; PrintWriter output; // output file // The serial port Serial myPort; // hor position graph int. xPos = 1;

void setup () 800, 300); // set the window size: { size(// List serial ports println(Serial.list()); new Serial(this, Serial.list()[0], 9600); // initialize to 9600 baud mvPort = myPort.bufferUntil('\n'); // serialEvent()newline ch background(0); // set inital background: println("Click on image and hit s to start"); // will start serial data println("Hit w to write to file"); // dump to file ad stop createWriter("TheDataFile.txt"); // Sketch->Show Sketch fie output = // end

void draw () { if(keyPressed) (key == 's' || key == 'S') { if "H"); { myPort.write(//if (key == 's' || key == 'S') (key == 'w' || key == 'W') i f { output.flush(); // Writes the remaining data to the file output.close(); // Finishes the file


// Stops the program exit(); // if (key == 'w' || key == 'W') // if(keyPressed) } // draw () }

serialEvent (Serial myPort) void myPort.readStringUntil('\n'); // get the ASCII string: { String inString = if (inString != null) { inString = trim(inString); // trim whitespace: int(split(inString, ' ')); int[] **vv** =

// println(

```
output.println(
                    inString );
 float val0 =
                     float(vv[0]);
 float val1 =
                     float(vv[1]);
 val0 =
                     map(val0, 0, 1023, 0, height*.95);
 val1 =
                     map(val1, 0, 1023, 0, height*.95);
 stroke(
                     127,34,255);
                                                                      // set color draw
 line(
                     xPos, height - val0-6, xPos, height - val0-3); // draw line:
 stroke(
                     127,34,32);
                                                                      // set color draw
                     xPos, height - val1-6, xPos, height - val1-3); // draw line:
 line(
                     (xPos >= width)
 i f
{ xPos =
                     0:
                                                                      // if edge go back
 background(
                     0);
                     // if (xPos >= width)
 else
{ xPos=
                     xPos+1;
                                                                      // increment hor
                      // else
                      // if (inString != null)
                      // serialEvent (Serial myPort)
```

It is possible to generate any kind of waveform at the "analog" output ports as well.



```
// read incoming serial data
 int
                 incomingByte;
 int
                 slope = 4 ;
 float
                 x;
 void
                 setup()
{ Serial.begin(
                 9600);
                                                  // set baud
} //
                 setup() end
 int j =
                 0;
 void
                 loop()
                 (Serial.available() > 0)
                                                  // see if incoming serial
{ if
{ incomingByte =
                 Serial.read();
                                                 // read oldest byte in serial
} //
                 if (Serial.available() > 0)
 if
                 (incomingByte == 'H')
                                                  // if H (ASCII 72), printoutput
{ delay(
                 1000);
                 (int i=0; i \le 2550; i++)
 for
                 4*j);
{ Serial.print(
                 " ");
 Serial.print(
                 3.14*i/63;
```

```
Serial.println( int(400*sin(x))+500);
                 50);
                                                         // stabilize adc:
 delay(
 j =
                 j+slope;
 if
                 (j > 254) slope = -4;
 if
                 (j < 1) slope = 4;
} //
                for (int i=0; i <= 2550; i++)
                 if (incomingByte == 'H')
} //
                 loop()
} //
```

Conclusion...

The analog input/output ports of the Arduino, together with some support hardware, and free online software, makes it easy to build an automated analog test interface with a laptop.

10.14.11_1.18PM dsauersanjose@aol.com Don Sauer