

cat034 category specification

Release 2007-05-01, 1.27

Transmission of Monoradar Service Messages

2007-05-01

CONTENTS:

1	Preamble	3
2	Description of standard data items 2.1 1034/000 - Message Type 2.2 1034/010 - Data Source Identifier 2.3 1034/020 - Sector Number 2.4 1034/030 - Time of Day 2.5 1034/041 - Antenna Rotation Speed 2.6 1034/050 - System Configuration and Status 2.7 1034/060 - System Processing Mode 2.8 1034/070 - Message Count Values 2.9 1034/090 - Collimation Error 2.10 1034/100 - Generic Polar Window 2.11 1034/110 - Data Filter 2.12 1034/120 - 3D-Position Of Data Source 2.13 1034/RE - Reserved Expansion Field 2.14 1034/SP - Special Purpose Field	6 6 7 10 13 13 14 15 15
3	User Application Profile for Category 034	17
4	Indices and tables	19

category: 034
edition: 1.27

date: 2007-05-01

CONTENTS:

2 CONTENTS:

CHAPTER ONE

PREAMBLE

Surveillance data exchange.

DESCRIPTION OF STANDARD DATA ITEMS

2.1 I034/000 - Message Type

Definition: This Data Item allows for a more convenient handling of the messages at the receiver side by further defining the type of transaction.

Structure:

- 8 bits [.....]
- · values:
 - 1: North marker message
 - 2: Sector crossing message
 - 3: Geographical filtering message
 - 4: Jamming strobe message

Notes:

- 1. In applications where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.
- 2. All Message Type values are reserved for common standard use.
- 3. The list of items present for the four message types is defined in the following table.

 \boldsymbol{M} stands for mandatory, \boldsymbol{O} for optional, \boldsymbol{X} for never present.

TODO: message types table

2.2 I034/010 - Data Source Identifier

Definition: Identification of the radar station from which the data are received.

Structure:

I034/010/SAC - System Area Code

- · raw value

I034/010/SIC - System Identification Code

- 8 bits [.....]
- · raw value

Note:

• The up-to-date list of SACs is published on the EUROCONTROL Web Site (http://www.eurocontrol.int/asterix).

2.3 I034/020 - Sector Number

Definition: Eight most significant bits of the antenna azimuth defining a particular azimuth sector.

Structure:

- 8 bits [.....]
- · unsigned quantity
- scaling factor: 360
- fractional bits: 8
- unit: "deg"
- LSB = $360/2^8$ deg = 360/256 deg ≈ 1.40625 deg

2.4 I034/030 - Time of Day

Definition: Absolute time stamping expressed as UTC time.

Structure:

- 24 bits [......]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "s"
- LSB = $1/2^7$ s = 1/128 s ≈ 0.0078125 s

Notes:

• The time of day value is reset to zero each day at midnight.

2.5 I034/041 - Antenna Rotation Speed

Definition: Antenna rotation period as measured between two consecutive North crossings or as averaged during a period of time.

Structure:

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "s"
- LSB = $1/2^7$ s = 1/128 s ≈ 0.0078125 s

Notes:

• This item represents the antenna rotation period as measured by the radar station between two consecutive North crossings, or a calculated antenna rotation speed as averaged during a period of time, or during a number of antenna rotation scans.

2.6 I034/050 - System Configuration and Status

Definition: Information concerning the configuration and status of a System.

Structure:

Compound item (FX)

I034/050/COM - Common Part

I034/050/COM/NOGO - Operational Release Status of the System

- 1 bit [.]
- values:
 - 0: System is released for operational use
 - 1: Operational use of System is inhibited, i.e. the data shall be discarded by an operational SDPS

1034/050/COM/RDPC - Radar Data Processor Chain Selection Status

- 1 bit [.]
- · values:
 - 0: RDPC-1 selected
 - 1: RDPC-2 selected

I034/050/COM/RDPR - Event to signal a reset/restart of the selected Radar Data Processor Chain, i.e. expect a new assignment of track numbers

- 1 bit [.]
- · values:
 - 0: Default situation
 - 1: Reset of RDPC

I034/050/COM/OVLRDP - Radar Data Processor Overload Indicator

- 1 bit [.]
- values:
 - 0: Default, no overload
 - 1: Overload in RDP

I034/050/COM/OVLXMT - Transmission Subsystem Overload Status

- 1 bit [.]
- values:
 - 0: Default, no overload
 - 1: Overload in transmission subsystem

I034/050/COM/MSC - Monitoring System Connected Status

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/COM/TSV - Time Source Validity

• 1 bit [.]

- values:
 - 0: Valid
 - 1: Invalid

I034/050/COM/(spare)

• 1 bit [.]

(empty subitem)

(empty subitem)

I034/050/PSR - Specific Status information for a PSR sensor

I034/050/PSR/ANT - Selected antenna

- 1 bit [.]
- values:
 - 0: Antenna 1
 - 1: Antenna 2

I034/050/PSR/CHAB - Channel A/B selection status

- 2 bits [...]
- values:
 - 0: No channel selected
 - 1: Channel A only selected
 - 2: Channel B only selected
 - 3: Diversity mode; Channel A and B selected

I034/050/PSR/OVL - Overload condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/PSR/MSC - Monitoring System Connected Status

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/PSR/(spare)

• 3 bits [...]

1034/050/SSR - Specific Status information for a SSR sensor

I034/050/SSR/ANT - Selected antenna

- 1 bit [.]
- values:
 - 0: Antenna 1
 - 1: Antenna 2

I034/050/SSR/CHAB - Channel A/B selection status

- 2 bits [...]
- values:

- 0: No channel selected
- 1: Channel A only selected
- 2: Channel B only selected
- 3: Invalid combination

I034/050/SSR/OVL - Overload condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/SSR/MSC - Monitoring System Connected Status:

- 1 bit [.]
- · values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/SSR/(spare)

• 3 bits [...]

$\textbf{1034/050/MDS} \cdot Specific \ Status \ information \ for \ a \ Mode \ S \ sensor$

I034/050/MDS/ANT - Selected antenna

- 1 bit [.]
- values:
 - 0: Antenna 1
 - 1: Antenna 2

I034/050/MDS/CHAB - Channel A/B selection status

- 2 bits [..]
- values:
 - 0: No channel selected
 - 1: Channel A only selected
 - 2: Channel B only selected
 - 3: Illegal combination

I034/050/MDS/OVLSUR - Overload condition

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/MSC - Monitoring System Connected Status:

- 1 bit [.]
- values:
 - 0: Monitoring system connected
 - 1: Monitoring system disconnected

I034/050/MDS/SCF - Channel A/B selection status for Surveillance Coordination Function

• 1 bit [.]

- values:
 - 0: Channel A in use
 - 1: Channel B in use

I034/050/MDS/DLF - Channel A/B selection status for Data Link Function

- 1 bit [.]
- values:
 - 0: Channel A in use
 - 1: Channel B in use

 ${\bf 1034/050/MDS/OVLSCF}\ -\ Overload\ in\ Surveillance\ Co-ordination\ Function$

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/OVLDLF - Overload in Data Link Function

- 1 bit [.]
- values:
 - 0: No overload
 - 1: Overload

I034/050/MDS/(spare)

• 7 bits [.....]

(empty subitem)

2.7 I034/060 - System Processing Mode

Definition: Status concerning the processing options, in use during the last antenna revolution, for the various Sensors, composing the System.

Structure:

Compound item (FX)

I034/060/COM - Common Part

I034/060/COM/(spare)

• 1 bit [.]

 ${f I034/060/COM/REDRDP}$ - Reduction Steps in use for an overload of the RDP

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active

- 5: Reduction step 5 active
- 6: Reduction step 6 active
- 7: Reduction step 7 active

 $\textbf{1034/060/COM/REDXMT} \cdot \textit{Reduction Steps in use for an overload of the Transmission subsystem}$

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/COM/(spare)

• 1 bit [.]

(empty subitem)

(empty subitem)

1034/060/PSR - Specific Processing Mode information for a PSR sensor

I034/060/PSR/POL - Polarization in use by PSR

- 1 bit [.]
- values:
 - 0: Linear polarization
 - 1: Circular polarization

 ${f I034/060/PSR/REDRAP}$ - Reduction Steps in use as result of an overload within the PSR subsystem

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

1034/060/PSR/STC - Sensitivity Time Control Map in use

- 2 bits [...]
- values:
 - 0: STC Map-1
 - 1: STC Map-2
 - 2: STC Map-3
 - 3: STC Map-4

I034/060/PSR/(spare)

• 2 bits [...]

I034/060/SSR - Specific Processing Mode information for a SSR sensor

 $\textbf{1034/060/SSR/REDRAD} \cdot Reduction \ Steps \ in \ use \ as \ result \ of \ an \ overload \ within \ the \ SSR \ subsystem$

- 3 bits [...]
- values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/SSR/(spare)

• 5 bits [.....]

 ${f I034/060/MDS}$ - Specific Processing Mode information for a Mode S sensor

 $\textbf{1034/060/MDS/REDRAD} \cdot Reduction \, Steps \, in \, use \, as \, result \, of \, an \, overload \, \\ within \, the \, Mode \, S \, subsystem$

- 3 bits [...]
- · values:
 - 0: No reduction active
 - 1: Reduction step 1 active
 - 2: Reduction step 2 active
 - 3: Reduction step 3 active
 - 4: Reduction step 4 active
 - 5: Reduction step 5 active
 - 6: Reduction step 6 active
 - 7: Reduction step 7 active

I034/060/MDS/CLU - Cluster State

- 1 bit [.]
- values:
 - 0: Autonomous
 - 1: Not autonomous

I034/060/MDS/(spare)

• 4 bits [....]

Notes:

• Applicable to all defined secondary subfields. The actual mapping between the up to seven data reduction steps and their associated data reduction measures is not subject to standardisation.

2.8 I034/070 - Message Count Values

Definition: Message Count values, according the various types of messages, for the last completed antenna revolution, counted between two North crossings

Structure:

Repetitive item, repetition factor 8 bits.

I034/070/TYP - Type of message counter

- 5 bits [.....]
- · values:
 - 0: No detection (number of misses)
 - 1: Single PSR target reports
 - 2: Single SSR target reports (Non-Mode S)
 - 3: SSR+PSR target reports (Non-Mode S)
 - 4: Single All-Call target reports (Mode S)
 - 5: Single Roll-Call target reports (Mode S)
 - 6: All-Call + PSR (Mode S) target reports
 - 7: Roll-Call + PSR (Mode S) target reports
 - 8: Filter for Weather data
 - 9: Filter for Jamming Strobe
 - 10: Filter for PSR data
 - 11: Filter for SSR/Mode S data
 - 12: Filter for SSR/Mode S+PSR data
 - 13: Filter for Enhanced Surveillance data
 - 14: Filter for PSR+Enhanced Surveillance
 - 15: Filter for PSR+Enhanced Surveillance + SSR/Mode S data not
 - in Area of Prime Interest
 - 16: Filter for PSR+Enhanced Surveillance + all SSR/Mode S data

1034/070/COUNT - COUNTER

- 11 bits [.....]
- · unsigned integer

2.9 **I034/090 - Collimation Error**

Definition: Averaged difference in range and in azimuth for the primary target position with respect to the SSR target position as calculated by the radar station.

Structure:

1034/090/RNG - Range Error

- 8 bits [.....]
- · signed quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM ≈ 0.0078125 NM

I034/090/AZM - Azimuth Error

• 8 bits [.....] signed quantity • scaling factor: 360 • fractional bits: 14 • unit: "dea" • LSB = $360/2^{14}$ deg = 360/16384 deg ≈ 0.02197265625 deg Notes: • Negative values are coded in two's complement form. 2.10 **I034/100 - Generic Polar Window** Definition: Geographical window defined in polar co-ordinates. Structure: I034/100/RHOST - Rho start • 16 bits [.....] unsigned quantity • scaling factor: 1 • fractional bits: 8 • unit: "NM" • LSB = $1/2^8$ NM = 1/256 NM ≈ 0.00390625 NM • value \leq 256 NM I034/100/RHOEND - Rho end • 16 bits [.....] unsigned quantity • scaling factor: 1 • fractional bits: 8 • unit: "NM" • LSB = $1/2^8$ NM = 1/256 NM ≈ 0.00390625 NM • value <= 256 NM I034/100/THETAST - Theta start • 16 bits [.....] unsigned quantity • scaling factor: 360 • fractional bits: 16 • unit: "deg" • LSB = $360/2^{16}$ deg = 360/65536 deg ≈ 0.0054931640625 deg

Chapter 2. Description of standard data items

1034/100/THETAEND - Theta end • 16 bits [.....]

· unsigned quantity

- scaling factor: 360
- fractional bits: 16
- unit: "deg"
- LSB = $360/2^{16}$ deg = 360/65536 deg ≈ 0.0054931640625 deg

2.11 I034/110 - Data Filter

Definition: Data Filter, which allows suppression of individual data types.

Structure:

- 8 bits [.....]
- values:
 - 0: Invalid value
 - 1: Filter for Weather data
 - 2: Filter for Jamming Strobe
 - 3: Filter for PSR data
 - 4: Filter for SSR/Mode S data
 - 5: Filter for SSR/Mode S + PSR data
 - 6: Enhanced Surveillance data
 - 7: Filter for PSR+Enhanced Surveillance data
 - 8: Filter for PSR+Enhanced Surveillance + SSR/Mode S data not in Area of Prime Interest
 - 9: Filter for PSR+Enhanced Surveillance + all SSR/Mode S data

Notes:

- 1. This Data Item is often used in conjunction with I034/100 and represents a Data Filter for a specific geographical subarea. A Data Source may have zero, one or multiple data filters active at any time.
- 2. If I034/110 is not accompanied with I034/100, then the Data Filter is valid throughout the total area of coverage.

2.12 I034/120 - 3D-Position Of Data Source.

Definition: 3D-Position of Data Source in WGS 84 Co-ordinates.

Structure:

I034/120/HGT - Height of Data Source

- 16 bits [......]
- unsigned quantity
- scaling factor: 1
- fractional bits: 0
- unit: "m"
- LSB = 1 m

I034/120/LAT - *Latitude*

- · signed quantity
- scaling factor: 180
- fractional bits: 23
- unit: "deg"
- LSB = $180/2^{23}$ deg = 180/8388608 deg $\approx 2.1457672119140625e 05$ deg
- value $>= -90 \deg$
- value <= 90 deg

I034/120/LON - Longitude

- 24 bits [......]
- signed quantity
- scaling factor: 180
- fractional bits: 23
- unit: "deg"
- LSB = $180/2^{23}$ deg = 180/8388608 deg $\approx 2.1457672119140625e 05$ deg
- value $>= -180 \deg$
- value <= 180 deg

2.13 I034/RE - Reserved Expansion Field

Definition: Expansion

Structure: Explicit item

2.14 I034/SP - Special Purpose Field

Definition: Special Purpose Field

Structure: Explicit item

CHAPTER

THREE

USER APPLICATION PROFILE FOR CATEGORY 034

- (1) I034/010 Data Source Identifier
- (2) I034/000 Message Type
- (3) I034/030 Time of Day
- (4) I034/020 Sector Number
- (5) I034/041 Antenna Rotation Speed
- (6) I034/050 System Configuration and Status
- (7) I034/060 System Processing Mode
- (FX) Field extension indicator
- (8) I034/070 Message Count Values
- (9) I034/100 Generic Polar Window
- (10) I034/110 Data Filter
- (11) I034/120 3D-Position Of Data Source.
- (12) I034/090 Collimation Error
- (13) I034/RE Reserved Expansion Field
- (14) I034/SP Special Purpose Field
- (FX) Field extension indicator

cat034 category specification, Release 2007-05-01, 1.27	

CHAPTER

FOUR

INDICES AND TABLES

- genindex
- modindex
- search