## **COMP2121 Sample Exam Questions**

| 1. |    | Conver   | the following         | g numbers from the original base to the specified base: |  |  |  |  |
|----|----|--|-----------------------|---|--|--|--|--|
|    | a) | 123 <sub>10</sub>  | $\rightarrow$         | 2   |  |  |  |  |
|    | b) | 10101 <sub>2</sub>   | $\rightarrow$         | 10  |  |  |  |  |
|    | c) | 1084 <sub>10</sub>   | $\rightarrow$         | 16  |  |  |  |  |
|    | d) | A5 <sub>16</sub>   | $\rightarrow$         | 10  |  |  |  |  |
|    | e) | 110010   | 01 <sub>2</sub> →     | 16  |  |  |  |  |
|    | f) | 2D5 <sub>16</sub>  | $\rightarrow$         | 2   |  |  |  |  |
| 2. |    | What is the result of the following calculations?  |                       |   |  |  |  |  |
|    | a) | 1395 +   | 4988 (base 1          | 5)  |  |  |  |  |
|    | b) | 110010   | 01 (base 2)           |   |  |  |  |  |
|    | c) | A41 – 560 (base 16)  |                       |   |  |  |  |  |
|    | d) | 11001 – 011 (base 2)   |                       |   |  |  |  |  |
| 4. |    | What number does 10010010 represent as an unsigned number? What doe represent in 2's complement notation?  |                       |   |  |  |  |  |
| 5. |    | In 2's complement addition, $11011011 + 01100000 = 00111011$ . Was ther 2's complement overflow? Why? What do the values in this sum representation. |                       |   |  |  |  |  |
| 6. |    | What is the difference between performing 2's complement addition and unsigned addition in the AVR processor?  |                       |   |  |  |  |  |
| 7. |    | Represent the following numbers in IEEE 754 32-bit floating point notation:  |                       |   |  |  |  |  |
|    | a) | 1.5  |                       |   |  |  |  |  |
|    | b) | 1084   |                       |   |  |  |  |  |
|    | c) | -1   |                       |   |  |  |  |  |
|    | d) | -13.75   |                       |   |  |  |  |  |
| 8. |    | What does the following IEEE 754 FP number represent:  |                       |   |  |  |  |  |
|    |    |  | 1000 0001<br>Exponent | 110 0000 0000 0000 0000 0000<br>Mantissa                |  |  |  |  |

- 9. Encode the following instructions into Atmel AVR machine code:
  - a) ldi r18, 127
  - b) mov r18, r2
  - c) lds r2, 0xABCD

Refer to the AVR Instruction Set document on the course website (in the AVR Material section).

- 10. How many bits are needed to address:
  - a) 16 32-bit general purpose registers?
  - b) a memory space of 65536 bytes (assume byte addressing)?
  - c) a memory space of 65536 32-bit words (assume byte addressing)?
- 11. What do the following letters in a typical status register stand for and how are they generated?
  - a) Z
  - b) C
  - c) V
  - d) N
  - e) S
- 12. What is the main difference between the memory models of Princeton (von Neumann) and Harvard architectures?

13.

| Memory address | Data |
|----------------|------|
| 0x0000100      | 0xAF |
| 0x0000101      | 0x1B |
| 0x0000102      | 0xC2 |
| 0x00000103     | 0x05 |

Based on the above, what is the 32-bit word stored at the memory address  $0 \times 00000100$  in a:

- a) big-endian machine?
- b) little-endian machine?
- 14. Can you design an 8-bit instruction format that can allow 4 2-operand instructions for a machine with 8 registers?

15. What do these notations mean in AVR assembly programming? Where are they used?

- a) .def
- d) .dseq q) .dw

- b) .set
- e) .org h) .byte
- c) .cseq
- f) .db
- i) .equ

16. Where are the functions **low()** and **high()** utilised? Load -200 into a two byte number.

- 17. What are the differences between **Macros** and **Functions**? In what circumstances are each of them appropriate, and when should each be avoided? Write a Macro called **Invert** to invert the value of a register (Note: The register should be sent as a parameter)
- 18. What are word addressable and byte addressable? Explain them with examples using AVR memories.
- 19. Consider the following AVR assembly code segment and fill the initialization part?

.dseg array: .byte 20 .cseg data: .dw 0x1234 // Initialize the X pointer with array

// Initialize the Z pointer with data

- 20. What are **little endian** and **big endian** representations? Which endian is used in AVR?
- 21. Identify the errors in the following instructions,
  - a) ldi r1,18
  - b) cp r16, 'L'
  - c) ldi zh, high  $(0x3476) \Rightarrow Word Addressable$
  - d) ldi r40, 23
  - e) brge loop => for both unsigned numbers
  - f) brlo end => for both signed numbers

- 22. Write AVR assembly code segments for the following scenarios,
  - a) Initialize an array A of size 20 (each element is one byte) with values ranging from 1 to 20.
  - b) Initialize an array B of size 20 (each element is two bytes) with values ranging from -1 to -20.
  - c) Add the arrays A and B together and store the result into an array C.
  - d) Store the string 12345678 into program memory using .db and .dw.
  - e) Load the values stored in the program memory in (d) and store them into data memory in the reverse order.
- 23. How do you multiply a two byte number by a one byte number? (Explain using a simple example). Do we have to consider the carry bit in the STATUS register for this case?
- 24. Investigate the different ways of writing AVR assembly code for the following scenarios,
  - a) Copying a pair of registers into another pair of register.
  - b) Multiply a number by 4.
  - c) Divide a number by 4.
- 25. When are MUL, MULS and MULSU instructions used and how are they are used? Write AVR assembly code to perform multiplication for the following set of numbers,
  - a) 10, 12 (1 byte result) d) 32, 258 (2 bytes result) b) -11,11 (1 byte result) e) -352, 28 (2 bytes result) c) -4,-14 (1 byte result) f) -27,-375 (2 byte result)
- 26. 1 Minimally modify the code below to add two numbers (in r17:r16 and r19:r18) when the result is bigger than 255.

ldi r16, 1

ldi r17, 0

ldi r18, 255

ldi r19, 0

add r16, r18

add r17, r19

26.2 Write AVR code to add two 32 bits values? (Using R16-R23 to hold all values.)

a = 0x00000100

b = 0x002000FF

27. Please complete the following table with instructions used for each operation.

| Instructions | Registers | Stack | Memory |         | I/O      |        |
|--------------|-----------|-------|--------|---------|----------|--------|
|              | C         |       | Data   | Program | Separate | Mapped |
| Initialize   |           |       |        |         | •        | - 1    |
|              |           |       |        |         |          |        |
|              |           |       |        |         |          |        |
|              |           |       |        |         |          |        |
|              |           |       |        |         |          |        |
| Write to     |           |       |        |         |          |        |
|              |           |       |        |         |          |        |
| Dood from    |           |       |        |         |          |        |
| Read from    |           |       |        |         |          |        |
|              |           |       |        |         |          |        |

- 28. How do you setup a port to act as an input port or as an output port in AVR? What instructions are used to read from an I/O port? What instructions are used to write to an I/O port?
- 29. Consider the following example AVR code segment:

```
Address
0x1000
            .def grade=r20
0x1002
            .include "m64def.inc"
0x1004
            LDI r29, high (RAMEND)
0x1006
            LDI r28, low (RAMEND)
            OUT SPH, r29
0x1008
0x100A
            OUT SPL, r28
0x100C
            LDI r18,45
0x100E
            RCALL GRADE CAL
            end:
0x1010
                    RJMP end
            GRADE CAL:
0x1012
                    PUSH r29
0x1014
                    PUSH r28
0x1016
                    CPI r18,50
0x1018
                    BRGE grade1
0x101A
                    LDI grade, 2
0x101C
                    RJMP exit
            grade1:
0x101E
                    LDI grade,1
            exit:
0x1020
                    POP r28
0x1022
                    POP r29
0x1024
                    RET
```

What are the values of r28, r29, SPL and SPH:

- a) after line "LDI r28,low(RAMEND)"?
- b) after line "OUT SPL, r28"?
- c) after line "BRGE grade1"?

d) after line "POP r29"?

| 30. | The EICRA register is used to indicate what condition should be present for external interrupts to occur, and looks like this: |
|-----|--|
|     |  |
|     | where each pair of bits ISCn1 and ISCn0 mean the following for INTn:   |


The EIMSK register is used to enable the external interrupts and looks like this:

In "m64def.inc", the values in these registers have been defined to their bit value. e.g., ISC00 = 0, ISC11=3 and INT2=2. Knowing this, examine the following code:

```
.def temp=r16
ldi temp, (0b10 << ISC00) | (0 << ISC10) | (0b11 << ISC20)
sts EICRA, temp
ldi temp, (1 << INT0) | (1 << INT2)
out EIMSK, temp
sei</pre>
```

- a) What is the value (in binary) that is written to the EICRA register?
- **b)** Why do we use this approach to set up the register values?
- c) Which external interrupts can occur, and when will they occur?
- d) What is the difference between the 'sts' instruction and the 'out' instruction?
- **31.** This question looks at the registers associated with PORT A. The following tables might help:

- a) What is the purpose of the DDRA register?
- **b)** What is the purpose of PORTA0 when DDA0 = 1?
- what is the purpose of PORTA0 when DDA0 = 0 and PUD = 0?
- **d)** What is the purpose of the PINA register?
- **32.** The Keypad on the AVR boards is a set of 16 push buttons. The keypad has four rows and four columns, accessible via the pins R0-R3 and C0-C3. When you push a button on the keypad, it connects the column of the key to the row of the key as follows:



One method to correctly read what keys are being pressed is to:

- 1: Set up the rows so that they read a Logic 1 when none of the buttons on the row is pushed.
- 2: Set one column to Logic 0 and all other columns to Logic 1.
- **3:** Read the values of the row pins. If a row reads as Logic 0, you know that the switch at that row and column must be pushed.
- **4:** Set a different column to Logic 0 and read the rows.
- 5: Repeat steps 3 and 4 until a switch is found to be pressed or you run out of columns.
- **6:** Repeat steps 2-5 again if you want to see whether a different switch is pushed.

Part of your third lab requires you to perform this algorithm. Steps 2-5 should be fairly simple to code, but step 1 is not so obvious. The way to accomplish this is with pull-up resistors. A pull-up resistor ties an input pin to Logic 1 via a resistor. This means that an input pin will still read any value that is input, and will read Logic 1 if disconnected.

To further understand this, look at switch 5 in the above diagram. When none of the switches connected to row 1 are pushed, the circuit (with pull-up shown) looks like this:



If read, the port would read a Logic 1 via the pull-up resistor.

When switch 5 is pushed, the circuit looks like this:



In this case, the port connected to R1 will always read the current value of C1. When C1 is Logic 0 there will be a voltage drop across the resistor, but this will not affect the value being read. Thus, the pull-up resistor accomplishes the desired task.

- a) How do you setup an AVR I/O port so that it has pull-up resistors connected to its input pins? (See question 2 of this tute)
- **b)** Write the code to find a switch that has been pushed by scanning either the columns or rows. (You have to do this for your lab, anyway)
- c) Can you see an electrical problem with this scanning method when two switches on the same row are pushed at the same time (e.g., 5 and 6)? How could you correct this? (Hint: There might be something better you can do than output logic 1s to the columns you are not testing.)