SYSTEM HARDWARE LECTURE 4 - INSTRUCTION FORMATS

OBJECTIVES

- Understand the factors involved in instruction set architecture design.
- The design of fixed length Instructions.
- Gain familiarity with addressing modes.
- Understanding Instruction Set Architecture (ISA) leads to a deeper understanding of computer architecture.

INTRODUCTION

- Instruction formats affect the degree of ease that can be achieved in performing certain operations.
- Simplicity and uniformity are critical to the speed with which a sequence of machine instructions can be *pipelined* efficiently.
- The MIPS processor, like many RISC processors, uses fixedlength instructions.
- All MIPS instructions are exactly 32 bits. The size of 1 word.
- Fixed-length instructions offer the advantage of simpler instruction fetching, which also means a smaller, cheaper processor (and possibly faster).

INSTRUCTIONS & ADDRESSING MODES

- A typical machine instruction is add r1,r2,r3, which causes the values in r2 and r3 to be added, and the sum put in r1.
- A machine instruction for an arithmetic/logic operation specifies an opcode, one or more source operands, and, usually, one destination register.
- The opcode is a binary code (bit pattern) that specifies an operation. The operands of an arithmetic or logical instruction can come from a variety of sources.
- The method used to specify where the operands are found, and where the result must go, is called the addressing mode or addressing scheme. For Simplicity, we will assume that all operands are in registers.

Instruction Formats

The MIPS processor has three different instruction formats:

- Register or R-type instructions
- Immediate or I-type instructions
 - Pure Immediate instructions (I-1)
 - Load, store and branch (I-2)
- Jump or J-type instructions

Instruction Formats

Lets recall a sample MIPS code from Lecture 2

```
loop: l.d f0,0(r1)
add.d f4,f0,f2
s.d f4,0(r1)
daddiu r1,r1,#-8
bne r1,r2,loop
....
J done
....
done: ....
```

INSTRUCTION FORMATS REGISTER (R-TYPE)

Register or R-type instructions operate on the two registers identified in the 'rs' and 'rt' fields and **Store the result** in register 'rd'.

Examples:

mul.d f4,f2,f6 add r3,r1,r2

opcode		rd (destination)		rs (source 1)		rt (source 2)		Other stuff	
6 bits		5 bits		5 bits		5 bits		11 bits	
31	26	25	21	20	16	15	11	10	0

INSTRUCTION FORMATS IMMEDIATE (I-TYPE)

Immediate or I-type instructions come in two flavors. The general format for an I-type instruction is below. (immediate = operand or offset). The two different types of I-type instructions are presented in the next slides.

opcode		rd (destination)		rs (source)		Immediate	
6 bits		5 bits		5 bits		16 bits	
31	26	25	21	20	16	15	0

Instruction Formats I-1 Pure Immediate

I-1 Pure Immediate:

- The 16-bit field in bits 0 15 holds a 16-bit integer that plays the same role as 'rt' in the R-type instructions.
- The specified operation is performed on 'rs' and the immediate operand (constant), and the result is written into 'rd', the destination register.

```
Examples: daddiu r1,r1,#-8 <subi r1,r1,8 in RISC-V> daddiu r1,r1,#8 <addi r1,r1,8 in RISC-V>
```

Subtracts/adds the 16-bit immediate to '**r1**' to compute a number (mostly a memory address) and write it into '**r1**'.

Instruction Formats I-2 Instructions

I-2 load, store & conditional branch Instructions:

- The 16-bit field is interpreted as an offset, or relative address, that is added to the base value in register 'rs'.
- For data access instructions (load or store), the offset is the number of bytes forward (positive) or backward (negative) relative to the base address.
 - Example: I.d f6,-24(r2) adds the immediate byte-offset -24 to 'r2' to determine a memory address. The doubleprecision floating point number (64 bits) at that memory address is then loaded into floating-point register 'f6'.

INSTRUCTION FORMATS IMMEDIATE (I-TYPE)

store Example:

s.d f6, 24(r2) adds the immediate *byte-offset* 24 to 'r2' to determine a *memory address*. The double-precision floating point number (64 bits) in floating-point register 'f6' is then stored into that *memory address*.

Conditional Branch Example:

bne r1,r2,loop compares registers 'r1' and 'r2'. If they are not equal, the word-offset derived from the immediate 'loop' is added to the current value of PC (which is the memory address of the branch instruction). That is, we extend the signed integer offset to 18 bits (multiply by 4) to obtain word-address offset, which is then sign-extended to 32 bits.

INSTRUCTION FORMATS IMMEDIATE (I-TYPE)

branch Instructions:

- For branch instructions, the offset is in words, given that instructions always occupy complete 32bit memory words.
- ❖ To interpret the 16-bit signed integer as a wordaddress offset, we multiply by 4. Since offsets can be positive or negative, this allows for branching to other instructions within +/- 2^15 (32,768) instructions of the current instruction.

INSTRUCTION FORMATS JUMP INSTRUCTIONS

Jump or J-type Instructions (Unconditional Branch):

opcod	е	partial jump-target address (word address)					
6 bits		26 bits					
31	26	25	0				

Example: j done, causes *unconditional transfer* of control to the instruction at the *specified word address* (32 bits).

But only 26 bits are available in the jump address and assumed to specify a word address. *Two zero bits* are appended to the right (multiply X4). We now have 28 bits. The four missing bits (on the left) are taken from PC. The *partial jump-target address* 'done' is expanded into a full 32-bit address, and transfer control there.

ADDRESSING MODES SUMMARY

- We have seen that addressing mode differs from one instruction to another.
- addressing mode is used within the instruction to specify where operands are found, and where the result must go.
- Immediate addressing: An operand is given in the instruction itself. Example: daddui r1, r1, #-8 <addi r1, r1, 8>
- Register addressing: Operands and result are specified in registers. Example mul.d f4, f2, f6
- Base addressing: An operand is in memory, its location is computed by adding an offset (16-bit signed integer) to the contents of a specified base register. Example I.d f6,-24(r2)

ADDRESSING MODES SUMMARY

Addressing modes for branch and jump instructions.

- ❖ PC Relative addressing: Same as base addressing, except that the "base" register is always PC, and a hardware trick is used to extend the constant offset to 18 bits. Namely, we multiply by 4 to obtain a word-address offset, which is then sign extended to 32 bits. This addressing mode is used in conditional branches. Example: beq r1, r2, found
- Absolute addressing: The addressing mode for unconditional branches is different because there is no "base" register. Example: j done 'done' is a 26-bit natural number. Multiplying by 4 gives a 28-bit natural number. The 4 high order bits of 'done' are then filled with the 4 high order bits of the PC.

ADDRESSING MODES QUESTIONS

Q1- Assume 32-bit registers, instructions, and memory addresses, and 16-bit immediates. Consider the instruction "I.d f6, 7390(r2)". What is the (8-hexit) hexadecimal representation of the 32-bit integer that will be added to r2.

Q2- Assume 32-bit registers, instructions and memory addresses, and 32-bit immediates. Consider the instruction 'bne r1,r2, loop', where 'loop' is -2,608. Write the (4-hexit) hexadecimal representation of the low-order 16 bits of the 32-bit integer that will be added to the 'PC'.

ADDRESSING MODES QUESTIONS

Q3- Assume 32-bit registers, instructions, and memory addresses, and 16-bit immediates. Consider the instruction "I.d f6, -31708(r2)". Write the (8-hexit) hexadecimal representation of the 32-bit integer that will be added to r2.

Q4- Assume 64-bit registers, instructions and memory addresses, and 32-bit immediates. Consider the instruction 'bne r1,r2, loop', where 'loop' is -20,608. Write the (8-hexit) hexadecimal representation of the low-order 32 bits of the 64-bit integer that will be added to the 'PC'.

CONCLUSION

- MIPS processor, like many RISC processors, uses
 32-bit fixed-length instructions.
- The opcode (control code) is a binary identification code of an instruction (6-bit pattern in MIPS).
- @addressing mode is the method used to specify where operands of an instruction are found, and where the result must go.
- The MIPS processor has 3 different instruction formats (r-type, I-type and Jtype) and 5 different addressing modes.