Workshop Basic Arduino Class 1 – Arduino Fundamentals

MSc. David Velásquez Rendón



Contents



- 1. Introduction.
- 2. Arduino MEGA 2560 Pinout.
- 3. Electronics Common Notations.
- 4. Variables in Arduino Programming.
- 5. Typical Operators for Arduino Programming.
- 6. Arduino Program Structure.
- 7. Arduino common used commands.
- 8. Arduino common statements.

Arduino

UNIVERSIDAD

DIGITAL OUT

PWM OUT

SUPPLY (7V - 12V)

¿What is?

- Open source electronics platform.
- Allows creation of electronics prototypes.
- Based on open source software.
- Ease of use.
- Allows to do sequences and mathematics operations.
- Used for automation.

Arduino Types





Arduino Leonardo



COMMUNICATION (SERIAL)

CPU








Arduino Uno



Arduino Mega 2560



Arduino Due



Arduino Yún




Arduino Micro

DIGITAL IN

ANALOG IN





Arduino Ethernet


Arduino Mini

LilyPad Arduino

Arduino Nano

Arduino MEGA 2560 Pinout





- Based on the microcontroller ATMEGA 2560.
- **Supply:** Using Jack connecter with voltage range from **7V to 12V**. Also it can be powered via USB but with low consumption.
- Maximum current per I/O digital pin: 40 mA.
- Maximum current for 3.3V supply pin: 50 mA.
- Digital Inputs and Outputs: 54 pins (OV or 5V).
- **Analog Inputs:** 16 pins (from **0V to 5V** of analog voltage).
- **PWM Outputs:** 15 pins (Considered in the 54 digital I/O pins). Can be used as normal digital I/O pins too.
- Oscilator frequency/Flash Memory/RAM/ROM: 16 MHz / Flash 256 Kb/ SRAM 8 Kb / EEPROM 4 Kb.
- Communications: USB CDC (Serial) + I2C + SPI.

Electronics common notations



Symbol	Description		
$+ \uparrow or \perp$	Power supply: Cell or battery		
or ————	Resistor		
	Switch: Single Pole Single Throw (SPST)		
L1	Switch: Single Pole Double Throw (SPDT)		
\longrightarrow	Output Pin		

Cable Color	Notation		
RED	Positive (+)		
BLACK	Negative (-) / GND		
BLUE GREEN	Sensor/Actuator Signal		

Variables



NAME	SINTAX	SIZE	RANGE		EXAMPLE
IVA/VIL			WITHOUT SIGN	WITH SIGN	EXAMPLE
Boolean	boolean	1 bit	false True	N/A	boolean state = false;
Char ¹	char unsigned char	8 bits (1 byte)	0 a 255	-128 a 127	<pre>char myChar = 'A'; char myChar = 65; Both examples are equivalent</pre>
Byte	byte	8 bits (1 byte)	0 a 255	N/A	byte hello = B00000111; byte hello = 7; B indicates binary notation B00000111 is equal to 7 in decimal.
Integer	int unsigned int	16 bit (2 bytes)	0 a 65535	-32768 a 32767	unsigned int counter = 0;
Long ²	long unsigned long	32 bit	0 a 4,294,967,295	-2,147,483,648 a 2,147,483,647	unsigned long number = 20000;
Float ³	float	32 bit	N/A	-3.4028235E+38 a 3.4028235E+38	<pre>float temperature = 88.5;</pre>

¹Check ASCII table (http://www.asciitable.com/index/asciifull.gif)

EQUIVALENTS		
word	unsigned int	
short	int	

²Timing vars are commonly declared as unsigned long.

³Check Arduino documentation for more info (http://arduino.cc/en/Reference/Float#.UxOT7 15Njl)

7 Typical Operators



	SYMBOL	DESCRIPTION				
	-	Assignment				
<u>ગ</u>	+	Addition				
ARITHMETIC	-	Subtraction				
ITH	*	Multiplication				
AF	/	Division				
	%	Module				
		Equal to: $x == y$ is equivalent to: x is equal to y ?				
IVE	!= Not equal to: $x! = y$ is equivalent: x is not equal to y ?					
COMPARATIVE	V	Less than				
MPA	^	Greater than				
COI	"	Less than or equal to				
	 	Greater than or equal to				
NS	&&	AND				
BOOLEANS	Ш	OR				
BO	!	Negation (NOT)				
	++	Increment: $y = x + +$ is equivalent to: $y = x + 1$				
ORS		Decrement: $y = x$ is equivalent to: $y = x - 1$				
LAT	+=	Addition assignment: $y += x$ is equivalent to: $y = y + x$				
JMU	Į.	Subtraction assignment: $y = x$ is equivalent to: $y = y - x$				
ACCUMULATORS	*=	Multiplication assignment: $y *= x$ is equivalent to: $y = y * x$				
A	/=	Division assignment: $y/=x$ is equivalent to: $y=y/x$				

Arduino Program Structure




```
Library declaration(e.g: #include <SFEMP3Shield.h>)
I/O Pin Labeling (e.g: #define LEDPIN 13)
Constant declaration (e.g: const unsigned int contMax = 10;)
Variable declaration (e.g: float temperature = 0;)
Subroutines or functions declaration:
Example for subroutine:
void readSens() {
                                    //Example of a subroutine that reads the analog value from 0 to 1023 and converts it
                                    //from 0 to 100 degrees storing it in the float variable named temperature.
                                   //Analog read from pin Al
     y = analogRead(1);
     temperature = y*100.0/1023.0; //Float to degree Celsius conversion
Example for function:
                                   //Example of a function that sums two numbers "x" y "y" and returns the result as int
int sum(int x, int y) {
     return x + y;
Pin configuration and cleaning:
void setup() {
     //CONFIGURATION: Indicate which pins are inputs and which are outputs "pinMode(PIN,OUTPUT o INPUT);" without quotes.
     //CLEANING: For safety, it is important to clean used outputs with the purpose that they are turned off at the
     //beginning of the program. Use the function "digitalWrite(PIN,LOW);" without quotes.
     //COMMUNICATIONS: For example, for communications with the computer, use the function "Serial.begin(BAUDIOS);"
     //without quotes.
Infinite loop (Main program - Execution):
void loop() {
     //Main program
```

Note: Each line of Arduino takes approximately 63 nanoseconds to execute (16 MHz Crystal)

Arduino IDE



Software download: http://arduino.cc



10 Arduino common used commands



Arduino functions are declared using Camel Case: First letter starts in minuscules and when another word is written starts with capital letter. E.g. iPod, getMode, etc.

pinMode

- Configures the specified pin as input or output
- Sintax: pinMode (pin, mode);
 - pin: The pin # that will be configured
 - mode: Determines if the pin is an input or an output. Receives INPUT or OUTPUT

digitalWrite

- Writes a logical state to an output pin: a HIGH logic state (5V) or a LOW logic state (0V)
- Sintax: digitalWrite (pin, value);
 - pin: The pin # that will be written
 - value: HIGH or LOW

digitalRead

- Reads and returns the logic state value of a digital input pin
- Sintax: digitalRead (pin)
 - pin: The input pin # that will be read
 - Returns HIGH or LOW depending on the logic state value of the input pin that was read

delay

- Pauses the program execution for a desired time (in milliseconds)
- Not recommended to use because it pauses the whole program execution for the input time
- Sintax: delay (ms);
 - ms: The number of milliseconds that is desired to pause the program (var type: unsigned long)

Arduino Serial Monitor commands



- **Serial** is a **communications protocol** that can be used to program Arduino.
- For debugging the code, use the "Serial Monitor" by printing text or variables in Arduino code. Here are some commands to use the Serial Monitor:
- Serial.begin
 - Initializes Serial communication at a desired speed.
 - Sintax: Serial.begin (bauds);
 - bauds: Baud rate or speed to transfer data. Default value is 9600 bauds
- Serial.print
 - **Prints** specified **variable** or **text** through serial communication.
 - Sintax: Serial.print(val);
 - val: Value to print, can be a variable or a text using quote marks "Hello World".
 - If used multiple times it will concatenate the next variable or text to the previous printed data.
- Serial.println
 - **Prints and change line** specified **variable** or **text** through serial communication.
 - Sintax: Serial.println(val);
 - val: Value to print, can be a variable or a text using quote marks "Hello World".

- Serial.available
 - Returns the number of bits available (incoming) to be read from the Serial port.
 - Sintax: Serial.available();
 - Commonly used as a trigger function to read an input command from Serial Port.
- Serial.read
 - **Returns** the **next character available** from the **Serial** Port **buffer**
 - Sintax: Serial.read();
 - Commonly used to read incoming data.
 - Use multiple times to read all the buffer incoming data.
- Serial.readBytesUntil
 - Function to read multiple incoming bytes from Serial Port buffer
 - Sintax:


```
Serial.readBytesUntil(terchar, arrayToStore, numBytes);
```

- terchar: termination character to end reading. It's commonly used the '\n' which is the end of line.
- arrayToStore: array variable to store incoming read buffer.
- numByres: maximum bytes to read.

Example 1.1A – Arduino common used commands



- In PIN 13 there is a LED (L1) connected. Blink the LED $\frac{1}{2}$ second ON and $\frac{1}{2}$ second OFF.
 - 1. Connect the LED (L1 in the Arduino code) in PIN 13 (cf Picture).
 - 2. Execute the code of the next slide to blink the LED $\frac{1}{2}$ sec. ON and $\frac{1}{2}$ sec. OFF.



Example 1.1A – Arduino common used commands




```
//I/O pin labeling
#define L1 13 //Label LED connected in pin 13 as "L1"
//Constant declaration
unsigned long TBLINK = 500; //Blink constant TBLINK initialized on
                            //500 \text{ ms}
void setup() {
 //I/O Pin Configuration
 pinMode(L1, OUTPUT); //Set pin L1 as Output
 //Output cleaning
 digitalWrite(L1, LOW); //Turn OFF L1
void loop() {
 digitalWrite(L1, HIGH); //Turn ON L1
 delay(TBLINK); //Delay of TBLINK milliseconds(500 ms)
 digitalWrite(L1, LOW); //Turn OFF L1
 delay(TBLINK); //Delay of TBLINK milliseconds(500 ms)
```

Example 1.1B – Arduino common used commands



- In PIN 13 there is a LED (L1) connected. Blink the LED $\frac{1}{2}$ second ON and $\frac{1}{2}$ second OFF. Print the LED status on the Serial Monitor.
 - 1. Connect the LED (L1 in the Arduino code) in PIN 13 (cf Picture).
 - 2. Execute the code of the next slide to blink the LED $\frac{1}{2}$ sec. ON and $\frac{1}{2}$ sec. OFF.
 - 3. Print the current LED status using the Serial Monitor



Example 1.1B – Arduino common used commands



```
//I/O pin labeling
#define L1 13 //Label LED connected in pin 13 as "L1"
//Constant declaration
unsigned long TBLINK = 500; //Blink constant TBLINK initialized on
                            //500 \text{ ms}
void setup() {
 //I/O Pin Configuration
 pinMode(L1, OUTPUT); //Set pin L1 as Output
 //Output cleaning
 digitalWrite(L1, LOW); //Turn OFF L1
 //Communications
 Serial.begin (9600); //Start Serial communications with PC at 9600 bauds
void loop() {
 digitalWrite(L1, HIGH); //Turn ON L1
 Serial.println("LED ON"); //(Debug)Print current LED status
 delay(TBLINK); //Delay of TBLINK miliseconds(500 ms)
 digitalWrite(L1, LOW); //Turn OFF L1
 Serial.println("LED OFF"); // (Debug) Print current LED status
 delay(TBLINK); //Delay of TBLINK miliseconds(500 ms)
```

If statement



- Used in conjunction with a comparison operator.
- Tests if a condition is met, and in the positive case, executes desired actions and then it continues with the program.
- Sintax:

```
if (condition) {
    //Do something here
}
else if (othercondition) {
    //Do something else if the first condition wasn't met but the othercondition was met
}
else {
    //Do something here in other case
}
```

Example with digital input pins

```
if (digitalRead(pin) == HIGH) {
    //Do something here if the current pin
    //logic state is HIGH
}
```

Example with internal variables

```
if (temperature > 25) {
    //Do something here if temperature is
    //greater than 25 degree Celsius
}
```

Common **error** using if statement:

```
if (pin == HIGH) {
```



The if statement needs to ask if the actual **PIN STATE** is **HIGH**. Not like shown at the left, where it's asked if the **PIN NUMBER** is equals to **HIGH**.

Switch statement



- Allows to do different actions depending of different variable values.
- Similar to do multiple if..else if statements for the same var but with different values.
- Each case is the possible value that the variable can have and it's ended with a break;
- Sintax:


It is possible to check the case with labels instead of raw numbers predefined at the beginning of the program with #define.

```
switch (var) {
    case label1:
        //Do something here if var is equal to the label1
    break;
    case label2:
        //Do something here if var is equal to the label2
    break;
}
```

Example 1.2 – If statement with digital input



Example: In the PIN 2 there is a button or switch (SW) and in the PIN 13 there is a LED (L1). Turn ON the LED if the switch is activated, in other case, turn off the LED



Example 1.2 – If statement with digital input




```
//I/O pin labeling
#define SW 2 //Switch "SW" connected on pin 2
#define L1 13 //LED "L1" connected on pin 13
void setup() {
 //I/O Pin Configuration
 pinMode(SW, INPUT); //SW as INPUT
 pinMode(L1, OUTPUT); //L1 as OUTPUT
 //Output cleaning
 digitalWrite(L1, LOW); //Turn OFF L1
void loop() {
 if (digitalRead(SW) == HIGH) { //Check if SW is in logic state HIGH
   digitalWrite(L1, HIGH); //If it is, turn ON L1
 else { //In other case
   digitalWrite(L1, LOW); //If the SW is OFF, turn OFF L1
```

Example 1.3 – Traffic light



Write a program that controls a traffic light with 2 maintenance switches. If both switches are activated, the Red light will blink. In other case the traffic light will work normally (Red, Yellow, Green).



Example 1.3 – Traffic light



```
//I/O pin labeling
                                                                              void loop() {
#define LR 4 //Red LED "LR" connected on digital pin 4
                                                                               if (digitalRead(S1) == HIGH && digitalRead(S2) == HIGH) { //If both
#define LY 3 //Yellow LED "LY" connected on digital pin 3
                                                                              maintenance switchs are ON, blink
#define LG 2 //Green LED "LG" connected on digital pin 2
                                                                                 //Turn OFF all LEDs
#define S1 7 //Switch "S1" connected on digital pin 7
                                                                                  digitalWrite(LR, LOW);
#define S2 8 //Switch "S2" connected on digital pin 8
                                                                                  digitalWrite(LY, LOW);
                                                                                  digitalWrite(LG, LOW);
//Constant declaration
                                                                                  delay(TIT); //Delay of TIT mseqs (5000msecs)
const unsigned long TRV = 5000; //Time constant from Red to Green
initialized on 5000 ms
                                                                                  //Turn ON red led
const unsigned long TVA = 2500; //Time constant from Green to Yellow
                                                                                  digitalWrite(LR, HIGH);
initialized on 2500 ms
                                                                                  digitalWrite(LY, LOW);
const unsigned long TAR = 1000; //Time constant from Yellow to Red
                                                                                  digitalWrite(LG, LOW);
initialized on 1000 ms
                                                                                  delay(TIT); //Delay of TIT mseqs (5000msecs)
const unsigned long TIT = 5000; //Time constant for blinking initialized on
                                                                                else {//In other case
5000 ms
                                                                                  //Normal traffic light sequence
                                                                                  digitalWrite(LR, HIGH);
void setup() {
                                                                                  digitalWrite(LY, LOW);
 //Pin configuration
                                                                                  digitalWrite(LG, LOW);
  pinMode(LR, OUTPUT); //LR as output
                                                                                  delay(TRV); //Delay of TRV msecs (5000msecs)
  pinMode(LY, OUTPUT); //LY as output
  pinMode(LG, OUTPUT); //LG as output
                                                                                  digitalWrite(LR, LOW);
  pinMode(S1, INPUT); //S1 as intput
                                                                                  digitalWrite(LY, LOW);
  pinMode(S2, INPUT); //S2 as intput
                                                                                  digitalWrite(LG, HIGH);
                                                                                  delay(TVA); //Delay of TVA msegs (2500msecs)
  //Physical Output Cleaning
  digitalWrite(LR, LOW); //Turn off LR
                                                                                  digitalWrite(LR, LOW);
  digitalWrite(LY, LOW); //Turn off LY
                                                                                  digitalWrite(LY, HIGH);
  digitalWrite(LG, LOW); //Turn off LG
                                                                                  digitalWrite(LG, LOW);
                                                                                  delay(TAR); //Delay of TAR msegs (1000msecs)
```



Thanks!