# Workshop Basic Arduino Class 5 – Relative Timing and FSM with Arduino

MSc. David Velásquez Rendón



# Contents




- 1. Relative timings in Arduino using millis() function.
- 2. Finite State Machines with Arduino.

# Relative timing in Arduino using millis()



- The function var = millis(); returns the total execution time in milliseconds since the Arduino was turned ON.
- Allows to do relative timing calculations without using delays.
- To do this relative calculations, three variables must be taken into account:
  - tact: It's the actual execution time. This variable needs to be refreshed always and is exactly equal to what is returned by millis (). In short terms, tact = millis ();
  - tini: It's the initial time for relative timing count. Similar to push Start in a chronometer to begin the timing. This variable is only assigned once, at the beginning when it's desired to do the timing calculation.
  - trel: Relative time. It's the subtraction between the tact and tini. In short terms, trel = tact tini. This variable allows to know exactly how much time has passed since the beginning of the relative timing calculation.


Note: If it's required to compute more precise relative timings, use the function var = micros(); which returns the execution time in microseconds.



# Example 5.1 – Relative timing in Arduino with millis()



Do an Arduino program that allows to blink a LED (L1) ½ sec ON and ½ sec OFF using the millis() function.



## Example 5.1 – Relative timing in Arduino with millis()



```
//I/O Pin Labeling
#define L1 13 //L1 connected on pin 13
//Constants declaration
const unsigned long TBLINK = 500; //Blinking time constant (TBLINK) as unsigned long and initialized on 500 miliseconds
//Variables declaration
unsigned long tact = 0; //Actual time (tact) as unsigned long
unsigned long tini = 0; //Initial time (tini) as unsigned long
unsigned long trel = 0; //Relative time (trel) as unsigned long
void setup() {
 //I/O Pin Configuration
 pinMode(L1, OUTPUT); //L1 as OUTPUT
  //Physical Output Cleaning
  digitalWrite(L1, LOW); //Turn OFF L1
  tini = millis(); //Initialize for the first time the tini variable because the first relative timing calculation will take place in the void loop
void loop()
  tact = millis(); //Take always the actual execution time
  trel = tact - tini; //Calculate the relative time
  if (trel < TBLINK) { //If relative time (trel) is less than the blinking time constant (TBLINK)
   digitalWrite(L1, HIGH); //Turn ON L1
  else if (trel < TBLINK) { //If trel is greater than blinking time constant but less than blinking time x 2 (1/2 sec ON and ½ sec OFF)
    digitalWrite(L1, LOW); //Turn OFF L1
  else { //In other case (if trel is greater than 2 times the blinking time constant)
    tini = millis(); //Take a new initial time in order to begin again the blinking cycle (reset rel time to 0 in next iteration)
```


# FSM Template - Arduino

```
LIBRARIES Declaration(e.g: #include <SFEMP3Shield.h>)
FSM STATES Labeling (e.g: #define SINI 0)
I/O PINS Labeling (e.g #define LED 13)
CONSTANTS Declaration (e.g const unsigned int MAXCYCLES = 6;)
VARIABLES Declaration (e.g float temperature = 0;)
     CURRENT STATE Variable Declaration (unsigned int state = SINI;)
     TIMING VARIABLES Declaration (e.g unsigned long timi = 0;)
SUBROUTINES OR FUNCTIONS Declaration (e.g void blink()) (e.g unsigned int sum(unsigned int A, unsigned int B))
CONFIGURATION
       void setup() {
              //I/O Pin Configuration
              //Physical Outputs Cleaning
               //Communications
               tini = millis(); //(Optional) First assignation of tini time (Only if it's required, if the first relative timing calculation will take place at the beginning of the
              void loop
EXECUTION OR RUN-TIME
                                                                                                                  case ELEDON:
       void loop() {
                                                                                                                   //Physical Outputs state assignation ...
               tact = millis(); //Calculate the actual execution time (if FSM requires
              timing)
              //FSM
               switch (state) {
                      case SINI: //Initial State
                        //Physical Outputs state assignation
                        digitalWrite(L1, LOW); //Turn OFF LED L1 in the SINI state
                        //Internal Variables Computation (mapping, readings, etc)
                        //->Relative timing calculation (if required by the state)
                        trel = tact - tini;
                        //Transition questions
                        if (trel >= VALUE) { //If relative time is greater or equal than
                      VALUE constant
                            state = SLEDON; //Next state is SLEDON (State LED ON)
                            tini = millis(); //Reset the relative timing by taking a new
                      tini time (Only necessary if it's required to do timing in the next
                      state
                        else if (digitalRead(BTNEMG) == HIGH) { //If the emergency button
                      is ON
                            state = EALERT; //Next state is SALERT
                      break;
```


# Example 5.2 – FSM with Arduino



Do an Arduino program that blinks a LED (L1) connected on pin 2, ½ sec ON and ½ sec OFF while the emergency button is not activated (BEMG) connected on pin 8. If BEMG is ON, the LED L1 remains OFF and the LED L2 connected on pin 3 turns ON. When there isn't anymore an emergency, the process returns to its normal blinking.




ENTRADAS			SALIDAS			
Nombre	Descripción	Tipo	Nombre		Descripción	Tipo
BEMG	Emergency button	Boolean (Digital)	<i>L</i> 1		LED	Boolean (Digital)
			L2		Red LED for emergency	Boolean (Digital)
			t	$t_{act}$ $t_{ini}$ $t_{rel}$	Timer	Internal Variable



# Example 5.2 – FSM with Arduino





fritzing

# Example 5.2 – FSM with Arduino

```
//FSM States Labeling
#define SLOFF 0 //State LED OFF
#define SLON 1 //State LED ON
#define SAEMG 2 //State Alert Emergency
//I/O Pin Labeling
#define BEMG 8 //BEMG connected on pin 8
#define L1 2 //L1 connected on pin 2
#define L2 3 //L2 connected on pin 3
//Constants declaration
const unsigned long TBLINK = 500; //Define blinking time constant as unsigned long and
initialize it in 500 milisecs
//Variables declaration
unsigned int state = SLOFF; //Variable for storing the current FSM state and initialized
in SLOFF
//->Timing Vars
unsigned long tact = 0; //Actual time (tact) as unsigned long
unsigned long tini = 0; //Initial time (tini) as unsigned long
unsigned long trel = 0; //Relative time (trel) as unsigned long
void setup()
 //I/O Pin Configuration
  pinMode(BEMG, INPUT); //BEMG as INPUT
  pinMode(L1, OUTPUT); //L1 as OUTPUT
  pinMode(L2, OUTPUT); //L2 as OUTPUT
  //Physical Output Cleaning
  digitalWrite(L1, LOW); //Turn OFF L1
  digitalWrite(L2, LOW); //Turn OFF L2
  tini = millis(); //Initialization of tini (first state ELOFF requires timing)
void loop()
  tact = millis(); //Refresh always actual time
  switch (state) {
   case SLOFF:
     //Physical Outputs state assignation
     digitalWrite(L1, LOW); //Turn OFF L1
     digitalWrite(L2, LOW); //Turn OFF L2
     //Internal Variables Computation
     //->Relative timing calculation
     trel = tact - tini;
     //Transition Ouestions
```


```
if (trel >= TBLINK) { //If the relative time is greater or equal to TBLINK time
   state = SLON; //Next state is then SLON
    tini = millis(); //Reset the timer to a new value for next state timing
  else if (digitalRead(BEMG) == HIGH) { //In other case if the BEMG is activated
    state = SAEMG; //Next state is then SAEMG
break;
case SLON:
 //Physical Outputs state assignation
  digitalWrite(L1, HIGH); //Turn ON L1
  digitalWrite(L2, LOW); //Turn OFF L2
 //Internal Variables Computation
 //->Relative timing calculation
  trel = tact - tini;
  //Transition Ouestions
  if (trel >= TBLINK) {//If the relative time is greater or equal to TBLINK time
   state = SLOFF; //Next state is then SLOFF
   tini = millis(); //Reset the timer to a new value for next state timing
  else if (digitalRead(BEMG) == HIGH) { // In other case if the BEMG is activated
   state = SAEMG; // Next state is then SAEMG
 break;
case SAEMG:
 //Physical Outputs state assignation
  digitalWrite(L1, LOW); //Turn OFF L1
  digitalWrite(L2, HIGH); //Turn ON L2
  //Transition Ouestions
  if (digitalRead(BEMG) == LOW) { //If BEMG is deactivated
   state = SLON; //Next state is then SLON
   tini = millis(); //Reset the timer to a new value for next state timing
 break;
```

# Challenge 1 – Traffic light with temperature sensor



Design a traffic light with 3 LEDs (Red, White and Green) and a LM35 Linear temperature sensor, which works like the following procedure:


- It must start for safety in RED, wait 20 seconds and then change to GREEN.
- In GREEN, it waits 10 seconds and then changes to WHITE.
- In WHITE, it must wait 5 seconds and then change back to RED.
- If at any time the temperature sensor LM35 detects that the temperature is greater or equal to 30° C inside the traffic light electronic board, The traffic light advises the maintenance personal of a posible failure blinking its three LEDs ½ sec ON and ½ sec OFF. If the temperature goes back to normal conditions, the traffic light returns to the initial state (RED) and works again normally.




## Challenge 2 – Proximity Indicator System



Design a proximity indicator system, which alerts certain user of a posible collision to a wall. Use a RGB LED and a <u>Sharp Optic distance analog sensor</u> following the next steps:



- The RGB LED will turn Orange and blink 3 times (½ sec ON, ½ sec OFF) and then stay lit if the wall is located between 300 mm and 500 mm.
- The RGB LED will turn Red and constantly blink (200 msec ON, 200 msec OFF) if the wall is located at less than 300 mm.



## Function to convert ADC value to mm value

```
unsigned int adc2mm (unsigned int senval) {
   if (value < 10) value = 10;
   return ((67870.0 / (value - 3.0)) - 40.0);
}</pre>
```







# Thanks!