

BLUEBOX Gen 2 Firmware Update

iDTRONIC GmbH
Donnersbergweg 1
67059 Ludwigshafen
Germany/Deutschland

Issue 2.0

– 27. November 2012 –

Phone: +49 621 6690094-0

Fax: +49 621 6690094-9 E-Mail: info@idtronic.de Web: idtronic.de

© Copyright iDTRONIC GmbH 2011 Printed in Germany

Subject to alteration without prior notice.

Page 2 of 6 BLUEBOX Gen 2

R-OEM-LF-880 Preparation


Contents

1	Preparation		4
	1.1	How to identify the current firmware version	4
	1.2	How to obtain the latest firmware version	
	1.3	Tools Needed	4
2	Update Procedure		5
	2.1	Serial connection with the BLUEBOX	Fehler! Textmarke nicht definiert.
	2.2	Update Using the Software "BLUEBOX Show"	5

BLUEBOX Gen 2 Page 3 of 6

1 Preparation

1.1 How to identify the current firmware version



1.2 How to obtain the latest firmware version

Send an E-Mail to: support@idtronic.de

1.3 Tools Needed

- BLUEBOX Show Software
- Power Supply for the BLUEBOX (18 30 Vdc)
- USB or other Interface connection to the BLUEBOX

Page 4 of 6 BLUEBOX Gen 2


R-OEM-LF-880 Update Procedure

2 Update Procedure


2.1 Update Using the Software "BLUEBOX Show"




Establish Connection



Choose Menu Entry "Upgrade"




Now select the firmware binary file (Image File).




Please wait until the whole update process has finished.

You can click on OK.



Please wait until the whole update process has finished.

BLUEBOX Gen 2 Page 5 of 6



Please wait until the reader has rebooted!

Then the green Run LED will blink.

Page 6 of 6 BLUEBOX Gen 2