DepthVista

DepthVista Console Application Build Manual



Version 1.1 e-con Systems 9/3/2022





Disclaimer

e-con Systems reserves the right to edit/modify this document without any prior intimation of whatsoever.



Contents

INTRODUCTION TO DEPTHVISTA	3
Prerequisites	3
DESCRIPTION	3
INSTALLING OPENCV	5
INSTALLING DEPTHVISTASDK	6
BUILDING DEPTHVISTA CONSOLE APPLICATION	7
TROUBLESHOOTING	8
SUPPORT	9



Introduction to DepthVista

This document describes how to build the DepthVista console application step by step on the host PC (Linux).

Prerequisites

The prerequisites are as follows:

- DepthVista console application source code.
- CMake (version 3.5 and above).
- DepthVistaSDK.

Description

DepthVista has USB interface controller with USB Type-C connector to interface with the host PC. It is a ready-to-manufacture camera board with all the necessary firmware built-in and is compatible with the UVC version 1.0 standard. You can integrate this camera into the products, and this helps to cut short the time-to-market.

DepthVista is a UVC compatible and will work with the standard drivers available with Windows and Linux OS. There is no need for any additional driver installation. So, video streaming through UVC is possible without any special drivers on OSes that have built-in support for UVC standards.

Table 1: DepthVista supported Format, Resolutions, and Frame Rates

S.No	Format	Camera Mode	Resolution	Frame Rate (fps) USB 3.2 Gen 1
1	UYVY	RGB Mode	2.3MP (1920 x 1200)	30
			FHD (1920 x 1080)	30
			HD (1280 x 720)	60
			VGA (640 x 480)	60
2	Y16	TOF Mode	Depth (640 x 480)	30
	(RAW 12-bit)		IR (640 x 480)	30
			Depth + IR (640 x 960)	30



3	RGB-D Mode	_	1280 x 600 (RGB-D)	30
		1443 X 960 (RGB-D)	30	

TOF camera in DepthVista can be used in two depth modes as follows:

- Far Mode: Effective depth range is between 1000 mm to 6500 mm.
- Near Mode: Effective depth range is between 200 mm to 1200 mm.

The TOF camera controls of DepthVista are as follows:

- TOF Data Mode
- TOF Depth Range
- TOF Mask
- TOF Gain

The RGB camera controls of DepthVista are as follows:

- Brightness
- Contrast
- Saturation
- Gamma
- Gain
- Sharpness
- White Balance
- Exposure
- Power line frequency



Installing OpenCV

This section describes the installation of OpenCV.

Run the following command to install OpenCV.

sudo apt-get install libopencv-dev



Installing DepthVistaSDK

This section describes the installation of DepthVistaSDK which is essential for building DepthVista Application.

 Extract the DepthVistaConsoleApp_Linux_v1.0.0.1.zip file using the following command.

unzip DepthVistaConsoleApp Linux v1.0.0.1.zip

<Extracted Directory>\
 DepthVistaConsoleApp_Linux_v1.0.0.1\x64\SDK\DepthVistaSDK_installer
 will have a install.sh file.

Note: DepthVistaConsoleApp_Linux_v1.0.0.1 folder will contain two folders **ARM** and **x64.** Choose the folder based on the machine you are working.

- Open the folder containing install.sh in terminal
- Run the following command to give executable permission for install.sh file

chmod +x install.sh

Install the DepthVistaSDK with the following command

sudo ./install.sh

Once installation is success, you will get "Installation DepthVistaSDK success".



Building DepthVista Console Application

This section will discuss about building DepthVista console application.

- <Extracted Directory>\ DepthVistaConsoleApp_Linux_v1.0.0.1\x64\Source
 will have the DepthVistaConsoleApp.cpp and a CMakeLists.txt file. Open that
 folder in terminal.
- 2. Run the following commands.

mkdir build && cd build

The above command creates a build directory and changes the terminal to build directory on successful creation of build directory.

```
sudo cmake ..
```

The above command creates make file from CMakeLists.txt.

sudo make

The above command generates DepthVistaConsole executable file using the make file.

Once the make is completed successfully, DepthVistaConsoleApp executable will be generated.

3. Running DepthVistaConsole application

sudo ./DepthVistaConsoleApp

4. Follow the *DepthVista_Console_Application_User_Manual_Rev_1_0.pdf* provided in the package.



Troubleshooting

- 1. Error: libopencv_world.so needed by libDepthVistaSDK.so is missing.
 - Create an opency.conf file and add the directory containing the libopency_world.so to that file.
 - Move the opency.conf file to /etc/ld.so.conf.d directory.
 - Run the following command

sudo ldconfig -v



Support

Contact Us

If you need any support on DepthVista product, please contact us using the Live Chat option available on our website - https://www.e-consystems.com/

Creating a Ticket

If you need to create a ticket for any type of issue, please visit the ticketing page on our website - https://www.e-consystems.com/create-ticket.asp

RMA

To know about our Return Material Authorization (RMA) policy, please visit the RMA Policy page on our website - https://www.e-consystems.com/RMA-Policy.asp

General Product Warranty Terms

To know about our General Product Warranty Terms, please visit the General Warranty Terms page on our website - https://www.e-consystems.com/warranty.asp



Revision History

Rev	Date	Description	Author
1.0	06-July-2022	Initial Draft	Camera Products
1.1	03-September-2022	Added OpenCV installation steps and changed build steps	Camera Products