

eYs3D Windows SDK 1.5.2.5

Generated by Doxygen 1.9.1

| 1 Introduction | 3 |
|--------------------------------------|--------|
| 2 Data Structure Index | 5 |
| 2.1 Data Structures | 5 |
| 3 File Index | 7 |
| 3.1 File List | 7 |
| 4 Data Structure Documentation | 9 |
| 4.1 DEVINFORMATIONEX | 9 |
| 4.1.1 Detailed Description | 9 |
| 4.1.2 Field Documentation | 9 |
| 4.1.2.1 nChipID | 9 |
| 4.1.2.2 nDevType | 9 |
| | 10 |
| 4.1.2.4 wPID | 10 |
| 4.1.2.5 wUsbNode | 10 |
| | 10 |
| 4.2 eSPCtrl_RectLogData | 10 |
| | 11 |
| | 11 |
| | 13 |
| | 13 |
| · · | 14 |
| | 14 |
| | 14 |
| • | 14 |
| | 14 |
| | 14 |
| | 15 |
| | 15 |
| 4.4.2.0 WVID | J |
| 5 File Documentation | 17 |
| 5.1 eSPDI_Common.h File Reference | 17 |
| 5.1.1 Detailed Description | 21 |
| 5.1.2 Typedef Documentation | 21 |
| 5.1.2.1 DEVINFORMATION | 21 |
| 5.1.2.2 eSPCtrl_RectLogData | 21 |
| 5.1.2.3 PARALUT | 21 |
| 5.1.3 Enumeration Type Documentation | 22 |
| 5.1.3.1 APC_DEVICE_TYPE | 22 |
| 5.1.3.2 SENSOR_TYPE_NAME | 22 |
| | 22 |
| 5.1.4 Function Documentation | 23 |

| 5.1.4.1 APC_CloseDevice() |
|--|
| 5.1.4.2 APC_DisableAE() |
| 5.1.4.3 APC_DisableAWB() |
| 5.1.4.4 APC_EnableAE() |
| 5.1.4.5 APC_EnableAWB() |
| 5.1.4.6 APC_EnableGPUAcceleration() |
| 5.1.4.7 APC_FindDevice() |
| 5.1.4.8 APC_GetCTPropVal() |
| 5.1.4.9 APC_GetCurrentIRValue() |
| 5.1.4.10 APC_GetDepthFilterVersion() |
| 5.1.4.11 APC_GetDeviceNumber() |
| 5.1.4.12 APC_GetDeviceResolutionList() |
| 5.1.4.13 APC_GetFlexibleGyroData() |
| 5.1.4.14 APC_GetFlexibleGyroLength() |
| 5.1.4.15 APC_GetFWRegister() |
| 5.1.4.16 APC_GetFwVersion() |
| 5.1.4.17 APC_GetGPIOValue() |
| 5.1.4.18 APC_GetHWRegister() |
| 5.1.4.19 APC_GetIRMaxValue() |
| 5.1.4.20 APC_GetIRMinValue() |
| 5.1.4.21 APC_GetLogData() |
| 5.1.4.22 APC_GetPidVid() |
| 5.1.4.23 APC_GetPUPropVal() |
| 5.1.4.24 APC_GetSensorRegister() |
| 5.1.4.25 APC_GetSlaveHWRegister() |
| 5.1.4.26 APC_GetSlaveLogData() |
| 5.1.4.27 APC_GetSlaveSensorRegister() |
| 5.1.4.28 APC_Init() |
| 5.1.4.29 APC_Init2() |
| 5.1.4.30 APC_Is360Device() |
| 5.1.4.31 APC_OpenDevice() |
| 5.1.4.32 APC_ReadFlashData() |
| 5.1.4.33 APC_RefreshDevice() |
| 5.1.4.34 APC_RegisterDeviceEvents() |
| 5.1.4.35 APC_Release() |
| 5.1.4.36 APC_ResetUNPData() |
| 5.1.4.37 APC_SetCTPropVal() |
| 5.1.4.38 APC_SetCurrentIRValue() |
| 5.1.4.39 APC_SetFWRegister() |
| 5.1.4.40 APC_SetGPIOCtrl() |
| 5.1.4.41 APC_SetGPIOValue() |
| 5.1.4.42 APC_SetHuffmanTableData() |

| 5.1.4.43 APC_SetHWRegister() | 43 |
|---|----|
| 5.1.4.44 APC_SetIRMaxValue() | 44 |
| 5.1.4.45 APC_SetLogData() | 44 |
| 5.1.4.46 APC_SetLogData_Advanced() | 45 |
| 5.1.4.47 APC_SetPidVid() | 45 |
| 5.1.4.48 APC_SetPUPropVal() | 46 |
| 5.1.4.49 APC_SetQuantizationTableData() | 46 |
| 5.1.4.50 APC_SetSensorTypeName() | 46 |
| 5.1.4.51 APC_SetSlaveHWRegister() | 48 |
| 5.1.4.52 APC_SetSlaveLogData() | 48 |
| 5.1.4.53 APC_SetUserData() | 49 |
| 5.2 eSPDI_DM.h File Reference | 49 |
| 5.2.1 Detailed Description | 51 |
| 5.2.2 Function Documentation | 51 |
| 5.2.2.1 APC_GetDepthDataType() | 51 |
| 5.2.2.2 APC_GetRectifyMatLogData() | 51 |
| 5.2.2.3 APC_GetRectifyTable() | 52 |
| 5.2.2.4 APC_GetSlaveRectifyTable() | 52 |
| 5.2.2.5 APC_GetSlaveYOffset() | 53 |
| 5.2.2.6 APC_GetYOffset() | 53 |
| 5.2.2.7 APC_GetZDTable() | 54 |
| 5.2.2.8 APC_IsInterleaveDevice() | 55 |
| 5.2.2.9 APC_SetDepthDataType() | 55 |
| 5.2.2.10 APC_SetHWPostProcess() | 56 |
| 5.2.2.11 APC_SetSlaveYOffset() | 56 |
| 5.2.2.12 APC_SetYOffset() | 57 |
| 5.2.2.13 APC_SetYOffset_Advanced() | 57 |
| 5.3 eSPDI_ErrCode.h File Reference | 58 |
| 5.3.1 Detailed Description | 58 |
| Index | 59 |

Chapter 1

Introduction

This document describes the usage of Application Programming Interfaces of eYs3D Windows SDK

What's inside the SDK

Table 1.1 File List

| Folder | Subfolder | Filename | Description |
|----------------------|---------------|-----------------|--|
| bin Win32 All files | | All files | Sample executables on Win32 platform |
| DIII | x64 All files | | Sample executables on Windows 64-bits platform |
| eSPDI_Common.h Basic | | eSPDI_Common.h | Basic API declaration header |
| | include | eSPDI_DM.h | Depth Map specific API declaration header |
| | | eSPDI_ErrCode.h | Error code definitions |
| eSPDI | Win32 | eSPDI_DM.dll | eSPDI dynamical linked library for Win32 platform |
| | VVIIIOZ | eSPDI_DM.lib | eSPDI static linked library for Win32 platform |
| | x64 | eSPDI_DM.dll | eSPDI dynamical linked library for Windows 64-bits |
| | X04 | eSPDI_DM.lib | eSPDI static linked library for Windows 64-bits |
| doc | html | index.html | This documentation |
| DMPrevio | ew | | A sample VC++ project demonstrating how to open multiple devices in an application |

4 Introduction

Chapter 2

Data Structure Index

2.1 Data Structures

Here are the data structures with brief descriptions:

| DEVINFORMATIONEX | 9 |
|---------------------|----|
| eSPCtrl_RectLogData | |
| ESPCtrl_RectLogData | 10 |
| ParaLUT | |
| ParaLUT | 11 |
| tagDEVINFORMATION | |
| DEVINFORMATION | 13 |

6 Data Structure Index

Chapter 3

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

| eSPDI_Common.h | |
|---|----|
| EYs3D SDK API export functions, data structure and variable definition | 17 |
| eSPDI_DM.h | |
| EYs3D SDK API export functions, data structure and variable definition for depth map module . | 49 |
| eSPDI_ErrCode.h | |
| Definition of eYs3D SDK error code Copyright: This file copyright (C) 2017 by | 58 |

8 File Index

Chapter 4

Data Structure Documentation

4.1 DEVINFORMATIONEX

Data Fields

- unsigned short wPID
- unsigned short wVID
- char strDevName [512]
- unsigned short nChipID
- unsigned short nDevType
- unsigned short wUsbNode

4.1.1 Detailed Description

extended device information class

4.1.2 Field Documentation

4.1.2.1 nChipID

unsigned short nChipID

chip ID, 0x18 for AXES1, 0x1C for KIWI, 0x15 for PUMA

4.1.2.2 nDevType

unsigned short nDevType

chip enum value, see APC_DEVICE_TYPE

4.1.2.3 strDevName

char strDevName[512]

device name

4.1.2.4 wPID

unsigned short wPID

product ID

Table 4.1 PID List

| Chip Name | Chip ID | PID |
|-----------|---------|--------|
| | 0x18 | 0x0568 |
| | | 0x0668 |
| AXES1 | | 0x0113 |
| | | 0x0115 |
| | | 0x0116 |
| KIWI | 0x1C | 0x0118 |
| PUMA | 0x15 | 0x0112 |
| | | 0x0120 |

4.1.2.5 wUsbNode

unsigned short wUsbNode

USB Node

4.1.2.6 wVID

unsigned short wVID

vender ID, 0x1E4E for ApcDI device

The documentation for this class was generated from the following file:

• eSPDI_Common.h

4.2 eSPCtrl_RectLogData

eSPCtrl_RectLogData

4.3 ParaLUT

4.2.1 Detailed Description

```
eSPCtrl_RectLogData
```

Rectified log data structure

The documentation for this struct was generated from the following file:

• eSPDI_Common.h

4.3 ParaLUT

ParaLUT.

Data Fields

```
• long long file_ID_header
```

[00]-[000] File ID header: 2230

long long file_ID_version

[01]-[008] File ID version: 4

double FOV

[02]-[016] Field of view with degree

long long semi_FOV_pixels

[03]-[024] Pixels for semi-FOV

long long img_src_cols

[04]-[032] Width for source image (single image)

• long long img_src_rows

[05]-[040] Height for source image

double img_L_src_col_center

[06]-[048] Center of width for L side source image

double img_L_src_row_center

[07]-[056] Center of height for L side source image

double img_R_src_col_center

[08]-[064] Center of width for R side source image

double img_R_src_row_center

[09]-[072] Center of height for R side source image

double img_L_rotation

[10]-[080] Rotation for L side image

• double img_R_rotation

[11]-[088] Rotation for R side image

• double spline_control_v1

[12]-[096] Spline control value for row = DIV x 0 pixel, DIV = rows/6

double spline_control_v2

[13]-[104] Spline control value for row = DIV x 1 pixel, DIV = rows/6

double spline_control_v3

[14]-[112] Spline control value for $row = DIV \times 2$ pixel, DIV = rows/6

double spline_control_v4

[15]-[120] Spline control value for row = DIV x 3 pixel, DIV = rows/6

```
• double spline_control_v5
     [16]-[128] Spline control value for row = DIV x 4 pixel, DIV = rows/6

    double spline control v6

     [17]-[136] Spline control value for row = DIV x 5 pixel, DIV = rows/6

    double spline_control_v7

     [18]-[144] Spline control value for row = DIV x 6 pixel, DIV = rows/6
• long long img_dst_cols
     [19]-[152] Width for output image (single image), according to "Original" parameters

    long long img_dst_rows

     [20]-[160] Height for output image, according to "Original" parameters
· long long img L dst shift
     [21]-[168] Output L side image shift in row
• long long img_R_dst_shift
     [22]-[176] Output R side image shift in row
· long long img overlay LR
     [23]-[184] Overlay between L/R in pixels, far field, (YUV must be even)
· long long img_overlay_RL
     [24]-[192] Overlay between R/L in pixels, far field, (YUV must be even)
· long long img stream cols
     [25]-[200] Output image stream of cols
· long long img stream rows
     [26]-[208] Output image stream of rows

    long long video_stream_cols

     [27]-[216] Output video stream of cols
· long long video_stream_rows
     [28]-[224] Output video stream of rows

    long long usb_type

     [29]-[232] 2 for usb2, 3 for usb3

    long long img_type

     [30]-[240] 1 for yuv422, 2 for BGR, 3 for RGB

    long long lut_type

     [31]-[248] Output LUT tye eys::LutModes
• long long blending_type
     [32]-[256] 0 for choosed by function, 1 for alpha-blending, 2 for Laplacian pyramid blending
· double overlay ratio
      [33]-[264] far field overlay value is equal to img_overlay_LR(RL) = overlay_value + overlay_ratio

    long long serial number date0

     [34]-[272] 8 bytes, yyyy-mm-dd

    long long serial_number_date1

     [35]-[280] 8 bytes, hh-mm-ss-xxx, xxx for machine number
· double unit_sphere_radius
     [36]-[288] Original: Unit spherical radius for dewarping get x and y
· double min col
     [37]-[296] Original: Parameters of min position of image width

    double max_col

     [38]-[304] Original: Parameters of max position of image width
· double min row
```

[39]-[312] Original: Parameters of min position of image height

· double max row

[40]-[320] Original: Parameters of max position of image height

long long AGD_LR

[41]-[328] Err: Average gray-level value discrepancy at LR boundary

· long long AGD_RL

[42]-[336] Err: Average gray-level value discrepancy at RL boundary

long long out_img_resolution

[43]-[344] Set output resolution eys::ImgResolutionModes

· long long out lut cols

[44]-[352] Output side-by-side lut width, according to the set of out_img_resolution

long long out_lut_rows

[45]-[360] Output lut height, according to the set of out img resolution

long long out_lut_cols_eff

[46]-[368] Output effective pixels in out_lut_cols, 0 is for all

• long long out_lut_rows_eff

[47]-[376] Output effecitve pixels in out_lut_rows, 0 is for all

• long long out_img_cols

[48]-[384] Output side-by-side image width after dewarping and stitching, according to the set of out_img_resolution

long long out_img_rows

[49]-[392] Output image height, according to the set of out_img_resolution

· long long out overlay LR

[50]-[340] Output L/R overlay value, according to the set of out_img_resolution

· long long out overlay RL

[51]-[408] Output R/L overlay value, according to the set of out_img_resolution

long long reserve [44]

[52]-[416] Reserve 44 parameter to use

4.3.1 Detailed Description

ParaLUT.

Spherical look-up table conversion parameters

The documentation for this struct was generated from the following file:

· eSPDI_Common.h

4.4 tagDEVINFORMATION

DEVINFORMATION.

Data Fields

- · unsigned short wPID
- · unsigned short wVID
- char * strDevName
- unsigned short nChipID
- unsigned short nDevType
- unsigned short wUsbNode

4.4.1 Detailed Description

DEVINFORMATION.

device information

4.4.2 Field Documentation

4.4.2.1 nChipID

unsigned short nChipID

chip ID, 0x18 for AXES1, 0x1C for KIWI, 0x15 for PUMA

4.4.2.2 nDevType

unsigned short nDevType

chip enum value,

See also

APC_DEVICE_TYPE

4.4.2.3 strDevName

char* strDevName

pointer to device name stored inside the SDK

4.4.2.4 wPID

unsigned short wPID

product ID

Table 4.2 PID List

| Chip Name | Chip ID | PID |
|-----------|------------|--------|
| - | AXES1 0x18 | 0x0568 |
| | | 0x0668 |
| AXES1 | | 0x0113 |
| | | 0x0115 |
| | | 0x0116 |
| KIWI | 0x1C | 0x0118 |
| DLIMA | 0v15 | 0x0112 |

0x15

0x0120

PUMA

Generated by Doxygen

4.4.2.5 wUsbNode

unsigned short wUsbNode

USB Node

4.4.2.6 wVID

unsigned short wVID

vender ID, 0x1E4E for ApcDI device

The documentation for this struct was generated from the following file:

• eSPDI_Common.h

Chapter 5

File Documentation

5.1 eSPDI_Common.h File Reference

eYs3D SDK API export functions, data structure and variable definition

Data Structures

- · struct eSPCtrl RectLogData
 - eSPCtrl_RectLogData
- struct ParaLUT
 - ParaLUT.
- struct tagDEVINFORMATION
 - DEVINFORMATION.
- class DEVINFORMATIONEX

Typedefs

- typedef struct eSPCtrl_RectLogData eSPCtrl_RectLogData
 - eSPCtrl_RectLogData
- typedef struct ParaLUT PARALUT
 - ParaLUT.
- typedef struct tagDEVINFORMATION DEVINFORMATION.

Enumerations

```
    enum APC_DEVICE_TYPE { OTHERS = 0 , AXES1 , PUMA , PLUM , GRAPE_FPGA }
    enum USERDATA_SECTION_INDEX {
        USERDATA_SECTION_0 = 0 , USERDATA_SECTION_1 , USERDATA_SECTION_2 , USERDATA_SECTION_3 ,
        USERDATA_SECTION_4 , USERDATA_SECTION_5 , USERDATA_SECTION_6 , USERDATA_SECTION_7 ,
        USERDATA_SECTION_8 , USERDATA_SECTION_9 , USERDATA_SECTION_10 , USERDATA_SECTION_NUM }

    enum SENSOR_TYPE_NAME {
        APC_SENSOR_TYPE_H22 = 0 , APC_SENSOR_TYPE_OV7740 , APC_SENSOR_TYPE_AR0134 ,
        APC_SENSOR_TYPE_AR0135 ,
        APC_SENSOR_TYPE_AR0144 , APC_SENSOR_TYPE_OV9714 , APC_SENSOR_TYPE_OV9282 ,
        APC_SENSOR_TYPE_AR0330 ,
        APC_SENSOR_TYPE_AR1335 , APC_SENSOR_TYPE_H65 , APC_SENSOR_TYPE_AR0522 , APC_
        SENSOR_TYPE_OV2740 ,
        APC_SENSOR_TYPE_OV2740 ,
        APC_SENSOR_TYPE_OCOSA10 , APC_SENSOR_TYPE_UNKOWN = 0xffff }
```

Functions

• int APC_API APC_Init (void **ppHandleApcDI, bool blsLogEnabled)

entry point of eYs3D camera SDK. This API allocates resource and find all the eSPI camera devices connected to the system.

int APC_API APC_Init2 (void **ppHandleApcDI, bool blsLogEnabled, bool bAutoRestart)

entry point of eYs3D camera SDK. This API allocates resource and find all the eSPI camera devices connected to the system.

• int APC_API APC_RegisterDeviceEvents (void *pHandleApcDI, APC_DeviceEventFn cbFunc, void *pData)

Register the USB device plug or unplug events. Any USB capture device attachment or detachment events will call the callback function cbFunc.

void APC API APC Release (void **ppHandleApcDI)

release all resource that APC_Init had allocated

int APC API APC FindDevice (void *pHandleApcDI)

find out all eYs3D USB devices by PID, VID and ChipID, also remember device types

int APC API APC RefreshDevice (void *pHandleApcDI)

refresh all eYs3D UVC devices

int APC API APC GetDeviceNumber (void *pHandleApcDI)

get eYs3D USB device numbers

• int APC_API APC_GetSlaveSensorRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nld, unsigned short address, unsigned short *pValue, int flag, int nSensorMode)

get value from sensor register

• int APC_API APC_GetSensorRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nld, unsigned short address, unsigned short *pValue, int flag, int nSensorMode)

get value from sensor register

int APC_API APC_GetFWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short *pValue, int flag)

get firmware register value

• int APC_API APC_SetFWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short nValue, int flag)

set firmware register value

 int APC_API APC_GetSlaveHWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short *pValue, int flag)

get hardware register value

int APC_API APC_GetHWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short *pValue, int flag)

get hardware register value

 int APC_API APC_SetSlaveHWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short nValue, int flag)

set hardware register

• int APC_API APC_SetHWRegister (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short address, unsigned short nValue, int flag)

set hardware register

int APC_API APC_GetFwVersion (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, char *pszFwVersion, int nBufferSize, int *pActualLength)

get the firmware version of device, the version is a string

• int APC_API APC_GetPidVid (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short *pPidBuf, unsigned short *pVidBuf)

get PID(product ID) and VID(vendor ID) of device

int APC_API APC_SetPidVid (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short *pPidBuf, unsigned short *pVidBuf)

set PID and VID to device

• int APC_API APC_GetSlaveLogData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

get log data from flash

• int APC_API APC_GetLogData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

get log data from flash

• int APC_API APC_SetSlaveLogData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set log data to flash

• int APC_API APC_SetLogData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set log data to flash

• int APC_API APC_SetLogData_Advanced (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set log data to flash

• int APC_API APC_SetUserData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, USERDATA_SECTION_INDEX usi)

set user data to flash

int APC_API APC_ReadFlashData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, FLASH_DATA_TYPE fdt, BYTE *pBuffer, unsigned long int nLengthOfBuffer, unsigned long int *pActualBufferLen)

read firmware code(.bin) form flash The firmware code is the combination of boot loader, firmware body and plug-in data. This input buffer length has to match with the flash data type

• int APC_API APC_OpenDevice (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int colorStreamIndex, int depthStreamIndex, int depthStreamSwitch, int iFps, APC_ImgCallbackFn callbackFn, void *pCallbackParam, int pid=-1)

open camera device with image callback support

• int APC_API APC_GetColorImage (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *pBuf, unsigned long int *pImageSize, int *pSerial=NULL)

get color image

• int APC_API APC_CloseDevice (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

close device and stop video render

• int APC_API APC_GetDeviceResolutionList (void ∗pHandleApcDI, PDEVSELINFO pDevSelInfo, int nMax↔

Int APC_API APC_GetDeviceResolutionList (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, Int nMax Count0, APC_STREAM_INFO *pStreamInfo1) aget the device resolution list

bool APC_API APC_Is360Device (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)
 check module is spherical device or not

get the module serial number

- int APC_API APC_SetCurrentIRValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD wType) set current infrared radiation(IR) value
- int APC_API APC_GetCurrentIRValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD *pwType) get current infrared radiation(IR) value
- int APC_API APC_GetIRMinValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD *pwType) get minimum IR value the module support
- int APC_API APC_SetIRMaxValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD wType) set maximum IR value the module support
- int APC_API APC_GetIRMaxValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD *pwType)
 get maximum IR value the module support
- int APC_API APC_SetIRMode (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD wType)
 set IR mode, left, right or both
- int APC_API APC_GetIRMode (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD *pwType)

set IR mode, left, right or both

int APC_API APC_EnableSensorIF (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, bool bIsEnable)
 turn on/off sensor IF function

int APC_API APC_SetSensorTypeName (void *pHandleApcDI, SENSOR_TYPE_NAME stn)
 select which sensor to operate

int APC_API APC_EnableAE (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)
 enable auto exposure function of ISP

• int APC_API APC_DisableAE (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

disable auto exposure function of ISP

• int APC_API APC_EnableAWB (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

enable auto white balance function of ISP

• int APC_API APC_DisableAWB (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

disable auto white balance of ISP

• int APC_API APC_GetGPIOValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nGPIOIndex, BYTE *pValue)

get general purpose IO value

int APC_API APC_SetGPIOValue (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nGPIOIndex, BYTE nValue)

set GPIO value

int APC_API APC_SetGPIOCtrl (void *pHandleApcDl, PDEVSELINFO pDevSelInfo, int nGPIOIndex, BYTE nValue)

set GPIO control address

• int APC_API APC_GetPUPropVal (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nld, int *pValue)

get processing unit property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff568122 85).aspx The PROPSETID_VIDCAP_VIDEOPROCAMP property set controls devices that can adjust image color attributes of analog or digital signals.

• int APC API APC SetPUPropVal (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nId, int nValue)

get processing unit property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff568122 (
85).aspx https://msdn.microsoft.com/en-us/library/windows/hardware/ff566089 (v=vs.↔
85).aspx

• int APC API APC GetCTPropVal (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nld, int *pValue)

set control terminal property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff567802 85).aspx The PROPSETID_VIDCAP_CAMERACONTROL property set controls camera device settings. The controls it provides are a subset of the ITU T.RDC standard.

• int APC_API APC_SetCTPropVal (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int nId, int nValue)

get control terminal property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff56780285).aspx https://msdn.microsoft.com/en-us/library/windows/hardware/ff566089($v=vs. \leftrightarrow 85$).aspx

 int APC_API APC_GetAutoExposureMode (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short *mode)

misc function : get auto exposure mode

 int APC_API APC_SetAutoExposureMode (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short mode)

misc function : set auto exposure mode

• int APC_API APC_GetFlexibleGyroData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, int length, BYTE *pGyroData)

get IMU(Gyro) data

• int APC_API APC_GetFlexibleGyroLength (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, unsigned short *GyroLen)

get the IMU(Gyro) data length

• int APC_API APC_SetHuffmanTableData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, const char *filename, bool bLogFile)

set huffman table data for jpeg encode

• int APC_API APC_SetQuantizationTableData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, const char *filename)

set quantication table data for jpeg encode

- int APC_API APC_SetPlumAR0330 (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, bool bEnable) Set Plum Sensor AR0330.
- int APC_API APC_ResetUNPData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

 Reset the UNProtection area's datum.
- int APC_API APC_EnableGPUAcceleration (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, bool enable) enable depth filter with GPU acceleration or not
- APC_API char * APC_GetDepthFilterVersion (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)
 get depth filter version

5.1.1 Detailed Description

eYs3D SDK API export functions, data structure and variable definition

Copyright

This file copyright (C) 2017 by eYs3D company

An unpublished work. All rights reserved. This file is proprietary information, and may not be disclosed or copied without the prior permission of eYs3D company.

5.1.2 Typedef Documentation

5.1.2.1 DEVINFORMATION

 ${\tt typedef \ struct \ tagDEVINFORMATION \ DEVINFORMATION}$

DEVINFORMATION.

device information

5.1.2.2 eSPCtrl_RectLogData

typedef struct eSPCtrl_RectLogData eSPCtrl_RectLogData

eSPCtrl_RectLogData

Rectified log data structure

5.1.2.3 PARALUT

typedef struct ParaLUT PARALUT

ParaLUT.

Spherical look-up table conversion parameters

5.1.3 Enumeration Type Documentation

5.1.3.1 APC_DEVICE_TYPE

enum APC_DEVICE_TYPE

chip enum value

Enumerator

| OTHERS | Other |
|--------|-------|
| AXES1 | AXIS1 |
| PUMA | PUMA |

5.1.3.2 SENSOR_TYPE_NAME

enum SENSOR_TYPE_NAME

Enumerator

| APC_SENSOR_TYPE_H22 | H22 |
|------------------------|--------|
| APC_SENSOR_TYPE_OV7740 | OV7740 |
| APC_SENSOR_TYPE_AR0134 | AR0134 |
| APC_SENSOR_TYPE_AR0135 | AR0135 |
| APC_SENSOR_TYPE_AR0144 | AR0144 |
| APC_SENSOR_TYPE_OV9714 | OV9714 |
| APC_SENSOR_TYPE_OV9282 | OV9282 |
| APC_SENSOR_TYPE_AR0330 | AR0330 |
| APC_SENSOR_TYPE_AR1335 | AR1335 |
| | |

5.1.3.3 USERDATA_SECTION_INDEX

enum USERDATA_SECTION_INDEX

Enumerator

| USERDATA_SECTION_0 | Section 0 |
|--------------------|-----------|
| USERDATA_SECTION_1 | Section 1 |
| USERDATA_SECTION_2 | Section 2 |
| USERDATA_SECTION_3 | Section 3 |
| USERDATA_SECTION_4 | Section 4 |

Enumerator

| USERDATA_SECTION_5 | Section 5 |
|----------------------|----------------------|
| USERDATA_SECTION_6 | Section 6 |
| USERDATA_SECTION_7 | Section 7 |
| USERDATA_SECTION_8 | Section 8 |
| USERDATA_SECTION_9 | Section 9 |
| USERDATA_SECTION_10 | Section 10 |
| USERDATA_SECTION_NUM | Total Section Number |

5.1.4 Function Documentation

5.1.4.1 APC_CloseDevice()

close device and stop video render

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |

Returns

success:APC_OK, others:see eSPDI_ErrCode.h

5.1.4.2 APC_DisableAE()

disable auto exposure function of ISP

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.3 APC_DisableAWB()

disable auto white balance of ISP

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.4 APC_EnableAE()

enable auto exposure function of ISP

Parameters

| pHandleApcDl | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.5 APC_EnableAWB()

enable auto white balance function of ISP

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.6 APC_EnableGPUAcceleration()

enable depth filter with GPU acceleration or not

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| enable | true:enable, fales:diable |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.7 APC_FindDevice()

find out all eYs3D USB devices by PID, VID and ChipID, also remember device types

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
|--------------|--|

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.8 APC_GetCTPropVal()

set control terminal property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff5678 85) .aspx The PROPSETID_VIDCAP_CAMERACONTROL property set controls camera device settings. The controls it provides are a subset of the ITU T.RDC standard.

The KSPROPERTY_VIDCAP_CAMERACONTROL enumeration in Ksmedia.h specifies the properties of this set.

Support for this property set is optional and should be implemented only by minidrivers of devices that offer camera control settings. For more information, see the ITU website.

Prior to USB video class, this enumeration contained the following properties: KSPROPERTY_CAMERACONTROL _EXPOSURE KSPROPERTY_CAMERACONTROL_FOCUS KSPROPERTY_CAMERACONTROL_IRIS KSPROPERTY _CAMERACONTROL_ZOOM KSPROPERTY_CAMERACONTROL PAN KSPROPERTY_CAMERACONTROL ROLL KSPROPERTY CAMERACONTROL TILT

 $\label{library/windows/hardware/ff566089} $$ (v=vs. \leftarrow 85).aspx $$$

Parameters

| *pHandleApcDI | CApcDI handler |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| nld | specifies the member of the property set |
| pValue | pointer of store CT property value |

Returns

success: APC OK, others: see eSPDI ErrCode.h

5.1.4.9 APC_GetCurrentIRValue()

get current infrared radiation(IR) value

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |
| рwТуре | value of current IR |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.10 APC_GetDepthFilterVersion()

get depth filter version

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |

Returns

success: get version string, others: get N/A string

5.1.4.11 APC_GetDeviceNumber()

get eYs3D USB device numbers

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
|--------------|--|

Returns

number of eYs3D device

5.1.4.12 APC_GetDeviceResolutionList()

```
int nMaxCount0,
APC_STREAM_INFO * pStreamInfo0,
int nMaxCount1,
APC_STREAM_INFO * pStreamInfo1 )
```

get the device resolution list

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nMaxCount0 | max count of endpoint1 resolutions |
| pStreamInfo0 | resolution infos of endpoint1 |
| nMaxCount1 | max count of endpoint2 resolutions |
| pStreamInfo1 | resolutions infos of endpoint2 |

Returns

```
success: nCount0*256+nCount1, others: see eSPDI_ErrCode.h
```

5.1.4.13 APC_GetFlexibleGyroData()

get IMU(Gyro) data

Parameters

| pHandleApcDI | CApcDI handler | |
|--------------|--|--|
| pDevSelInfo | pointer of device select index | |
| length | length of IMU data to read, should be get from APC_GetFlexibleGyroLength | |
| pGyroData | data buffer to store IMU data | |

5.1.4.14 APC_GetFlexibleGyroLength()

get the IMU(Gyro) data length

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|----------------------------------|
| pDevSelInfo | pointer of device select index |
| GyroLen | pointer to store IMU data length |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.15 APC_GetFWRegister()

get firmware register value

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| pValue | pointer of value got from register address |
| flag | address and value data length(2 or 1 byte) ie FG_Address_2Byte FG_Value_2Byte is 2 byte address and 2 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.16 APC_GetFwVersion()

```
int APC_GetFwVersion (
     void * pHandleApcDI,
     PDEVSELINFO pDevSelInfo,
     char * pszFwVersion,
     int nBufferSize,
     int * pActualLength )
```

get the firmware version of device, the version is a string

Parameters

| pHandleApcDI | CApcDI handler |
|---------------|---|
| pDevSelInfo | pointer of device select index |
| pszFwVersion | firmware version string |
| nBufferSize | input buffer length to receive FW version |
| pActualLength | the actual length of FW version in byte |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.17 APC_GetGPIOValue()

get general purpose IO value

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |
| nGPIOIndex | GPIO index, 1 or 2 is valid |
| pValue | pointer of GPIO value |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.18 APC_GetHWRegister()

get hardware register value

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| pValue | pointer of value got from register address |
| flag | address and value data length(2 or 1 byte) ie FG_Address_2Byte FG_Value_2Byte is 2 byte address and 2 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.19 APC_GetIRMaxValue()

get maximum IR value the module support

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| | |
| рwТуре | pointer strors maximum IR value |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.20 APC_GetIRMinValue()

get minimum IR value the module support

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| | |
| pwType | pointer strors minimum IR value |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.21 APC_GetLogData()

get log data from flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store log data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify log data for corresponding depth |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.22 APC_GetPidVid()

```
int APC_GetPidVid (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    unsigned short * pPidBuf,
    unsigned short * pVidBuf )
```

get PID(product ID) and VID(vendor ID) of device

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|----------------------------------|
| pDevSelInfo | pointer of device select index |
| pPidBuf | 4 byte buffer to store PID value |
| pVidBuf | 4 byte buffer to store VID value |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.23 APC_GetPUPropVal()

get processing unit property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff568185) .aspx The PROPSETID_VIDCAP_VIDEOPROCAMP property set controls devices that can adjust image color attributes of analog or digital signals.

The KSPROPERTY VIDCAP VIDEOPROCAMP enumeration in ksmedia.h specifies the properties of this set.

Support for this property set is optional and should be implemented only by devices that allow adjustment of brightness, contrast, hue, and other image quality settings.

https://msdn.microsoft.com/en-us/library/windows/hardware/ff566089(v=vs.↔ 85).aspx The KSPROPERTY_VIDEOPROCAMP_S structure describes filter-based property settings in the PROPSETID VIDCAP VIDEOPROCAMP property set.

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nld | specifies the member of the property set |
| pValue | pointer of store PU property value |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.24 APC_GetSensorRegister()

```
int APC_GetSensorRegister (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          int nId,
          unsigned short address,
          unsigned short * pValue,
          int flag,
          int nSensorMode )
```

get value from sensor register

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nld | sensor slave address. see SENSOR_TYPE_NAME enum definition |
| address | register address |
| pValue | pointer of value got from register address |
| flag | address and value data length(2 or 1 byte) ie FG_Address_2Byte FG_Value_2Byte is 2 byte address and 2 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |
| nSensorMode | sensor mode(sensor A, B or Both) A is 0, B is 1, Both is 2 |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.25 APC_GetSlaveHWRegister()

```
int APC_GetSlaveHWRegister (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          unsigned short address,
          unsigned short * pValue,
          int flag )
```

get hardware register value

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| pValue | pointer of value got from register address |
| flag | address and value data length(2 or 1 byte) ie FG_Address_2Byte FG_Value_2Byte is 2 byte address and 2 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.26 APC_GetSlaveLogData()

get log data from flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store log data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify log data for corresponding depth |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.27 APC_GetSlaveSensorRegister()

get value from sensor register

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nld | sensor slave address. see SENSOR_TYPE_NAME enum definition |

Parameters

| address | register address |
|-------------|--|
| pValue | pointer of value got from register address |
| flag | address and value data length(2 or 1 byte) ie FG_Address_2Byte FG_Value_2Byte is 2 byte address and 2 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |
| nSensorMode | sensor mode(sensor A, B or Both) A is 0, B is 1, Both is 2 |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.28 APC_Init()

entry point of eYs3D camera SDK. This API allocates resource and find all the eSPI camera devices connected to the system.

Parameters

| ppHandleApcDI | a pointer of pointer to receive ApcDI SDK instance |
|---------------|---|
| blsLogEnabled | set to true to generate log file, named log.txt in current folder |

Returns

success: none negative integer to indicate numbers of devices found in the system.

5.1.4.29 APC_Init2()

entry point of eYs3D camera SDK. This API allocates resource and find all the eSPI camera devices connected to the system.

| ppHandleApcDI | a pointer of pointer to receive ApcDI SDK instance |
|--------------------|--|
| blsLogEnabled | set to true to generate log file, named log.txt in current folder |
| bEnableAutoRestart | set true to auto-restart the device if the device was detached and attached again. |

Returns

success: none negative integer to indicate numbers of devices found in the system.

Note

Calls APC_Init or APC_Init2 to initilize the ApcDI SDK. APC_Init2 adds the auto-restart function to the initilization options. If you call APC_Init, the bEnableAutoRestart is set as disabled.

5.1.4.30 APC_Is360Device()

check module is spherical device or not

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |

Returns

true: module support 360, false: not support

5.1.4.31 APC_OpenDevice()

```
int APC_OpenDevice (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    int colorStreamIndex,
    int depthStreamIndex,
    int depthStreamSwitch,
    int iFps,
    APC_ImgCallbackFn callbackFn,
    void * pCallbackParam,
    int pid = -1 )
```

open camera device with image callback support

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|------------------|--|
| pDevSelInfo | pointer of device select index |
| colorStreamIndex | index of the desired color stream |
| depthStreamIndex | index of the desired sdepth tream |

Parameters

| depthStreamSwitch | depth switch for S0, S1 or S2 | |
|-------------------|--|---|
| iFps | pointer to the desired frame rate, returns the | e actual frame rate. |
| callbackFn | set image callback function | |
| pCallbackParam | the data to associate with the callback funct | ion |
| pid | Specify device pid. | |
| | Table 5.34 Imaç | ge Control Mode |
| | Mode | Description |
| | 0x01 | color and depth frame output |
| | | synchrously, for depth map module only |
| | 0x02 | enable post-process, for Depth Map |
| | | module only |
| | 0x04 | stitch images if this bit is set, for fisheye |
| | | spherical module only |
| | 0x08 | use OpenCL in stitching. This bit |
| | | effective only when bit-2 is set. |
| | | |
| | | |

Returns

success:APC_OK, others:see eSPDI_ErrCode.h

5.1.4.32 APC_ReadFlashData()

read firmware code(.bin) form flash The firmware code is the combination of boot loader, firmware body and plug-in data. This input buffer length has to match with the flash data type

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|------------------|--|
| pDevSelInfo | pointer of device select index |
| fdt | segment type of flash be read |
| pBuffer | buffer to store firmware code |
| nLengthOfBuffer | input buffer length |
| pActualBufferLen | actual length has written to pBuffer |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.33 APC_RefreshDevice()

refresh all eYs3D UVC devices

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| | |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.34 APC_RegisterDeviceEvents()

```
int APC_RegisterDeviceEvents (
    void * pHandleApcDI,
    APC_DeviceEventFn cbFunc,
    void * pData )
```

Register the USB device plug or unplug events. Any USB capture device attachment or detachment events will call the callback function cbFunc.

Parameters

| pHandleApcDI | a pointer to ApcDI SDK instance |
|--------------|---|
| cbFunc | a callback function of type #APC_DeviceEventFn that will receive USB cappure device events when the device is attached or detached. |
| pData | user defined data which will send to the callback function |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.35 APC_Release()

```
void APC_Release (
     void ** ppHandleApcDI )
```

release all resource that APC_Init had allocated

| ppHandleApcDI | pointer of the pointer to the initilized ApcDI SDK instance. |
|---------------|--|
| 1-1 1 | |

Returns

none

Note

the pointer to ppHandleApcDI will be set to NULL when this call returns successfully.

5.1.4.36 APC_ResetUNPData()

Reset the UNProtection area's datum.

Parameters

| void | *pHandleApcDI CApcDI handler |
|-------------|--|
| PDEVSELINFO | pDevSelInfo pointer of device select index |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.37 APC_SetCTPropVal()

get control terminal property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff5678
85).aspx https://msdn.microsoft.com/en-us/library/windows/hardware/ff566089(v=vs.↔
85).aspx

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nld | specifies the member of the property set |
| nValue | CT property value to set |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.38 APC_SetCurrentIRValue()

set current infrared radiation(IR) value

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |
| wType | value to set |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.39 APC_SetFWRegister()

set firmware register value

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| nValue | register value to set |
| flag | address and value data length(2 or 1 byte) ie FG_Address_1Byte FG_Value_1Byte is 1 byte address and 1 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.40 APC_SetGPIOCtrl()

set GPIO control address

Parameters

| nGPIOIndex | index of GPIO (1 \sim 4) |
|------------|----------------------------|
| nValue | register value to set |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.41 APC_SetGPIOValue()

set GPIO value

Parameters

| pHandleApcDl | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |
| nGPIOIndex | GPIO index, 1 or 2 is valid |
| nValue | GPIO value to set |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.42 APC_SetHuffmanTableData()

set huffman table data for jpeg encode

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| filename | huffman table file, see jh_vga_422.dat sample file |
| bLogFile | if true then puma_htable.dat file is generated |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.43 APC_SetHWRegister()

set hardware register

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| nValue | register value to set |
| flag | address and value data length(2 or 1 byte) ie FG_Address_1Byte FG_Value_1Byte is 1 byte address and 1 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.44 APC_SetIRMaxValue()

set maximum IR value the module support

Parameters

| pHandleApcDl | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| | |
| wType | pointer strors maximum IR value |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.45 APC_SetLogData()

set log data to flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store log data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify log data for corresponding depth |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.46 APC_SetLogData_Advanced()

```
int APC_SetLogData_Advanced (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          BYTE * buffer,
          int BufferLength,
          int * pActualLength,
          int index )
```

set log data to flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store log data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify log data for corresponding depth |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.47 APC_SetPidVid()

set PID and VID to device

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--------------------------------|
| pDevSelInfo | pointer of device select index |
| pPidBuf | 4 byte PID value buffer to set |
| pVidBuf | 4 byte VID value buffer to set |

Returns

success: EtronDI_OK, others: see eSPDI_ErrCode.h

5.1.4.48 APC_SetPUPropVal()

get processing unit property value https://msdn.microsoft.com/en-us/library/windows/hardware/ff5681
85).aspx https://msdn.microsoft.com/en-us/library/windows/hardware/ff566089(v=vs.↔
85).aspx

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| nld | specifies the member of the property set |
| nValue | value to set |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.49 APC_SetQuantizationTableData()

set quantication table data for jpeg encode

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|---|
| pDevSelInfo | pointer of device select index |
| filename | quantization table file, see FS_DEF_010.txt sample file |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.50 APC_SetSensorTypeName()

select which sensor to operate

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|----------------|
| stn | sensor type |

Returns

APC_OK

5.1.4.51 APC_SetSlaveHWRegister()

set hardware register

Parameters

| pHandleApcDI | CApcDI handler |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| address | register address |
| nValue | register value to set |
| flag | address and value data length(2 or 1 byte) ie FG_Address_1Byte FG_Value_1Byte is 1 byte address and 1 byte value #define FG_Address_1Byte 0x01 #define FG_Address_2Byte 0x02 #define FG_Value_1Byte 0x10 #define FG_Value_2Byte 0x20 |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.1.4.52 APC_SetSlaveLogData()

set log data to flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store log data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify log data for corresponding depth |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.1.4.53 APC_SetUserData()

set user data to flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store user data |
| BufferLength | input buffer length |
| usi | which user index data to select |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.2 eSPDI_DM.h File Reference

eYs3D SDK API export functions, data structure and variable definition for depth map module

Functions

• int APC_API APC_GetSlaveYOffset (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

```
get Y offset data
```

int APC_API APC_GetYOffset (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int Buffer ← Length, int *pActualLength, int index)

get Y offset data

• int APC_API APC_GetSlaveRectifyTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

get rectify values from flash

• int APC_API APC_GetRectifyTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

get rectify values from flash

• int APC_API APC_GetZDTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, PZDTABLEINFO pZDTableInfo)

get disparity and Z values from flash

• int APC_API APC_SetSlaveYOffset (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set Y offset data

int APC_API APC_SetYOffset (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int Buffer ← Length, int *pActualLength, int index)

set Y offset data

int APC_API APC_SetYOffset_Advanced (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set Y offset data in both Groups #1 and #2 when the firmware has the flash protection.

• int APC_API APC_SetSlaveRectifyTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set rectify data to flash, see APC_SetRectifyTable except set

• int APC_API APC_SetRectifyTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set rectify data to flash, see APC_SetRectifyTable except set

• int APC_API APC_SetRectifyTable_Advanced (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, int index)

set rectify data to flash, see APC_SetRectifyTable except set

• int APC_API APC_SetZDTable (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, PZDTABLEINFO pZDTableInfo)

set disparity and Z values to flash, see APC_GetZDTable except get

int APC_API APC_SetZDTable_Advanced (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, BYTE *buffer, int BufferLength, int *pActualLength, PZDTABLEINFO pZDTableInfo)

set disparity and Z values to flash, see APC_GetZDTable except get

int APC_API APC_GetRectifyMatLogData (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, eSPCtrl_RectLogData *pData, int index)

get rectify log data from flash for Puma IC

• int APC_API APC_SetDepthDataType (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD wType) set depth data type, 11 bit for disparity data, 14 bit for Z data notice: only PUMA type IC can support this setting

• int APC_API APC_GetDepthDataType (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, WORD *pwType)

get current depth data type setting
• int APC_API APC_SetHWPostProcess (void *pHandleApcDI, PDEVSELINFO pDevSelInfo, bool enable)

enable or disable internal chip post processing function

bool APC_API APC_IsInterleaveDevice (void *pHandleApcDI, PDEVSELINFO pDevSelInfo)

enable or disable interleave function

5.2.1 Detailed Description

eYs3D SDK API export functions, data structure and variable definition for depth map module

Copyright

This file copyright (C) 2017 by eYs3D company

An unpublished work. All rights reserved. This file is proprietary information, and may not be disclosed or copied without the prior permission of eYs3D company.

5.2.2 Function Documentation

5.2.2.1 APC_GetDepthDataType()

get current depth data type setting

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| рwТуре | pointer of current depth data type in device |

Returns

success: APC_OK, others: see eSPDI_ErrCode.h

5.2.2.2 APC GetRectifyMatLogData()

```
int APC_GetRectifyMatLogData (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    eSPCtrl_RectLogData * pData,
    int index )
```

get rectify log data from flash for Puma IC

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|--|
| pDevSelInfo | pointer of device select index |
| pData | rectify log data, its buffer size is 4096 bytes |
| | see eSPCtrl_RectLogData for detailed members |
| index | index to identify rectify log data for corresponding depth |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.2.2.3 APC_GetRectifyTable()

```
APC_GetRectifyTable (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    BYTE * buffer,
    int BufferLength,
    int * pActualLength,
    int index )
```

get rectify values from flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|---|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store rectify table data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify rectify table for corresponding depth |

Returns

```
success:APC_OK, others: see eSPDI_ErrCode.h
```

5.2.2.4 APC_GetSlaveRectifyTable()

```
APC_GetSlaveRectifyTable (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    BYTE * buffer,
    int BufferLength,
    int * pActualLength,
    int index )
```

get rectify values from flash

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|---|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store rectify table data |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| index | index to identify rectify table for corresponding depth |

Returns

```
success:APC_OK, others: see eSPDI_ErrCode.h
```

5.2.2.5 APC_GetSlaveYOffset()

get Y offset data

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store |
| BufferLength | length of buffer |
| pActualLength | actual byte of reading |
| index | index of Y offset file ID |

Returns

```
success:APC_OK, others:see eSPDI_ErrCode.h
```

5.2.2.6 APC_GetYOffset()

```
int BufferLength,
int * pActualLength,
int index )
```

get Y offset data

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance | |
|---------------|--|--|
| pDevSelInfo | pointer of device select index | |
| buffer | buffer to store | |
| BufferLength | length of buffer | |
| pActualLength | actual byte of reading | |
| index | index of Y offset file ID | |

Returns

success:APC_OK, others:see eSPDI_ErrCode.h

5.2.2.7 APC_GetZDTable()

```
int APC_GetZDTable (
    void * pHandleApcDI,
    PDEVSELINFO pDevSelInfo,
    BYTE * buffer,
    int BufferLength,
    int * pActualLength,
    PZDTABLEINFO pZDTableInfo )
```

get disparity and Z values from flash

- 1. if depth data type is APC_DEPTH_DATA_14_BITS then just get Z value from depth buffer
- 2. if depth data type is APC_ZD_TABLE_FILE_SIZE_11_BITS then using depth buffer value as a index to get Z value inside ZD table
- 3. see $\mathsf{GetZValue}()$ of example.c to get Z value from different depth data type

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|---|
| pDevSelInfo | pointer of device select index |
| buffer | bufer to store ZD table |
| BufferLength | input buffer length |
| pActualLength | actual length has written to buffer |
| pZDTableInfo | index to identify ZD table and data type for corrresponding depth |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.2.2.8 APC_IsInterleaveDevice()

enable or disable interleave function

check module support interleave function or not

Parameters

| pHandleApcDI the pointer to the initilized ApcDI SDK instance | |
|---|---|
| pDevSelInfo | pointer of device select index |
| enable | set true to enable interleave, or set false to disable interleave |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance | |
|--------------|--|--|
| pDevSelInfo | pointer of device select index | |

Returns

true: support interleave, false: not support

5.2.2.9 APC_SetDepthDataType()

set depth data type, 11 bit for disparity data, 14 bit for Z data notice: only PUMA type IC can support this setting

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------------------------------|--|
| pDevSelInfo | pointer of device select index |
| <i>wType</i> Generated by Doxygen | depth data type you want to set, see APC_DEPTH_DATA_xxx in APC_O.h \output success: APC_OK, others: see eSPDI_ErrCode.h |

5.2.2.10 APC_SetHWPostProcess()

enable or disable internal chip post processing function

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|--------------|---|
| pDevSelInfo | pointer of device select index |
| enable | set true to enable post-process, or set false to disable post-process |

Returns

```
success: APC_OK, others: see eSPDI_ErrCode.h
```

5.2.2.11 APC_SetSlaveYOffset()

```
int APC_SetSlaveYOffset (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          BYTE * buffer,
          int BufferLength,
          int * pActualLength,
          int index )
```

set Y offset data

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance |
|---------------|--|
| pDevSelInfo | pointer of device select index |
| buffer | buffer to store |
| BufferLength | length of buffer |
| pActualLength | actual byte of reading |
| index | index of Y offset file ID |

Returns

```
success:APC_OK, others:see eSPDI_ErrCode.h
```

5.2.2.12 APC_SetYOffset()

```
int APC_SetYOffset (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          BYTE * buffer,
          int BufferLength,
          int * pActualLength,
          int index )
```

set Y offset data

Parameters

| pHandleApcDI | the pointer to the initilized ApcDI SDK instance | |
|---------------|--|--|
| pDevSelInfo | pointer of device select index | |
| buffer | buffer to store | |
| BufferLength | length of buffer | |
| pActualLength | actual byte of reading | |
| index | index of Y offset file ID | |

Returns

success:APC_OK, others:see eSPDI_ErrCode.h

5.2.2.13 APC_SetYOffset_Advanced()

```
int APC_SetYOffset_Advanced (
          void * pHandleApcDI,
          PDEVSELINFO pDevSelInfo,
          BYTE * buffer,
          int BufferLength,
          int * pActualLength,
          int index )
```

set Y offset data in both Groups #1 and #2 when the firmware has the flash protection.

| void | *pHandleApcDI the pointer to the initilized ApcDI SDK instance |
|-------------|--|
| PDEVSELINFO | pDevSelInfo CApcDI handler |
| BYTE | *buffer buffer to store |
| int | BufferLength length of buffer |
| int | *pActualLength actual byte of reading |
| int | index index of Y offset file ID |

Returns

success:APC_OK, others:see eSPDI_ErrCode.h

5.3 eSPDI_ErrCode.h File Reference

definition of eYs3D SDK error code Copyright: This file copyright (C) 2017 by

5.3.1 Detailed Description

definition of eYs3D SDK error code Copyright: This file copyright (C) 2017 by

eYs3D company

An unpublished work. All rights reserved.

This file is proprietary information, and may not be disclosed or copied without the prior permission of eYs3D company.

Index

| APC_CloseDevice | eSPDI_Common.h, 33 |
|-----------------------------|----------------------------|
| eSPDI_Common.h, 23 | APC_GetRectifyMatLogData |
| APC_DEVICE_TYPE | eSPDI DM.h, 51 |
| eSPDI_Common.h, 22 | APC_GetRectifyTable |
| APC DisableAE | eSPDI_DM.h, 52 |
| eSPDI_Common.h, 23 | APC GetSensorRegister |
| APC DisableAWB | eSPDI_Common.h, 33 |
| eSPDI_Common.h, 24 | APC_GetSlaveHWRegister |
| APC EnableAE | eSPDI_Common.h, 34 |
| eSPDI_Common.h, 24 | APC_GetSlaveLogData |
| APC EnableAWB | eSPDI Common.h, 35 |
| eSPDI_Common.h, 24 | APC_GetSlaveRectifyTable |
| APC_EnableGPUAcceleration | eSPDI_DM.h, 52 |
| eSPDI_Common.h, 25 | APC_GetSlaveSensorRegister |
| APC FindDevice | eSPDI_Common.h, 35 |
| eSPDI_Common.h, 25 | APC_GetSlaveYOffset |
| APC_GetCTPropVal | eSPDI DM.h, 53 |
| eSPDI_Common.h, 25 | APC GetYOffset |
| APC GetCurrentIRValue | eSPDI_DM.h, 53 |
| eSPDI Common.h, 26 | APC GetZDTable |
| APC_GetDepthDataType | eSPDI_DM.h, 54 |
| eSPDI_DM.h, 51 | APC_Init |
| APC_GetDepthFilterVersion | eSPDI_Common.h, 36 |
| eSPDI_Common.h, 27 | APC_Init2 |
| APC GetDeviceNumber | eSPDI_Common.h, 36 |
| eSPDI_Common.h, 27 | APC Is360Device |
| APC GetDeviceResolutionList | eSPDI_Common.h, 37 |
| eSPDI_Common.h, 27 | APC IsInterleaveDevice |
| APC_GetFlexibleGyroData | eSPDI DM.h, 55 |
| eSPDI_Common.h, 28 | APC_OpenDevice |
| APC_GetFlexibleGyroLength | eSPDI Common.h, 37 |
| eSPDI_Common.h, 28 | APC_ReadFlashData |
| APC_GetFWRegister | eSPDI_Common.h, 38 |
| eSPDI_Common.h, 29 | APC_RefreshDevice |
| APC GetFwVersion | eSPDI_Common.h, 38 |
| eSPDI_Common.h, 29 | APC_RegisterDeviceEvents |
| APC GetGPIOValue | eSPDI_Common.h, 39 |
| _ | |
| eSPDI_Common.h, 30 | APC_Release |
| APC_GetHWRegister | eSPDI_Common.h, 39 |
| eSPDI_Common.h, 30 | APC_ResetUNPData |
| APC_GetIRMaxValue | eSPDI_Common.h, 40 |
| eSPDI_Common.h, 31 | APC_SENSOR_TYPE_AR0134 |
| APC_GetIRMinValue | eSPDI_Common.h, 22 |
| eSPDI_Common.h, 31 | APC_SENSOR_TYPE_AR013 |
| APC_GetLogData | eSPDI_Common.h, 22 |
| eSPDI_Common.h, 32 | APC_SENSOR_TYPE_AR0144 |
| APC_GetPidVid | eSPDI_Common.h, 22 |
| eSPDI_Common.h, 32 | APC_SENSOR_TYPE_AR0330 |
| APC_GetPUPropVal | eSPDI_Common.h, 22 |

60 INDEX

| APC_SENSOR_TYPE_AR1335 | DEVINFORMATIONEX, 9 |
|--------------------------------------|--|
| eSPDI_Common.h, 22 | nChipID, 9 |
| APC_SENSOR_TYPE_H22 | nDevType, 9 |
| eSPDI_Common.h, 22 | strDevName, 9 |
| APC_SENSOR_TYPE_OV7740 | wPID, 10 |
| eSPDI_Common.h, 22 | wUsbNode, 10 |
| APC_SENSOR_TYPE_OV9282 | wVID, 10 |
| eSPDI_Common.h, 22 | |
| APC_SENSOR_TYPE_OV9714 | eSPCtrl_RectLogData, 10 |
| eSPDI Common.h, 22 | eSPDI_Common.h, 21 |
| APC_SetCTPropVal | eSPDI_Common.h, 17 |
| eSPDI_Common.h, 40 | APC_CloseDevice, 23 |
| APC_SetCurrentIRValue | APC_DEVICE_TYPE, 22 |
| eSPDI_Common.h, 41 | APC_DisableAE, 23 |
| APC_SetDepthDataType | APC_DisableAWB, 24 |
| eSPDI_DM.h, 55 | APC_EnableAE, 24 |
| APC_SetFWRegister | APC_EnableAWB, 24 |
| eSPDI_Common.h, 41 | APC_EnableGPUAcceleration, 25 |
| APC SetGPIOCtrl | APC_FindDevice, 25 |
| eSPDI_Common.h, 42 | APC_GetCTPropVal, 25 |
| APC SetGPIOValue | APC_GetCurrentIRValue, 26 |
| eSPDI_Common.h, 42 | APC_GetDepthFilterVersion, 27 |
| APC_SetHuffmanTableData | APC GetDeviceNumber, 27 |
| eSPDI Common.h, 42 | APC_GetDeviceResolutionList, 27 |
| APC_SetHWPostProcess | APC_GetFlexibleGyroData, 28 |
| eSPDI_DM.h, 56 | APC_GetFlexibleGyroLength, 28 |
| APC_SetHWRegister | APC_GetFWRegister, 29 |
| eSPDI_Common.h, 43 | APC_GetFwVersion, 29 |
| APC_SetIRMaxValue | APC_GetGPIOValue, 30 |
| | APC_GetHWRegister, 30 |
| eSPDI_Common.h, 43 | APC GetIRMaxValue, 31 |
| APC_SetLogData eSPDI_Common.h, 44 | APC GetIRMinValue, 31 |
| APC_SetLogData_Advanced | APC_GetLogData, 32 |
| eSPDI Common.h, 44 | APC GetPidVid, 32 |
| APC_SetPidVid | APC_GetPUPropVal, 33 |
| | APC_GetSensorRegister, 33 |
| eSPDI_Common.h, 45 | APC_GetSlaveHWRegister, 34 |
| APC_SetPUPropVal | APC_GetSlaveLogData, 35 |
| eSPDI_Common.h, 45 | APC_GetSlaveSensorRegister, 35 |
| APC_SetQuantizationTableData | APC Init, 36 |
| eSPDI_Common.h, 46 | APC_Init2, 36 |
| APC_SetSensorTypeName | APC_Is360Device, 37 |
| eSPDI_Common.h, 46 | APC_OpenDevice, 37 |
| APC_SetSlaveHWRegister | APC ReadFlashData, 38 |
| eSPDI_Common.h, 48 | APC_RefreshDevice, 38 |
| APC_SetSlaveLogData | APC RegisterDeviceEvents, 39 |
| eSPDI_Common.h, 48 | APC Release, 39 |
| APC_SetSlaveYOffset | APC ResetUNPData, 40 |
| eSPDI_DM.h, 56 | APC_SENSOR_TYPE_AR0134, 22 |
| APC_SetUserData | APC_SENSOR_TYPE_AR0135, 22 |
| eSPDI_Common.h, 49 | APC_SENSOR_TYPE_AR0144, 22 |
| APC_SetYOffset | APC_SENSOR_TYPE_AR0330, 22 |
| eSPDI_DM.h, 56 | APC SENSOR TYPE AR1335, 22 |
| APC_SetYOffset_Advanced | APC_SENSOR_TYPE_H22, 22 |
| eSPDI_DM.h, 57 | APC_SENSOR_TYPE_0V7740, 22 |
| AXES1 | APC_SENSOR_TYPE_OV9282, 22 |
| eSPDI_Common.h, 22 | APC_SENSOR_TYPE_OV9262, 22 APC_SENSOR_TYPE_OV9714, 22 |
| DEVINFORMATION | APC_SetCTPropVal, 40 |
| | · |
| eSPDI_Common.h, 21 | APC_SetCurrentIRValue, 41 |

INDEX 61

| APC_SetFWRegister, 41 | eSPDI_Common.h, 22 |
|----------------------------------|------------------------|
| APC_SetGPIOCtrl, 42 | |
| APC_SetGPIOValue, 42 | PARALUT |
| APC_SetHuffmanTableData, 42 | eSPDI_Common.h, 21 |
| APC_SetHWRegister, 43 | ParaLUT, 11 |
| APC SetIRMaxValue, 43 | PUMA |
| APC_SetLogData, 44 | eSPDI_Common.h, 22 |
| APC_SetLogData_Advanced, 44 | |
| APC SetPidVid, 45 | SENSOR_TYPE_NAME |
| APC SetPUPropVal, 45 | eSPDI_Common.h, 22 |
| APC SetQuantizationTableData, 46 | strDevName |
| APC_SetSensorTypeName, 46 | DEVINFORMATIONEX, 9 |
| APC_SetSlaveHWRegister, 48 | tagDEVINFORMATION, 14 |
| APC_SetSlaveLogData, 48 | |
| APC_SetUserData, 49 | tagDEVINFORMATION, 13 |
| AXES1, 22 | nChipID, 14 |
| DEVINFORMATION, 21 | nDevType, 14 |
| eSPCtrl_RectLogData, 21 | strDevName, 14 |
| OTHERS, 22 | wPID, 14 |
| | wUsbNode, 15 |
| PARALUT, 21 PUMA. 22 | wVID, 15 |
| - , | |
| SENSOR_TYPE_NAME, 22 | USERDATA_SECTION_0 |
| USERDATA_SECTION_0, 22 | eSPDI_Common.h, 22 |
| USERDATA_SECTION_1, 22 | USERDATA_SECTION_1 |
| USERDATA_SECTION_10, 23 | eSPDI_Common.h, 22 |
| USERDATA_SECTION_2, 22 | USERDATA_SECTION_10 |
| USERDATA_SECTION_3, 22 | eSPDI_Common.h, 23 |
| USERDATA_SECTION_4, 22 | USERDATA_SECTION_2 |
| USERDATA_SECTION_5, 23 | eSPDI_Common.h, 22 |
| USERDATA_SECTION_6, 23 | USERDATA_SECTION_3 |
| USERDATA_SECTION_7, 23 | eSPDI_Common.h, 22 |
| USERDATA_SECTION_8, 23 | USERDATA_SECTION_4 |
| USERDATA_SECTION_9, 23 | eSPDI_Common.h, 22 |
| USERDATA_SECTION_INDEX, 22 | USERDATA SECTION 5 |
| USERDATA_SECTION_NUM, 23 | eSPDI_Common.h, 23 |
| eSPDI_DM.h, 49 | USERDATA SECTION 6 |
| APC_GetDepthDataType, 51 | eSPDI Common.h, 23 |
| APC_GetRectifyMatLogData, 51 | USERDATA SECTION 7 |
| APC_GetRectifyTable, 52 | eSPDI Common.h, 23 |
| APC_GetSlaveRectifyTable, 52 | USERDATA SECTION 8 |
| APC_GetSlaveYOffset, 53 | eSPDI Common.h, 23 |
| APC_GetYOffset, 53 | USERDATA SECTION 9 |
| APC_GetZDTable, 54 | eSPDI Common.h, 23 |
| APC_IsInterleaveDevice, 55 | USERDATA SECTION INDEX |
| APC_SetDepthDataType, 55 | eSPDI Common.h, 22 |
| APC SetHWPostProcess, 56 | USERDATA SECTION NUM |
| APC_SetSlaveYOffset, 56 | |
| APC SetYOffset, 56 | eSPDI_Common.h, 23 |
| APC_SetYOffset_Advanced, 57 | wPID |
| eSPDI ErrCode.h, 58 | DEVINFORMATIONEX, 10 |
| | tagDEVINFORMATION, 14 |
| nChipID | |
| DEVINFORMATIONEX, 9 | wUsbNode |
| tagDEVINFORMATION, 14 | DEVINFORMATIONEX, 10 |
| nDevType | tagDEVINFORMATION, 15 |
| DEVINFORMATIONEX, 9 | WVID |
| tagDEVINFORMATION, 14 | DEVINFORMATIONEX, 10 |
| | tagDEVINFORMATION, 15 |
| | |