# Module Interface Specification for Measuring Microstructure Changes During Thermal Treatment

Team #30, ReSprint
Edwin Do
Joseph Braun
Timothy Chen
Abdul Nour Seddiki
Tyler Magarelli

 $January\ 18,\ 2023$ 

# 1 Revision History

Date	Name	Notes
Jan 17, 2023	Timothy Chen	Added Modules to Module Decomposition
Jan 18, 2023	Timothy Chen	Added Current State Module
Jan 18, 2023	Timothy Chen	Added File Output Module
Jan 18, 2023	Timothy Chen	Added Graphical Output Module

## 2 Symbols, Abbreviations and Acronyms

See SRS Documentation at [give url —SS] [Also add any additional symbols, abbreviations or acronyms —SS]

## Contents

1	Rev	ision F	listory							
2	Symbols, Abbreviations and Acronyms									
3	Introduction									
4	Not	ation								
5	Mo	dule D	ecomposition							
6	MIS	MIS of Current State Module								
	6.1	Modul	le							
	6.2	Uses								
		6.2.1	Imported Types							
		6.2.2	Imported Access Programs							
	6.3	•	<u> </u>							
		6.3.1	Exported Constants							
		6.3.2	Exported Access Programs							
	6.4	Seman								
		6.4.1	State Variables							
		6.4.2	State Invariant							
		6.4.3	Environment Variables							
		6.4.4	Assumptions							
		6.4.5	Access Routine Semantics							
		6.4.6	Local Functions	•						
7			leOutput Module							
	7.1		e							
	7.2									
		7.2.1	Imported Types							
	7.9	7.2.2	Imported Access Programs							
	7.3	•	E-marked Constants							
			Exported Constants							
	7.4	7.3.2	Exported Access Programs							
	7.4		State Verichles							
		7.4.1	State Variables							
		7.4.2	State Invariant							
		7.4.3	Environment Variables							
		7.4.4	Assumptions							
		7.4.5								
		7.4.6	Local Functions							

8	MIS of Graphical Output Module				
	8.1	Modul	e	,	
	8.2	Uses		,	
		8.2.1	Imported Types	,	
		8.2.2	Imported Access Programs	,	
	8.3	Syntax	α	,	
		8.3.1	Exported Constants	,	
		8.3.2	Exported Access Programs	,	
	8.4	Seman	tics	,	
		8.4.1	State Variables	,	
		8.4.2	State Invariant	,	
		8.4.3	Environment Variables	,	
		8.4.4	Assumptions	6	
		8.4.5	Access Routine Semantics	8	
		8.4.6	Local Functions	8	
9	App	oendix		10	

## 3 Introduction

The following document details the Module Interface Specifications for [Fill in your project name and description—SS]

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at .... [provide the url for your repo —SS]

## 4 Notation

[You should describe your notation. You can use what is below as a starting point. —SS]

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form  $(c_1 \Rightarrow r_1 | c_2 \Rightarrow r_2 | ... | c_n \Rightarrow r_n)$ .

The following table summarizes the primitive data types used by Measuring Microstructure Changes During Thermal Treatment.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	$\mathbb{Z}$	a number without a fractional component in $(-\infty, \infty)$
natural number	N	a number without a fractional component in $[1, \infty)$
real	$\mathbb{R}$	any number in $(-\infty, \infty)$

The specification of Measuring Microstructure Changes During Thermal Treatment uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, Measuring Microstructure Changes During Thermal Treatment uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

## 5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1 Level 2				
Hardware-Hiding				
	Input Communication Module			
	Output Communication Module			
	Remote Access Module			
Behaviour-Hiding	Current State Module			
	FileOutput Module			
	Graphical Output Module			
	Calculation Module			
Software Decision	User Input Validation Module			
	Hardware Input Validation Module			

Table 1: Module Hierarchy

## 6 MIS of Current State Module

#### 6.1 Module

Current State Module

#### 6.2 Uses

#### 6.2.1 Imported Types

 ${\bf Hardware Input:}\ (\ Voltage: real\ ;\ Time: real;\ Temperature: real;\ Current: real\ )$ 

 $\label{thm:continuity} \textbf{UserInput:} \ (\ Sampling Rate: real; Sample Lengthgth: real; Sample Width: real; Filename: real; Sample Vidth: real; Filename: real; F$ 

string; Name: string; SampleName: string; Date: string)

#### 6.2.2 Imported Access Programs

GetUserInput(): UserInput

GetHardwareInput(): HardwareInput

## 6.3 Syntax

#### 6.3.1 Exported Constants

N/A

#### 6.3.2 Exported Access Programs

Name	In	Out	Exceptions
StateInit()			
DisplayUserInfo()	string, string, string, string,		INVALID
	real, real, real		
DisplayHardwareState()	real, real, real		INVALID

#### 6.4 Semantics

#### 6.4.1 State Variables

N/A

#### 6.4.2 State Invariant

#### 6.4.3 Environment Variables

ApplicationWindow: the screen inferface where the information displayed to the user

#### 6.4.4 Assumptions

StateInit() is called before any other access program

#### 6.4.5 Access Routine Semantics

StateInit():

• transition: State Display is initialized on ApplicationWindow

• exception: none

DisplayUserInfo(Name, SampleName, Date, Filename, SamplingRate, SampleLength, SampleWidth):

- transition: Display Name, SampleName Date, Filename, SamplingRate, SampleLength, and SampleWidth on the ApplicationWindow
- exception:  $exc := SamplingRate \notin \mathbb{R} \vee SamplingRate < 0 \vee SampleLength \notin \mathbb{R} \vee SampleLength < 0 \vee SampleWidth \notin \mathbb{R} \vee SampleWidth < 0 \Rightarrow INVALID$

DisplayHardwareState(Voltage, Current, Time, Temperature):

- transition: Display Voltage, Current, and Time on the ApplicationWindow
- exception:  $exc := Voltage \notin \mathbb{R} \lor Voltage < 0 \lor Current \notin \mathbb{R} \lor Current < 0 \lor Time \notin \mathbb{R} \lor Time < 0 \lor Temperature \notin \mathbb{R} \Rightarrow INVALID$

#### 6.4.6 Local Functions

## 7 MIS of FileOutput Module

#### 7.1 Module

FileOutput Module

#### 7.2 Uses

#### 7.2.1 Imported Types

HardwareInput: ( Voltage : real ; Time : real; Temperature : real; Current : real )
UserInput: ( SamplingRate : real; SampleLength : real; SampleWidth : real; Filename : string Name : string; SampleName : string; Date : string)

### 7.2.2 Imported Access Programs

GetResistivity(): Real GetResistance(): Real GetUserInput(): UserInput

GetHardwareInput(): HardwareInput

## 7.3 Syntax

## 7.3.1 Exported Constants

N/A

#### 7.3.2 Exported Access Programs

Name	In	Out	Exceptions
FileInit()			
WriteUserInput()	string, string, string, real real,		INVALID
	real		
Write Sample Output ()	real, real, real, real, real	record	INVALID

#### 7.4 Semantics

#### 7.4.1 State Variables

N/A

#### 7.4.2 State Invariant

#### 7.4.3 Environment Variables

OutputFile: a file used to store data such as the user inputs and hardware outputs

#### 7.4.4 Assumptions

FileInit() is called before any other access program.

#### 7.4.5 Access Routine Semantics

FileInit():

• transition: Initializes an empty file

• exception: none

WriteUserInput(Name, SampleName, Date, SamplingRate, SampleLength, SampleWidth):

- transition: Write user input into the first line of the OutputFile
- exception:  $exc := SamplingRate \notin \mathbb{R} \vee SamplingRate < 0 \vee SampleLength \notin \mathbb{R} \vee SampleLength < 0 | lorSampleWidth \notin \mathbb{R} \vee SampleWidth < 0 \Rightarrow INVALID$

WriteSampleOutput(Time, Temperature, Voltage, Current, Resistance, Resistivity):

- transition: Write each data set into the OutputFile at each time interval
- exception:  $exc := Time \notin \mathbb{R} \lor Time < 0 \lor Temperature \notin \mathbb{R} \lor Voltage < 0 \lor Voltage \notin \mathbb{R} \lor Current < 0 \lor Current \notin \mathbb{R} \lor Resistance < 0 \lor Resistance \notin \mathbb{R} \lor Resistivity < 0 \lor Resistance \notin \mathbb{R} \lor Resistivity < 0 \Rightarrow INVALID$

#### 7.4.6 Local Functions

## 8 MIS of Graphical Output Module

## 8.1 Module

File Output Module

#### 8.2 Uses

### 8.2.1 Imported Types

HardwareInput: (Voltage: real; Time: real; Temperature: real; Current: real)

#### 8.2.2 Imported Access Programs

GetResistivity(): Real GetResistance(): Real GetHardwareInput(): HardwareInput

## 8.3 Syntax

#### 8.3.1 Exported Constants

### 8.3.2 Exported Access Programs

Name	In	Out	Exceptions
GraphInit()			
GraphTimeVResistance()	real, real		INVALID
GraphTimeVResistivity()	real, real		INVALID
GraphVoltageVResistence()	real, real		INVALID
GraphVoltageVResistivity()	real, real		INVALID
GraphTemperatureVResistence()	real, real		INVALID
GraphTemperatureVResistivity()	real, real		INVALID

#### 8.4 Semantics

#### 8.4.1 State Variables

N/A

#### 8.4.2 State Invariant

N/A

#### 8.4.3 Environment Variables

ApplicationWindow: the screen inferface where the information displayed to the user

#### 8.4.4 Assumptions

GraphInit() is called before any other access program

#### 8.4.5 Access Routine Semantics

#### GraphInit():

- transition: Graph is initialized on ApplicationWindow
- exception: none

GraphTimeVResistance(Time, Resistance):

- transition: Disaply graph of Time versus Resistance on ApplicationWindow
- exception:  $exc := Time \notin \mathbb{R} \lor Time < 0 \lor Resistance \notin \mathbb{R} \lor Resistance < 0 \Rightarrow INVALID$

GraphTimeVResistivity(Time, Resistivity):

- transition: Display graph of Time versus Resistivity on ApplicationWindow
- exception:  $exc := Time \notin \mathbb{R} \lor Time < 0 \lor Resistivity \notin \mathbb{R} \lor Resistivity < 0 \Rightarrow INVALID$

GraphVoltageVResistance(Voltage, Resistance):

- transition: Display graph of Voltage versus Resistance on ApplicationWindow
- exception:  $exc := Voltage \notin \mathbb{R} \lor Voltage < 0 \lor Resistance \notin \mathbb{R} \lor Resistance < 0 \Rightarrow INVALID$

GraphVoltageVResistivity(Voltage, Resistivity):

- transition: Display graph of Voltage versus Resistivity on ApplicationWindow
- exception:  $exc := Voltage \notin \mathbb{R} \lor Voltage < 0 \lor Resistivity \notin \mathbb{R} \lor Resistivity < 0 \Rightarrow INVALID$

GraphTemperatureVResistance(Temperature, Resistance):

- transition: Display graph of Temperature versus Resistance on ApplicationWindow
- exception:  $exc := Temperature \notin \mathbb{R} \lor Resistance \notin \mathbb{R} \lor Resistance < 0 \Rightarrow INVALID$ GraphTemperatureVResistivity(Temperature, Resistivity):
  - transition: Display graph of Temperature versus Resistivity on ApplicationWindow
  - exception:  $exc := Temperature \notin \mathbb{R} < Resistivity \notin \mathbb{R} \lor Resistivity < 0 \Rightarrow INVALID$

#### 8.4.6 Local Functions

## References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. Fundamentals of Software Engineering. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. Software Design, Automated Testing, and Maintenance: A Practical Approach. International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.

# 9 Appendix

 $[{\bf Extra~information~if~required~-\!SS}]$