



A Guide to Interiors That Endure

A considered guide to the finishes, materials, and decisions that define spaces of lasting distinction.

EPASERO CONTRACTING

We Design the Feeling of Live

On the Nature of a Well-Considered Interior

Every surface you commission, from the particular grain of your flooring to the undertone held within your wall colour and the temperature of light falling across a room at dusk, determines not merely how a space appears, but how it is experienced. These are not decorative choices. They are architectural ones, and they deserve the same rigour.

What follows draws on decades of work inside some of the most demanding residential projects in the region. It is not a survey of trends. Trends, by their nature, expire. This is a distillation of principles that have proven durable across generations of design: the kind of knowledge that separates a space that photographs beautifully from one that is genuinely extraordinary to inhabit.

We offer it as a reference, and as an invitation to bring the same care to your own project that we bring to every commission we undertake.

Colour: The Discipline Behind the Instinct

Colour is the most immediate and most misread instrument available to the interior. Applied with understanding, it can expand a room beyond its physical boundaries, draw warmth from light that would otherwise feel cold, and create a sense of repose that no amount of furniture or decoration can manufacture. Applied carelessly, it undermines everything else.

The difficulty is that colour does not behave in isolation. It responds to the quality of light in the room, to the undertones of adjacent surfaces, and to the reflective properties of the materials surrounding it. A choice that appears resolved in the showroom can reveal itself as something altogether different once the room takes its final form. Understanding why this happens is what separates confident, lasting decisions from ones that require revisiting.

The Truth About Undertones

Every colour, however neutral its surface character, carries a secondary undertone that the light in your specific room will either amplify or suppress. A white that presents as crisp and unimpeachable on the chip will frequently shift to a discernible green in a north-facing room, or develop a blush quality under the warmth of tungsten-equivalent light. Greige, the tonal family that has defined a decade of refined interiors, can oscillate between purple and ochre depending on the fixed finishes that surround it.

The diagnostic that decorators of the highest calibre use is simple: hold the chip against a sheet of pure white paper. The colour that emerges at the edges is the undertone your room will amplify. That is the colour you are truly committing to, not the surface impression you first encountered.

Light as a Material

North-facing rooms receive only reflected, diffused light, a quality that renders cool undertones more pronounced and quietly defeats warm ones. If warmth is your intention in such a room, select considerably warmer than intuition suggests. A tone that reads as burnished honey under direct light will read as pale stone on a north-facing wall.

South-facing rooms are more generous: the light is direct, flattering, and consistent in its warmth. East-facing rooms present a more nuanced challenge, flooding with a blue-white clarity in the morning before deepening toward amber as the afternoon arrives. A colour that works in one mood must work in the other.

Artificial light is the dimension most frequently overlooked. Warm-spectrum LED sources below 2700K intensify warm undertones and render cool hues muddy. Sources above 3500K produce the reverse effect. No colour decision can be considered final until it has been assessed under the precise light source, at the precise Kelvin, that will illuminate the finished room.

Principles That Endure

- Assess colour on the wall itself, in a patch of at least 30 centimetres square, under morning light, afternoon light, and full artificial illumination
- The 60-30-10 proportion: dominant tone across 60% of the room's surfaces, a secondary across 30%, an accent at 10%, a discipline as applicable to the most considered interiors as to any other
- Cool undertones recede, lending a room the quality of greater volume; warm undertones advance, drawing a space inward and lending it intimacy
- A ceiling treated in the same tone as the walls, but lifted two LRV points, adds the perception of height without introducing a discordant break
- A single wall taken to depth, rendered in a true dark, gives a room a sense of architecture that paint on all four walls cannot achieve; the three remaining walls must remain light for the device to read correctly
- In open-plan volumes, allow colour to shift gradually across zones rather than changing at thresholds; abrupt transitions read as a failure of nerve and fracture spatial continuity
- Satin and eggshell sheens amplify undertones more aggressively than dead flat; always assess the exact finish you intend to specify, not a variant of it

A NOTE ON THE COLOUR CHIP

- The industry standard chip is designed to be read quickly, not accurately. The smaller the sample, the more readily the eye compensates for undertone, producing a false impression of neutrality. Request a sample no smaller than A5 before committing to any colour for a principal surface.
- When two shades appear indistinguishable on the chip, they will not appear so on the wall. The one that is fractionally warmer will read as dramatically different once the room's existing tones interact with it. Choose decisively, and commit.
- In any doubt between two values of the same tone, select the lighter. Depth and richness can always be introduced through textiles, material, and furniture. Repainting is a disruption that precision avoids entirely.

Flooring: Where Architecture Meets the Ground

Flooring is the largest continuous surface in any residence and, by consequence, the decision with the greatest capacity to elevate or diminish every element above it. It anchors the furniture, absorbs or reflects sound, and establishes the material language to which everything else must respond. It is also, in the most literal sense, an engineering choice, governed by what lies beneath, how the building moves with the seasons, and what the climate demands.

Projects that compromise on flooring consistently reveal themselves. No quantity of exceptional furniture, considered lighting, or refined wall treatment can fully compensate for a floor that is inadequate in material, in installation, or in its relationship to the space it occupies.

The Substrate: Where Integrity Begins

The substrate is the element design guides neglect and the source of the most costly remediation work. Any timber flooring, whether solid or engineered, demands a surface deviation of no more than three millimetres across any span of 1.8 metres. Exceed this tolerance and the floor will creak at the joints, lift at the perimeters, or cup across its width. The substrate must be assessed and corrected before a single board is committed. This is not a contingency; it is a prerequisite.

Moisture presents the more insidious threat. A concrete slab that presents as dry to the eye continues to release vapour for years post-construction. Without an appropriate vapour barrier, that moisture travels into the timber and begins its work invisibly. Solid hardwood should never be laid directly onto concrete under any circumstance; engineered construction, with its cross-laminated core, offers the dimensional stability that this subfloor demands.

Seasonal Movement: Understanding a Living Material

Timber is hygroscopic: it draws moisture from the surrounding air in summer and releases it in the drier atmosphere of a heated interior in winter. A floor in a well-appointed, climate-controlled residence will show hairline separations between boards in the winter months that close entirely as summer returns. This is not a defect. It is the behaviour of a natural material, and it is the reason that the expansion gap at the room's perimeter, a minimum of ten millimetres dressed by the skirting board, is not a detail but a structural provision. Eliminate it and the floor will have no recourse but to rise.

Wider boards express this movement more visibly than narrow ones: a 200mm plank will move appreciably more across a year than a 90mm plank. For residences where stability across all seasons is paramount, engineered oak in the 150 to 190mm width range represents the considered professional specification.

Principles of Enduring Specification

- Wider boards extend the visual scale of a room; 150mm and above is the minimum to consider in generous open-plan volumes
- Hardwood should run parallel to the longest axis of the room, both for visual continuity and for structural logic at the joins
- Underfloor heating demands engineered construction, not solid; confirm the manufacturer's maximum surface temperature before committing to any species
- Large-format tile, at 600mm and above, reads as inherently more refined, reducing the visual noise of grout lines and allowing the material to speak for itself
- Herringbone and chevron patterns reward the spaces they occupy with an architectural quality impossible to achieve through any other means; allow for fifteen to twenty percent additional material to account for the cut
- In multi-storey residences, the underlay governs acoustic performance; specifying the finish first and the underlay as an afterthought invariably produces an inadequate result
- Polished concrete sealed with a penetrating treatment is, in practical terms, indestructible; avoid topical coatings, which abrade and demand periodic reapplication
- Rectified large-format porcelain, laser-cut to precise tolerances, is the only specification that achieves the minimal grout lines that allow this material to realise its full potential

Materials of Distinction

Solid Oak Hardwood

PRINCIPAL ROOMS |
BEDROOMS

The enduring benchmark of premium residential flooring. Solid oak offers a warmth and depth that no composite material has yet equalled, and the capacity to be refinished across generations of use. Its application demands a level, moisture-assessed subfloor and a controlled interior climate. It is not a floor for concrete substrates or spaces with underfloor heating, but in the rooms for which it is suited, nothing surpasses it.

Engineered Oak

THROUGHOUT | OVER
RADIANT SYSTEMS

A cross-laminated birch core with a genuine oak wear layer bonded above. Dimensionally stable under the conditions that would compromise solid timber, including concrete substrates and underfloor heating, and indistinguishable in finish and character from its solid counterpart. A wear layer of six millimetres permits two to three refinishes across a lifetime. The considered specification for whole-home renovations and contemporary extensions.

Calacatta Marble

BATHROOMS | ENTRANCE
HALLS

No two pieces of Calacatta marble are alike. The veining, bold, directional, and impossible to replicate, ensures that every surface laid in this material is singular. It demands a penetrating stone sealer on installation and maintenance every twelve to twenty-four months. Specify a matching or near-matching grout to preserve the visual continuity of the surface. In areas of sustained traffic, honed finishes conceal wear more gracefully than polished.

Polished Concrete

OPEN PLAN | EXTENSIONS |
BASEMENTS

A material of industrial origin that has earned its place in the most considered contemporary interiors. Seamless, cooling, and of a visual weight that grounds even the most voluminous spaces. Pairs with particular distinction alongside radiant underfloor heating. When properly treated with a penetrating sealer, it requires essentially no maintenance and will not fail. Its limitations are thermal and acoustic, felt underfoot and in the absence of sound absorption, both answered by the considered placement of rugs and textiles.

Large Format Porcelain

KITCHENS | BATHROOMS |
WET ROOMS

Advances in ceramic manufacture have produced porcelain tiles of extraordinary verisimilitude: materials that replicate the character of stone, concrete, and timber without their demands. For wet rooms, an anti-slip classification of R10 or above is the minimum defensible specification. Rectified large format, 800x800 or 1200x600, with minimal grout joints is the consistent choice in premium kitchen and bathroom commissions.

Lighting: The Architecture You Cannot See

Light is the one element in an interior that cannot be added retrospectively without consequence. Every other decision, the floor, the walls, the joinery, can be revised, replaced, or refined after the fact. Light, if it is to work at the level that an interior of genuine ambition demands, must be conceived at the same stage as the structural drawings. Commission it after the walls are closed and you have already accepted a ceiling on what the space can become.

The prevailing failure in residential lighting is one of category: it is treated as an electrical decision, assigned to a contractor at the point of specification, and resolved by the path of least resistance: a grid of downlights on a single circuit. The result functions. It does not inspire.

The Fourth Layer

Lighting is conventionally described in three layers: ambient, task, and accent. These are necessary but insufficient. The spaces that consistently produce a visceral response in those who inhabit them carry a fourth layer: architectural light.

Architectural light is not a fitting. It is an integration. It lives in the ceiling cove that washes upward across the plaster, in the linear element concealed within the shelf reveal, in the strip at floor level that gives the impression of the floor plane floating free of the wall. It costs no more than a conventional approach when planned at the right moment. Planned retrospectively, it frequently cannot be achieved at all.

Six Principles of Exceptional Illumination

01

Layer with Intention

Ambient light establishes the room. Task light enables it. Accent light gives it character. Architectural light elevates it. A space governed by a single source, however well-chosen, cannot achieve the range of mood that a layered scheme makes possible. The ability to extinguish one layer while retaining another is what transforms a room from functional to restorative.

02

Colour Temperature Is a Design Decision

2700 to 3000 Kelvin produces the warm, enveloping quality suited to principal living rooms, dining rooms, and bedrooms. 3500 to 4000 Kelvin serves the precision required in kitchens and studies. Mixing these temperatures within a single open-plan volume creates a dissonance that the eye registers as something unresolved, even when the precise cause cannot be named. Commit to one register throughout any continuous space.

03

Control Is as Important as the Fitting

The capacity to moderate intensity is what gives a lighting scheme its expressive range. Every circuit deserves a dimmer, and each circuit should operate independently. A pendant circuit, a downlight circuit, a wall-light circuit, each capable of being set and held at a different level. This is not an extravagance. It is the most cost-effective means of multiplying the number of distinct atmospheres a room can inhabit.

04

Precision in Placement

A recessed downlight positioned too close to the wall does not illuminate it; it scallops it, producing a series of curved shadows that immediately reads as unplanned. Six hundred millimetres from the wall surface is the minimum that avoids this. Centres between fittings should approximate 1.2 times the ceiling height. A room of 2.4 metres suggests fittings at roughly 2.9 metres apart, substantially fewer than most installers propose. Restraint in quantity consistently produces a more resolved result.

05

The Pendant as Focal Point

A pendant above a dining table should be positioned between 700 and 800 millimetres above the surface; above a kitchen island, 900 millimetres. This is the fitting that declares the design intention of a room most directly. It should be selected with the confidence that it deserves: in a generous volume, a pendant that appears overwhelming in the showroom will almost invariably look correct in place.

06

Natural Light as the Standard

Before any artificial scheme is designed, the natural light of the space deserves to be maximised. A well-positioned roof light can transform a room's character in a way that no arrangement of artificial sources can replicate. Glazed internal doors, enlarged openings, and light-channelling elements should be considered before, not alongside, the lighting plan. Daylight is the reference against which all artificial illumination is ultimately measured.

WHAT THE SPECIFICATION PROCESS RARELY SURFACES

- Circuit separation is the most consequential lighting decision that rarely appears on a brief. Pendant, downlight, and wall-light circuits must each be independently controlled. A single circuit for the room's entire lighting removes, at a stroke, the capacity to layer.
- DALI or smart control systems should be considered at the wiring stage. The additional cost at first fix is modest. The cost of retrofitting conventional wiring for intelligent control is almost always prohibitive.
- The Colour Rendering Index (CRI) determines how accurately a light source renders colour, skin tone, and material. Sources below CRI 90 flatten the very finishes and surfaces the design has worked to achieve. Specify CRI 90 or above in all principal rooms, without exception.

Wall Finishes: The Surface That Sets the Tone

The walls of a room are its most continuous and most intimate surface. Their finish determines not merely the visual character of the space but its acoustic quality, the way light moves within it, and the degree to which materials age with grace or require constant intervention. A well-chosen finish, properly applied to a properly prepared substrate, will endure without compromise. A beautiful finish applied carelessly will reveal its limitations within a season.

Preparation: The Investment That Precedes Beauty

Newly plastered walls must cure fully before any finish is applied. In temperate conditions this requires a minimum of four weeks; in winter or in spaces with restricted airflow, six to eight weeks is the defensible minimum. Finishing over uncured plaster traps residual moisture in the substrate, producing failure, whether peeling, cracking, or mould, that reflects not on the product but on the process.

Prior to any decorative application, new plaster must receive a mist coat: emulsion diluted to approximately 70% paint and 30% water, applied across the entire surface. This seals the porous face of the plaster, prevents the topcoat from being absorbed with the unevenness that produces a patchy finish, and renders any remaining surface imperfections visible while correction remains possible. The mist coat is the single most commonly omitted step in residential decoration, and the single most common origin of premature paint failure.

Finishes of Distinction

Dead Flat and Ultra-Matt Emulsion. The pre-eminent choice for principal rooms. Dead flat absorbs light rather than reflecting it, lending walls a quality that photographs with extraordinary richness and reads as deeply considered in person. Its one limitation, that standard dead flat is not washable, is addressed by a generation of washable matt formulations that maintain the finish without compromising durability. These should be specified as a matter of course in any residence that is genuinely lived in.

Limewash and Clay Plaster. Materials of genuine depth that no paint, however sophisticated, can replicate. Applied in successive layers by a craftsman with knowledge of the material, they produce a surface that breathes in the vapour-permeable sense, and that changes with the light in the way that only a textured, mineral-based surface can. In buildings of age and character, these finishes are not merely aesthetic choices; they are technically superior, permitting the walls to manage moisture in the way solid construction demands.

Panelling: Shaker and Fluted. The means by which a flat, unornamented wall acquires the quality of architecture. Shaker panelling in the lower third of a hallway or dining room lends a space a calm, classical authority. Fluted panels on a feature wall bring a rhythm and depth that no applied finish can achieve. The specification detail that fails most often: panel mouldings secured with adhesive alone, or with fixings alone. Both are required. Adhesive without fixings fails; fixings without adhesive crack the decorated surface at every stress point.

Micro-cement and Venetian Plaster. Two of the most demanding, and most rewarding, interior finishes available. Micro-cement is applied across a specific primer sequence in a minimum of three coats, producing a seamless, waterproof surface that serves bathrooms with a sophistication that tile cannot approach. Venetian plaster is worked with a steel trowel and burnished at the point of partial cure to develop its characteristic translucent depth. Both require a specialist applicator, and neither can be repaired invisibly at a single point of damage. They demand commitment to the whole surface.

Considered Wallpaper. A room in which a single wall is papered and the three remaining walls are held in a tone drawn from within the paper achieves a coherence that feels both effortless and intentional. The substrate is the variable that

determines success or failure: paper applied over inadequately prepared plaster will lift and bubble within months. The step that the finest decorators never omit, and that cost pressure most commonly removes, is horizontal lining paper applied before the decorative layer. It produces a surface of greater smoothness and extends the life of the paper considerably.

Eggshell and Silk in Functional Rooms. Kitchens and bathrooms demand a finish with sufficient sheen to resist moisture and permit cleaning without damage. Eggshell, at a sheen level of ten to twenty percent, provides both without compromising appearance. In shower enclosures and anywhere that receives direct water contact, no paint formulation offers sufficient protection: micro-cement, tile, or a proprietary wet room system is the only defensible specification.

The Sequence of Work: An Uncompromising Order

The most costly errors in any significant renovation are not material errors. They are errors of sequence: decisions taken at the wrong moment, in the wrong order, that oblige subsequent work to be undone, circumvented, or corrected at disproportionate expense. The sequence set out below has been refined across some of the most exacting residential projects in the region. It does not allow for improvisation.

The Considered Renovation Sequence

01

Surveys and Structural Understanding First

No design decision of consequence should precede a thorough understanding of the building. Structural surveys, damp assessments, electrical condition reports, and mechanical evaluations must be complete before finishes, materials, or schemes are committed to. A structural deficiency discovered after new flooring has been laid is not a complication; it is a compounding of costs that rigorous sequencing renders impossible.

02

First Fix: All Trades Before All Finishes

Every mechanical, electrical, and plumbing element must be installed, tested, and signed off before a single decorative surface is introduced. Underfloor heating, electrical circuits, pipework, and air handling must all be roughed in and pressure-tested. Any tradesperson entering the space after finishes have been applied introduces risk to work that cannot be economically repeated.

03

Plastering, Then Patience

Once first fix is complete and inspected, the plasterer works. Then the project rests. The instinct to accelerate the drying phase through forced heating is understandable; it is also inadvisable. Forced drying introduces stresses that the plaster resolves through cracking. Four to six weeks of natural drying produces a surface that accepts paint and applied finishes without subsequent movement.

04

Painting Precedes Flooring, Without Exception

Walls and ceilings are painted before a floor of any material is laid. Splashes and drips on an unprepared subfloor are of no consequence. The same splashes on a finished timber or stone surface require skilled remediation that is both disruptive and expensive. This single sequencing principle eliminates a category of risk entirely.

05

Flooring and Second Fix as a Continuous Phase

Hard flooring follows painting. Second fix, comprising sockets, switches, light fittings, ironmongery, and heating elements, follows flooring. Skirtings and architraves are always last, concealing every edge and junction cleanly. Sanitary ware is the final element installed in any bathroom. The discipline of this order is the reason a finished project reads as resolved rather than assembled.

06

Snagging as a Formal Discipline

Before any furniture is introduced or any room is occupied, a methodical room-by-room snagging exercise must take place. Empty rooms conceal nothing. Every gap, imperfection, variation in finish, and incomplete junction is visible and addressable. Once the residence is furnished, the same defects become practically invisible and practically unaddressable. Snagging is not a formality. It is the final act of quality assurance.

Material Combinations: The Intelligence of the Palette

Individual materials are selected on their own merits. But the difference between an interior that is merely well-specified and one that is genuinely affecting lies almost entirely in the relationships between materials, in the decisions about which surfaces are placed in dialogue with one another, and why.

The logic is not purely visual. It operates through qualities that are felt as much as seen: the visual weight of a surface, its reflectivity, its thermal quality, its acoustic character. Materials of comparable visual weight coexist without competition: brushed concrete and raw oak share a quietness that allows each to be itself. Materials of comparable finish ambition, honed marble and lacquered joinery for instance, sit together because each is explicit about the quality of its surface. The combinations that consistently fail are those where one material is of high visual intensity and another is deliberately self-effacing; the disproportion produces a tension that no styling can resolve.

The principle that governs the finest interiors is one of deliberate restraint: no more than three primary materials in any space. A floor material, a wall material, and a material for the joinery and cabinetry. Every other surface, whether worktops, ironmongery, or textiles, is either a derivation of one of those three, or a considered foil to them. Complexity is not sophistication. A palette of three materials, chosen with intelligence and applied with precision, is almost always more powerful than one of six.

MATERIAL RELATIONSHIPS THAT CONSISTENTLY SUCCEED

- White oak with honed Carrara marble and painted cabinetry: a combination of classical warmth and tonal discipline that ages without ever appearing dated
- Smoked or fumed oak with brushed brass and limewashed walls: a palette of considered texture that reads as substantially more refined than the cost of its individual components suggests
- Polished concrete with American walnut joinery and raw plaster: the tension between the industrial and the organic, resolved through a shared commitment to material honesty
- Engineered stone worktop with fluted oak panelling and aged brass ironmongery: the kitchen palette that clients who have experienced it in a completed project request, consistently, above all others
- The combinations that invariably disappoint: metals of closely related but distinct finishes used alongside one another (brushed nickel with chrome, for instance); more than two distinct stone patterns within a single room; dark floors with dark walls in the absence of a strong and deliberate light source anchoring the space