(wafer2,0,8,-1,-1,1,3) Plots and Summary

- Cell Size = 10um
- Number of Times Accessed = 30
- Last Stimulated = 2022/April/05 at 03:29:48PM

Stimulated at 02:38:32PM on 2022/April/05

Activity = form

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set from the beginning





Stimulated at 02:38:54PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset



Stimulated at 02:39:45PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at 1.55 V, very low





Stimulated at 02:40:42PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Weird reset, mostly normal



Stimulated at 02:41:03PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA


Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at normal voltage level this time







Stimulated at 02:41:42PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Good reset



Stimulated at 02:42:22PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA


Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at 3.2 V





Stimulated at 02:49:59PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Still set State: Set*



Stimulated at 02:50:25PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s

Compliance Current = 8.0mA

Platinum Voltage =


Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Still resets, so it's not burned out

-0.001166-0.001750 -0.002333

-4




-2

Voltage (V)

-1

Ö

-3



Stimulated at 02:50:40PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at 1.4 V, very low



Stimulated at 03:06:50PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 35.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Not set State: Reset*

Probe A plots



Stimulated at 03:08:06PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at low voltage



Stimulated at 03:13:29PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset*



Stimulated at 03:13:50PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = set



Stimulated at 03:14:42PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Reset not cleanly



Stimulated at 03:15:09PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset*



Stimulated at 03:15:35PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Low voltage



Stimulated at 03:16:08PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Reset, not setting properly State: Reset*



Stimulated at 03:16:33PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 35.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Low voltage



Stimulated at 03:17:38PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 35.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Reset State: Reset*



0.1 Voltage (V)

Stimulated at 03:18:01PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 40.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Set at higher voltage



Stimulated at 03:18:23PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>


Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 40.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>



Stimulated at 03:18:41PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Still weird



Stimulated at 03:19:01PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 40.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Still low voltage, Amrita thinks it's burned



Stimulated at 03:24:35PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>


Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 40.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>



Stimulated at 03:26:09PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>


Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 40.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>



Stimulated at 03:28:21PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>


Ramp Rate = <2 probe observe activity, so invalid>

Compliance Current = 40.0uA

Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>



Stimulated at 03:28:44PM on 2022/April/05

Activity = reset

Start Voltage = 0V

End Voltage = -4V

Ramp Rate = 1V/s


Compliance Current = 8.0mA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = This cell is not working



Stimulated at 03:29:07PM on 2022/April/05

Activity = set

Start Voltage = 0V

End Voltage = 5V

Ramp Rate = 1V/s


Compliance Current = 40.0uA

Platinum Voltage =

Copper Voltage =

Run Folder Name = <2 probe, so invalid>

Comments = Very strange



Stimulated at 03:29:48PM on 2022/April/05

Activity = observe

Start Voltage = <2 probe observe activity, so invalid>

End Voltage = <2 probe observe activity, so invalid>

Ramp Rate = <2 probe observe activity, so invalid>


Compliance Current = 40.0uA


Platinum Voltage = 0V

Copper Voltage = 0.100V

Run Folder Name = <2 probe, so invalid>

Comments = Set, it is burned State: Set*





.....