

Imperas Peripheral Model Guide

Model Specific Information for freescale.ovpworld.org / KinetisAXBS

Imperas Software Limited

Imperas Buildings, North Weston Thame, Oxfordshire, OX9 2HA, U.K. docs@imperas.com.



Author	Imperas Software Limited
Version	20211118.0
Filename	OVP_Peripheral_Specific_Information_KinetisAXBS.pdf
Created	31 December 2021
Status	OVP Standard Release

Copyright Notice

Copyright 2021 Imperas Software Limited. All rights reserved. This software and documentation contain information that is the property of Imperas Software Limited. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Imperas Software Limited, or as expressly provided by the license agreement.

Right to Copy Documentation

The license agreement with Imperas permits licensee to make copies of the documentation for its internal use only. Each copy shall include all copyrights, trademarks, service marks, and proprietary rights notices, if any.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the readers responsibility to determine the applicable regulations and to comply with them.

Disclaimer

IMPERAS SOFTWARE LIMITED, AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Table Of Contents

1.0 Model Specific Information	4
1.1 Description	4
1.2 Limitations	4
1.3 Reference	4
1.4 Licensing	4
1.5 Location	4
2.0 Net Ports	4
3.0 Bus Slave Ports	4
3.1 Bus Slave Port: bport1	4
4.0 Platforms that use this peripheral component	5
5.0 Peripheral components in the library	б
6.0 General Information on Peripheral Models	8
6.1 Background	8
7.0 Building peripherals easily with Imperas iGen	8
8.0 Peripheral model internals	8
9.0 Parts of peripheral models	9
9.1 Configuring the Peripheral Instance with Parameters	9
9.2 Net Ports	9
9.3 Bus master ports	9
9.4 Bus slave ports	9
9.5 Packetnets	9
10.0 More information (documentation) on peripheral models and modeling	9

1.0 Model Specific Information

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers, other component parts, and configuration options and general information for peripheral modeling with Imperas OVP.

1.1 Description

Model of the AXBS peripheral used on the Freescale Kinetis platform

1.2 Limitations

Provides the base behaviour for the OVP Freescale Kinetis platforms

1.3 Reference

www.freescale.com/Kinetis

1.4 Licensing

Open Source Apache 2.0

1.5 Location

The KinetisAXBS peripheral model is located in an Imperas/OVP installation at the VLNV: freescale.ovpworld.org / peripheral / KinetisAXBS / 1.0.

2.0 Net Ports

This model has the following net ports:

Table 1. Net Ports

Name	Туре	Must Be Connected	Description
Reset	input	F (False)	

3.0 Bus Slave Ports

This model has the following bus slave ports:

3.1 Bus Slave Port: bport1

Table 2. Bus Slave Port: bport1

Name	Size (bytes)	Must Be Connected	Description
bport1	0x1000	F (False)	

Table 3. Bus Slave Port: bport1 Registers:

Name	Offset	Width (bits)	Description	R/W	is Volatile
ab0_PRS	0x0	32			

Copyright (c) 2021 Imperas Software Limited

www.imperas.com

OVP License. Release 20211118.0

ab0_CRS	0x10	32		
ab1_PRS	0x100	32		
ab1_CRS	0x110	32		
ab2_PRS	0x200	32		
ab2_CRS	0x210	32		
ab3_PRS	0x300	32		
ab3_CRS	0x310	32		
ab4_PRS	0x400	32		
ab4_CRS	0x410	32		
ab5_PRS	0x500	32		
ab5_CRS	0x510	32		
ab6_PRS	0x600	32		
ab6_CRS	0x610	32		
ab7_PRS	0x700	32		
ab7_CRS	0x710	32		
ac_MGPCR0	0x800	32	Master General Purpose Control Register, offset: 0x800	
ac_MGPCR1	0x900	32	Master General Purpose Control Register, offset: 0x900	
ac_MGPCR2	0xa00	32	Master General Purpose Control Register, offset: 0xA00	
ac_MGPCR3	0xb00	32	Master General Purpose Control Register, offset: 0xB00	
ac_MGPCR6	0xe00	32	Master General Purpose Control Register, offset: 0xE00	
ac_MGPCR7	0xf00	32	Master General Purpose Control Register, offset: 0xF00	

4.0 Platforms that use this peripheral component

Peripheral components can be used in many different platforms, including those developed by Imperas or by other users of OVP. You can use this peripheral in your own platforms.

Table 4. Publicly available platforms using peripheral 'KinetisAXBS'

Platform Name	Vendor
FreescaleKinetis60	freescale.ovpworld.org
FreescaleKinetis64	freescale.ovpworld.org

5.0 Peripheral components in the library

Table 5. Publicly available Imperas/OVP peripheral models (227 models)

Peripheral	Peripheral	Peripheral
freescale.ovpworld.org/KinetisCAN	freescale.ovpworld.org/KinetisCMP	freescale.ovpworld.org/KinetisCMT
freescale.ovpworld.org/KinetisCRC	freescale.ovpworld.org/KinetisDAC	freescale.ovpworld.org/KinetisDDR
freescale.ovpworld.org/KinetisDMA	freescale.ovpworld.org/KinetisDMAC	freescale.ovpworld.org/KinetisDMAMUX
freescale.ovpworld.org/KinetisENET	freescale.ovpworld.org/KinetisEWM	freescale.ovpworld.org/KinetisFB
freescale.ovpworld.org/KinetisFMC	freescale.ovpworld.org/KinetisFTFE	freescale.ovpworld.org/KinetisFTM
freescale.ovpworld.org/KinetisGPIO	freescale.ovpworld.org/KinetisI2C	freescale.ovpworld.org/KinetisI2S
freescale.ovpworld.org/KinetisLLWU	freescale.ovpworld.org/KinetisLPTMR	freescale.ovpworld.org/KinetisMCG
freescale.ovpworld.org/KinetisMPU	freescale.ovpworld.org/KinetisNFC	freescale.ovpworld.org/KinetisOSC
freescale.ovpworld.org/KinetisPDB	freescale.ovpworld.org/KinetisPIT	freescale.ovpworld.org/KinetisPMC
freescale.ovpworld.org/KinetisPORT	freescale.ovpworld.org/KinetisRCM	freescale.ovpworld.org/KinetisRFSYS
freescale.ovpworld.org/KinetisRFVBAT	freescale.ovpworld.org/KinetisRNG	freescale.ovpworld.org/KinetisRTC
freescale.ovpworld.org/KinetisSDHC	freescale.ovpworld.org/KinetisSIM	freescale.ovpworld.org/KinetisSMC
freescale.ovpworld.org/KinetisSPI	freescale.ovpworld.org/KinetisTSI	freescale.ovpworld.org/KinetisUART
freescale.ovpworld.org/KinetisUSB	freescale.ovpworld.org/KinetisUSBDCD	freescale.ovpworld.org/KinetisUSBHS
freescale.ovpworld.org/KinetisVREF	freescale.ovpworld.org/KinetisWDOG	freescale.ovpworld.org/Uart
freescale.ovpworld.org/VybridADC	freescale.ovpworld.org/VybridANADIG	freescale.ovpworld.org/VybridCCM
freescale.ovpworld.org/VybridDMA	freescale.ovpworld.org/VybridGPIO	freescale.ovpworld.org/VybridI2C
freescale.ovpworld.org/VybridLCD	freescale.ovpworld.org/VybridQUADSPI	freescale.ovpworld.org/VybridSDHC
freescale.ovpworld.org/VybridSPI	freescale.ovpworld.org/VybridUART	freescale.ovpworld.org/VybridUSB
imperas.ovpworld.org/frameBuffer	imperas.ovpworld.org/uart	imperas.ovpworld.org/usecCounter
intel.ovpworld.org/82077AA	intel.ovpworld.org/82371EB	intel.ovpworld.org/8253
intel.ovpworld.org/8259A	intel.ovpworld.org/NorFlash48F4400	intel.ovpworld.org/PciIDE
intel.ovpworld.org/PciPM	intel.ovpworld.org/PciUSB	intel.ovpworld.org/Ps2Control
marvell.ovpworld.org/GT6412x	maxim.ovpworld.org/max673x	microsemi.ovpworld.org/CoreUARTapb
mips.ovpworld.org/16450C	mips.ovpworld.org/MaltaFPGA	mips.ovpworld.org/SmartLoaderLinux
motorola.ovpworld.org/MC146818	national.ovpworld.org/16450	national.ovpworld.org/16550
national.ovpworld.org/16550_4bytes	nxp.ovpworld.org/iMX6_Analog	nxp.ovpworld.org/iMX6_CCM
nxp.ovpworld.org/iMX6_GPC	nxp.ovpworld.org/iMX6_GPIO	nxp.ovpworld.org/iMX6_GPT
nxp.ovpworld.org/iMX6_MMDC	nxp.ovpworld.org/iMX6_SDHC	nxp.ovpworld.org/iMX6_SRC
nxp.ovpworld.org/iMX6_UART	nxp.ovpworld.org/iMX6_WDOG	ovpworld.org/Alpha2x16Display
ovpworld.org/DynamicBridge	ovpworld.org/FlashDevice	ovpworld.org/ledRegister
ovpworld.org/SerInt	ovpworld.org/SimpleDma	ovpworld.org/switchRegister
ovpworld.org/temperatureSensor	ovpworld.org/trap	ovpworld.org/trap4K
ovpworld.org/vEthernet_Bridge	ovpworld.org/VirtioBlkMMIO	ovpworld.org/VirtioNetMMIO
philips.ovpworld.org/ISP1761	renesas.ovpworld.org/adc	renesas.ovpworld.org/bcu
renesas.ovpworld.org/brg	renesas.ovpworld.org/can	renesas.ovpworld.org/can
renesas.ovpworld.org/clkgen	renesas.ovpworld.org/crc	renesas.ovpworld.org/csib
renesas.ovpworld.org/csie	renesas.ovpworld.org/dma	renesas.ovpworld.org/intc
renesas.ovpworld.org/memc	renesas.ovpworld.org/rng	renesas.ovpworld.org/taa
renesas.ovpworld.org/tms	renesas.ovpworld.org/tmt	renesas.ovpworld.org/uartc
renesas.ovpworld.org/UPD70F3441Logic	riscv.ovpworld.org/CLINT	riscv.ovpworld.org/PLIC
riscv.ovpworld.org/SmartLoaderRV64Linux	safepower.ovpworld.org/node	safepower.ovpworld.org/NostrumNode
safepower.ovpworld.org/ring_oscillator	safepower.ovpworld.org/TTELNode	sifive.ovpworld.org/artyIO

Copyright (c) 2021 Imperas Software Limited OVP License. Release 20211118.0

sifive.ovpworld.org/DDRCTL	sifive.ovpworld.org/gpio	sifive.ovpworld.org/MSEL
sifive.ovpworld.org/PLIC	sifive.ovpworld.org/PRCI	sifive.ovpworld.org/pwm
sifive.ovpworld.org/spi	sifive.ovpworld.org/teststatus	sifive.ovpworld.org/UART
smsc.ovpworld.org/LAN9118	smsc.ovpworld.org/LAN91C111	ti.ovpworld.org/tca6416a
ti.ovpworld.org/UartInterface	ti.ovpworld.org/ucd9012a	ti.ovpworld.org/ucd9248
vendor.com/fifo	xilinx.ovpworld.org/axi-gpio	xilinx.ovpworld.org/axi-intc
xilinx.ovpworld.org/axi-pcie	xilinx.ovpworld.org/axi-timer	xilinx.ovpworld.org/logicore-fit
xilinx.ovpworld.org/mdm	xilinx.ovpworld.org/mpmc	xilinx.ovpworld.org/xps-gpio
xilinx.ovpworld.org/xps-iic	xilinx.ovpworld.org/xps-intc	xilinx.ovpworld.org/xps-ll-temac
xilinx.ovpworld.org/xps-mch-emc	xilinx.ovpworld.org/xps-sysace	xilinx.ovpworld.org/xps-timer
xilinx.ovpworld.org/xps-uartlite	xilinx.ovpworld.org/zynq_7000-can	xilinx.ovpworld.org/zynq_7000-ddrc
xilinx.ovpworld.org/zynq_7000-devcfg	xilinx.ovpworld.org/zynq_7000-dmac	xilinx.ovpworld.org/zynq_7000-gpio
xilinx.ovpworld.org/zynq_7000-iic	xilinx.ovpworld.org/zynq_7000-ocm	xilinx.ovpworld.org/zynq_7000-qos301
xilinx.ovpworld.org/zynq_7000-qspi	xilinx.ovpworld.org/zynq_7000-sdio	xilinx.ovpworld.org/zynq_7000-slcr
xilinx.ovpworld.org/zynq_7000-spi	xilinx.ovpworld.org/zynq_7000-swdt	xilinx.ovpworld.org/zynq_7000-ttc
xilinx.ovpworld.org/zynq_7000-tz_GPVsecurity	xilinx.ovpworld.org/zynq_7000-tz_security	xilinx.ovpworld.org/zynq_7000-usb
altera.ovpworld.org/dw-apb-timer	altera.ovpworld.org/dw-apb-uart	altera.ovpworld.org/IntervalTimer32Core
altera.ovpworld.org/IntervalTimer64Core	altera.ovpworld.org/JtagUart	altera.ovpworld.org/PerformanceCounterCore
altera.ovpworld.org/RSTMGR	altera.ovpworld.org/SystemIDCore	altera.ovpworld.org/Uart
amd.ovpworld.org/79C970	andes.ovpworld.org/ATCUART100	andes.ovpworld.org/NCEPLIC100
andes.ovpworld.org/NCEPLMT100	arm.ovpworld.org/AaciPL041	arm.ovpworld.org/CompactFlashRegs
arm.ovpworld.org/CoreModule9x6	arm.ovpworld.org/DebugLedAndDipSwitch	arm.ovpworld.org/DMemCtrlPL341
arm.ovpworld.org/IcpControl	arm.ovpworld.org/IcpCounterTimer	arm.ovpworld.org/IntICP
arm.ovpworld.org/IntICP	arm.ovpworld.org/KbPL050	arm.ovpworld.org/L2CachePL310
arm.ovpworld.org/LcdPL110	arm.ovpworld.org/MmciPL181	arm.ovpworld.org/RtcPL031
arm.ovpworld.org/SerBusDviRegs	arm.ovpworld.org/SmartLoaderArm64Linux	arm.ovpworld.org/SmartLoaderArmLinux
arm.ovpworld.org/SMemCtrlPL354	arm.ovpworld.org/SysCtrlSP810	arm.ovpworld.org/TimerSP804
arm.ovpworld.org/TzpcBP147	arm.ovpworld.org/UartPL011	arm.ovpworld.org/VexpressSysRegs
arm.ovpworld.org/WdtSP805	atmel.ovpworld.org/AdvancedInterruptController	atmel.ovpworld.org/ParallelIOController
atmel.ovpworld.org/PowerSaving	atmel.ovpworld.org/SpecialFunction	atmel.ovpworld.org/TimerCounter
atmel.ovpworld.org/UsartInterface	atmel.ovpworld.org/WatchdogTimer	cadence.ovpworld.org/gem
cadence.ovpworld.org/uart	cirrus.ovpworld.org/GD5446	freescale.ovpworld.org/KinetisADC
freescale.ovpworld.org/KinetisAIPS	freescale.ovpworld.org/KinetisAXBS	

Copyright (c) 2021 Imperas Software Limited OVP License. Release 20211118.0

6.0 General Information on Peripheral Models

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers etc. and configuration options and general information for peripheral modeling with Imperas OVP.

6.1 Background

Imperas OVP simulation technology enables very high performance simulation, debug and analysis of platforms containing multiple processors and peripheral models. The technology is designed to be extensible: you can create new models of processors, peripherals and other platform components using interfaces and libraries defined by OVP.

The peripheral models created using the OVP APIs run on the Peripheral Simulation Engine (PSE).

The model is typically written in C and compiled into an executable for the PSE processor architecture. The model is compiled for speed of execution and to protect IP. It is dynamically loaded by the simulator at run time.

7.0 Building peripherals easily with Imperas iGen

To aid with model creation, Imperas products include iGen, a model generation tool. iGen takes the laborious and error-prone task of constructing the various hardware model and software element files required for a typical model, and automates this process. iGen creates the needed C files. iGen also creates the C++ SystemC TLM2 interface files needed to run peripheral models in SystemC simulations.

iGen takes as input a simple script specification that includes device internals such as registers and memories, port information, component descriptors, and other elements. iGen then builds the C code model files and user editable templates. These include model frameworks with registers, function calls, memory map, and other items. It ensures that all component parts of the model are well-structured using best practices, and are consistent throughout the files, thus eliminating a common source of errors.

More information on iGen can be found: <u>imperas.com/products</u>.

8.0 Peripheral model internals

Each instance of a peripheral model runs on its own virtual machine with an address space large enough for the model. This processor (the PSE) and its memory are separate from any processors, memories and buses in the platform being simulated; they exist only to execute the code of the peripheral model.

Interception of functions defined in the peripheral model allows the use of features of the host system in the

implementation of the behavior of a peripheral. As an example, a real platform might contain a video display device. When simulating this system, it is generally more convenient not to simulate the complete video display device but to use a video package available on the host machine, such as SDL, and to use this to render to the host display. Also models of uarts, ethernet devices and USB components can make use of the host PC resources during simulation, to allow, for example, a simulation to browse the real internet, or the simulation to connect to a real USB device.

9.0 Parts of peripheral models

9.1 Configuring the Peripheral Instance with Parameters

A peripheral can include the behaviour of several configurations. These are controlled when the peripheral is instanced in the platform by setting parameters defined on the peripheral.

9.2 Net Ports

Peripherals may be connected to other peripherals or processors with signal wires (nets). These can be used to act as interrupt signals or used to control behavior between peripherals.

The wires are created in the platform as nets and this net is connected into the peripheral using a net port.

9.3 Bus master ports

A bus master port initiates (and controls the address of) a bus cycle. Bus cycles are generated by behavioral code within the peripheral model.

9.4 Bus slave ports

A peripheral can be defined as having several bus slave ports. The bus slave ports can be split into several address blocks. Each address block be either local memory or memory mapped registers. Both of these can have associated callback functions. A memory mapped register can also be defined as specific read/write access, whether it is volatile, and also whether it is associated with a reset pin and mask. A memory mapped register can also have specific bit fields defined.

9.5 Packetnets

A peripheral can be defined as being connected to packetnet ports. A packetnet is used to model packet based communication such as Ethernet, CAN bus or GSM. A packetnet is created in a platform, then connected to packetnet ports on model instances. A packetnet can have many connections, each able to send or receive packets. A packetnet is used as an efficient method of communication within OVP models.

For more information on modeling with packetnets, please see the peripheral modeling documentation: OVP_Peripheral_Modeling_Guide.pdf, OVPsim_and_CpuManager_User_Guide.pdf and the example: \$IMPERAS_HOME/Examples/Models/Peripherals/packetnet.

10.0 More information (documentation) on peripheral models and modeling

More information on modeling and APIs can be found at: OVPworld.org/technology_apis.

Copyright (c) 2021 Imperas Software Limited www.imperas.com

OVP License. Release 20211118.0 Page 9 of 10

Specifics on modeling peripherals can be found: OVP_Peripheral_Modeling_Guide.pdf .						
A full list of the currently available OVP documentation is available: OVPworld.org/documentation #						