Imperas Peripheral Model Guide

Model Specific Information for freescale.ovpworld.org / KinetisFB

Imperas Software Limited

Imperas Buildings, North Weston
Thame, Oxfordshire, OX9 2HA, U.K.
docs@imperas.com.

Author	Imperas Software Limited
Version	20211118.0
Filename	OVP_Peripheral_Specific_Information_KinetisFB.pdf
Created	31 December 2021
Status	OVP Standard Release

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 1 of 11

Copyright Notice

Model Release Status

This model is released as part of OVP releases and is included in OVPworld packages. Please visit OVPworld.org.

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 2 of 11

Table Of Contents

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 3 of 11

1.0 Model Specific Information

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers, other component parts, and configuration options and general information for peripheral modeling with Imperas OVP.

1.1 Description

Model of the FB peripheral used on the Freescale Kinetis platform

1.2 Limitations

Provides the base behaviour for the OVP Freescale Kinetis platforms

1.3 Reference

www.freescale.com/Kinetis

1.4 Licensing

Open Source Apache 2.0

1.5 Location

The KinetisFB peripheral model is located in an Imperas/OVP installation at the VLNV: freescale.ovpworld.org / peripheral / KinetisFB / 1.0.

2.0 Net Ports

This model has the following net ports:

Table 1. Net Ports

Name	Type	Must Be Connected	Description
Reset	input	F (False)	

3.0 Bus Slave Ports

This model has the following bus slave ports:

3.1 Bus Slave Port: bport1

Table 2. Bus Slave Port: bport1

Name	Size (bytes)	Must Be Connected	Description
bport1	0x1000	F (False)	

Table 3. Bus Slave Port: bport1 Registers:

Name	Offset	Width (bits)	Description	R/W	is Volatile
ab_CSAR0	0x0	32	Chip select address register, array offset: 0x0,		

			array step: 0xC		
ab_CSMR0	0x4	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR0	0x8	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSAR1	0xc	32	Chip select address register, array offset: 0x0, array step: 0xC		
ab_CSMR1	0x10	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR1	0x14	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSAR2	0x18	32	Chip select address register, array offset: 0x0, array step: 0xC		
ab_CSMR2	0x1c	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR2	0x20	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSAR3	0x24	32	Chip select address register, array offset: 0x0, array step: 0xC		
ab_CSMR3	0x28	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR3	0x2c	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSAR4	0x30	32	Chip select address register, array offset: 0x0, array step: 0xC		
ab_CSMR4	0x34	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR4	0x38	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSAR5	0x3c	32	Chip select address register, array offset: 0x0, array step: 0xC		
ab_CSMR5	0x40	32	Chip select mask register, array offset: 0x4, array step: 0xC		
ab_CSCR5	0x44	32	Chip select control register, array offset: 0x8, array step: 0xC		
ab_CSPMCR	0x60	32	Chip select port multiplexing control register, offset: 0x60		

4.0 Platforms that use this peripheral component

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 5 of 11

Peripheral components can be used in many different platforms, including those developed by Imperas or by other users of OVP. You can use this peripheral in your own platforms.

Table 4. Publicly available platforms using peripheral 'KinetisFB'

Platform Name	Vendor
FreescaleKinetis60	freescale.ovpworld.org
FreescaleKinetis64	freescale.ovpworld.org

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 6 of 11

5.0 Peripheral components in the library

Table 5. Publicly available Imperas/OVP peripheral models (227 models)

Peripheral	Peripheral	Peripheral
freescale.ovpworld.org/KinetisFMC	freescale.ovpworld.org/KinetisFTFE	freescale.ovpworld.org/KinetisFTM
freescale.ovpworld.org/KinetisGPIO	freescale.ovpworld.org/KinetisI2C	freescale.ovpworld.org/KinetisI2S
freescale.ovpworld.org/KinetisLLWU	freescale.ovpworld.org/KinetisLPTMR	freescale.ovpworld.org/KinetisMCG
freescale.ovpworld.org/KinetisMPU	freescale.ovpworld.org/KinetisNFC	freescale.ovpworld.org/KinetisOSC
freescale.ovpworld.org/KinetisPDB	freescale.ovpworld.org/KinetisPIT	freescale.ovpworld.org/KinetisPMC
freescale.ovpworld.org/KinetisPORT	freescale.ovpworld.org/KinetisRCM	freescale.ovpworld.org/KinetisRFSYS
freescale.ovpworld.org/KinetisRFVBAT	freescale.ovpworld.org/KinetisRNG	freescale.ovpworld.org/KinetisRTC
freescale.ovpworld.org/KinetisSDHC	freescale.ovpworld.org/KinetisSIM	freescale.ovpworld.org/KinetisSMC
freescale.ovpworld.org/KinetisSPI	freescale.ovpworld.org/KinetisTSI	freescale.ovpworld.org/KinetisUART
freescale.ovpworld.org/KinetisUSB	freescale.ovpworld.org/KinetisUSBDCD	freescale.ovpworld.org/KinetisUSBHS
freescale.ovpworld.org/KinetisVREF	freescale.ovpworld.org/KinetisWDOG	freescale.ovpworld.org/Uart
freescale.ovpworld.org/VybridADC	freescale.ovpworld.org/VybridANADIG	freescale.ovpworld.org/VybridCCM
freescale.ovpworld.org/VybridDMA	freescale.ovpworld.org/VybridGPIO	freescale.ovpworld.org/VybridI2C
freescale.ovpworld.org/VybridLCD	freescale.ovpworld.org/VybridQUADSPI	freescale.ovpworld.org/VybridSDHC
freescale.ovpworld.org/VybridSPI	freescale.ovpworld.org/VybridUART	freescale.ovpworld.org/VybridUSB
imperas.ovpworld.org/frameBuffer	imperas.ovpworld.org/uart	imperas.ovpworld.org/usecCounter
intel.ovpworld.org/82077AA	intel.ovpworld.org/82371EB	intel.ovpworld.org/8253
intel.ovpworld.org/8259A	intel.ovpworld.org/NorFlash48F4400	intel.ovpworld.org/PciIDE
intel.ovpworld.org/PciPM	intel.ovpworld.org/PciUSB	intel.ovpworld.org/Ps2Control
marvell.ovpworld.org/GT6412x	maxim.ovpworld.org/max673x	microsemi.ovpworld.org/CoreUARTapb
mips.ovpworld.org/16450C	mips.ovpworld.org/MaltaFPGA	mips.ovpworld.org/SmartLoaderLinux
motorola.ovpworld.org/MC146818	national.ovpworld.org/16450	national.ovpworld.org/16550
national.ovpworld.org/16550_4bytes	nxp.ovpworld.org/iMX6_Analog	nxp.ovpworld.org/iMX6_CCM
nxp.ovpworld.org/iMX6_GPC	nxp.ovpworld.org/iMX6_GPIO	nxp.ovpworld.org/iMX6_GPT
nxp.ovpworld.org/iMX6_MMDC	nxp.ovpworld.org/iMX6_SDHC	nxp.ovpworld.org/iMX6_SRC
nxp.ovpworld.org/iMX6_UART	nxp.ovpworld.org/iMX6_WDOG	ovpworld.org/Alpha2x16Display
ovpworld.org/DynamicBridge	ovpworld.org/FlashDevice	ovpworld.org/ledRegister
ovpworld.org/SerInt	ovpworld.org/SimpleDma	ovpworld.org/switchRegister
ovpworld.org/temperatureSensor	ovpworld.org/trap	ovpworld.org/trap4K
ovpworld.org/vEthernet_Bridge	ovpworld.org/VirtioBlkMMIO	ovpworld.org/VirtioNetMMIO
philips.ovpworld.org/ISP1761	renesas.ovpworld.org/adc	renesas.ovpworld.org/bcu
renesas.ovpworld.org/brg	renesas.ovpworld.org/can	renesas.ovpworld.org/can
renesas.ovpworld.org/clkgen	renesas.ovpworld.org/crc	renesas.ovpworld.org/csib
renesas.ovpworld.org/csie	renesas.ovpworld.org/dma	renesas.ovpworld.org/intc
renesas.ovpworld.org/memc	renesas.ovpworld.org/rng	renesas.ovpworld.org/taa
renesas.ovpworld.org/tms	renesas.ovpworld.org/tmt	renesas.ovpworld.org/uartc
renesas.ovpworld.org/UPD70F3441Logic	riscv.ovpworld.org/CLINT	riscv.ovpworld.org/PLIC
riscv.ovpworld.org/SmartLoaderRV64Linux	safepower.ovpworld.org/node	safepower.ovpworld.org/NostrumNode
safepower.ovpworld.org/ring_oscillator	safepower.ovpworld.org/TTELNode	sifive.ovpworld.org/artyIO
sifive.ovpworld.org/DDRCTL	sifive.ovpworld.org/gpio	sifive.ovpworld.org/MSEL
sifive.ovpworld.org/PLIC	sifive.ovpworld.org/PRCI	sifive.ovpworld.org/pwm
sifive.ovpworld.org/spi	sifive.ovpworld.org/teststatus	sifive.ovpworld.org/UART
smsc.ovpworld.org/LAN9118	smsc.ovpworld.org/LAN91C111	ti.ovpworld.org/tca6416a

www.imperas.com

ti.ovpworld.org/UartInterface	ti.ovpworld.org/ucd9012a	ti.ovpworld.org/ucd9248
vendor.com/fifo	xilinx.ovpworld.org/axi-gpio	xilinx.ovpworld.org/axi-intc
xilinx.ovpworld.org/axi-pcie	xilinx.ovpworld.org/axi-timer	xilinx.ovpworld.org/logicore-fit
xilinx.ovpworld.org/mdm	xilinx.ovpworld.org/mpmc	xilinx.ovpworld.org/xps-gpio
xilinx.ovpworld.org/xps-iic	xilinx.ovpworld.org/xps-intc	xilinx.ovpworld.org/xps-ll-temac
xilinx.ovpworld.org/xps-mch-emc	xilinx.ovpworld.org/xps-sysace	xilinx.ovpworld.org/xps-timer
xilinx.ovpworld.org/xps-uartlite	xilinx.ovpworld.org/zynq_7000-can	xilinx.ovpworld.org/zynq_7000-ddrc
xilinx.ovpworld.org/zynq_7000-devcfg	xilinx.ovpworld.org/zynq_7000-dmac	xilinx.ovpworld.org/zynq_7000-gpio
xilinx.ovpworld.org/zynq_7000-iic	xilinx.ovpworld.org/zynq_7000-ocm	xilinx.ovpworld.org/zynq_7000-qos301
xilinx.ovpworld.org/zynq_7000-qspi	xilinx.ovpworld.org/zynq_7000-sdio	xilinx.ovpworld.org/zynq_7000-slcr
xilinx.ovpworld.org/zynq_7000-spi	xilinx.ovpworld.org/zynq_7000-swdt	xilinx.ovpworld.org/zynq_7000-ttc
xilinx.ovpworld.org/zynq_7000-tz_GPVsecurity	xilinx.ovpworld.org/zynq_7000-tz_security	xilinx.ovpworld.org/zynq_7000-usb
altera.ovpworld.org/dw-apb-timer	altera.ovpworld.org/dw-apb-uart	altera.ovpworld.org/IntervalTimer32Core
altera.ovpworld.org/IntervalTimer64Core	altera.ovpworld.org/JtagUart	altera.ovpworld.org/PerformanceCounterCore
altera.ovpworld.org/RSTMGR	altera.ovpworld.org/SystemIDCore	altera.ovpworld.org/Uart
amd.ovpworld.org/79C970	andes.ovpworld.org/ATCUART100	andes.ovpworld.org/NCEPLIC100
andes.ovpworld.org/NCEPLMT100	arm.ovpworld.org/AaciPL041	arm.ovpworld.org/CompactFlashRegs
arm.ovpworld.org/CoreModule9x6	arm.ovpworld.org/DebugLedAndDipSwitch	arm.ovpworld.org/DMemCtrlPL341
arm.ovpworld.org/IcpControl	arm.ovpworld.org/IcpCounterTimer	arm.ovpworld.org/IntICP
arm.ovpworld.org/IntICP	arm.ovpworld.org/KbPL050	arm.ovpworld.org/L2CachePL310
arm.ovpworld.org/LcdPL110	arm.ovpworld.org/MmciPL181	arm.ovpworld.org/RtcPL031
arm.ovpworld.org/SerBusDviRegs	arm.ovpworld.org/SmartLoaderArm64Linux	arm.ovpworld.org/SmartLoaderArmLinux
arm.ovpworld.org/SMemCtrlPL354	arm.ovpworld.org/SysCtrlSP810	arm.ovpworld.org/TimerSP804
arm.ovpworld.org/TzpcBP147	arm.ovpworld.org/UartPL011	arm.ovpworld.org/VexpressSysRegs
arm.ovpworld.org/WdtSP805	atmel.ovpworld.org/AdvancedInterruptController	atmel.ovpworld.org/ParallelIOController
atmel.ovpworld.org/PowerSaving	atmel.ovpworld.org/SpecialFunction	atmel.ovpworld.org/TimerCounter
atmel.ovpworld.org/UsartInterface	atmel.ovpworld.org/WatchdogTimer	cadence.ovpworld.org/gem
cadence.ovpworld.org/uart	cirrus.ovpworld.org/GD5446	freescale.ovpworld.org/KinetisADC
freescale.ovpworld.org/KinetisAIPS	freescale.ovpworld.org/KinetisAXBS	freescale.ovpworld.org/KinetisCAN
freescale.ovpworld.org/KinetisCMP	freescale.ovpworld.org/KinetisCMT	freescale.ovpworld.org/KinetisCRC
freescale.ovpworld.org/KinetisDAC	freescale.ovpworld.org/KinetisDDR	freescale.ovpworld.org/KinetisDMA
freescale.ovpworld.org/KinetisDMAC	freescale.ovpworld.org/KinetisDMAMUX	freescale.ovpworld.org/KinetisENET
freescale.ovpworld.org/KinetisEWM	freescale.ovpworld.org/KinetisFB	

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 8 of 11

6.0 General Information on Peripheral Models

This document provides usage information for an Imperas OVP peripheral behavioral model.

The document is split into sections providing specific information for this peripheral, including any ports for connecting into a platform, registers etc. and configuration options and general information for peripheral modeling with Imperas OVP.

6.1 Background

Imperas OVP simulation technology enables very high performance simulation, debug and analysis of platforms containing multiple processors and peripheral models. The technology is designed to be extensible: you can create new models of processors, peripherals and other platform components using interfaces and libraries defined by OVP.

The peripheral models created using the OVP APIs run on the Peripheral Simulation Engine (PSE).

The model is typically written in C and compiled into an executable for the PSE processor architecture. The model is compiled for speed of execution and to protect IP. It is dynamically loaded by the simulator at run time.

7.0 Building peripherals easily with Imperas iGen

To aid with model creation, Imperas products include iGen, a model generation tool. iGen takes the laborious and error-prone task of constructing the various hardware model and software element files required for a typical model, and automates this process. iGen creates the needed C files. iGen also creates the C++ SystemC TLM2 interface files needed to run peripheral models in SystemC simulations.

iGen takes as input a simple script specification that includes device internals such as registers and memories, port information, component descriptors, and other elements. iGen then builds the C code model files and user editable templates. These include model frameworks with registers, function calls, memory map, and other items. It ensures that all component parts of the model are well-structured using best practices, and are consistent throughout the files, thus eliminating a common source of errors.

More information on iGen can be found: imperas.com/products.

8.0 Peripheral model internals

Each instance of a peripheral model runs on its own virtual machine with an address space large enough for the model. This processor (the PSE) and its memory are separate from any processors, memories and buses in the platform being simulated; they exist only to execute the code of the peripheral model.

Interception of functions defined in the peripheral model allows the use of features of the host system in the

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 9 of 11

implementation of the behavior of a peripheral. As an example, a real platform might contain a video display device. When simulating this system, it is generally more convenient not to simulate the complete video display device but to use a video package available on the host machine, such as SDL, and to use this to render to the host display. Also models of uarts, ethernet devices and USB components can make use of the host PC resources during simulation, to allow, for example, a simulation to browse the real internet, or the simulation to connect to a real USB device.

9.0 Parts of peripheral models

9.1 Configuring the Peripheral Instance with Parameters
A peripheral can include the behaviour of several configurations. These are controlled when the peripheral is instanced in the platform by setting parameters defined on the peripheral.

9.2 Net Ports
Peripherals may be connected to other peripherals or processors with signal wires (nets). These can be used to act as interrupt signals or used to control behavior between peripherals.
The wires are created in the platform as nets and this net is connected into the peripheral using a net port.

9.3 Bus master ports
A bus master port initiates (and controls the address of) a bus cycle. Bus cycles are generated by behavioral code within the peripheral model.

9.4 Bus slave ports
A peripheral can be defined as having several bus slave ports. The bus slave ports can be split into several address blocks. Each address block be either local memory or memory mapped registers. Both of these can have associated callback functions. A memory mapped register can also be defined as specific read/write access, whether it is volatile, and also whether it is associated with a reset pin and mask. A memory mapped register can also have specific bit fields defined.

9.5 Packetnets
A peripheral can be defined as being connected to packetnet ports. A packetnet is used to model packet based communication such as Ethernet, CAN bus or GSM. A packetnet is created in a platform, then connected to packetnet ports on model instances. A packetnet can have many connections, each able to send or receive packets. A packetnet is used as an efficient method of communication within OVP models.

For more information on modeling with packetnets, please see the peripheral modeling documentation: OVP_Peripheral_Modeling_Guide.pdf, OVPsim_and_CpuManager_User_Guide.pdf and the example: $IMPERAS_HOME/Examples/Models/Peripherals/packetnet.

10.0 More information (documentation) on peripheral models and modeling
More information on modeling and APIs can be found at: OVPworld.org/technology_apis.

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 10 of 11

Specifics on modeling peripherals can be found: OVP_Peripheral_Modeling_Guide.pdf.

A full list of the currently available OVP documentation is available: OVPworld.org/documentation.
 #

Copyright (c) 2021 Imperas Software Limited   www.imperas.com

OVP License. Release 20211118.0   Page 11 of 11