Resistor Temperature Correction

Emmanuel Jesus R. Estallo

Electrical and Electronics Engineering Institute
University of the Philippines - Diliman
Quezon City, Philippines
emmanuel.estallo@eee.upd.edu.ph

I. CALCULATIONS

For any integrated resistor with a nominal temperature T_{ref} and temperature coefficient α , the temperature dependence is modeled by

$$R = R_{ref}[1 + \alpha(T - T_{ref})]$$

where R_{ref} is the resistance at $T = T_{ref}$.

Suppose R_{n+} is an n^+ polysilicon resistor with the following parameters:

- $R_{shn} = 100\Omega/\Box$
- $T_C = -800 ppm/^{\circ}C$ at $T_{NOM} = 27^{\circ}C$

similarly, R_{p+} is a p^+ polysilicon resistor with the following parameters:

- $R_{shp} = 180\Omega/\Box$
- $T_C = 200 ppm/^{\circ}C$ at $T_{NOM} = 27^{\circ}C$

The series resistance R_{tot} is equal to:

$$R_{tot} = R_{ref,n}[1 + \alpha_n(T - T_{ref})] + R_{ref,p}[1 + \alpha_p(T - T_{ref})]$$

For a temperature independent device, the CTAT and PTAT parameters must cancel each other. Since the resistors have the same widths,

$$\alpha_n R_{ref,n}(T - T_{ref}) = -\alpha_p R_{ref,p}(T - T_{ref})$$

$$\alpha_n R_{ref,n} = -\alpha_p R_{ref,p}$$

$$\frac{R_{ref,n}}{R_{ref,p}} = \frac{-\alpha_p}{\alpha_n}$$

$$\frac{R_{sh,n} \cdot l_n}{R_{sh,p} \cdot l_p} = \frac{-\alpha_p}{\alpha_n}$$

$$\frac{l_n}{l_p} = \frac{-\alpha_p R_{sh,p}}{\alpha_n R_{sh,n}} = 0.45$$

$$l_n = 0.45 \cdot l_p$$

Substituting the lengths,

$$R_{sh,n}\frac{l_n}{w_n} + R_{sh,p}\frac{l_p}{w_p} = 1k\Omega$$

Since $w = 2\mu m$, $l_n = 4\mu m$ and $l_p \approx 8.8888\mu m$

II. SIMULATIONS

The resistance is obtained by measuring the current across a 1V DC source.

The plots are shown below




Fig. 1. TEMP SWEEP: $-40^{\circ}C$ to $125^{\circ}C$




Fig. 2. A zoomed out Fig. 1

The resulting resistance is temperature independent, as expected.