Semiconductor Physics

Emmanuel Estallo

July 20, 2021

1 Resistivity and Conductivity

For any material, if we connect two terminals across it, we can obtain its resistance. The resistance of any device is defined as

$$R =
ho rac{L}{A}$$

where L is the length of the device, ρ is the resistivity, and A is the cross-sectional area.

Similarly, conductivity is obtained by

$$G=\frac{1}{R}$$

2 Quantum Mechanics

The Wave Particle Duality states that a particle can behave as a wave and at the same time, a wave can behave as a particle. This is captured by the **De Broglie Wavelength** which states that for any particle with momentum p, we can associate a wavelength λ such that

$$\lambda = \frac{h}{p}$$

where h is the Planck's constant.

Now, consider the hydrogen atom. It has a single proton, and a single electron on its orbital. The electron is moving with a momentum p and charge -e. If the electron is treated as a wave, the question is that "What are the allowed trajectories?"

From those, we can calculate the allowed energies, and some other parameters.

Since the ψ function represents probability of presence, if I want to have a significant presence along the orbital of the atom, then we want the circumference to be an integer multiple of the wavelength. This means that the integer multiples of the wavelength are the possible trajectories.

$$2\pi r=n\lambda=n\;rac{h}{p}$$

Is the condition for having a sustainable trajectory.

We also know that the electron does not move way from the proton because it is bound by a force. That force is

$$F=\frac{1}{4\pi\epsilon_0}\frac{e^2}{r^2}=\frac{mv^2}{r}=\frac{p^2}{mr}$$

1

Simplifying, we get

$$2\pi r = n \, rac{h}{p}$$
 $rac{1}{4\pi\epsilon_0} rac{e^2}{r} = rac{p^2}{m}$

Obtaining p,

$$egin{aligned} r &= rac{nh}{2\pi p} \ &rac{1}{4\pi\epsilon_0}\,rac{e^2(2\pi p)}{nh} = rac{p^2}{m} \ &rac{1}{2\epsilon_0}\,rac{e^2}{nh} = rac{p}{m} \end{aligned}$$

Finally,

$$p = rac{me^2}{2\epsilon_0 h} \; rac{1}{n}$$

Plugging it back to the r equation gives

$$r=rac{nh}{2\pi}~rac{2\epsilon_0}{me^2}~nh$$
 $r=rac{nh}{\pi}rac{\epsilon_0}{me^2}~nh$

Finally,

$$r = \frac{\epsilon_0}{\pi m e^2} \, n^2 h^2$$

where $n \in \mathbb{N}$ and m is the mass of the electron.

This means that both radius and momentum are quantized. They can only take certain values given that they have a bound state. It requires that the sum of the kinetic and potential energies of the particle be negative.

$$E_{total} = E_{kinetic} + E_{potential}$$

$$E_{total} = \frac{p^2}{2m} - \frac{1}{4\pi\epsilon_0} \frac{e^2}{r}$$

$$E_{total} = \frac{p^2}{2m} - \frac{p^2}{m} = -\frac{p^2}{2m} o E_{total} < 0$$

Substituting p to the total energy equation gives

$$E_{total} = -\frac{me^4}{8\epsilon_0^2 h^2} \cdot \frac{1}{n^2}$$

$$E_{total} = -rac{13.6 \; eV}{n^2}$$

If we have another atom of the same kind that is close to it, the energy levels of either of those atoms would change because of the **Pauli Exclusion Principle.** The principle states that you cannot have the same quantum numbers when two particles come together.

Since the two atoms occupy the same spatial area, their energy levels cannot be the same. Each energy level will split (each energy level can take two electrons: up-spin or down-spin). This is what we call degeneracy.

The next question is that: When does the Pauli Exclusion Principle become important? Apparently, the principle is always there. No two atoms in the universe have the same quantum numbers. It just becomes less noticeable when they are far apart and more evident when they get close.

When we create a crystal lattice, many electrons come together and we see more degeneracy. These degenerate energy levels are what we call energy bands. **Hybridization** happens within some of these bands specifically those of tetrahedral structure with a 109.5° angle. At 0~K, the bands are filled from the lowest to the highest energy band. Thus for a carbon atom which has 6 electrons, the $1s^2$ band is filled as well as the $2s^1~2p^3$ hybrid band.

Consider two bands, a valence band and a conduction band. If the valence band is full, then the material is a bad conductor since it allows no electron movement. A good conductor is one that allows full electron movement from the valence band to the conduction band. A **semiconductor** is somewhat in the middle. The bands where there are no electrons can be called holes and carry a positive charge. Electrons move faster than holes. **Recombination** is the process of combining holes and electrons within a band. At the steady-state, the rate of recombination and hole generation are equal.

3 Solid-State Physics

The concept of **Doping** allows us to introduce a different element to control the ratio of electrons and holes. For example, if we use an element from the column IV of the periodic table, then we can choose elements from columns III and V as **Dopants**. As we increase the temperature, the number of electrons reach the number of dopants since they all become ionized. We call this number N_D . Similarly, we use N_A for the holes.

Electrons are fermions. They follow the **Fermi-Dirac Distribution** which tells us that we can obtain the probability of finding an electron with energy E by

$$f(E) = \frac{1}{1 + e^{\frac{E - E_f}{kT}}}$$

where k is the Boltzmann's constant and T is the absolute temperature. E_f defined as the energy where the probability of finding an electron is $\frac{1}{2}$. As $E - E_f$ gets > 3kT, the more it resembles the Boltzmann Distribution.

$$f(E) \propto e^{rac{-E}{kT}}$$

We can then obtain the relation

$$n=N_c e^{rac{E_f-E_c}{kT}}$$

and

$$p = N_v e^{\frac{E_v - E_f}{kT}}$$

For an intrinsic semiconductor,

$$n_i^2 = np$$

where n_i is the intrinsic carrier concentration.

Similarly, the density of carriers n and p are given by

$$N_D = n = n_i e^{\frac{E_f - E_i}{kT}}$$

and

$$N_A = p = n_i e^{rac{E_i - E_f}{kT}}$$

3.1 Drift and Diffusion

The Equipartition Theorem states that in thermal equilibrium, each degree of freedom takes an energy

$$E=rac{1}{2}kT$$

on average. For an electron, the degree of freedom is equal to 3. That translates to

$$E_{total} = rac{3}{2}kT$$

From classical mechanics,

$$E_{kinetic} = rac{1}{2} m v^2$$

We get,

$$\frac{1}{2}mv^2 = \frac{3}{2}kT$$
$$v^2 = \frac{3kT}{m}$$

Since the mass is very small for an electron, the velocity is very high.

Consider an electric field on which the electron is placed. Assume that the field has a magnitude of E.

We know that,

$$F = \frac{dP}{dt}$$

and

$$-qE = \frac{\Delta P}{\Delta T} = \frac{m\Delta v}{\tau_c}$$

$$\Delta v = rac{qE au_c}{m}$$

We can assume that the velocity, on average, is equal to

$$oxed{v_{ave} = rac{1}{2}\Delta v = rac{1}{2}rac{qE au_c}{m} = v_{drift}}$$

Which is also equal to

$$v_{drift} = -\mu_n E$$

where μ_n is the mobility.

The incremental charge that passes through a slice of a slab is obtained by

$$dq = -qnAv_d \cdot dt$$

where -q is the charge of an electron, n is the electron density, A is the cross-sectional area of the slab, and v_d is the drift velocity. We know that

$$I_n = \frac{dq}{dt} = -qnAv_d$$

and

$$J_n = rac{I}{A} = -nqv_d = qn\mu_n E$$

Similarly for holes,

$$J_p = qp\mu_p E$$

Finally,

$$J_{total} = q \cdot (n\mu_n + p\mu_p)E = \sigma E$$

where σ is the conductivity. The resistivity, ρ , is the reciprocal of σ .

3.2 PN Junction

Consider two pieces of semiconductor. A P-type semiconductor has acceptor atoms; an N-type has donor atoms. In a simple sense, the P-type semiconductor has more holes, and the N-type semiconductor has more electrons.

As the temperature increases, some atoms get ionized. Some holes from the p-type material goes to the n-type material. Similarly, some electrons from the n-type material goes to the p-type material. The border of these regions get depleted. This is what we call the **Depletion Region**. Recombination happens to some electrons and holes. This process happens randomly.

This depletion region generates an electric field. As the temeperature increases, the depletion region gets larger. As the depletion region gets larger, the generated electric field becomes stronger. This electric field impedes the movement of a charge from a region to the other. If an electron has enough energy, then that electron can jump from the n region to the p region. Those electron-hole pairs that recombined at the depletion region gets affected by the electric field. This opposes the creation of a depletion region.

We know that energy is the product of charge and voltage. Thus,

$$q\psi_p = E_{i,p} - E_f = kT \cdot ln\left(rac{N_A}{n_i}
ight)$$

and

$$\psi_p = E_{i,p} - E_f = rac{kT}{q} ln \left(rac{N_A}{n_i}
ight)$$

similarly for the electrons,

$$\psi_n = E_f - E_{i,n} = rac{kT}{q} ln \left(rac{N_D}{n_i}
ight)$$

Finally,

$$\boxed{\psi_o = \psi_n + \psi_p = \frac{kT}{q} ln \left(\frac{N_A N_D}{n_i^2} \right)}$$

where ψ_o is the built in potential.

From the Boltzmann distribution,

$$n \propto \exp\left(-rac{q\psi_o}{kT}
ight)$$

where n is the number of electrons that has enough energy to pass the potential barrier. This is also true for the holes.

If we apply a forward-bias V_D across the ends of the pn junction, then the depletion region will be smaller. The electric field will go down and the potential barrier will be lowered by qV_D . This means that more electrons can pass through.

$$n \propto \exp\left(-rac{q(\psi_o-V_D)}{kT}
ight)$$

The net flow of electrons is obtained by

$$\left|J_n = \exp\left(-\frac{q(\psi_o - V_D)}{kT}\right) - \exp\left(-\frac{q\psi_o}{kT}\right) = \exp\left(-\frac{q\psi_o}{kT}\right) \cdot \left[\exp\left(\frac{qV_D}{kT}\right) - 1\right]$$

This means that the net current is proportional to

$$\exp\left(rac{qV_D}{kT}
ight)-1$$

The diode current is then obtained by

$$I = I_s \left[\exp \left(rac{q V_D}{k T}
ight) - 1
ight]$$

where I_s is the proportionality constant.