Homework 3: LeNet Accelerator Engine

Submission Due Dates: 2022/4/19 23:59

Objective

In this homework, you will implement a CNN accelerator for the quantized LeNet model.

Model architecture

In Homework 1 and 2, we implemented a quantized LeNet model with 8-bit parameters (e.g., filter weights, input activations, and output activations). In this homework, you will need to implement an accelerator engine to compute all five layers of LeNet in Verilog. The CNN model is listed for your reference, as in Homework 1 and 2:

	=======================================	=======================================
Layer (type:depth-idx)	Output Shape	Param #
Net		
—Sequential: 1-1	[1, 6, 28, 28]	
└─Conv2d: 2-1	[1, 6, 28, 28]	150
ReLU: 2-2	[1, 6, 28, 28]	
—Sequential: 1-2	[1, 6, 14, 14]	
└─MaxPool2d: 2-3	[1, 6, 14, 14]	
—Sequential: 1-3	[1, 16, 10, 10]	
└─Conv2d: 2-4	[1, 16, 10, 10]	2,400
└─ReLU: 2-5	[1, 16, 10, 10]	
—Sequential: 1-4	[1, 16, 5, 5]	
└─MaxPool2d: 2-6	[1, 16, 5, 5]	
—Sequential: 1-5	[1, 120, 1, 1]	
└─Conv2d: 2-7	[1, 120, 1, 1]	48,000
└─ReLU: 2-8	[1, 120, 1, 1]	
—Sequential: 1-6	[1, 84]	
Linear: 2-9	[1, 84]	10,080
└─ReLU: 2-10	[1, 84]	
—Sequential: 1-7	[1, 10]	
Linear: 2-11	[1, 10]	840

Testbench & SRAM

- 1. A testbench ./sim/lenet_tb.v for your validation . It can load pattern and weight files into weight SRAM and activation SRAM, respectively, and validate the activation SRAM, where you should store your computation results. This testbench provides a simple result comparison for each layer's activations. You can modify and enhance its debugging capability accordingly. But note that we will use the original testbench to justify your design.
- 2. We have two dual-port SRAMs in ./sim/sram_model: one is the weight SRAM, the other is the activation SRAM. For the given dual-port SRAM, you can perform two 32-bit memory accesses of separate addresses in the same clock cycle.
- 3. Figure 1 shows the layout of the weight SRAM. In Conv1 and Conv2 weight layers, we only store five 8-bit weights in every two addresses, which is possible to access five weights in one clock cycle. Since Conv3 layer can be treated as a fully-connection layer, for Conv3, FC1, and FC2 weight layers, we store four 8-bit weights in each address. For FC2 biases, one 32-bit bias is stored in every address.




Figure 1: Layout of weight SRAM.

4. Figure 2 shows the layout of activation SRAM. The testbench will load the input feature map from offset 0 to offset 255 in SRAM. Each address holds four 8-bit inputs. In Conv1 layer, you should place fourteen 8-bit quantized activations in every four addresses, as figure 2 shows. In this case, the computation in the following Conv2 layer may be easier. For Conv2, Conv3, and FC1 layers, you should place four 8-bit quantized data in every address for the fully-connected computation. In the last layer, FC2, we omit the rescaling and clipping since the classification result will not

be affected. You should keep the 32-bits activation without rescaling and clipping.




Figure 2: Layout of the activation SRAM.

5. You should use the **parameter.zip** (with image, weight, bias, quantization scale, and golden data) generated and submitted in Homework 2 to validate your design, which should be pre-processed to match the format in Figures 1 and 2 (i.e., you have to write your own tool to convert the format). It is recommended to understand the testbench before writing your own pre-processing code. (You may use either C++ or Python, or any programming language.)

Note: Refer to the **Appendix** for further discussion on the data arrangement in SRAMs.

Note: You should put proper quantization scale factors in the testbench.

6. TA will use unreleased patterns to evaluate your homework.

Design

- 1. A template ./hdl/lenet.v is provided. DO NOT change the I/O declaration.
- 2. **Input and output delay constraints** are added in the synthesis script. Make sure to add flip-flops after input data port (**except for the clk port**) and before output data ports.




Figure 3: I/O-registered design style.

3. Figure 4 illustrates possible data reuse in convolution operations and max-pooling in CONV1 and CONV2. Typically, four 5x5 convolution operations generate 2x2 activations. The following max pool operation produces one result (see Figure 4). You may consider loading 6x6 ifmaps to improve the data reusability. Note that the dual-port SRAM allows you to load two 32-bit words (i.e., eight 8-bit ifmaps) at the same time. So it is possible to process Columns 2 to 7 while dealing with Columns 0 to 5 for further improvement.




Figure 4: Data reuse for convolution operations.

4. I/O port descriptions

Signals	Width	1/0	Description
clk	1	Input	Clock.
rst_n	1	Input	Active-low reset.
compute_start	1	Input	Single-cycle active-high pulse. The
			testbench uses this signal to inform the
			engine to start computing.
compute_finish	1	Output	You should pull up a single-cycle active-
			high pulse to inform the testbench the

	\ \	LSI System D	esign Spring 2022
			computation is finished.
scale_CONV1	32	Input	Quantization scale factor for CONV1
scale_CONV2	32	Input	Quantization scale factor for CONV2
scale_CONV3	32	Input	Quantization scale factor for CONV3
scale_FC1	32	Input	Quantization scale factor for FC1
scale_FC2	32	Input	Quantization scale factor for FC2
sram_weight_wea0	4	Output	Each bit represents the byte-write
			enable for SRAM port 0. E.g., 4'b1001
			means RAM[addr][31:24] =
			wdata[31:24] and RAM[addr][7:0] =
			wdata[7:0], leaving RAM[addr][23:8]
			untouched. Please refer to the SRAM
			behavior code to know how it works.
sram_weight_addr0	16	Output	Read/write address of port 0 in the
			weight SRAM.
<pre>sram_weight_wdata0</pre>	32	Output	Write data of port 0 in the weight SRAM.
sram_weight_rdata0	32	Input	Read data of port 0 in the weight SRAM.
sram_weight_wea1	4	Output	Each bit represents the byte-write
			enable for SRAM port 1.
sram_weight_addr1	16	Output	Read/write address of port 1 in the
			weight SRAM.
sram_weight_wdata1	32	Output	Write data of port 1 in the weight SRAM.
sram_weight_rdata1	32	Input	Read data of port 1 in the weight SRAM.
sram_act_wea0	4	Output	Each bit represents the byte-write
			enable for SRAM port 0.
sram_act_addr0	16	Output	Read/write address of port 0 in the
			activation SRAM.
sram_act_wdata0	32	Output	Write data of port 0 in the activation
			SRAM.
sram_act_rdata0	32	Input	Read data of port 0 in the activation
			SRAM.
sram_act_wea1	4	Output	Each bit represents the byte-write
			enable for SRAM port 1.
sram_act_addr1	16	Output	Read/write address of port 1 in the
		_	activation SRAM.
sram_act_wdata1	32	Output	Write data of port 1 in the activation
			SRAM.
sram_act_rdata1	32	Input	Read data of port 1 in the activation
			SRAM.

Simulation & Synthesis

1. RTL behavior simulation

Before synthesis, make sure the result of the RTL behavior simulation is correct. Figure 5 shows the simulation message when the validation is passed. You should modify the file **sim_rtl.f** with proper file paths.

RTL simulation command:

```
cd sim/
make sim
```

```
ncsim> source /usr/cad/cadence/INCISIV/cur/tools/inca/files/ncsimrc
FSDB Dumper for IUS, Release Verdi_R-2020.12, Linux, 11/19/2020
(C) 1996 - 2020 by Synopsys, Inc. *
*Verdi* : Create FSDB file 'lenet.fsdb'
*Verdi* : Begin traversing the scopes, layer (0).
*Verdi* : End of traversing.
Reset System
Compute start
Compute finished, start validating result...
                     [PASS]
Image
Conv 1 activation
                     [PASS]
Conv 2 activation
                     [PASS]
Conv 3 activation
      1 activation
                    [PASS]
     2 activation [PASS]
    Congratulation! All result are correct
Clock Period:
                          60 ns,Total cycle count:
                                                             23729 cycles
Simulation finish
Simulation complete via $finish(1) at time 1429950 NS + 3
 /lenet_tb.v:186
                             $finish;
ncsim> exit
```

Figure 5: Simulation pass message

2. Synthesis

Please refer to the **Spyglass tutorial** to ensure that your design is synthesizable. You may modify the Verilog file names and clock period (**cycle**) in **syn/synthesis.tcl** accordingly.

Synthesis command:

```
cd syn/
dc_shell -f synthesis.tcl
```

The synthesis script also produces timing and area reports. Make sure the timing slack is **MET**.

clock clk (rise edge) clock network delay (ideal) sram_act_wdata0_reg[19]/CK (DFFQXL) library setup time data required time	10.0000 0.0000 0.0000 -0.0727	10.0000 10.0000 10.0000 r 9.9273 9.9273
data required time data arrival time		9.9273 -8.0147
slack (MET)		1.9126

Figure 6: Design Compiler timing report screenshot

3. Gate-level simulation

Before doing gate-level simulation, please modify the clock period (**CYCLE**) to meet the synthesis clock period in **sim/lenet_tb.v**. You may add 1 to 3 ns to the synthesis clock period when encountering setup time violation. For example, if you set the synthesis clock constraint to 10 ns, you may set the clock period in the testbench to 12 ns to prevent setup time violation in gate-level simulation.

Gate-level simulation command:

```
cd sim/
make syn
```

Grading Policy

- 1. RTL simulation pass (40%)
- 2. Spyglass report to show your design is synthesizable (10%)
- 3. Gate-level simulation pass (20%)

Note: Setup/hold time violation is not acceptable, even though you can pass the gate-level simulation.

- 4. Report (10%)
- 5. Performance ranking (20%)

This part is only for those who passed the gate-level simulation.

Please fill following items to this form: https://reurl.cc/WkWnGe

- (a) Name & Student ID
- (b) Gate-level simulation clock period (e.g. 12 ns)
- (c) Gate-level simulation latency (e.g. 23729 cycles)
- (d) **Total cell area** of Design Compiler report (e.g. 77649 um^2)

Note: If you didn't fill out the form, you will not get the grade for this part!

```
Image
                  [PASS]
Conv 1 activation
                  [PASS]
Conv 2 activation [PASS]
Conv 3 activation [PASS]
    1 activation [PASS]
    2 activation [PASS]
>>> Congratulation! All result are correct
                                                       23729 cycles
Clock Period:
                       12 ns Total cycle count:
Simulation finish
Simulation complete via $finish(1) at time 285990580 PS + 0
./lenet_tb.v:196
                         $finish;
ncsim> exit
```

Figure 7: Screenshot of gate-level simulation result.

Report

- 1. Design concept (Brief and concise explanation of one to two pages would be enough. You may use Chinese.)
 - Overall hardware architecture (4%)
 - Block diagram (2%)
 - Finite-state machine diagram (2%)
 - Explanation of dataflow (and data reuse) for convolution and fully connected layers (2%)
- 2. Result (copy this table to report)

Item	Description
RTL simulation	(PASS / FAIL)
Gate-level simulation	(PASS / FAIL)
Gate-level simulation clock period	(XXX ns)
Gate-level simulation clock latency	(XXX cycles)
Total cell area	(XXX um²)

- 3. Others (optional)
 - Suggestions or comments about this class to teacher or TA.

Submission

- 1. Please submit the following files to EECLASS (or 20-point penalty if not following the rules).
 - lenet.v # Include top module lenet and all other modules.
 - lenet_syn.v # Gate-level netlist
 - lenet_syn.sdf # Standard Delay Format file for gate-level simulation
 - spyglass.rpt # Please follow the tutorial to generate this file.
 - report_timing.log # Generated by Design Compiler
 - report_area.log # Generated by Design Compiler
 - <student id> hw3 report.pdf # Use the template we provide.
- 2. **DO NOT** compress them!

Appendix

Pipeline architecture:

You may want to optimize your design for better performance. Pipeline is a common technique to improve the throughput with a higher clock rate. For example, for a combinational circuit with flip-flops in Figure 8, you can partition it into two or more pipeline stages. The clock rate can be higher with a larger hardware area (i.e., additional flip-flops between stages).




Figure 8: Simple pipeline concept.

Data arrangement in SRAMs:

You need to prepare three pattern files for Verilog simulation (please trace the testbench code to know where to place them). First one is **weights.csv**, which consists of all quantized weights. You need to process and integrate the weight files in **parameters/weights** of HW2 (also refer to Figure 1, Table 1 and Table 2).

Note: weight.csv contains 15760 lines; each line has a 32-bits HEX data (in ASCII format for \$readmemh()).

Table 1: Mapping of weights.csv and original quantized weight files

Line # of weights.csv	Original filename
0 – 59	c1.conv.weight.csv
60 – 1019	c3.conv.weight.csv

1020 – 13019	c5conv.weight.csv
13020 – 15539	f6.fc.weight.csv
15540 – 15749	output.fc.weight.csv
15750 – 15759	output.fc.bias.csv

Table 2: Weight files data comparison

Table 2. Weight files data comparison				
Processed weight file		Original weight files		
Line #	Data (HEX)	Line #	Data (DEC)	
Filename	e: weight.csv	Filename: c1.	conv.weight.csv	
0	26F7EAC8	0	-56	
		1	-22	
		2	-9	
		3	38	
1	000000F	4	15	
		BLANK	0	
		BLANK	0	
		BLANK	0	
Filename	Filename: weight.csv		Filename: c5.conv.weight.csv	
1020	FB020203	0	3	
		1	2	
		2	2	
		3	-5	
1021	FFFE00FB	4	-5	
		5	0	
		6	-2	
		7	-1	
Filename: weight.csv		Filename: ou	tput.fc.bias.csv	
15750	0000003A	0	58	
15751	FFFFFAD	1	-83	
15752	FFFFF50	2	-176	
15753	000000D	3	13	

The second one is **golden00.csv**, which consists of quantized activations. You need to process and integrate the files in **parameters/activations/img0** (also refer to Figure 2, Table 3, and Table 4).

Note: golden00.csv contains 753 lines, each line has 32-bits HEX data.

Table 3: Mapping of golden00.csv and original activation files

Line # of golden00.csv	Original filename	
0 – 255	c1/input.csv	
256 – 591	c3/input.csv	
592 – 691	c5/input.csv	
692 – 721	f6/input.csv	
722 – 742	output/input.csv	
743 – 752	output/output.csv	

Table 4: Activation files data comparison

Processe	ed activation file	Original ac	ctivation files
Line #	Data (HEX)	Line #	Data (DEC)
Filenam	e: golden00.csv	Filename:	c1/input.csv
65	D48F8080	260	-128
		261	-128
		262	-113
		263	-44
66	DE111B29	264	41
		265	27
		266	17
		267	-34
		•••	
Filenam	e: golden00.csv	Filename:	c3/input.csv
324	52250800	238	0
		239	8
		240	37
		241	82
325	6E6F6F6E	242	110
		243	111
		244	111
		245	110
326	14576B6D	246	109
		247	107
		248	87
		249	20
327	0000576B	250	107
		251	87
		BLANK	0
		BLANK	0

Filename: golden00.csv Filenam		Filename: ou	tput/output.csv
743	FFFFA07C	0	-24452
744	FFFFD10A	1	-12022
745	FFFFD82A	2	-10198
746	FFFFD645	3	-10683

The last one is **image00.csv**, which is similar to **golden00.csv**, but it only contains the image part. You need to process **input.csv** in **parameters/activations/img0/c1** (also refer to Figure 2, Table 5, and Table 6).

Note: image00.csv contains 256 lines, each line has 32-bits HEX data.

Table 5: Mapping of image00.csv and original activation files

Line # of image00.csv	Original filename
0 – 255	c1/input.csv

Table 6: Image files data comparison

9 1			
Processed activation file		Original activation files	
Line #	Data (HEX)	Line #	Data (DEC)
Filename: image00.csv		Filename: c1/input.csv	
65	D48F8080	260	-128
		261	-128
		262	-113
		263	-44
66	DE111B29	264	41
		265	27
		266	17
		267	-34