neter ID	Parameter Name	Parameter Description	Type	Min. Write Value	Max. Write Value	Value Description	Request	Response
						0=Delete existing MCA data		
C	Run Start	Start acquisition of MCA data	Func		0 1	1=Resume existing MCA data	Standard	Standard
1	Run Stop	Stop acquisition of MCA data	Func		-	- -	Standard	Standard
						0=None		
						1=Stop at fixed Livetime		
						2=Stop at fixed Realtime		
		Set type of stop condition for MCA data				3=Stop at fixed Input Counts		
2	Run Stop Condition Type	acquisition	R/W		0 4	4=Stop at fixed Output Counts	Standard	Standard
		Set LSBytes value of stop condition for MCA data						
3	Run Stop Condition Value Low	acquisition	R/W		0 65535	Time in units of 10μs or number of counts	Standard	Standard
		Set MSBytes value of stop condition for MCA data						
4	Run Stop Condition Value High	acquisition	R/W		0 65535	Time in units of 10μs or number of counts	Standard	Standard
						0=No run active		
5	Run Status	Read current status of run	R		-	- 1=run active	Standard	Standard
6	Run Reatime Low	Read LSBytes of realtime in run	R		-	- Time in units of 10μs	Standard	Standard
7	Run Realtime High	Read MSBytes of realtime in run	R		-	- Time in units of 10μs	Standard	Standard
8	Run Livetime Low	Read LSBytes of livetime in run	R		-	- Time in units of 10μs	Standard	Standard
9	Run Livetime High	Read MSBytes of livetime in run	R		-	- Time in units of 10μs	Standard	Standard
10	Run Output Counts Low	Read LSBytes of output counts in run	R		-	Number of counts	Standard	Standard
11	Run Output Counts High	Read MSBytes of output counts in run	R		-	Number of counts	Standard	Standard
12	Run Input Counts Low	Read LSBytes of input counts in run	R		-	Number of counts	Standard	Standard
13	Run Input Counts High	Read MSBytes of input counts in run	R		-	Number of counts	Standard	Standard
14	Run Output Count Rate Low	Read MSBytes of output count rate in run	R		-	- Counts per second	Standard	Standard
15	Run Output Count Rate High	Read MSBytes of output count rate in run	R		-	- Counts per second	Standard	Standard
16	Run Input Count Rate Low	Read LSBytes of input count rate in run	R		-	- Counts per second	Standard	Standard
17	Run Input Count Rate High	Read MSBytes of output count rate in run	R		-	- Counts per second	Standard	Standard
						Response Bytes 1-2 : 0=No Run Active, 1=Run Active		
						Response Bytes 3-10 : Time in units of 10μs		
						Response Bytes 11-18: Numbers of counts		Non-Standard
18	Run Statistics	Read Parameters 5 to 17 simultaneously	Func	-	-	Response Bytes 19-26: Counts per second	Standard	(13 x 4Byte)
								Non-Standard
						Counts per bin		(Configured by
						Starts at LSByte of bin 0		Parameter 20
	MCA Read		Func		-	Ends at MSByte of last bin	Non-Standard	21)
20	MCA Number of Bins	Set or read the number of bins in MCA	R/W		9 13	Width of MCA as 2^x	Standard	Standard
21	MCA Bytes per bin	Set or read the number of bytes per bin in MCA	R/W		1 3	Bytes per bin	Standard	Standard

Parameter ID	Parameter Name	Parameter Description	Туре	Min. Write Value	Max. Write Value	Value Description	Request	Response
32	Fastfilter Peaking Time	Set or read the peaking time of the fastfilter	R/W	2	40	Time in units of 12.5ns	Standard	Standard
33	Fastfilter Gap Time	Read the gap time of the fastfilter	R	-	-	Time in units of 12.5ns	Standard	Standard
34	Mediumfilter Peaking Time	Read the peaking time of the mediumfilter	R	-	-	Time in units of 12.5ns	Standard	Standard
35	Mediumfilter Gap Time	Read the gap time of the mediumfilter	R	-	-	Time in units of 12.5ns	Standard	Standard
36	Slowfilter Peaking Time	Set or read the peaking time of the slowfilter	R/W	2	1008	Time in units of 12.5ns, Permitted values: 2, 4, 6, 8, 12 and n*16	Standard	Standard
37	Slowfilter Gap Time	Set or read the gap time of the slowfilter	R/W	2	127	Time in units of 12.5ns	Standard	Standard
		Set or read trigger threshold for pulse detection						
38	Fastfilter Trigger Threshold	with the fastfilter	R/W	C	16384	Arbitrary Unit	Standard	Standard
		Set or read the trigger threshold for pulse						
39	Mediumfilter Trigger Threshold	detection with the mediumfilter	R/W	C	16384	Arbitrary Unit	Standard	Standard
		Set or read utilisation of mediumfilter for pulse				0=Disable pulse detection by mediumfilter		
40	Mediumfilter Pulse Detection Enable	detection	R/W	C	1	1=Enable pulse detection by mediumfilter	Standard	Standard
41	Fastfilter Maximum Width	Set or read maximum width of fastfilter	R/W	0	255	Time in units of 12.5ns	Standard	Standard
42	Mediumfilter Maximum Width	Set or read maximum width of mediumfilter	R/W	0	1023	Time in units of 12.5ns	Standard	Standard
43	Reset Inhibit Time	Set or read inhibit time after detection of reset	R/W	C	255	Time in units of 12.5ns	Standard	Standard
		Set or read length of running average for baseline						
44	Baseline Average Length	mean	R/W	1	. 8	Length of running average as 2 ^x	Standard	Standard
						0=Longest possible medium filter		
						1=Long medium filter		
						2=Intermediate medium filter		
						3=Short medium filter		
45	Baseline Trim	Set or read value of baseline trim	R/W	C	4	4=Shortest possible medium filter	Standard	Standard
						0=Disable Baseline Correction		
46	Baseline Correction Enable	Set or read utilisation of baseline correction	R/W	0	1	1=Enable Baseline Correction	Standard	Standard
47	Digital Energy Gain	Set or read value for digital gain for energy values	R/W	0	16383	Arbitrary Unit: 5461 ≈ 5eV/Bin	Standard	Standard
48	Digital Energy Offset	Set or read value for digital offset for energy values	R/W	0	65535	Arbitrary Unit: 0 is -256 Bins, 32768 is 0 Bins, 65565 is +256 Bins	Standard	Standard
						0=Disable Dynamic Reset		
49	Dynamic Reset Enable	Set or read utilisation of dynamic reset	R/W	0	1	1=Enable Dynamic Reset	Standard	Standard
						ADC-Code (1 LSB=30μV)		
50	Dynamic Reset Threshold	Set or read threshold of dynamic reset	R/W		65535	0= -1V; 65535= +1V	Standard	Standard
51	Dynamic Reset Duration	Set or read duration of dynamic reset	R/W	0	65535	Time in units of 12.5ns	Standard	Standard

neter ID	Parameter Name	Parameter Description	Type	Min. Write Value	Max. Write Value	Value Description	Request	Response
64	Parameter Set Load	Load parameter set from user data memory	Func		0	1 Number of memory slot	Standard	Standard
		Save current parameter set into user data						
65	Parameter Set Save	memory	Func		0	1 Number of memory slot	Standard	Standard
66	Firmware Version Major	Read major number of firmware version	R		-	- Version number	Standard	Standard
67	Firmware Version Minor	Read minor number of firmware version	R		-	- Version number	Standard	Standard
68	Firmware Version Patch	Read patch number of firmware version	R		-	- Version number	Standard	Standard
69	Firmware Version Build	Read build number of firmware version	R		-	- Version number	Standard	Standard
70	Firmware Variant	Read variant code of firmware	R		-	- Variant Code	Standard	Standard
71	MCU Passthrough	UART communication with MCU	Func		-	- MCU Datagramm	Non-Standard	Non-Standard
						Bit 0: 0=Not PWR; 1=PWR		
						Bit 1: 0=Not RDY; 1=RDY		
72	MCU Status	Read status information about the MCU	R		-	- Bit 2: 0=Not ARDY; 1=ARDY	Standard	Standard
73	Board Temperature	Read board temperature	R			- Temperature in units of 1/16 K	Standard	Standard
	·	Set or read powerdown status of analog	1			0=Disable Powerdown		
74	Analog Hardware Powerdown	hardware	R/W		o	1 1=Enable Powerdown	Standard	Standard
	Clocking Speed	Set or read clocking speed of DPP	R/W		0	0 0=80MHz	Standard	Standard
			†					Non-Standard
79	Read all Parameter	Read parameters 0 to 255 simultaneously	Func		_	- See respective entries in this document	Standard	(256 x4Byte)
		Set or read trigger source for "Event Scope Get"				0=Instant Trigger, 1=Specific ADC Value, 2=ADC Out of Range, 3=Fastfilter Trigger, 4=Fastfilter Reset Detected, 5=Fastfilter Pileup, 6=Mediumfilter Trigger, 7=Mediumfilter Reset Detected, 8=Mediumfilter Pileup, 9=New Output Count (Any Energy), 10=New Output Count (Specific Energy),		
80	Event Trigger Source	and "Event Rate Calculate"	R/W		0 1	.2 11=New Baseline Sample, 12=Dynamic Reset	Standard	Standard
81	Event Trigger Value	Set or read trigger value for "Event Scope Get" and "Event Rate Calculate"	R/W		0 6553	Depends on parameter "Event Trigger Source"	Standard	Standard
		Set or read sampling interval for "Event Scope						
82	Event Scope Sampling Interval	Get"	R/W		1 6553	Sample frequency as fraction of 80MHz	Standard	Standard
						0=Timeout after 1s without trigger		
						1=Timeout after 2s without trigger		
						2=Timeout after 4s without trigger		
						3=Timeout after 8s without trigger		
83	Event Scope Trigger Timeout	Set or read trigger timeout for "Event Scope Get"	R/W		0	4 4=Timeout after 16s without trigger	Standard	Standard
						0=ADC-Data, 1=Fastfilter, 2=Mediumfilter, 3=Slowfilter, 4=Baseline-		
84	Event Scope Get	Trigger and read signal trace	Func		0	5 Average, 5= Baseline-Sample	Non-Standard	Non-Standard
						0=Run trigger for 1s		
						1=Run trigger for 2s		
						2=Run trigger for 4s		
						3=Run trigger for 8s		
85	Event Rate Calculate	Refresh parameter 86 und 87	Func		0	4 4=Run trigger for 16s	Standard	Standard
86	Event Rate Low	Amount of triggered events LSBytes	R	-	-	Trigger amount	Standard	Standard
87	Event Rate High	Amount of triggered events MSBytes	R	-	-	Trigger amount	Standard	Standard

eter ID	Parameter Name	Parameter Description	Туре	Min. Write Value	Max. Write Value	Value Description	Request	Response
						0=Disable Powerdown		
96	Ethernet Powerdown	Set or read powerdown status of ethernet chip	R/W) 1	1=Enable Powerdown	Standard	Standard
97	Ethernet Protocol	Set or read ethernet protocol	R/W		1 2	1=TCP, 2=UDP	Standard	Standard
						0=Auto negotiation		
						1=10MBits Half Duplex		
						2=10MBits Full Duplex		
						3=100MBits Half Duplex		
98	Ethernet Speed	Set or read ethernet speed mode	R/W		0 4	4=100Mbits Full Duplex	Standard	Standard
100	Ethernet IP Address 0-1	Set or read MSByte of ethernet IP address	R/W		65535	IP Address	Standard	Standard
101	Ethernet IP Address 2-3	Set or read LSByte of ethernet IP address	R/W		65535	IP Address	Standard	Standard
102	Ethernet Subnet Mask 0-1	Set or read MSByte of ethernet subnet mask	R/W		65535	Subnet	Standard	Standard
103	Ethernet Subnet Mask 2-3	Set or read LSByte of ethernet subnet mask	R/W		65535	Subnet	Standard	Standard
		Set or read MSByte of ethernet gateway IP						
104	Ethernet Gateway IP Address 0-1	address	R/W	(65535	IP Address	Standard	Standard
105	Ethernet Gateway IP Address 2-3	Set or read LSByte of ethernet gateway IP address	R/W	,	65535	IP Address	Standard	Standard
106	Ethernet Port	Read ethernet port	R	-	-	Port number	Standard	Standard
107	Ethernet MAC Address 0-1	Read LSByte of ethernet MAC address	R	(65535	MAC des DPPs	Standard	Standard
108	B Ethernet MAC Address 2-3	Read Medium Bytes of ethernet MAC address	R		65535	MAC des DPPs	Standard	Standard
	Ethernet MAC Address 4-5	Read MSByte of ethernet MAC address	R	(MAC des DPPs	Standard	Standard
	Ethernet Reconfigure		Func	-	-	-	Standard	Standard
	<u> </u>	,				0=Disable Powerdown		
115	USB Powerdown	Set or read powerdown status of the USB chip	R/W	(1	1=Enable Powerdown	Standard	Standard
						0=Disable Powerdown		
118	SPI Powerdown	Set or read powerdown status SPI communication	R/W) 1	1=Enable Powerdown	Standard	Standard