
Review

- Register Conventions: Each register has a purpose and limits to its usage. Learn these and follow them, even if you're writing all the code yourself.
- Logical and Shift Instructions
 - Operate on bits individually, unlike arithmetic, which operate on entire word.
 - Use to isolate fields, either by masking or by shifting back and forth.
 - Use <u>shift left logical</u>, <u>s11</u>, for multiplication by powers of 2
 - Use <u>shift right logical</u>, <u>srl</u>, for division by powers of 2 of unsigned numbers (unsigned int)
 - Use <u>shift right arithmetic</u>, <u>sra</u>, for division by powers of 2 of signed numbers (int)
- New Instructions:

The Big Picture



I.e., storage in computer systems

Memory Hierarchy

Processor

- holds data in register file (~100 Bytes)
- Registers accessed on nanosecond timescale
- Memory (we'll call "main memory")
 - More capacity than registers (~Gbytes)
 - Access time ~50-100 ns
 - Hundreds of clock cycles per memory access?!

Disk


- HUGE capacity (virtually limitless)
- VERY slow: runs ~milliseconds

Memory Caching

- Mismatch between processor and memory speeds leads us to add a new level: a memory cache
- Implemented with same IC processing technology as the CPU (usually integrated on same chip): faster but more expensive than DRAM memory.
- Cache is a copy of a subset of main memory.
- Most processors have separate caches for instructions and data.

Characteristics of the Memory Hierarchy

Increasing distance from the processor in access time




Inclusive-

what is in L1\$ is a subset of what is in L2\$ is a subset of what is in MM that is a subset of is in SM

CS61C L12 Caches I (5) CMPS 321 @ CSUB I Winter 2016

Typical Memory Hierarchy

 The Trick: present processor with as much memory as is available in the cheapest technology at the speed offered by the factors technology



CS61 C L12 Caches I (6) CMPS 321 @ CSUB | Winter 2016

Memory Hierarchy

- If level closer to Processor, it is:
 - Smaller
 - Faster
 - More expensive
 - subset of lower levels (contains most recently used data)
- Lowest Level (usually disk) contains all available data (does it go beyond the disk?)
- Memory Hierarchy presents the processor with the illusion of a very large & fast memory

Memory Hierarchy Analogy: Library

- You're writing a term paper (Processor) at a table in Stiern
- Stiern Library is equivalent to disk
 - essentially limitless capacity, very slow to retrieve a book
- Table is main memory
 - smaller capacity: means you must return book when table fills up
 - easier and faster to find a book there once you've already retrieved it
- Open books on table are cache
 - smaller capacity: can have very few open books fit on table; again, when table fills up, you must close a book
 - much, much faster to retrieve data
- Illusion created: whole library open on the tabletop
 - Keep as many recently used books open on table as possible since likely to use again
 - Also keep as many books on table as possible, since faster than going to library

Memory Hierarchy Basis

- Cache contains copies of data in memory that are being used.
- Memory contains copies of data on disk that are being used.
- Caches work on the principles of temporal and spatial locality.
 - Temporal Locality: if we use it now, chances are we'll want to use it again soon.
 - Spatial Locality: if we use a piece of memory, chances are we'll use the neighboring pieces soon.

Two Types of Locality

- Temporal Locality (locality in time)
 - If a memory location is referenced then it will tend to be referenced again soon
 - ⇒ Keep most recently accessed data items closer to the processor
- Spatial Locality (locality in space)
 - If a memory location is referenced, the locations with nearby addresses will tend to be referenced soon
 - ⇒ Move blocks consisting of contiguous words closer to the processor

Cache Design (for ANY cache)

- How do we organize cache?
- Where does each memory address map to?
 - (Remember that cache is subset of memory, so multiple memory addresses map to the same cache location.)
- How do we know which elements are in cache?
- How do we quickly locate them?

How is the Hierarchy Managed?

- registers → memory
 - By compiler (or assembly level programmer)
- cache → main memory
 - By the cache controller hardware
- - By the operating system (virtual memory)
 - Virtual to physical address mapping assisted by the hardware (TLB)
 - By the programmer (files)

Administrivia


- Midterm 1 Next Week
- HW 1 Solutions
- HW 2 Available
- Lab 3 Online
- Notes Updated

Direct-Mapped Cache (1/4)


- In a direct-mapped cache, each memory address is associated with one possible block within the cache
 - Therefore, we only need to look in a single location in the cache for the data if it exists in the cache
 - Block is the unit of transfer between cache and memory

Direct-Mapped Cache (2/4)


CS61C L12 Caches I (15)



Direct-Mapped Cache (3/4)



Direct-Mapped Cache (4/4)



Issues with Direct-Mapped

- Since multiple memory addresses map to same cache index, how do we tell which one is in there?
- What if we have a block size > 1 byte?
- Answer: divide memory address into three fields

tag index byte to check to offset within correct block block

Direct-Mapped Cache Terminology

All fields are read as <u>unsigned</u> integers.

Index

specifies the cache index (which "row"/block of the cache we should look in)

Offset

 once we've found correct block, specifies which byte within the block we want

Tag

 the remaining bits after offset and index are determined; these are used to distinguish between all the memory addresses that map to the same location

TIO Eddie's great cache mnemonic

AREA (cache size, B)

= HEIGHT (# of blocks)


 $2^{(H+W)} = 2^{H} * 2^{W}$

* WIDTH (size of one block, B/block)

Tag Index Offset

WIDTH (size of one block, B/block)

HEIGHT (# of blocks)



Direct-Mapped Cache Example (1/3)

- Suppose we have a 8B of data in a directmapped cache with 2 byte blocks
 - Sound familiar?
- Determine the size of the tag, index and offset fields if we're using a 32-bit architecture
- Offset
 - need to specify correct byte within a block
 - block contains 2 bytes

= 2¹ bytes

need 1 bit to specify correct byte

Direct-Mapped Cache Example (2/3)

- Index: (~index into an "array of blocks")
 - need to specify correct block in cache
 - cache contains 8 B = 2³ bytes
 - block contains 2 B = 2¹ bytes
 - # blocks/cache
 - bytes/cache bytes/block
 - = <u>2³ bytes/cache</u> 2¹ bytes/block
 - = 2² blocks/cache
 - need 2 bits to specify this many blocks

Direct-Mapped Cache Example (3/3)

- Tag: use remaining bits as tag
 - tag length = addr length offset index
 = 32 1 2 bits
 = 29 bits
 - so tag is leftmost 29 bits of memory address
 - Tag can be thought of as "cache number"
- Why not full 32 bit address as tag?
 - All bytes within block need same address (4b)
 - Index must be same for every address within a block, so it's redundant in tag check, thus can leave off to save memory (here 10 bits)

Peer Instruction

- A. For a given cache size: a larger block size can cause a lower hit rate than a smaller one.
- B. If you know your computer's cache size, you can often make your code run faster.
- C. Memory hierarchies take advantage of spatial locality by keeping the most recent data items closer to the processor.

ABC

1: FFF

1: FFT

2: **FTF**

2: FTT

3: TFF

3: **TFT**

4: TTF

5: **TTT**

Peer Instruction Answer

- A. Yes if the block size gets too big, fetches become more expensive and the big blocks force out more useful data.
- B. Certainly! That's call "tuning"
- C. "Most Recent" items ⇒ <u>Temporal</u> locality

- A. For a given cache size: a larger block size can cause a lower hit rate than a smaller one.
- B. If you know your computer's cache size, you can often make your code run faster.
- C. Memory hierarchies take advantage of spatial locality by keeping the most recent data items closer to the processor.

ABC

1: FFF

1: FFT

2: FTF

2: FTT

3: TFF

3: **TFT**

4: TTF

J: TIT

And in Conclusion...

- We would like to have the capacity of disk at the speed of the processor: unfortunately this is not feasible.
- So we create a memory hierarchy:
 - each successively lower level contains "most used" data from next higher level
 - exploits temporal & spatial locality
 - do the common case fast, worry less about the exceptions (design principle of MIPS)
- Locality of reference is a Big Idea