# ECE 486/586 Computer Architecture Winter 2019

### **Instruction Set Architecture Simulator**

#### Introduction

Simulation has a number of uses, but simulation at the instruction set architecture level is particularly useful for computer architects and designers. Without needing to simulate at a deeper machine organization or register-transfer level, you can explore the impact of instruction set architecture changes on CPI, look at the instruction counts for various program mixes (or benchmarks), and generate trace files useful for analyzing and comparing results of decisions in branch predictor algorithms and cache designs.

For this project, you are to write an instruction set architecture (ISA) level simulator for the PDP-11/20 minicomputer capable of generating memory trace files like those used in the cache simulations in ECE 485/585. You can write your simulator in Verilog, C, C++, or Java. If you want to use a language not on the list, check with me first.

The PDP-11/20 is one of a family of popular minicomputers from decades past. Despite its age, the PDP-11 architecture makes a good example because of its simplicity and regularity. For background on the PDP-11 architecture, please consult the following two Wikipedia articles:

http://en.wikipedia.org/wiki/PDP-11

http://en.wikipedia.org/wiki/PDP-11 architecture

For the definitive documentation, see the PDP-11/20 processor handbook (widely available on the web). Here's one:

http://research.microsoft.com/en-us/um/people/gbell/Digital/PDP%2011%20Handbook%201969.pdf

Some of these systems are still in use:

http://www.theregister.co.uk/2013/06/19/nuke plants to keep pdp11 until 2050/

#### **PDP-11 Highlights**

The PDP-11 was a 16-bit machine. All tools generally used octal for describing memory addresses and contents. Word references (and program counter values) are word aligned. You must support all addressing modes on all registers. The upper 4K words of memory space is used for I/O registers. The addresses from 0 to 400 (octal) are used for PCs and PSWs of interrupt service routines.

Note that your simulation of the PDP-11/20 will not require simulation of memory management or floating point operations. For this project you will also not need to simulate I/O (the PDP-11 used exclusively memory mapped I/O so it really wouldn't affect your simulation of the processor). You must accommodate a memory as large as 32K words. Moreover, many instructions were design to

have two variants: one that operates on words and another on bytes. You need to implement and test all the instructions in page 4-4 and 4-5 of the following link, except trap & interrupt, miscellaneous and condition code operation instructions.

https://pdos.csail.mit.edu/6.828/2005/readings/pdp11-40.pdf

#### **Software**

To test your simulator you'll write program fragments in PDP-11 assembly language and use the Macro-11 assembler to assemble them. Documentation for the Macro-11 assembler can be found at:

http://bitsavers.trailing-edge.com/pdf/dec/pdp11/rsx11/RSX11M V2/DEC-11-OIMRA-A-D MACRO 75.pdf

A translator has been written to convert these object files to an easily parsed ASCII representation your simulator can read.

Executable versions of the Macro-11 assembler and the translator can be found in the following bin directory:

(~faustm/bin/macro11 and ~faustm/bin/obj2ascii) on the MCECS Linux systems (linux.cecs.pdx.edu).

Use the following command to copy the Macro-11 assembler and the translator to your own project folder:

cp -r ~/faustm/bin/macro11 /u/username/your project folder name

cp –r ~/faustm/bin/obj2ascii /u/username/your project folder name

where username is your MCECS Linux system username, your project folder name is the folder name of your project.

Invoking macro11 without arguments will give you help. You'll most likely want to use a command line like:

```
/u/username/macro11 source.mac -o source.obj -l source.lst
```

where source.mac is your assembly language input file, source.obj is the object file created and source.lst is the list file created.

To convert the code from the object file to ASCII use

```
/u/username/obj2ascii source.obj source.ascii
```

Your simulator will then read the source.ascii memory image file.

Note that because your code will not be simulated along with an operating system, you cannot make system calls (e.g. PRINT).

#### **Format of Code File**

The program obj2ascii will read an object file produced by Macro-11 and generate an ASCII file containing a series of lines, each representing a 16-bit octal value. Each line begins with either a @, –, or \* character. Lines beginning with an - indicate an octal value to be loaded at the current load address. The starting load address defaults to 0 and is incremented by two (one word) after each load. Any line that begins with an @ indicates a change to the current load address. There will be at most one line beginning with \* to indicate the starting address of the program. Your simulator should use this if present, or allow the user to otherwise input the starting address (e.g. command line argument or prompt).

## **Simulator Output**

Your simulator should produce the following outputs:

- A memory trace file like that used in ECE 485/585 showing each instruction fetch and memory data read and write
- A summary, displayed on the screen upon completion of the simulation (execution of a HALT instruction) indicating the total number of instructions executed
- An optional display that (at every instruction fetch) succinctly indicates the contents of each register, the contents of the NZVC flags, and the currently fetched instruction

#### Trace file format

The format of the trace file should be

# <type> <address>

Where <type> of 0 indicates a data read, 1 indicates a data write, and 2 indicates an instruction fetch. The address should be displayed in <u>octal</u>. Do not display the data being read/written. The following example shows an instruction fetch from location  $200_8$  followed by a data read from location  $167_8$  and a data write back to that same location.

- 2 200
- 0 167
- 1 167

### Grading

Your project will be graded as follows:

- 50% Correctness (generates complete and correct output on all test cases)
- 25% Code quality (organized, readable, maintainable, robust)
- 15% Testing (sensible test strategy articulated and executed)
- 10% Project report (concise summary of design and testing, presentation of results)

You can also earn extra credit (up to an additional 20%) as follows:

• Create a graphical user interface that allows the user to observe the simulated execution (e.g.

- by tracing value of the registers) and to interrupt the execution to display memory contents. You can go further and permit breakpoints, single-stepping, interactive assembly, etc.
- Create a branch trace file that contains the PC for each branch you encountered, the type of branch, the target address, and whether the branch was taken. Note that subroutine calls and returns are branches.

## Plagiarism

Plagiarism on this assignment will not be tolerated. All code must be your own. You may make use of other tools to validate your assumptions about the PDP-11 architecture but you may not incorporate any outside code in your project. "Borrowed" code will result in a zero for the assignment.

## Suggestions

- Start early
- Consider
  - Get the basic memory loading working
  - o Implement memory read/write macros or functions along with trace file creation
  - Get the fetch/decode/execute framework working
  - Then work on the effective address calculation
  - Then implement each instruction type
- Complete the following milestones by the specified dates below
  - Complete the assembly code development by 2/12/2019
  - Complete all project, project report and demo by 3/15/2019
- Have a written test strategy
- Test each aspect of the ISA (opcode, addressing modes, etc)
- Include useful debugging information
  - Consider debugging modes/levels
  - Useful, but not too verbose