Freescale MQX RTOS Example Guide event example

This document explains the event example, what to expect from the example and a brief introduction to the API.

The example

The event example code shows how a task waits for an event. This event can be set by any other process or interrupt in the system. The example simulates an ISR event using another simple task.


Running the example

Connect a serial cable from the UARTO port of the board to the PC. Start HyperTerminal on the PC (Start menu->Programs->Accessories->Communications).


Make a connection to the serial port that is connected to the board (usually will be ${\tt COM1}$).



Set it for 115200 baud, no parity, 8 bits and click OK.



After the board is flashed the HyperTerminal will start printing the "Tick" message every certain time.



Explanation of the example

The example application creates two tasks. The service_task task creates an event group, opens it and enters a loop in which it waits for an event bit. When the appropriate event bit is set, it clears it and prints "Tick.". The simulated_ISR_task task opens a connection to the event group and periodically sets the corresponding event bit with a delay in between.

