



GoDroid

Application Notes

Standby Configuration



Copyright Statement

Copyright in this document is owned by GoWarrior Community. Any person is hereby authorised to view, copy, print and distribute this document subject to the following conditions:

- The document may be used for informational purposes only
- The document may be used for non-commercial purposes only
- Any copy of this document or portion thereof must include this copyright notice

This document is provided "as is" without any warranty of any kind, either express or implied, statutory or otherwise; without limiting the foregoing, the warranties of satisfactory quality, fitness for a particular purpose or non-infringement are expressly excluded and under no circumstances will GoWarrior Community be liable for direct or indirect loss or damage of any kind, including loss of profit, revenue, goodwill or anticipated savings.

This document is intended only to assist the reader in the use of the product. GoWarrior Community makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, which is used at your own risk and should not be relied upon. The information could include technical inaccuracies or typographical errors. No license, whether express, implied, arising by estoppel or otherwise, to any intellectual property right is granted by this document.

The product described in this document is subject to continuous development and improvements. GoWarrior Community also reserves the right to make changes to the specifications and product description at any time without notice.

Third-party brands and names mentioned in this publication are for identification purpose only and may be the property of their respective owners.

AndroidTM is a registered trademark of Google Inc. Linux® is a registered trademark of Linus Torvalds. Microsoft® and Windows® are registered trademarks of Microsoft Corporation. Supply of this product does not convey a license nor imply a right under any patent, or any other industrial or intellectual property right of Google Inc., Linus Torvalds, and Microsoft Corporation to use this implementation in any finished end-user or ready-to-use final product. It is hereby notified that a license for such use is required from Google Inc., Linus Torvalds and Microsoft Corporation.

For the latest version of this document refer to:

www.gowarriorosh.com

Copyright © 2015 GoWarrior Community All Rights Reserved.



Table of Contents

Pre	face	1
	Overview	1
	Audience	1
	Applicable Products	1
	Reference Documents	1
	Conventions	2
	How to Contact Us	3
1	GoDroid Standby	4
	1.1 GoDroid Standby and Shutdown	4
2	PMU Standby Configuration	5
3	FAST Standby Configuration	6
Арр	pendix: Glossary	7
Rev	ision History	8
	Document Change History	8
	Software Changes	8



List of Tables

Table 1. Typographical Conventions	. 2
Table 2. Symbol Conventions	. 2
Table 3. List of Abbreviations	. 7
Table 4. Document Change History	. 8
Table 5. Software Change History	. 8



Preface

Overview

This manual design to illustrate Standby and Shutdown flow and also its related configuration of GoDroid software development kit. This manual is organized into the following chapters:

Chapter 1: GoDroid Standby:

This chapter provides information on GoDroid Standby, Shutdown flow and also the Standby modes.

Chapter 2: PMU Standby Configuration

This chapter gives a general overview on PMU Standby configuration.

• Chapter 3: FAST Standby Configuration

This chapter describes range of common questions and their corresponding solutions related to the configuration of FAST Standby mode.

Audience

This manual is primarily written to provide complete guidance for those who wants to exploit GoWarrior TIGER Board, such as makers, tinkers, innovators, students, etc.

Applicable Products

This manual is applicable for the GoWarrior TIGER Board.

Reference Documents

N/A



Conventions

Typographical Conventions

Item	Format
codes, keyboard input commands, file names, equations, and math	Courier New, Size 10.5
Variables, code variables, and code comments	Courier New, Size, Italic
Menu item, buttons, tool names	Ebrima, Size 10.5, Bold e.g. Select USB Debugging
	Ebrima, Size 10.5, Bold
Screens, windows, dialog boxes, and tabs	Enclosed in double quotation marks
	e.g. Open the "Debug Configuration" dialog box

Table 1. Typographical Conventions

Symbol Conventions

Item	Description
<u></u> Caution	Indicates a potential hazard or unsafe practice that, if not avoided, could result in data loss, device performance degradation, or other unpredictable results.
♦ Note	Indicates additional and supplemental information for the main contents.
② Тір	Indicates a suggestion that may help you solve a problem or save your time.

Table 2. Symbol Conventions



How to Contact Us

Submit all your comments and error reports to the author at:

info@gowarriorosh.com

Tel: +886-2-8752-2000

Fax: +886-2-8751-1001

For questions regarding GoWarrior, contact our support team at the email listed below:

support@gowarriorosh.com



1 GoDroid Standby

GoDroid v1.0 supports PMU Standby and Fast Standby modes.

PMU Standby and Fast Standby have different requirements on board circuit. TIGER Board can support both modes. For the board circuit design, please refer to "TIGER Board System Reference Manual".

1.1 GoDroid Standby and Shutdown

GoDroid standby and shutdown, both are Android native process. GoDroid interface needs to be called only when the Standby mode is really accessible.

- **Standby process:** Press the power button, and the system will enters in the Standby mode.
- **Shutdown process**: The dialog box will pop up by keep pressing the power button. Here users can select option to shut down the system. The system will shut down once the Shutdown option is selected.



2 PMU Standby Configuration

PMU Standby mode saves enormous amount of power, because only the front platform has power supply, while CPU, DDR or other components have no power supply. However, in case of reboot, the whole system will be rebooted from U-Boot. This is quite similar to cold boot, but it will take relatively a longer time.

To use PMU Standby, corresponding configurations need to be made for both the standby and shutdown processes.

1. Standby

Please open the macro definition in

/system/core/libsuspend/autosuspend_wakeup_count.c as below:

#define ALI PMU STANDBY

2. Shutdown

Please open the macro definition in

/system/core/libcutils/android reboot.c as below:

#define ALI PMU STANDBY



3 FAST Standby Configuration

As in Fast Standby mode only partial components of the device will be inactive, while CPU and DDR will still have power supply. This mode consumes higher power dissipation comparatively with PMU Standby mode.

However, it is faster to exit standby mode, because there is no need to reboot all from U-Boot, and CPU can continue to run from the breakpoint.



Appendix: Glossary

Abbr.	Full Name
PMU	Power Management Unit

Table 3. List of Abbreviations



Revision History

Document Change History

Revision	Changes	Date
v1.0	Initial Release	September 07, 2015

Table 4. Document Change History

Software Changes

Revision	Changes	Date
v1.0	Initial Release	September 07, 2015

Table 5. Software Change History



www.gowarriorosh.com

Headquarters

Tel: +886-2-8752-2000 Fax: +886-2-8751-1001

