

Sheet: /
File: uGSM-2G-BLE.sch

Title: uGSM-2G-BLE-board

Size: A4	Date:	**Rev: 1.0**
KiCad E.D.A. kicad 5.1.5		Id: 1/6

!! check http://www.ti.com/lit/ds/symlink/tps562201.pdf Layout Guidlines !!

assign footprint: L











Sheet: /Power/ File: Power.sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. kicad 5.1.5		Id: 2/6



Sheet: /mikroBUS/ File: mikroBUS.sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. kicad 5.1.5		Id: 3/6

! Not only VBAT but also return GND are very important in layout
! The positive line of VBAT should be as short and wide as possible;
! The correct flow from source to VBAT pin should go though Zener diode then huge capacitor;
! Pin 36 and Pin37 are GND signals, and shortest layout to GND of power source should be designed;
! There are 10 GND pads in the module; these pads could enhance the GND performances.
On the upper layer of these pads, do not trace any signal if possible.



! SIM card holder should be far away from GSM antenna
! SIM traces should keep away from RF lines, VBAT and high-speed signal lines
! The traces should be as short as possible
! Shielding the SIM card signal by ground well
! Keep SIM card holder's GND connect to main ground directly







Sheet: /SIM800/
File: SIM800.sch

Title:

Size: A4	Date:	**Rev:**
KiCad E.D.A. kicad 5.1.5		Id: 4/6

Sheet: /IO/
File: IO.sch

Title:

Size: A4	Date:	**Rev:**
KiCad E.D.A. kicad 5.1.5		Id: 5/6







Sheet: /BLE module/ File: BLE.sch		
Title:		
Size: A4	Date:	**Rev:**
KiCad E.D.A. kicad 5.1.5		Id: 6/6