# EusLisp

EusLisp version 9.29/ irteus version 1.2.5

## Reference Manual

-Extended Robot Modelling-

ETL-TR-95-19 + JSK-TR-10-03 2023年3月1日

(irteus 1.2.5)

The University of Tokyo

Graduate School of Information Science and Technology Department of Mechano Informatics 野沢 峻一,植田 亮平,岡田 慧

ueda@jsk.t.u-tokyo.ac.jp nozawa@jsk.t.u-tokyo.ac.jp k-okada@jsk.t.u-tokyo.ac.jp 〒 113-8656 東京都文京区本郷 7-3-1 工学部 2 号館 7 階 73B2

(EusLisp 9.29)

通商産業省 工業技術院

電子技術総合研究所 知能システム部

松井 俊浩, 原 功, 中垣 博文(九州電力)

matsui@etl.go.jp, hara@etl.go.jp, nakagaki@etl.go.jp

〒 305 茨城県つくば市梅園 1-1-4

## 目次

第	I部	EusLisp Basics	1
1	Int	roduction	1
	1.1	EusLisp's Object-Oriented Programming	2
	1.2	Features	2
	1.3	Compatibility with Common Lisp	3
	1.4	Revision History	3
	1.5	Installation	5
	1.6	License	5
	1.7	Demonstrations	7
2	Dat	ta Tynes	g

	2.1	Numbers	Ć
	2.2	Objects	10
	2.3	Class Hierarchy	10
	2.4	Type Specifier	14
3	For	ems and Evaluation	15
	3.1	Atoms	15
	3.2	Scoping	15
	3.3	Generalized Variables	15
	3.4	Special Forms	16
	3.5	Macros	16
	3.6	Functions	17
4	Co	ntrol Structures	19
	4.1	Conditionals	19
	4.2	Sequencing and Lets	19
	4.3	Local Functions	20
	4.4	Blocks and Exits	20
	4.5	Iteration	21
	4.6	Predicates	22
5	Ob	ject Oriented Programming	<b>2</b> 4
	5.1	Classes and Methods	24
	5.2	Message Sending	25
	5.3	Instance Management	26
	5.4	Basic Classes	27
6	Ari	ithmetic Functions	30
	6.1	Arithmetic Constants	30
	6.2	Arithmetic Predicates	30
	6.3	Integer and Bit-Wise Operations	31
	6.4	Generic Number Functions	32
	6.5	Trigonometric and Related Functions	34
	6.6	Extended Numbers	35
7	Syr	mbols and Packages	36
	7.1	Symbols	36
	7.2	Packages	38
8	Seq	quences, Arrays and Tables	41
	8.1	General Sequences	41
	8.2	Lists	45

	8.3	Vectors and Arrays	49
	8.4	Characters and Strings	51
	8.5	Foreign Strings	52
	8.6	Hash Tables	54
	8.7	Queue	55
9	Stre	eams and Input/Output	56
	9.1	Streams	56
	9.2	Reader	58
	9.3	Printer	62
	9.4	InterProcess Communication and Network	64
		9.4.1 Shared Memory	64
		9.4.2 Message Queues and FIFOs	64
		9.4.3 Sockets	65
	9.5	Asynchronous Input/Output	67
	9.6	Pathnames	68
	9.7	URL-Pathnames	68
	9.8	File-name generation	69
	9.9	File System Interface	69
10	Eva	luation	70
		Evaluators	70
		Top-level Interaction	73
		Compilation	76
		Program Loading	78
		Debugging Aid	80
		Dump Objects	
		Process Image Saving	
		Customization of Toplevel	83
		Miscelaneous Functions	83
第	II部	EusLisp Extension	84
11	Sve	tem Functions	84
	•	Memory Management	84
		Unix System Calls	87
	11.4	11.2.1 Times	87
		11.2.2 Process	87
		11.2.3 File Systems and I/O	
		11.2.4 Signals	
		11.4.1 NIGITOD	04

	11.2.5 Multithread	93
	11.2.6 Low-Level Memory Management	93
	11.2.7 IOCTL	94
	11.2.8 Keyed Indexed Files	95
11.5	3 Unix Processes	97
11.4	Adding Lisp Functions Coded in C	98
11.5	5 Foreign Language Interface	99
11.6	5 VxWorks	102
	11.6.1 VxWorks 側の起動	103
	11.6.2 ホスト側の起動	103
12 M	ıltithread	105
12.1	Design of Multithread EusLisp	105
	12.1.1 Multithread in Solaris 2 operating system	105
	12.1.2 Context Separation	
	12.1.3 Memory Management	
12.2	2 Asynchronous and Parallel Programming Constructs	106
	12.2.1 Thread Creation and Thread Pool	
	12.2.2 Parallel Execution of Threads	106
	12.2.3 Synchronization primitives	106
	12.2.4 Barrier synchronization	106
	12.2.5 Synchronized memory port	107
	12.2.6 Timers	107
12.3	B Measured Parallel Gains	108
12.4	Thread creation	108
12.5	Synchronization	109
13 Ge	cometric Functions	112
13.1	Float-vectors	112
13.2	2 Matrix and Transformation	113
13.3	3 LU decomposition	115
13.4	4 Coordinates	117
13.5	6 CascadedCoords	120
13.6	Relationship between transformation matrix and coordinates class	122
14 Ge	cometric Modeling	124
	Miscellaneous Geometric Functions	124
	2 Line and Edge	
	B Plane and Face	
	4 Body	
	•	138

	14.6	Body Composition	139
	14.7	Coordinates-axes	140
	14.8	Bodies in Contact	141
	14.9	Voronoi Diagram of Polygons	154
1 -	<b>T</b> 7.		150
15		wing and Graphics	156
		Viewing	
		Projection	
		Viewport	
		Viewer	
		Drawings	
	15.6	Animation	165
16	$\mathbf{X}\mathbf{w}^{i}$	indow Interface	167
	16.1	Xlib global variables and misc functions	167
		Xwindow	
		Graphic Context	
		Colors and Colormaps	
17		m polKit	181
	17.1	X Event	182
	17.2	Panel	183
		17.2.1 Subpanels (menu-panel and menubar-panel)	185
		17.2.2 File Panel	186
		17.2.3 Text View Panel	187
	17.3	Panel Items	188
	17.4	Canvas	193
	17.5	Text Window	194
第	III	部 irteus Extension	198
18		oot Modelling	198
	18.1	Robot Data Structure and modeling	
		18.1.1 Robot Data Structures and Forward Kinematics	
		18.1.2 Geometric Information Modeling with EusLisp	199
		18.1.3 Sample Program Using Parent-Child Relationship of Geometric Information	199
		18.1.4 Modeling a Robot (Multi-Link System) using $bodyset\text{-}link$ and $joints$	199
		18.1.5 Modeling of Robot (Multi-Link System) Using cascaded-link	201
		18.1.6 Forward Kinematics Calculations in EusLisp	203
	18.2	Robot Motion Generation	204
		18.2.1 Inverse Kinematics	204

	18.2.2 Basic Jacobian Matrix	206
	18.2.3 Inverse Kinematics Including Joint Angle Limit Avoidance	207
	18.2.4 Inverse Kinematics Including Collision Avoidance	208
	18.2.5 Joint Angular Velocity Calculation Method for Collision Avoidance	208
	18.2.6 Conflict Avoidance Calculation Example	209
	18.2.7 Whole-body Coordinated Motion Generation by Non-Block Diagonal Jacobian $\ \ldots \ \ldots$	209
	18.2.8 Jacobian Calculation with Inter-Link Overlap and Joint Angle Calculation $\dots$	211
	18.2.9 Whole-body Inverse Kinematics Method Using Base-Link Virtual Joints	211
	18.2.10 Base-Link Virtual Joint Jacobian	212
	18.2.11 Mass Property Calculation	212
	18.2.12 Momentum/Angular Momentum Jacobian	213
	18.2.13 Centroid Jacobian	214
	18.3 Motion Generation Programming for Robots	214
	18.3.1 An Example of Jacobian and Inverse Kinematics Using A Three-Axis Jointed Robot $$ .	214
	18.3.2 Example In The irreus Sample Program	217
	18.3.3 Real Robot Model	218
	18.3.4 Example of Specifying A Function for target-coords of inverse-kinematics $\dots \dots$	219
	18.3.5 Example of fullbody-inverse-kinematics Considering Center of Gravity Position	221
	18.3.6 Example of Solving fullbody-inverse-kinematics Considering External Forces	222
	18.4 Robot Model	224
	18.5 Sensor Model	273
	18.6 Environment Model	277
	18.7 Dynamics calculation/Walk motion generation	280
	18.7.1 Walking motion generation	280
	18.7.2 Example of Walking Motion Generation	282
19	Robot Viewer	296
20	Interference Calculation	303
	20.1 Interference Calculation Overview	303
	20.1.1 Interference Calculation Example Between Object Shape Models	304
	20.1.2 Robot Motion and Interference Calculation	305
	20.2 Interference Calculation by PQP	306
	20.3 Interference Calculation with Bullet	307
21	BVH Data	308
22	Collada Data	315
23	Point Cloud Data	317
24	Graph Representation	323

<b>25</b>	irteus Extension	333
	25.1 GL/X Display	333
	25.2 Utility Function	339
	25.3 Math Function	347
	25.4 Image Function	349

## 第I部

## **EusLisp Basics**

## 1 Introduction

EusLisp is an integrated programming system for the research on intelligent robots based on Common Lisp and Object-Oriented programming. The principal subjects in the field of robotics research are sensory data processing, visual environment recognition, collision avoiding motion planning, and task planning. In either problem, three dimensional shape models of robots and environment play crucial roles. A motivation to the development of EusLisp was a demand for an extensible solid modeler that can easily be made use of from higher level symbolic processing system. Investigations into traditional solid modelers proved that the vital requirement for their implementation language was the list processing capability to represent and manage topology among model components. Numerical computation power was also important, but locality of geometric computation suggested the provision of vector/matrix functions as built-ins would greatly ease programming.

Thus the primary decision to build a solid modeler in a Lisp equipped with a geometric computation package was obtained. Although a solid modeler provides facilities to define shapes of 3D objects, to simulate their behaviors, and to display them graphically, its applications are limited until it is incorporated in robot modules mentioned above. These modules also need to be tightly interconnected to achieve fully integrated robot systems. EusLisp sought for the framework of this integration in object-oriented programming (OOP). While OOP promotes modular programming, it facilitates incremental extension of existing functions by using inheritance of classes. In fact, components in the solid modeler, such as bodies, faces, and edges, can orderly be implemented by extending one of the most basic class *coordinates*. These components may have further subclasses to provide individual functions for particular robot applications.

Based upon these considerations, EusLisp has been developed as an object-oriented Lisp which implements an extensible solid modeler[?]. Other features include intertask communication needed for the cooperative task coordination, graphics facilities on X-window for visual user interface, and foreign language interface to support mixed language programming.

In the implementation of the language, two performance-effective techniques were invented in type discrimination and memory management [?, ?, ?]. The new type discrimination method guarantees constant-time discrimination between types in tree structured hiearchy without regard to the depth of trees. Heap memory is managed in Fibonacci buddy method, which improves memory efficiency without sacrificing runtime or garbage-collection performance.

This reference manual describes EusLisp version 7.27 in two parts, EusLisp Basics and EusLisp Extensions. The first part describes Common Lisp features and object-oriented programming. Since a number of literatures are available on both topics, the first part is rather indifferent except EusLisp's specific features as described in Interprocess Communication and Network, Toplevel Interaction, Disk Save, etc. Beginners of EusLisp are advised to get familiar with Common Lisp and object oriented programming in other ways [?, ?]. The second part deals with features more related with robot applications, such as Geometric Modelling, Image Processing, Manipulator Model and so on. Unfortunately, the descriptions in this part may become incomplete or inaccurate because of EusLisp's rapid evolution. The update information is available via euslisp mailing list as mentioned in section 1.6.

#### 1.1 EusLisp's Object-Oriented Programming

Unlike other Lisp-based object-oriented programming languages like CLOS [?], EusLisp is a Lisp system built on the basis of object-orientation. In the former approach, Lisp is used as an implementation language for the object-oriented programming, and there is apparent distinction between system defined objects and user defined objects, since system data types do not have corresponding classes. On the other hand, every data structure in EusLisp except number is represented by an object, and there is no inherent difference between built-in data types, such as cons and symbols, and user defined classes. This implies that even the system built-in data types can be extended (inherited) by user-defined classes. Also, when a user defines his own class as a subclass of a built-in class, he can use built-in methods and functions for the new class, and the amount of description for a new program can be reduced. For example, you may extend the cons class to have extra field other than car and cdr to define queues, trees, stacks, etc. Even for these instances, built-in functions for built-in cons are also applicable without any loss of efficiency, since those functions recognize type hierarchy in a constant time. Thus, EusLisp makes all the system built-in facilities open to programmers in the form of extensible data types. This uniformity is also beneficial to the implementation of EusLisp, because, after defining a few kernel functions such as defclass, send, and instantiate, in the implementation language, most of house-keeping functions to access the internal structure of built-in data types can be coded in EusLisp itself. This has much improved the reliability and maintainability of EusLisp.

#### 1.2 Features

- **object-oriented programming** EusLisp provides single-inheritance Object-Oriented programming. All data types except numbers are represented by objects whose behaviors are defined in their classes.
- Common Lisp EusLisp follows the specifications of Common Lisp described in [?] and [?] as long as they are consistent with EusLisp's goal and object-orientation. See next subsection for incompatibilities.
- **compiler** EusLisp's compiler can boost the execution 5 to 30 times as fast as the interpreted execution. The compiler keeps the same semantics as the interpreter.
- memory management Fibonacci buddy method, which is memory efficient, GC efficient, and robust, is used for the memory management. EusLisp can run on machines with relatively modest amount of memory. Users are free from the optimization of page allocation for each type of data.
- **geometric primitives** Since numbers are always represented as immediate data, no garbage is generated by numeric computation. A number of geometric functions for arbitrary-sized vectors and matrices are provided as built-in functions.
- **geometric modeler** Solid models can be defined from primitive bodies using CSG set operations. Mass properties, interference checking, contact detection, and so on, are available.
- graphics Hidden-line eliminated drawing and hidden-surface eliminated rendering are available. Postscript output to idraw can be generated.
- **image processing** Edge based image processing facility is provided.
- manipulator model 6 D.O.F.s robot manipulator can easily be modeled.
- **Xwindow interface** Three levels of Xwindow interface, the Xlib foreign functions, the Xlib classes and the original XToolKit classes are provided.

foreign-language interface Functions written in C or other languages can be linked into EusLisp. Bidirectional call between EusLisp and other language are supported. Functions in libraries like LINPACK become available through this interface. Call-back functions in X toolkits can be defined in Lisp.

- unix binding Most of unix system calls and unix library functions are assorted as Lisp functions. Signal handling and asynchronous I/O are also possible.
- multithread multithread programming, which enables multiple contexts sharing global data, is available on Solaris 2 operating system. Multithread facilitates asynchronous programming and improves real-time response[?, ?]. If EusLisp runs on multi-processor machines, it can utilize parallel processors' higher computating power.

#### 1.3 Compatibility with Common Lisp

Common Lisp has become the well-documented and widely-available standard Lisp [?, ?]. Although EusLisp has introduced lots of Common Lisp features such as variable scoping rules, packages, sequences, generalized variables, blocks, structures, keyword parameters, etc., incompatibilities still remain. Here is a list of missing features:

- 1. multiple values: multiple-value-call, multiple-value-prog1, etc., are present only in a limited way;
- 2. some of data types: bignum, character, deftype, complex number and ratio (the last two are present only in a limited way);
- 3. some of special forms: progv, compiler-let,macrolet

Following features are incomplete:

- 4. closure only valid for dynamic extent
- 5. declare, proclaim inline and ignore are unrecognized

#### 1.4 Revision History

- 1986 The first version of EusLisp ran on Unix-System5/Ustation-E20. Fibonacci buddy memory management, simple compiler generating M68020 assembly code, and vector/matrix functions were tested.
- 1987 The new fast type checking method is implemented. The foreign language interface and the SunView interface were incorporated.
- 1988 The compiler was changed to generate C programs as intermediate code. Since the compiler became processor independent, EusLisp was ported on Ultrix/VAX8800 and on SunOS3.5/Sun3 and /Sun4. IPC facility using socket streams was added. The solid modeler was implemented. Lots of Common Lisp features such as keyword parameters, labeled print format to handle recursive data objects, generic sequence functions, readtables, tagbody, go, flet, and labels special forms, etc., were added.
- 1989 The Xlib interface was introduced. % read macro to read C-like mathematical expressions was made. manipulator class is defined.
- 1990 The XView interface was written by M.Inaba. Ray tracer was written. Solid modeler was modified to keep CSG operation history. Asynchronous I/O was added.

1991 The motion constraint program was written by H.Hirukawa. Ported to DEC station. Coordinates class changed to handle both 2D and 3D coordinate systems. Body composition functions were enhanced to handle contacting objects. CSG operation for contacting objects. The package system became compatible with Common Lisp.

- 1992 Face+ and face\* for union and intersection of two coplanar faces were added. Image processing facility was added. The first completed reference manual was printed and delivered.
- 1993 EusLisp was stable.
- 1994 Ported to Solaris 2. Multi-context implementation using Solaris's multithread facility. XToolKit is built. Multi robot simulator, MARS was written by Dr. Kuniyoshi. EusLisp organized session at RSJ 94, in Fukuoka.
- 1995 The second version of the reference manual is published.
- **2010** Version 9.00 is released, The licence is changed to BSD.
- 2011 Add Darwin OS Support, Add model files.
- **2013** Add Cygwin 64 Bit support, expand MXSTACK from 65536 to 8388608, KEYWORDPARAMETER-LIMIT from 32 to 128.
- 2014 Use UTF-8 for documents, Version 9.10 is released.
- 2015 more error check on min/max, support arbitrary length for vplus, more quiet for non-ttyp mode, Version 9.11 is releaced.
- 2015 Version 9.12 is released, support ARM Version 9.13 is released, support class documentation Version 9.14 is released, fix assert API. Now message is optional (defmacro assert (pred &optional message) Version 9.15 is released, fix char comparison function (previous version returns opossite result), support multiple argument at function /=, add url encode feature (escape-url function), support microsecond add/subtract in interval-time class Version 9.16 is released, added make-random-state, fixed bug in lib/llib/unittest.l
- 2016 Version 9.17 is released, add trace option in (init-unit-test), enable to read #f(nan inf). fix models/doc. Version 9.18 is released, support gcc-5. Version 9.20 is released, support OSX (gluTessCallback, glGen-TexturesEXT), add GL\_COLOR\_ATTACHMENT constants, fix color-image class, (it uses RGB not BGR). Version 9.21 is released, fix :trim of hashtab class, enable to compile filename containing -, do not raise error when not found cygpq.dll (Cygwin) Version 9.22 is released, add :color option to :draw-box, :draw-polyline, :draw-star, with-output-to-string returns color instead of nil, print call stack on error, check if classof is called with pointer, pass symbol pointer to funcall in apply, add error check of butlast and append.
- **2017** Version 9.23 is released, support ARM64, udpate models.
- 2018 Version 9.24 is released, change trans.l to put .h file on same directory, fix potential segmentation error in READLINE, increase max count of pushsequence for 64bit machine, remove size limitation for READLINE, enable to compile filename containing '-', add pattern option in :methods, check norm is nan for ROTANGLE, force normalize norm vector in optional argument of vector-angle, fix error on :distance when point is on the same plane, fix compiler when argument is not integer wit (1+) / (1-), fix abs for 64bit machine, fix read-binary, use cfree instead of free, extend defun function for documentation, support 18.04. Version 9.25 is released, C defun() function now takes 5 arguments

FILES	this document
README	a brief guide to lisence, installation and sample run
VERSION	EUSLisp version number
bin	executables (eus, euscomp and eusx)
c/	EusLisp kernel written in C
1/	kernel functions written in EusLisp
comp/	EusLisp compiler written in EusLisp
clib/	library functions written in C
doc/	documentation (latex and jlatex sources and memos)
geo/	geometric and graphic programs
lib/	shared libraries (.so) and start-up files
llib/	Lisp library
llib2/	secondary Lisp library developed at UTYO
xwindow/	X11 interface
makefile@	symbolic link to one of makefile.sun[34]os[34],.vax, etc.
pprolog/	tiny prolog interpreter
xview/	xview tool kit interface
tool/	
vxworks/	interface with VxWorks real-time OS
robot/	robot models and simulators
vision/	image processing programs
contact/	motion constraint solver by H.Hirukawa [?, ?, ?]
demo/	demonstrative programs
bench/	benchmark programs

表 1: Directories in \*eusdir\*

includeing doc string. Version 9.26 is released, fix typo in manuals, move test code from jskeus repository, clean compile warnings, use minmemory instead of \_end in all architecture for some compiler (aarch64/gcc-6), fix problem on call :draw-on after :draw-arrow, generate euslisp.hlp when compiled, enable to run :halve and :double in color-image.

- 2019 Version 9.27 is released. Fix documentation. Print E\_USER within default error handler. Add :init method into ration class. Update Mesa version of GL constant files. Add :word-size=64 to \*features\* and refer this information to execute on 64bit machine.
- 2021 Version 9.28 is released. Fix bugs on foreign function call ARM. Add glpixmapsurface class for offline drawing. Fix compiled function name. Close file handler after reading help file. Set :primitive to set :csg on make-gdome and make-body-from-vertices. Use gcc as linker on i386.
- 2022 Version 9.29 is released. Introduce euspointer\_t in the source code. call malloc()/cfree() within mainthread(ctx).

#### 1.5 Installation

The installation procedure is described in README. The installation directory, which is assumed to be "/usr/local/eus/", should be set to the global variable \*eusdir\*, since this location is referenced by load and the compiler.

Subdirectories in \*eusdir\* are described in table 1. Among these, c/, 1/, comp/, geo/, clib/, and xwindow contain essential files to make eus and eusx. Others are optional libraries, demonstration programs and contributions from users.

#### 1.6 License

EusLisp is distributed under the following BSD License.

Copyright (c) 1984-2001, National Institute of Advanced Industrial Science and Technology (AIST)
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- \* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- \* Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- \* Neither the name of the National Institute of Advanced Industrial Science and Technology (AIST) nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Until version 8.25, Euslisp is distributed under following licence.

EusLisp can be obtained with its source code via ftp from etlport.etl.go.jp (192.31.197.99). Those who use EusLisp must observe following articles and submit a copy of license agreement (doc/LICENCE) to the author.

Toshihiro MATSUI Intelligent Systems Division, Electrotechnical Laboratory 1-1-4 Umezono, Tsukuba, Ibaraki 3058568, JAPAN. email: matsui@etl.go.jp

Users are registered in the euslisp mailing list (euslisp@etl.go.jp), where information for Q&A, bug fix, and upgrade information is circulated. This information has been accumulated in \*eusdir\*/doc/mails.

- 1. The copyright of EusLisp belongs to the author (Toshihiro Matsui) and Electrotechnical Laboratory. The user must get agreement of use from the author.
- 2. Licensee may use EusLisp for any purpose other than military purpose.
- 3. EusLisp can be obtained freely from Elecrotechnical Laboratory via ftp.


4. EusLisp may be copied or sold as long as articles described here are observed. When it is sold, the seller must inform the customers that the original EusLisp is free.

- 5. When licensees publicize their researches or studies which used EusLisp, the use of EusLisp must be cited with appropriate bibliography.
- 6. Licensees may add changes to the source code of EusLisp. The resulted program is still EusLisp as long as the change does not exceed 50% of codes, and these articles must be observed for unchanged part.
- 7. The copyright of programs developed in EusLisp belongs to the developer. However, he cannot extend his copyright over the main body of EusLisp.
- 8. Neither the author nor ETL provides warranty.

#### 1.7 Demonstrations

Demonstration programs are found in demo subdirectory. cd to \*eusdir\* and run eusx.

- Robot Animation Load demo/animdemo.1 from eusx. Smooth animation of eta3 manipulator will be shown after a precomputation of approximately 20 minutes.
- Ray-Tracing If you have 8-bit pseudo color display, a ray-tracing image can be generated by loading demo/renderdemo.1. Make sure geo/render.1 has already been compiled.
- Edge Vision Loading demo/edgedemo.1, a sample gray-scale image is displayed. You give parameters for choosing the gradient operator and edge thresholds. Edges are found in a few second and overlayed on the original image.



drawn by ONDA

## 2 Data Types

Like other Lisps, it is data objects that are typed, not variables. Any variable can have any object as its value. Although it is possible to declare the type of object which is bound to a variable, but usually it is only advisory information to the compiler to generate faster code. Numbers are represented as immediate values in pointers and all the others are represented by objects referenced by pointers.

In the implementation of Sun4, a pointer or a number is represented by a long word as depicted in fig.2. Two bits at LSB of a pointer are used as tag bits to discriminate between a pointer, an integer, and a float. Since a pointer's tags are all zero and it can use all 32 bits for addressing an object, EusLisp can utilize up to 4GB of process address space.



図 2: Pointer and Immediate Value

#### 2.1 Numbers

There are two kinds of numbers, integer and float (floating-point number), both are represented with 29 bits value and 1 bit sign. Thus, integers range from -536,870,912 to 536,870,911. Floats can represent

plus/minus from 4.8E-38 to 3.8E38 with the approximate accuracy of 6 digits in decimal, i.e., floating-point epsilon is approximately 1/1,000,000.

Numbers are always represented by immediate data, and not by objects. This is the only exception of EusLisp's object orientation. However, since numbers never waste heap memory, number crunching applications run efficiently without causing garbage collection.

EusLisp does not have the character type, and characters are represented by integers. In order to write a program independent of character code sets, #\ reader dispatch macro is used. However, when the character is read, it is converted to numerical representation, and the printer does not know how to reconvert it to #\ notation.

A number has two tag bits in a long word Figure 2, which must be stripped off by shifting or masking when used in arithmetic computation. Note that an integer should ignore two MSB bits by arithmetic shifting, while a float should ignore two LSB bits by masking. Byte swap is also necessary for an architecture like VAX which does not use the rightmost byte as the least-significant mantissa byte.

## 2.2 Objects

Every data other than number is represented by an object which is allocated in heap. Each memory cell of an object has the object header and fixed number of slots for object variables. Since vectors may consist of arbitrary number of elements, they have 'size' slot immediately after the header. Fig. 3 depicts the structures of object and vector, and their header word. Only the words indicated as *slot* and *element* are accessible from users.

A header is composed of six fields. Two MSB bits, m and b, are used to indicate the side of the neighbor cell in Fibonacci-buddy memory management. There are three mark bits in the mark field, each of which is used by the garbage collector to identify accessible cells, by the printer to recognize circular objects in printing in #n= and #n# notations, and by copy-object to copy shared objects. The elmt field discriminates one of seven possible data types of vector elements, pointer, bit, character, byte, integer, float and foreign-string. Although elmt can be available in the class, it is provided in the header to make the memory manager independent of the structure of a class and to make the element accessing faster. The bid field represents the physical size of a memory cell. 31 different sizes up to 16 MB are represented by the five bits in this field. The lower short word (16 bits) is used for the class id. This is used to retrieve the class of an object via the system's class table. This class id can be regarded as the type tag of traditional Lisps. Currently only the lower 8 bits of the cid are used and the upper 8 bits are ignored. Therefore, the maximum number of classes is limited to 256, though this limit can be raised up to 65536 by reconfiguring the EusLisp to allocate more memory to the system's class table.

#### 2.3 Class Hierarchy

The data structure of objects are defined by classes, and their behaviors are defined by methods in the classes. In EusLisp, a few dozens of classes have already been defined in tree structured hierarchy as depicted in fig. 4. You can browse the real inheritance structure by the **class-hierarchy** function. The class 'object' at the leftmost is the ultimate super-class of all the classes in EusLisp. User-defined classes can inherit any of these built-in classes.

A class is defined the **defclass** macro or by the **defstruct** macro.

Methods are defined by the **defmethod** special form. **Defmethod** can appear any times for a particular class.

```
(defmethod class-name
(:method-name1 (parameter...) . body1)
(:method-name2 (parameter...) . body2)
...)
```

Field definitions for most of built-in classes are found in \*eusdir\*/c/eus.h header file. (describe) class) gives the description of all the slots in class, namely, super class, slot names, slot types, method list, and so on. Definitions of built-in classes follow. Note that the superclass of class object is NIL since it has no super class.

```
(defclass object :super NIL :slots ())
(defclass cons :super object :slots (car cdr))
(defclass propertied-object :super object
            :slots (plist))
                                  ;property list
(defclass symbol :super propertied-object
            :slots (value
                                   ;specially bound value
                                   ;const(0),var(1),special(2)
                    vtype
                    function
                                   ;global func def
                    pname
                                   ;print name string
                    homepkg))
                                   ;home package
(defclass foreign-pod :super symbol
            :slots (podcode
                                     ;entry code
                    paramtypes
                                     ; type of arguments
                    resulttype))
```

(defclass package : super propertied-object

```
:slots (names
                                   ; list of package name and nicknames
                    uses
                                   ;spread use-package list
                    symvector
                                   ; hashed obvector
                    symcount
                                   ; number of interned symbols
                    intsymvector
                                   ; hashed obvector of internal symbols
                    intsymcount
                                   ; number of interned internal symbols
                    shadows
                                   ;shadowed symbols
                    used-by))
                                   ;packages using this package
(defclass stream :super propertied-object
           :slots (direction
                                ;:input or :output, nil if closed
                   buffer
                                 ;buffer string
                    count
                                 ; current character index
                                 ; last character index
                    tail))
(defclass file-stream :super stream
            :slots (fd
                             ;file descriptor (integer)
                    fname)) ;file name str; qid for msgq
(defclass broadcast-stream :super stream
           :slots (destinations))
                                         ;streams to which output is delivered
(defclass io-stream : super propertied-object
                    :slots (instream outstream))
(defclass socket-stream :super io-stream
                        :slots (address))
                                                      ; socket address
(defclass read-table :super propertied-object
            :slots (syntax
                                 ; byte vector representing character types
                                  ; 0:illegal, 1:white, 2:comment, 3:macro
                                  ; 4:constituent, 5:single_escape
                                  ; 6:multi_escape, 7:term_macro, 8:nonterm_macro
                                 ; character macro expansion function
                    macro
                    dispatch-macro))
(defclass array :super propertied-object
           :slots (entity
                                 ;simple vector storing array entity
                                 ;number of dimensions: 0-7
                    rank
                                 ;pointer to push next element
                    fillpointer
                    offset
                                 ;offset for displaced array
                    dim0,dim1,dim2,dim3,dim4,dim5,dim6)) ;dimensions
```

```
(defclass metaclass : super propertied-object
            :slots (name
                              ; class name symbol
                   super
                              ;super class
                   cix
                              ;class id
                              ; var name vector including inherited vars
                    vars
                    types
                              ;type vector of object variables
                    forwards ; components to which messages are forwarded
                    methods)) ;method list
(defclass vectorclass : super metaclass
            :slots (element-type ;vector element type 0-7
                                    ;vector size; 0 if unspecified
                   size))
(defclass cstructclass :super vectorclass
           :slots (slotlist)) ;cstruct slot descriptors
(defclass vector :super object :slots (size))
(defclass float-vector :super vector :element-type :float)
(defclass string :super vector :element-type :char)
(defclass hash-table :super propertied-object
            :slots (lisp::key
                                         ; hashed key vector
                    value
                                         ; value vector
                                         ; the size of the hash table
                   size
                    count
                                         ; number of elements entered in the table
                   lisp::hash-function
                    lisp::test-function
                    lisp::rehash-size
                    lisp::empty lisp::del@ted
(defclass queue :super cons)
(defclass pathname :super propertied-object
            :slots (lisp::host device
                                                 ; not used
                    directory
                                                 ; list of directories
                                                 ; file name before the last "."
                   name
                                                 ; type field after the last "."
                    type
                    lisp::version)
                                                 ; not used
(defclass label-reference
                              ;for reading #n=, #n# objects
           :super object
            :slots (label value unsolved next))
```

```
(defclass compiled-code :super object
            :slots (codevector
                    quotevector
                    type
                                  ;0=func, 1=macro, 2=special
                    entry))
                                  ;entry offset
(defclass closure :super compiled-code
                  :slots (env1 env2));environment
(defclass foreign-code :super compiled-code
                                     ; list of parameter types
            :slots (paramtypes
                    resulttype))
                                     ;function result type
(defclass load-module :super compiled-code
         :slots (symbol-table
                                 ; hashtable of symbols defined
                 object-file
                                 ; name of the object file loaded, needed for unloading
                 handle
                                 ;file handle returned by ''dlopen''
```

#### 2.4 Type Specifier

Though EusLisp does not have the **deftype** special form, type names are used in declarations and functions requesting to specify the type of results or contents, as in **coerce**, **map**, **concatenate**, **make-array**, etc. Usually, class names can be used as type specifiers, as in (concatenate cons "ab" "cd") = (97 98 99 100), where Common Lisp uses (quote list) instead of cons.

As EusLisp does not have classes to represent numbers, types for numbers need to be given by keywords. :integer, integer, :int, fixnum, or :fixnum is used to represent the integer type, :float or float, the floating point number type. As the *element-type* argument of make-array, :character, character, :byte, and byte are recognized to make strings. Low level functions such as defcstruct, sys:peek, and sys:poke, also recognize :character, character, :byte, or byte for the byte access, and :short or short for short word access. In any cases, keywords are preferable to lisp package symbols with the same pname.

## 3 Forms and Evaluation

#### 3.1 Atoms

A data object other than a cons is always an atom, no matter what complex structure it may have. Note that NIL, which is sometimes noted as () to represent an empty list, is also an atom. Every atom except a symbol is always evaluated to itself, although quoting is required in some other Common Lisp implementations.

#### 3.2 Scoping

Every symbol may have associated value. A symbol is evaluated to its value determined in the current binding context. There are two kinds of variable bindings; the lexical or static binding and the special or dynamic binding. Lexically bound variables are introduced by lambda form or let and let\* special forms unless they are declared special. Lexical binding can be nested and the only one binding which is introduced innermost level is visible, hiding outer lexical bindings and the special binding. Special variables are used in two ways: one is for global variables, and the other is for dynamically scoped local variables which are visible even at the outside of the lexical scope as long as the binding is in effect. In the latter case, special variables are needed to be declared special. The declaration is recognized not only by the compiler, but also by the interpreter. According to the Common Lisp's terms, special variables are said to have indefinite scope and dynamic extent.

Even if there exists a lexical variable in a certain scope, the same variable name can be redeclared to be special in inner scope. Function **symbol-value** can be used to retrieve the special values regardless to the lexical scopes. Note that **set** function works only for special variable, i.e. it cannot be used to change the value of lambda or let variables unless they are declared special.

A symbol can be declared to be a constant by **defconstant** macro. Once declared, an attempt to change the value signals an error thereafter. Moreover, such a constant symbol is inhibited to be used as the name of a variable even for a local variable. NIL and T are examples of such constants. Symbols in the keyword package are always declared to be constants when they are created. In contrast, **defvar** and **defparameter** macro declare symbols to be special variables. **defvar** initializes the value only if the symbol is unbound, and does nothing when it already has a value assigned, while **defparameter** always resets the value.

When a symbol is referenced and there is no lexical binding for the symbol, its special value is retrieved. However, if no value has been assigned to its special value yet, unbound variable error is signaled.

#### 3.3 Generalized Variables

Generally, any values or attributes are represented in slots of objects (or in stack frames). To retrieve and alter the value of a slot, two primitive operations, access and update, must be provided. Instead of

defining two distinct primitives for every slot of objects, EusLisp, like Common Lisp, provides uniform update operations based on the generalized variable concept. In this concept, a common form is recognized either as a value access form or as a slot location specifier. Thus, you only need to remember accessing form for each slot and update is achieved by **setf** macro used in conjunction with the access form. For example, (car x) can be used to replace the value in the car slot of x when used with **setf** as in (setf (car '(a b) 'c), as well as to take the car value out of the list.

This method is also applicable to all the user defined objects. When a class or a structure is defined, the access and update forms for each slot are automatically defined. Each of those forms is defined as a macro whose name is the concatenation of the class name and slot name. For example, car of a cons can be addressed by (cons-car '(a b c)).

```
(defclass person :super object :slots (name age))
(defclass programmer :super person :slots (language machine))
(setq x (instantiate programmer))
(setf (programmer-name x) "MATSUI"
      (person-age x) 30)
(incf (programmer-age x))
(programmer-age x)
(setf (programmer-language x) 'EUSLISP
      (programmer-machine x) 'SUN4)
  Array elements can be accessed in the same manner.
(setq a (make-array '(3 3) :element-type :float))
(setf (aref a 0 0) 1.0 (aref a 1 1) 1.0 (aref a 2 2) 1.0)
a \longrightarrow #2f((1.0 \ 0.0 \ 0.0) \ (0.0 \ 1.0 \ 0.0) \ (0.0 \ 0.0 \ 1.0))
(setq b (instantiate bit-vector 10)) --> #*0000000000
(setf (bit b 5) 1)
b --> #*000010000
  In order to define special setf methods for particular objects, defsetf macro is provided.
(defsetf symbol-value set)
```

(defsetf get (sym prop) (val) '(putprop ,sym ,val ,prop))

#### 3.4 Special Forms

All the special forms are listed in Table 2. **macrolet, compiler-let,** and **progv** have not been implemented. Special forms are essential language constructs for the management of evaluation contexts and control flows. The interpreter and compiler have special knowledge to process each of these constructs properly, while the application method is uniform for all functions. Users cannot add their own special form definition.

#### 3.5 Macros

Macro is a convenient method to expand language constructs. When a macro is called, arguments are passed to the macro body, which is a macro expansion function, without being evaluated. Then, the macro

and	flet	quote
block	function	return-from
catch	go	setq
cond	if	tagbody
declare	labels	the
defmacro	let	throw
defmethod	$let^*$	unwind-protect
defun	progn	while
eval-when	or	

表 2: EusLisp's special forms

expansion function expands the arguments, and returns the new form. The resulted form is then evaluated again outside the macro. It is an error to apply a macro or special form to a list of arguments. **Macroexpand** function can be used for the explicit macro expansion.

Though macro runs slowly when interpreted, it speeds up compiled code execution, because macro expansion is taken at compile-time only once and no overhead is left to run-time. Note that explicit call to eval or apply in the macro function may produce different results between interpreted execution and the compiled execution.

#### 3.6 Functions

A function is expressed by a lambda form which is merely a list whose first element is **lambda**. If a lambda form is defined for a symbol using **defun**, it can be referred as a global function name. Lambda form takes following syntax.

There is no function type such as EXPR, LEXPR, FEXPR, etc.: arguments to a function are always evaluated before its application, and the number of acceptable arguments is determined by lambda-list. Lambda-list specifies the sequence of parameters to the lambda form. Each of &optional, &rest, &key and &aux has special meaning in lambda-lists, and these symbols cannot be used as variable names. Supplied-p variables for &optional or &key parameters are not supported.

Since a lambda form is indistinguishable from normal list data, **function** special form must be used to inform the interpreter and compiler the form is intended to be a function. <sup>1</sup> **Function** is also important to freeze the environment onto the function, so that all the lexical variables can be accessible in the function

 $<sup>^1</sup>$ In CLtL-2 a quoted lambda form is no longer a function. Application of such a form is an error.

even the function is passed to another function of different lexical scope. The following program does not work either interpretedly nor after compiled, since sum from the let is invisible inside lambda form.

```
(let ((x '(1 2 3)) (sum 0))
(mapc '(lambda (x) (setq sum (+ sum x))) x))
```

To get the expected result, it should be written as follows:

```
(let ((x '(1 2 3)) (sum 0))
(mapc #'(lambda (x) (setq sum (+ sum x))) x ))
```

#' is the abbreviated notation of function, i.e. #'(lambda (x) x) is equivalent to (function (lambda (x) x)). Here is another example of what is called a funarg problem:

```
(defun mapvector (f v)
      (do ((i 0 (1+ i)))
            ((>= i (length v)))
            (funcall f (aref v i))))
(defun vector-sum (v)
      (let ((i 0))
            (mapvector #'(lambda (x) (setq i (+ i x))) v)
            i))
(vector-sum #(1 2 3 4)) --> 10
```

EusLisp's closure cannot have indefinite extent: i.e. a closure can only survive as long as its outer extent is in effect. This means that a closure cannot be used for programming of "generators". The following program does not work.

```
(proclaim '(special gen))
(let ((index 0))
    (setq gen #'(lambda () (setq index (1+ index)))))
(funcall gen)
```

However, the same purpose is accomplished by object oriented programming, because an object can hold its own static variables:

```
(defclass generator object (index))
(defmethod generator
  (:next () (setq index (1+ index)))
  (:init (&optional (start 0)) (setq index start) self))
(defvar gen (instance generator :init 0))
(send gen :next)
```

#### 4 Control Structures

#### 4.1 Conditionals

Although **and**, **or** and **cond** are advised to be macros by Common Lisp, they are implemented as special forms in EusLisp to improve the interpreting performance.

and  $\operatorname{\mathscr{E}rest}$  forms [special]

Forms are evaluated from left to right until NIL appears. If all forms are evaluated to non-NIL, the last value is returned.

or & rest forms [special]

Forms are evaluated from left to right until non-NIL appears, and the value is returned. If all forms are evaluated to NIL, NIL is returned.

if test then Goptional else

[special]

if can only have single *then* and *else* forms. To allow multiple *then* or *else* forms, they must be grouped by **progn**.

when test & rest forms [macro]

Unlike **if**, **when** and **unless** allow you to write multiple *forms* which are executed when *test* holds (**when**) or does not *unless*. On the other hand, these macros cannot have the *else* forms.

unless test & rest forms [macro]

is equivalent to (when (not test) . forms).

cond &rest (test &rest forms)

[special]

Arbitrary number of cond-clauses can follow **cond**. In each clause, the first form, that is *test*, is evaluated. If it is non-nil, the rest of the forms in that clause are evaluated sequentially, and the last value is returned. If no forms are given after the *test*, the value of the *test* is returned. When the *test* fails, next clause is tried until a *test* which is evaluated to non-nil is found or all clauses are exhausted. In the latter case, **cond** returns NIL.

case key &rest (label &rest forms)

[macro]

For the clause whose *label* matches with *key*, *forms* are evaluated and the last value is returned. Equality between *key* and *label* is tested with **eq** or **memq**, not with **equal**.

#### 4.2 Sequencing and Lets

prog1 form1 &rest forms

[function]

form1 and forms are evaluated sequentially, and the value returned by form1 is returned as the value of **prog1**.

progn Erest forms [special]

Forms are evaluated sequentially, and the value of the rightmost form is returned. **Progn** is a special form because it has a special meaning when it appeared at top level in a file. When such a form is compiled, all inner forms are regarded as they appear at top level. This is useful for a macro which expands to a series of **defuns** or **defmethods**, which must appear at top level.

setf  $\mathscr{E}rest$  forms [macro]

for each form in *forms*, assigns the second element to the generalized-variable signilized by the first element.

let (Erest (var Eoptional value)) Erest forms

[special]

introduces local variables. All *values* are evaluated and assigned to *vars* in parallel, i.e., (let ((a 1)) (let ((a (1+ a)) (b a)) (list a b))) produces (2 1). The first statements of *forms* can be declarations.

let\* (Erest (var Eoptional value)) Erest forms

[special]

introduces local variables. All *values* are evaluated sequentially, and assigned to *vars* i.e., (let ((a 1)) (let\* ((a (1+ a)) (b a)) (list a b))) produces (2 2).

#### 4.3 Local Functions

flet (Erest (fname lambda-list Erest body)) Erest forms

[special]

defines local functions.

labels (Erest (fname lambda-list Erest body)) Erest forms

[special]

defines locally scoped functions. The difference between *flet* and *labels* is, the local functions defined by *flet* cannot reference each other or recursively, whereas *labels* allows such mutual references.

#### 4.4 Blocks and Exits

block tag &rest forms

[special]

makes a lexical block from which you can exit by **return-from**. *Tag* is lexically scoped and is not evaluated.

return-from tag &optional value

[special]

exits the block labeled by tag. **return-from** can be used to exit from a function or a method which automatically establishes block labeled by its function or method name surrounding the entire body.

return &optional value

[macro]

(return x) is equivalent to (return-from nil x). This is convenient to use in conjunction with loop, while, do, dolist, and dotimes which implicitly establish blocks labeled NIL.

catch tag &rest forms

[special]

establishes a dynamic block from which you can exit and return a value by **throw**. *Tag* is evaluated. The list of all visible catch tags can be obtained by **sys:list-all-catchers**.

throw tag value

[special]

exits and returns value from a catch block. tag and value are evaluated.

unwind-protect protected-form & rest cleanup-forms

[special]

After the evaluation of *protected-form* finishes, *cleanup-form* is evaluated. You may make a block or a catch block outside the unwind-protect. Even return-from or throw is executed in *protected-form* 

to escape from such blocks, *cleanup-forms* are assured to be evaluated. Also, if you had an error while executing *protected-form*, *cleanup-form* would always be executed by *reset*.

#### 4.5 Iteration

while test & rest forms [special]

While test is evaluated to non-nil, forms are evaluated repeatedly. While special form automatically establishes a block by name of nil around forms, and return can be used to exit from the loop. To jump to next iteration, you can use following syntax with tagbody and go described below:

```
(setq cnt 0)
(while
  (< cnt 10)
  (tagbody while-top
     (incf cnt)
     (when (eq (mod cnt 3) 0)
        (go while-top)) ;; jump to next iteraction
     (print cnt)
     )) ;; 1, 2, 4, 5, 7, 8, 10</pre>
```

tagbody &rest tag-or-statement

[special]

tags can be used as labels for **go**. You can use **go** only in **tagbody**.

go tag [special]

transfers control to the form just after *tag* which appears in a lexically scoped **tagbody**. **Go** to the tag in a different **tagbody** across the lexical scope is inhibited.

prog varlist &rest tag-or-statement

[macro]

**prog** is a macro, which expands as follows:

```
(block nil (let varlist (tagbody tag-or-statement)))
```

do (Erest (var Eoptional optional init next)) (endtest Eoptional result) Erest forms [macro] vars are local variables. To each var, init is evaluated in parallel and assigned. Next, endtest is evaluated and if it is true, do returns result (defaulted to NIL). If endtest returns NIL, each form is evaluated sequentially. After the evaluation of forms, next is evaluated and the value is reassigned to each var, and the next iteration starts.

do\* (&rest (var &optional optional init next)) (endtest &optional result) &rest forms [macro]
do\* is same as do except that the evaluation of init and next, and their assignment to var occur sequentially.

dotimes (var count & optional result) & rest forms

[macro]

evaluates  $forms\ count$  times. count is evaluated only once. In each evaluation, var increments from integer zero to count minus one.

```
dolist (var list Goptional result) Grest forms
```

[macro]

Each element of *list* is sequentially bound to var, and forms are evaluated for each binding. **Dolist** runs faster than other iteration constructs such as **mapcar** and recursive functions, since **dolist** does

not have to create a function closure or to apply it, and no new parameter binding is needed.

until condition &rest forms

[macro]

evaluates forms until condition holds.

loop &rest forms

[macro]

evaluates forms forever. To terminate execution, **return-from**, **throw** or **go** needed to be evaluated in forms.

#### 4.6 Predicates

**Typep** and **subtypep** of Common Lisp are not provided, and should be simulated by **subclassp** and **derivedp**.

eq obj1 obj2 [function]

returns T if obj1 and obj2 are pointers to the same object or the same numbers. Examples: (eq 'a 'a) is T, (eq 1 1) is T, (eq 1. 1.0) is nil, (eq "a" "a") is nil.

eql obj1 obj2 [function]

Eq and eql are identical since all the numbers in EusLisp are represented as immediate values.

equal obj1 obj2 [function

Checks the equality of any structured objects, such as strings, vectors or matrices, as long as they do not have recursive references. If there is recursive reference in obj1 or obj2, equal loops infinitely.

superequal obj1 obj2

[function]

Slow but robust **equal**, since **superequal** checks circular reference.

null object [function]

T if object is nil. Equivalent to (eq object nil).

not object [function]

**not** is identical to **null**.

atom object [function]

returns NIL only if object is a cons. (atom nil) = (atom '()) = T). Note that atom returns T for vectors, strings, read-table, hash-table, etc., no matter what complex objects they are.

every pred &rest args

[function]

returns T if all args return T for pred. Every is used to test whether pred holds for every args.

some pred &rest args

[function]

returns T if at least one of args return T for pred. **Some** is used to test whether pred holds for any of args.

function pobject [function]

T if object is a function object that can be given to **apply** and **funcall**. Note that macros cannot be apply'ed or funcall'ed. **Functionp** returns T, if object is either a compiled-code with type=0, a symbol that has function definition, a lambda-form, or a lambda-closure. Examples: (functionp 'car) = T, (functionp 'do) = NIL

## ${\bf compiled\text{-}function\text{-}p}\ \mathit{object}$

[function]

T if *object* is an instance of compiled-code. In order to know the compiled-code is a function or a macro, send :type message to the object, and function or macro is returned.

## 5 Object Oriented Programming

The structures and behaviors of objects are described in classes, which are defined by **defclass** macro and **defmethod** special form. **defclass** defines the name of the class, its super class, and slot variable names, optionally with their types and message forwarding. **defmethod** defines methods which will invoked when corresponding messages are sent. Class definition is assigned to the symbol's special value. You may think of **class** as the counter part of Common Lisp's **structure**. Slot accessing functions and **setf** methods are automatically defined for each slot by **defclass**.

Most classes are instantiated from the built-in class **metaclass**. Class **vector-class**, which is a subclass of **metaclass**, is a metaclass for vectors. If you need to use class-variables and class-methods, you may make your own metaclass by subclassing **metaclass**, and the metaclass name should be given to **defclass** with :metaclass keyword.

Vectors are different from other record-like objects because an instance of the vector can have arbitrary number of elements, while record-like objects have fixed number of slots. EusLisp's object is either a record-like object or a vector, not both at the same time.

Vectors whose elements are typed or the number of elements are unchangeable can also be defined by **defclass**. In the following example, class intvec5 which has five integer elements is defined. Automatic type check and conversion are performed when the elements are accessed by the interpreter. When compiled with proper declaration, faster accessing code is produced.

```
(defclass intvec5 :super vector :element-type :integer :size 5)
(setq x (instantiate intvec5)) --> #i(0 0 0 0 0)
```

When a message is sent to an object, the corresponding method is searched for, first in its class, and next in its superclasses toward **object**, until all superclasses are exhausted. If the method is undefined, forward list is searched. This forwarding mechanism is introduced to simulate multiple inheritance. If the search fails again, a method named :nomethod is searched, and the method is invoked with a list of all the arguments. In the following example, the messages :telephone and :mail are sent to secretary slot object which is typed person, and :go-home message is sent to chauffeur slot.

In a method, two more local variables, **class** and **self**, become accessible. You should not change either of these variables. If you do that, the ones supplied by the system are hidden, and **send-super** and **send self** are confused.

#### 5.1 Classes and Methods

(metaclass metaclass) (element-type t) (size -1)

creates or redefine a class. When a class is redefined to have different superclass or slot variables, old objects instantiated from the previous class definition will behave unexpectedly, since method definitions assume the new slots disposition.

#### **defmethod** classname &rest (selector lambda-list &rest body)

[special]

defines one or more methods of classname. Each selector must be a keyword symbol.

defclassmethod classname &rest (selector lambda-list &rest body)

[macro]

classp object [function]

T if *object* is a class object, that is, an instance of class **metaclass** or its subclasses.

subclassp class super

[function]

Checks class is a subclass of super.

 $\mathbf{vector\text{-}class\text{-}p}\ x$  [function]

T if x is an instance of **vector-class**.

delete-method class method-name

[function]

The method definition is removed from the specified class.

find-method object selector

[function]

tries to find a method specified by *selector* in the class of *object* and in its superclass. This is used to know whether *object* can respond to *selector*.

class-hierarchy class

[function]

prints inheritance hierarchy below class.

system:list-all-classes

[function]

lists up all the classes defined so far.

#### system::method-cache &optional flag

[function]

Interrogates the hit ratio of the method cache, and returns a list of two numbers, hit and miss. If flag is NIL, method caching is disabled. If non-nil flag is given, method cache is purged and caching is enabled.

#### 5.2 Message Sending

 $\mathbf{send}\ \mathit{object}\ \mathit{selector}\ \mathcal{E}\mathit{rest}\ \mathit{args}$ 

[function]

send a message consisting of *selector* and *args* to *object*. *object* can be anything but number. *selector* must be evaluated to be a keyword.

send-message target search selector &rest args

[function]

Low level primitive to implement **send-super**.

send\* object selector &rest msg-list

[macro]

send\* applies send-message to a list of arguments. The relation between send and send\* is like the one between funcall and apply, or list and list\*.

#### $\mathbf{send\text{-}all}\ receivers\ selector\ \mathcal{E}rest\ mesg$

[function]

sends the same message to all the receivers, and collects the result in a list.

#### send-super selector &rest msgs

[macro]

sends msgs to self, but begins method searching at the superclass of the class where the method currently being executed is defined. It is an error to send-super outside a method (i.e. in a function).

#### send-super\* selector & rest msg-list

[macro]

**send-super\*** is apply version of send-super.

#### 5.3 Instance Management

#### instantiate class & optional size

[function]

the lowest primitive to create a new object from a class. If the class is a vector-class, *size* should be supplied.

#### instance class &rest message

[macro]

An instance is created, and the message is sent to it.

#### make-instance class &rest var-val-pairs

[function]

creates an instance of *class* and sets its slot variables according to *var-val-pairs*. For example, (make-instance cons :car 1 :cdr 2) is equivalent to (cons 1 2).

#### copy-object object

[function]

**copy-object** function is used to copy objects keeping the referencing topologies even they have recursive references. **Copy-object** copies any objects accessible from *object* except symbols and packages, which are untouched to keep the uniqueness of symbols. **copy-object** traverses all the references in an object twice: once to create new objects and to mark original objects that they have already copied, and again to remove marks. This two-step process makes copy-object work slower than copy-seq. If what you wish to copy is definitely a sequence, use of **copy-seq** or **copy-tree** is recommended.

#### become object class

[function]

changes the class of *object* to *class*. The slot structure of both the old class and the new class must be consistent. Usually, this can be safely used only for changing class between binary vectors, for example from an integer-vector to a bit-vector.

#### replace-object dest src

[function]

dest must be an instance of the subclass of src.

#### class object

[function]

returns the class object of object. To get the name of the class, send :name message to the class object.

#### derivedp object class

[function]

**derivedp** checks if an object is instantiated from *class* or *class*'s subclasses. **subclassp** and **derivedp** functions do not search in class hierarchy: type check always finishes within a constant time.

slot object class idex-or-name

[function]

Returns the named or indexed slot value.

#### setslot object class index-or-name value

[function]

Setslot is a internal function and users should not use it. Use, instead, combination of setf and slot.

#### 5.4 Basic Classes

object [Class]

:super

:slots

Object is the most basic class that is located at the top of class hierarchy. Since it defines no slot variables, it is no use to make an instance of **object**.

#### :prin1 &optional stream &rest mesq

[method]

prints the object in the standard re-readable object format, that is, the class name and the address, enclosed by angle brackets and preceded by a pound sign. Any subclasses of **object** can use this method to print itself with more comprehensive information by using **send-super** macro specifying *mesg* string. An object is re-readable if it begins with #<, followed by its class name, correct address, any lisp-readable information, and >. Since every data object except numbers inherits **object**, you can get print forms in this notation, even for symbols or strings. Specifying this notation, you can catch data objects that you forgot to **setq** to a symbol, as long as there happened no garbage collection after it is printed.

:slots [method]

returns the list of variable-name and value pair of all the slots of the object. You can get the value of a specific slot by applying **assoc** to this list, although you cannot alter them.

#### :methods &optional subname

[method]

returns a list of all methods callable by this object. If *subname* is given, returns only methods with names that include *subname*.

#### :get-val variable-name

[method]

returns the value of the slot designated by *variable-name*. If the object does not have the *variable-name* slot, an error is reported.

#### :set-val variable-name value

[method]

sets value in the variable-name slot of this object. If the object does not have the variable-name slot, an error is reported.

## propertied-object

[Class]

:super **object** :slots plist

defines objects that have property list. Unlike other Common Lisp, EusLisp allows any objects that inherit propertied-object to have property lists, even if they are not symbols.

:plist &optional plist [method]

if plist is specified, it is set to the plist slot of this object. Previous plist, if there had been one, is lost. Legal plist should be of the form of ((indicator1 . value1) (indicator2 . value2) ...). Each indicator can be any lisp form that are tested its equality with the eq function. When a symbol is used for an indicator, use of keyword is recommended to ensure the equality check will be performed interpackage-widely. :plist returns the current plist.

:get indicator [method]

returns the value associated with *indicator* in the property list. (send x : get : y) == (cdr (assoc :y (send x : plist)).

:put indicator value

[method]

associates value to indicator in the plist.

:remprop indicator

[method]

removes indicator and value pair from the plist. Further attempt to :qet the value returns nil.

:name &optional name

[method]

defines and retrieves the :name property in the plist. This property is used for printing.

:prin1 &optional stream &rest mesg

[method]

prints the object in the re-readable form. If the object has **:name** property, it is printed after the address of the object.

metaclass [Class]

:super propertied-object

:slots name super cix vars types forwards methods

Metaclass defines classes. Classes that have own class variables should be defined with **metaclass** as their superclass.

:new [method]

creates an instance of this class and returns it after filling all the slots with NIL.

:super [method]

returns the super class object of this class. You cannot alter superclass once defclassed.

:methods [method]

returns a list of all the methods defined in this class. The list is composed of lists each of which describes the name of the method, parameters, and body.

:method name [method]

returns the method definition associated with name. If not found, NIL is returned.

:method-names subname

[method]

returns a list of all the method names each of which contains subname in its method name. Methods are searched only in this class.

:all-methods [method]

returns a list of all methods that are defined in this class and its all the super classes. In other words, an instance of this class can execute each of these methods.

:all-method-names subname

[method]

returns a list of all the method names each of which matches with *subname*. The search is made from this class up to **object**.

:slots [method]

returns the slot-name vector.

:name [method]

returns the name symbol of this class.

:cid [method]

returns an integer that is assigned to every instance of this class to identify its class. This is an index to the system-internal class table, and is changed when a new subclass is defined under this class.

:subclasses [method]

returns a list of the direct subclass of this class.

:hierarchy [method]

returns a list of all the subclasses defined under this class. You can also call the **class-hierarchy** function to get a comprehensive listing of all the class hierarchy.

#### find-method object selector

[function]

searches for the method identified by *selector* in *object*'s class and its super classes. This function is useful when object's class is uncertain and you want to know whether the object can handle the message without causing nomethod error.

# 6 Arithmetic Functions

# 6.1 Arithmetic Constants

most-positive-fixnum [constant]

#x1fffffff=536,870,911

most-negative-fixnum [constant]

-#x200000000 = -536,870,912

short-float-epsilon [constant]

A floating point number on machines with IEEE floating-point format is represented by 21 bit mantissa with 1 bit sign and 7 bit exponent with 1 bit sign. Therefore, floating point epsilon is  $2^{-21} = 4.768368 \times 10^{-7}$ .

single-float-epsilon [constant]

same as **short-float-epsilon**,  $2^{-21}$ .

long-float-epsilon [constant]

same as **short-float-epsilon** since there is no double or long float.  $2^{-21}$ .

pi [constant]

 $\pi$ , actually 3.14159203, not 3.14159265.

2pi [constant]

 $2 \times \pi$ 

pi/2 [constant]

 $\pi/2$ 

-pi [constant]

-3.14159203

-2pi [constant]

 $-2 \times \pi$ 

-pi/2 [constant]

 $\pi/2$ 

## 6.2 Arithmetic Predicates

numberp object [function]

T if *object* is number, namely integer or float. Note that characters are also represented by numbers.

integerp object [function

T if *object* is an integer number. A float can be converted to an integer by **round**, **trunc** and **ceiling** functions.

floatp object [function]

T if object is a floating-point number. An integer can be converted to a float by the **float** function.

**zerop** number [function]

T if the number is integer zero or float 0.0.

plusp number [function]

equivalent to (> number 0).

minusp number [function]

equivalent to (< number 0).

oddp integer [function]

The argument must be an integer. T if *integer* is odd.

evenp integer [function]

The argument must be an integer. T if integer is an even number.

/= num1 num2 &rest more-numbers

[function]

Both *num1*, *num2* and all elements of *more-numbers* must be numbers. T if no two of its arguments are numerically equal, NIL otherwise.

= num1 num2 &rest more-numbers

[function]

Both n1 and n2 and all elements of more-numbers must be numbers. T if n1, n2 and all elements of more-numbers are the same in value, NIL otherwise.

> num1 num2 &rest more-numbers

[function]

Both n1 and n2 and all elements of *more-numbers* must be numbers. T if n1, n2 and all elements of *more-numbers* are in monotonically decreasing order, NIL otherwise. For numerical comparisons with tolerance, use functions prefixed by **eps** as described in the section 14.

< num1 num2 &rest more-numbers

[function]

Both n1 and n2 and all elements of *more-numbers* must be numbers. T if n1, n2 and all elements of *more-numbers* are in monotonically increasing order, NIL otherwise. For numerical comparisons with tolerance, use functions prefixed by **eps** as described in the section 14.

 $>= num1 \ num2 \ &rest \ more-numbers$ 

[function]

Both n1 and n2 and all elements of *more-numbers* must be numbers. T if n1, n2 and all elements of *more-numbers* are in monotonically nonincreasing order, NIL otherwise. For numerical comparisons with tolerance, use functions prefixed by **eps** as described in the section 14.

<= num1 num2 &rest more-numbers

[function]

Both n1 and n2 and all elements of *more-numbers* must be numbers. T if n1, n2 and all elements of *more-numbers* are in monotonically nondecreasing order, NIL otherwise. For numerical comparisons with tolerance, use functions prefixed by **eps** as described in the section 14.

# 6.3 Integer and Bit-Wise Operations

Following functions request arguments to be integers.

mod dividend divisor [function]

returns remainder when dividend is divided by divisor. (mod 6 5)=1, (mod -6 5)=-1, (mod 6 -5)=1, (mod -6 -5)=-1.

1- number [function]

number - 1 is returned.

1+ number [function]

number + 1 is returned.

logand & rest integers [function]

bitwise-and of *integers*.

logior & rest integers [function]

bitwise-inclusive-or of *integers*.

logxor Erest integers [function]

bitwise-exclusive-or of integers.

logeqv &rest integers [function]

**logeqv** is equivalent to (lognot (logxor ...)).

lognand & rest integers [function]

bitwise-nand of *integers*.

lognor & rest integers [function]

bitwise-nor of *integers*.

lognot integer [function]

bit reverse of *integer*.

logtest integer1 integer2 [function]

T if (logand integer1 integer2) is not zero.

logbitp index integer [function]

T if indexth bit of integer (counted from the LSB) is 1, otherwise NIL.

ash integer count [function]

Arithmetic Shift Left. If *count* is positive, shift direction is left, and if *count* is negative, *integer* is shifted to right by abs(*count*) bits.

ldb target position & optional (width 8) [function]

LoaD Byte. Byte specifier for **ldb** and **dpb** does not exist in EusLisp. Use a pair of integers instead. The field of *width* bits at *position* within *target* is extracted. For example, (ldb #x1234 4 4) is 3.

**dpb** value target position & optional (width 8) [function]

DePosit byte. Width bits of value is put in target at positionth bits from LSB.

#### 6.4 Generic Number Functions

+ & rest numbers [function]

returns the sum of *numbers*.

- num & rest more-numbers [function]

If more-numbers are given, they are subtracted from num. Otherwise, num is negated.

\* & rest numbers [function]

returns the product of *numbers*.

/ num &rest more-numbers

[function]

num is divided by more-numbers. If only one argument is given, 1.0 is divided by num. The result is an integer if all the arguments are integers, and a float if at least one of the arguments is a float.

abs number [function]

returns absolute number.

round number [function]

rounds to the nearest integer. (round 1.5)=2, (round -1.5)=-2.

floor number [function]

rounds to the nearest smaller integer. (floor 1.5)=1, (floor -1.5)=-2.

ceiling number [function]

rounds to the nearest larger integer. (ceiling 1.5)=2, (ceiling -1.5)=-1.

truncate number [function]

rounds to the absolutely smaller and nearest integer. (truncate 1.5)=1, (truncate -1.5)=-1.

float number [function]

returns floating-point representation of number.

max num &rest more-numbers

[function]

finds the maximum value among num and more-numbers.

min num &rest more-numbers

[function]

finds the minimum value among num and more-numbers.

make-random-state &optional (state \*random-state\*)

[function]

creates a fresh object of type random-state suitable for use as the value of \*random-state\*. If *state* is a random state object, the new-state is a copy of that object. If state is NIL, the new-state is a copy of the current \*random-state\*. If state is T, the new-state is a fresh random state object that has been randomly initialized.

random range & optional (state \*random-state\*)

[function]

Returns a random number between 0 or 0.0 and range. If range is an integer, the result is truncated to an integer. Otherwise, a floating value is returned. Optional state can be specified to get predictable random number sequence. There is no special data type for random-state, and it is represented with an integer vector of two elements.

incf variable & optional (increment 1)

[macro]

variable is a generalized variable. The value of variable is incremented by increment, and it is set back to variable.

**decf** variable &optional (decrement 1)

[macro]

variable is a generalized variable. The value of variable is decremented by decrement, and it is set back to variable.

reduce func seq [function]

combines all the elements in seq using the binary operator func. For an example, (reduce #'expt

'(2 3 4)) = (expt (expt 2 3) 4)=4096.

rad2deg radian [function]

Radian value is converted to degree notation. #R does the same thing at read time. Note that the official representation of angle in EusLisp is radian and every EusLisp function that accepts angle argument requests it to be represented by radian.

deg2rad degree [function]

Conversion from degree to radian. Also accomplished by #D reader's dispatch macros.

# 6.5 Trigonometric and Related Functions

sin theta [function]

theta is a float representing angle by radian. returns sin(theta).

cos theta [function]

theta is a float representing angle by radian. returns cos(theta).

tan theta [function]

theta is a float representing angle by radian. returns tan(theta).

 $\sinh x$  [function]

hyperbolic sine, that is,  $\frac{e^x - e^{-x}}{2}$ .

 $\cosh x$  [function]

hyperbolic cosine, that is,  $\frac{e^x + e^{-x}}{2}$ .

tanh x [function]

hyperbolic tangent, that is,  $\frac{e^x - e^{-x}}{e^x + e^{-x}}$ .

asin x [function]

arc sine.

 $\mathbf{acos}\ x$  [function]

arc cosine.

atan y Goptional x [function]

When **atan** is called with one argument, its arctangent is calculated. When called with two arguments, atan(y/x) is returned.

 $\mathbf{asinh}\ x$  [function]

hyperbolic arc sine.

 $a\cosh x$  [function]

hyperbolic arc cosine.

atanh x [function]

hyperbolic arc tangent.

sqrt number [function]

returns square root of number.

log number &optional base

[function]

returns natural logarithm of number. If base is provided, return the logarithm of number in the given base instead.

exp x

[function]

returns exponential,  $e^x$ .

 $\mathbf{expt}\ a\ x$ 

[function]

returns  $a^x$ .

## 6.6 Extended Numbers

ratio [Class]

:super **extended-number** :slots (numerator denominator)

Describes rational numbers.

:init num denom

initializes a rational number instance with numerator num and denominator denom.

complex

:super **extended-number** :slots (real imaginary)

Describes complex numbers.

:init re im

initializes a complex number instance with real part re and imaginary part im.

# 7 Symbols and Packages

# 7.1 Symbols

A symbols is assured to be unique if it is interned in a package. The uniqueness is tested by symbol's print-names. There are no duplicated symbols in a package which have the same print-name as other symbols in the package. When EusLisp is running, there always is a special package called the current package, which is referred by lisp:\*package\*. When a symbol without a package name is read by the reader, the current package is searched for to locate the symbol with the same print-name. If no such symbol is found, search is continued in the packages listed in the package use list of the current package. If still no such symbol is found, a new symbol object with the designated print-name is created and is interned in the current package. The package can be specified by prefixing the package name followd by a colon(:). If a symbol name is preceded by a package name, the search begins in the designated package.

Every symbol may have at most one home package. If a symbol has no such home package, it is said to be an uninterned symbol. Uninterned symbols can be created by the **gensym** or **make-symbol** function, and they are prefixed by "#:" when printed. Since these symbols are not interned, two such symbols with the same print-name are not guaranteed to be equal.

Usually, when the lisp reader encounters a symbol, the reader converts the print-name string of the symbol to uppper case. Thus, for example, if you input (symbol-name 'car), EusLisp responds "CAR" instead of "car". Note that (make-symbol "car") returns |car| instead of car or CAR. If you want the reader to make symbols constituted by lower case letters, use reader's escapes, \ and |...|.

symbol object [function]

returns T if object is an instance of CLASS symbol or its subclasses.

symbol-value symbol [function]

gets symbol's special value. Lexical (local) variables' values cannot be retrieved by this function.

#### symbol-function symbol

[function]

gets symbol's global function definition. Lexical (local) function cannot be taken by this function.

### symbol-package sym

[function]

returns the package where sym is interned.

# $\mathbf{symbol\text{-}name}\ sym$

[function]

returns sym's print-name. Note that **symbol-name** does not copy the pname string, whereas **string** does. Thus, if you change the string returned by **symbol-name**, the symbol becomes inaccessible through normal intern procedure.

## symbol-plist sym [function]

Returns sym's property list (plist). EusLisp's plist takes the same form as an association list, which consists of dotted pairs of an attribute name and its value. This is incompatible with Common Lisp definition which requests a plist to have linear lists of attribute name and value. In EusLisp, plist is not the unique facility of symbols. Any objects instantiated from a class that inherits **propertied-object** can have property lists. To set and retrieve these plists in propertied-objects, **propertied-object-plist** macro should be used instead of **symbol-plist**. However, **get** and **putprop** work for either object.

**boundp** symbol [function]

Checks if *symbol* has a globally bound value. Note that symbols used for local and object variables always have bound value and **boundp** cannot test the bound state of these local variables.

fboundp symbol [function]

Checks if *symbol* has a globally bound function definition.

makunbound symbol [function]

symbol is forced to be unbound (to have no special value). Note that lexical (local) variables always have values assigned and cannot be makunbounded.

get sym attribute [function]

retrieves sym's value associated with attribute in its plist. = (cdr (assoc attribute (symbol-plist sym))

putprop sym val attribute

[function]

Putprop should be replaced with the combination of **setf** and **get**.

remprop sym attr [function]

removes attribute-value pair from sym's property list.

setq &rest forms [special]

for each form in *forms*, assigns the second element to the first element, which is either a symbol or a dotted-pair. The first element is searched for in the name spaces of local variables, object variables, and special variables in this order unless explicitly declared special.

set sym val [function]

assigns val to the special value of sym. Set cannot assign values to local or object variables.

#### defun symbol lambda-list &rest body

[special]

defines a global function to symbol. First element in body can be a documentation string. Use flet or labels for defining local functions.

#### defmacro symbol lambda-list &rest body

[special]

defines a global macro. EusLisp does not have facilities for defining locally scoped macros.

#### defvar var & optional (init nil) doc

[macro]

If *var* symbol has any special value, **defvar** does nothing. If *var* is unbound, it is declared to be special and *init* is set to its value.

#### defparameter var init & optional doc

[macro]

defparameter declares var to be special and init is set to its value, even if var already has value.

## defconstant sym val &optional doc

macro

defconstant sets val as sym's special value. Unlike defvar, defparameter and setq, the value set by defconstant cannot be altered by these forms. If the value of a constant symbol is tried to be changed, an error is reported. However, another defconstant can override the previous constant value, issuing a warning message.

keywordp obj

T if *obj* is a symbol and its home package is **KEYWORD**.

## constantp symbol [function]

T if the symbol is declared to be constant with defconstant macro.

documentation sym &optional type

[function]

retrieves documentation string of sym.

 $\mathbf{gensym} \,\, \mathscr{C}optional \,\, x \tag{[function]}$ 

creates a new uninterned symbol composed of a prefix string and a suffix number like g001. Uninterned symbols are denoted by the #: package prefix indicating no package is associated with the symbols. Symbols with #: prefix are unreadable symbols and the reader cannot create references to these uninterned symbols. X can either be a string or an integer, which is used as the prefix or the suffix.

**gentemp** & optional (prefix "T") (pkg \*package\*)

[function]

creates a new symbol interned in pkg. In most applications, **gensym** is preferable to **gentemp**, because creation of uninterned symbols is faster and uninterned symbols are garbage collect-able.

## 7.2 Packages

Packages provide separate name spaces for groups of symbols. Common Lisp introduced the package system in order to reduce the symbol (function and variable name) conflict problems in the course of developing huge software systems which require more than one programmer to work together. Each package may have internal symbols and external symbols. When a symbol is created in a package, it is always internal, and it becomes external by **export**. External symbols in different packages are referenced by prefixing the package name and a single colon, as x:\*display\*, while referencing internal symbols in other packages requires double colons, as sys::free-threads. In order to omit this package prefixing, a package may **import** symbols from other packages. Moreover, **use-package** allows importing all external symbols from another package at once. When symbols are exported or imported, symbol name conflicts can be detected, since every symbol in any packages must have the unique print name. **Shadow** allows creating a symbol with the same print name as the existing symbol in a package by virtually removing the old symbol from the package.

EusLisp defines following eight packages;

**lisp:** All the lisp functions, macros, constants, etc.

keyword: keyword symbols

unix: unix system calls and library functions

system: system management or dangerous functions; nicknames=sys,si

compiler: EusLisp compiler; nicknames=comp

**user:** User's work space

geometry: geometric classes and functions

xwindow: X-window interface; nickname=x

These packages and user-defined packages are linked in the system's package list, which can be obtained by list-all-packages. Each package manages two hash tables to find and locate internal and external symbols. Also, a package records its name (string or symbol) and a list of nick names, and a list of other packages that the package is using. \*Package\* is a special variable that holds the current package for read and print. If \*package\* is not user:, top-level prompt changes to indicate the current package, like mypkg:eus\$.

\*lisp-package\* [constant]

Lisp package.

# \*user-package\*

[constant]

User package.

## \*unix-package\*

[constant]

Unix package.

## \*system-package\*

[constant]

System Package.

## \*keyword-package\*

[constant]

Keyword Package.

# find-symbol string &optional (package \*package\*)

[function]

finds and locates the symbol which has *string* as its print name in *package*. If found, the symbol is returned, NIL otherwise.

# make-symbol string

[function]

makes a new uninterned symbol by the print name of string.

# intern string Goptional (package \*package\*) (klass symbol)

[function]

tries to find a symbol whose print-name is same with *string*. If the search succeeds, the symbol is returned. If fails, a symbol whose print-name is *string* is newly made, and is located in *package*.

#### list-all-packages

[function]

returns the list of all packages ever made.

## find-package name

[function]

find the package whose name or nickname is equal to the name string.

## make-package name &key nicknames (use '(lisp))

[function]

makes a new package by the name of *name*. Name can either be a string or a symbol. If the package already exists, error is reported.

## in-package pkg &key nicknames (uses '(lisp))

[function]

changes the current package (the value of \*package\*) to pkg.

# package-name pkg

[function]

returns the string name of the pkg package.

## package-nicknames pkq

[function]

returns a list of nicknames of pkg.

#### rename-package pkg new-name &optional new-nicknames

[function]

changes the name of pkg to new-name and its nicknames to new-nicknames, which can either be a symbol, a string, or a list of symbols or strings.

## package-use-list pkq

[function]

returns the list of packages which are used by pkg.

#### packagep pkg

[function]

T if pkg is a package.

## use-package pkg &optional (curpkg \*package\*)

[function]

adds pkg to curpkg's use-list. Once added, symbols in pkg become visible from curpkg without package prefix.

# unuse-package pkg &optional (curpkg \*package\*)

[function]

removes pkg from curpkg's use-list.

### **shadow** sym & optional(pkg \*package\*)

[function]

makes a symbol interned in pkg, by hiding existing sym.

## **export** sym & optional (pkg \*package\*)

[function]

sym is a symbol or a list of symbols. **export** makes sym accessible from other packages as external symbol(s). Actually, sym is registered as an external symbol in pkg. If a symbol is exported, it becomes accessible using a single colon ":" as package marker, whereas unexported symbols require double colons. In addition, exported symbols do not need colons when they are used by **use-package** or they are imported into the package. Whether a symbol is exported or not is attributed to packages where it is interned, not to each symbol. So, a symbol can be internal in a package and external in another. **Export** checks sym to have name conflict with symbols in other packages using pkg. If there is a symbol having the same print name with sym, "symbol conflict" error is reported.

## unexport sym &optional pkg

[function]

If sym is an external symbol in pkg, it is unexported and becomes an internal symbol.

# import sym &optional (pkg \*package\*)

[function]

sym is a symbol or a list of symbols. **import** makes symbols defined in other packages visible in pkg as an internal symbol without package prefix. If there is already a symbol that has the same print name as sym, then an "name conflict" error is reported.

### do-symbols (var pkg &optional result) &rest forms

[macro]

repeats evaluating forms for each binding of var to symbols (internal or external) in pkg.

# do-external-symbols (var pkg &optional result) &rest forms

[macro]

repeats evaluating forms for each binding of var to external symbols in pkg.

## do-all-symbols (var &optional result) &rest forms

[macro]

repeats evaluating forms for each binding of *var* to symbols in all packages. Note that forms may be evaluated more than once to a symbol if it appears more than one package.

# 8 Sequences, Arrays and Tables

# 8.1 General Sequences

Vectors (one dimensional arrays) and lists are generic sequences. A string is a sequence, since it is a vector of characters.

For the specification of result type in map, concatenate and coerce, use class name symbol, such as cons, string, integer-vector, float-vector, etc. without quotes, since the class object is bound to the symbol.

elt sequence pos [function]

**elt** is the most general function to get and put (in conjunction with **setf**) value at the specific position pos in sequence. Sequence may be a list, or a vector of arbitrary object, bit, char, integer, or float. **Elt** cannot be applied to a multi-dimensional array.

length sequence [function]

returns the length of *sequence*. For vectors, **length** finishes in constant time, but time proportional to the length is required for a list. **Length** never terminates if *sequence* is a circular list. Use **list-length**, instead. If *sequence* is an array with a fill-pointer, **length** returns the fill-pointer, not the entire size of the array entity. Use **array-total-size** to know the entire size of those arrays.

#### subseq sequence start &optional end

[function]

makes a copy of the subsequence from *start*th through (*end*-1)th inclusively out of *sequence*. *end* is defaulted to the length of *sequence*.

copy-seq sequence [function]

does shallow-copying of *sequence*, that is, only the top-level references in *sequence* are copied. Use **copy-tree** to copy a nested list, or **copy-object** for deep-copying of a sequence containing recursive references.

reverse sequence [function]

reverse the order of sequence and returns a new sequence of the same type as sequence.

nreverse sequence [function]

**Nreverse** is the destructive version of **reverse**. **Nreverse** does not allocate memory, while **reverse** does.

## concatenate result-type &rest sequences

[function]

concatenates all *sequences*. Each *sequence* may be of any sequence type. Unlike **append**, all the sequences including the last one are copied. *Result-type* should be a class such as cons, string, vector, float-vector etc.

## coerce sequence result-type

[function]

changes the type of sequence. For examples, (coerce '(a b c) vector) = #(a b c) and (coerce "ABC" cons) = (a b c). A new sequence of type result-type is created, and each element of sequence is copied to it. result-type should be one of vector, integer-vector, float-vector, bit-vector, string, cons or other user-defined classes inheriting one of these. Note that sequence is copied even if its type equals to result-type.

map result-type function seq &rest more-seqs

[function]

function is applied to a list of arguments taken from seq and more-seqs orderly, and the result is accumulated in a sequence of type result-type. For example, you can write as follows: (map float-vector #'(lambda (x) (\* x x)) (float-vector 1 2 3))

fill sequence item &key (start 0) (end (length sequence))

[function]

fills item from startth through (end-1)th in sequence.

replace dest source Ekey start1 end1 start2 end2

[function]

elements in *dest* sequence indexed between *start1* and *end1* are replaced with elements in *source* indexed between *start2* and *end2*. *start1* and *start2* are defaulted to zero, and *end1* and *end2* to the length of each sequence. If the one of subsequences is longer than the other, its end is truncated to match with the shorter subsequence.

sort sequence compare & optional key

[function]

sequence is destructively sorted using Unix's quick-sort subroutine. key is not a keyword parameter. Be careful with the sorting of a sequence which have same elements. For example, (sort '(1 1) #'>) fails because comparisons between 1 and 1 in both direction fail. To avoid this problem, use functions like #'>= or #'<= for comparison.

merge result-type seq1 seq2 pred &key (key #'identity)

[function]

two sequences seq1 and seq2 are merged to form a single sequence of result-type whose elements satisfy the comparison specified by pred.

merge-list list1 list2 pred key

[function]

merges two lists. Unlike **merge** no general sequences are allowed for the arguments, but **merge-list** runs faster than **merge**.

Following functions consist of one basic function and its variants suffixed by -if and -if-not. The basic form takes at least the item and sequence arguments, and compares item with each element in the sequence, and do some processing, such as finding the index, counting the number of appearances, removing the item, etc. Variant forms take predicate and sequence arguments, applies the predicate to each element of sequence, and do something if the predicate returns non-nil (-if version), or nil (-if-not version).

position item seq &key start end test test-not key (count 1)

[function]

finds *count*th appearance of *item* in *seq* and returns its index. The search begins from the *start*th element, ignoring elements before it. By default, the search is performed by **eql**, which can be altered by the *test* or *test-not* parameter.

position-if predicate seq &key start end key

[function]

position-if-not predicate seq &key start end key

[function]

find item seq &key start end test test-not key (count 1)

[function]

finds *count*th element between the *start*th element and the *end*th element in *seq*. The element found, which is eql to *item* if no *test* or *test-not* other than #'eql is specified, is returned.

find-if predicate seq &key start end key (count 1)

[function]

finds countth element in seq for which pred returns non nil.

find-if-not predicate seq &key start end key

[function]

count item seq Ekey start end test test-not key

[function]

counts the number of items which appear between the startth element and the endth element in seq.

count-if predicate seq &key start end key

[function]

count the number of elements in seq for which pred returns non nil.

count-if-not predicate seq &key start end key

[function]

remove item seq &key start end test test-not key count

[function]

creates a new sequence which has eliminated count (defaulted to infinity) occurrences of of item(s) between the startth element and the endth element in seq. If you are sure that there is only one occurrence of item, count=1 should be specified to avoid meaningless scan over the whole sequence.

remove-if predicate seq &key start end key count

[function]

remove-if-not predicate seq &key start end key count

[function]

remove-duplicates seq &key start end key test test-not count

[function]

removes duplicated items in seq and creates a new sequence.

delete item seq &key start end test test-not key count

[function]

is same with **remove** except that **delete** modifies *seq* destructively and does not create a new sequence. If you are sure that there is only one occurrence of *item*, *count=1* should be specified to avoid meaningless scan over the whole sequence.

delete-if predicate seq &key start end key count

[function]

delete-if-not predicate seq &key start end key count

[function]

count for removes and deletes is defaulted to 1,000,000. If you have a long sequence and you want to delete an element which appears only once, :count should be specified as 1.

substitute newitem olditem seq &key start end test test-not key count

[function]

returns a new sequence which has substituted the *count* occurrence(s) of *olditem* in *seq* with *newitem*. By default, all the *olditems* are substituted.

(substitute #\Space #\\_ "Euslisp\_euslisp") ;; => "Euslisp euslisp"

substitute-if newitem predicate seq &key start end key count

[function]

substitute-if-not newitem predicate seq &key start end key count

[function]

nsubstitute newitem olditem seq &key start end test test-not key count

[function]

substitute the *count* occurrences of *olditem* in *seq* with *newitem* destructively. By default, all the *olditems* are substituted.

 $\mathbf{nsubstitute\text{-}if}\ newitem\ predicate\ seq\ \mathcal{C}key\ start\ end\ key\ count$ 

[function]

 $\mathbf{nsubstitute\text{-}if\text{-}not}\ \textit{newitem}\ \textit{predicate}\ \textit{seq}\ \textit{\&key}\ \textit{start}\ \textit{end}\ \textit{key}\ \textit{count}$ 

[function]

#### 8.2 Lists

available.

```
[function]
listp object
      returns T if object is an instance of cons or NIL.
                                                                                                   [function]
      equivalent to (not (atom object)). (consp '()) is nil.
car list
                                                                                                   [function]
      returns the first element in list. car of NIL is NIL. car of atom is error.
\mathbf{cdr}\ list
                                                                                                   [function]
      returns the list which removed the first element of list. cdr of NIL is NIL. cdr of atom is error.
cadr list
                                                                                                   [function]
      (cadr list) = (car (cdr list))
cddr list
                                                                                                   [function]
      (cddr list) = (cdr (cdr list))
cdar list
                                                                                                   [function]
      (cdar list) = (cdr (car list))
caar list
                                                                                                   [function]
      (caar list) = (car (car list))
\mathbf{caddr}\ \mathit{list}
                                                                                                   [function]
      (caddr list) = (car (cdr (cdr list)))
caadr list
                                                                                                   [function]
      (caadr list) = (car (cdr list)))
cadar list
                                                                                                   [function]
      (cadar list) = (car (cdr (car list)))
caaar list
                                                                                                   [function]
      (caaar list) = (car (car (car list)))
\operatorname{\mathbf{cdadr}}\ \mathit{list}
                                                                                                   [function]
      (cdadr list) = (cdr (car (cdr list)))
cdaar list
                                                                                                   [function]
      (cdaar list) = (cdr (car (car list)))
cdddr list
                                                                                                   [function]
      (cdddr list) = (cdr (cdr (cdr list)))
cddar list
                                                                                                   [function]
      (cddar list) = (cdr (cdr (car list)))
first list
                                                                                                   [function]
      retrieves the first element in list. second, third, fourth, fifth, sixth, seventh, eighth are als
```

nth count list

returns the *count*-th element in *list*. Note that (nth 1 list) is equivalent to (second list), and to (elt list 1).

nthcdr count list [function]

applies **cdr** count times to list.

last list [function]

the last cons is returned, not the last element.

butlast list & optional (n 1) [function]

returns a list which does not contain the last n elements.

cons car cdr [function]

makes a new cons whose car is *car* and *cdr* is *cdr*.

list & rest elements [function]

makes a list of elements.

list\* & rest elements [function]

makes a list of *elements*, but the last element is consed in cdr: for example, (list\* 1 2 3 '(4 5)) = (1 2 3 4 5).

list-length list [function]

returns the length of the list. List can be circular.

make-list size &key initial-element [function]

makes a list whose length is size and elements are initial-element.

rplaca cons a [function]

replace the car of *cons* with a. Use of **setf** to **car** is recommended.

rplacd cons d [function]

replace the cdr of *cons* with d. Use of **setf** to **cdr** is recommended.

memq item list [function]

resembles **member**, but test is always done by **eq**.

member item list &key key (test #'eq) test-not [function]

the *list* is searched for an element that satisfies the *test*. If none is found, NIL is returned; otherwise, the tail of *list* beginning with the first element that satisfied the test is returned. The *list* is searched on the top level only.

assq item alist [function]

assoc item alist &key key (test #'eq) test-not [function]

searches the association list *alist*. The value returned is the first pair in the *alist* such that the *car* of the pair satisfies the *test*, or NIL if there is no such pair in the *alist*.

rassoc item alist [function]

returns the first pair in *alist* whose cdr is equal to *item*.

pairlis 11 12 Eoptional alist [function]

makes a list of pairs consing corresponding elements in l1 and l2. If alist is given, it is concatenated at the tail of the pair list made from l1 and l2.

acons key val alist [function]

add the key val pair to alist, that is, (cons (cons key val) alist).

append & rest list [function]

appends list to form a new list. All the elements in list, except the last list, are copied.

nconc & rest list [function]

concatenates list destructively by replacing the last cdr of each list.

subst new old tree [function]

substitutes every old in tree with new.

flatten complex-list [function]

Complex-list composed of atoms and lists of any depth is transformed into a single level linear list which have all the elements in *complex-list* at the top level. For example, (flatten '(a (b (c d) e))) = (a b c d e)

push item place [macro]

pushes item into a stack (list) bound to place.

pop stack [macro]

removes the first item from stack and returns it. If stack is empty (nil), nil is returned.

**pushnew** item place &key test test-not key

[macro]

pushes *item* in the *place* list if *item* is not a member of *place*. The *test*, *test-not* and *key* arguments are passed to the member function.

adjoin item list [function]

The item is added at the head of the list if it is not included in the list.

union list1 list2 &key (test #'eq) test-not (key #'identity)

[function]

returns union set of two lists.

**subsetp** *list1 list2 &key* (test #'eq) test-not (key #'identity)

[function]

tests if *list1* is a subset of *list2*, i.e. if each element of *list1* is a member of *list2*.

intersection list1 list2 &key (test #'eq) test-not (key #'identity)

[function]

returns the intersection of two sets, list1 and list2.

set-difference list1 list2 &key (test #'eq) test-not (key #'identity)

[function]

returns the list whose elements are only contained in list1 and not in list2.

set-exclusive-or list1 list2 &key (test #'eq) test-not (key #'identity)

[function]

returns the list of elements that appear only either in *list1* or *list2*.

list-insert item pos list

[function]

insert *item* as the *pos*'th element in *list* destructively. If *pos* is bigger than the length of *list*, *item* is nonc'ed at the tail. For example, (list-insert 'x 2 '(a b c d)) = (a b x c d)

copy-tree tree [function]

returns the copy of tree which may be a nested list but cannot have circular reference. Circular lists

can be copied by copy-object. Actually, copy-tree is simply coded as (subst t t tree).

## mapc func arg-list &rest more-arg-lists

[function]

applies *func* to a list of N-th elements in *arg-list* and each of *more-arg-lists*. The results of application are ignored and *arg-list* is returned.

## mapcar func &rest arg-list

[function]

maps func to each element of arg-list, and makes a list from all the results. For example, you can write as follows: (mapcar #'(lambda (x) (\* x x)) '(1 2 3)). Before using mapcar, try dolist.

#### mapcan func arg-list Grest more-arg-lists

[function]

maps *func* to each element of *arg-list*, and makes a list from all the results by **nconc**. **Mapcan** is suitable for filtering (selecting) elements in *arg-list*, since nconc does nothing with NIL.

# 8.3 Vectors and Arrays

Up to seven dimensional arrays are allowed. A one-dimensional array is called vector. Vectors and lists are grouped as sequence. If the elements of an array is of any type, the array is said to be general. If an array does not have fill-pointer, is not displaced to another array, or is adjustable, the array is said to be simple.

Every array element can be recalled by **aref** and set by **setf** in conjunction with aref. But for simple vectors, there are simpler and faster access functions: **svref** for simple general vectors, **char** and **schar** for simple character vectors (string), **bit** and **sbit** for simple bit vectors. When these functions are compiled, the access is expanded in-line and no type check and boundary check are performed.

Since a vector is also an object, it can be made by instantiating some vector-class. There are five kinds of built-in vector-classes; vector, string, float-vector, integer-vector and bit-vector. In order to ease instantiation of vectors, the function make-array is provided. Element-type should be one of :integer, :bit, :character, :float, :foreign or user-defined vector class. :initial-element and :initial-contents key word arguments are available to set initial values of the array you make.

array-rank-limit [constant]

7. Is the maximum array rank supported.

## array-dimension-limit

[constant]

#x1ffffff, logically, but stricter limit is imposed by the physical or virtual memory size of the system.

vectorp object [function]

An array is not a vector even if it is one dimensional. T is returned for vectors, integer-vectors, float-vectors, strings, bit-vectors or other user-defined vectors.

vector & rest elements [function]

makes a simple vector from *elements*.

make-array [function]

dims &key (element-type vector)

initial-contents

initial-element

fill-pointer

displaced-to

(displaced-index-offset 0)

adjustable

makes a vector or array. dims is either an integer or a list. If dims is an integer, a simple-vector is created.

svref vector pos [function]

returns posth element of vector. Vector must be a simple general vector.

aref vector & rest indices [function]

returns the element indexed by *indices*. **Aref** is not very efficient because it needs to dispatch according to the type of *vector*. Type declarations should be given to improve the speed of compiled code whenever possible.

vector-push val array [function]

store val at the fill-pointerth slot in array. array must have a fill-pointer. After val is stored, the fill-pointer is advanced by one to point to the next location. If it exceeds the array boundary, an error is reported.

## vector-push-extend val array

[function]

Similar to **vector-push** except that the size of the array is automatically extended when *array*'s fill-pointer reaches the end.

arrayp obj

[function]

T if obj is an instance of array or vector.

array-total-size array

[function]

returns the total number of elements of array.

fill-pointer array

[function]

returns the fill-pointer of array. Returns NIL if array does not have any fill-pointer.

array-rank array

[function]

returns the rank of array.

array-dimensions array

[function]

returns a list of array-dimensions.

array-dimension array axis

[function]

Axis starts from 0. **array-dimension** returns the *axis*th dimension of *array*.

bit bitvec index

[function]

returns the indexth element of bitvec. Use setf and bit to change an element of a bit-vector.

 $\textbf{bit-and} \ \textit{bits1} \ \textit{bits2} \ \textit{\&Optional} \ \textit{result}$ 

[function]

bit-ior bits1 bits2 &optional result

[function]

bit-xor bits1 bits2 &optional result

[function]

bit-eqv bits1 bits2 &optional result

[function]

bit-nand bits1 bits2 &optional result

[function]

bit-nor bits1 bits2 &optional result

[function]

bit-not bits1 &optional result

[function]

For bit vectors bits1 and bits2 of the same length, their boolean and, inclusive-or, exclusive-or, equivalence, not-and, not-or and not are returned, respectively.

# 8.4 Characters and Strings

There is no character type in EusLisp; a character is represented by an integer. In order to handle strings representing file names, use **pathnames** described in 9.6.

digit-char-p ch [function]

T if ch is  $\#\setminus 0$  through  $\#\setminus 9$ .

alpha-char-p ch [function]

T if ch is  $\#\backslash A$  through  $\#\backslash Z$  or  $\#\backslash a$  through  $\#\backslash z$ .

upper-case-p ch [function]

T if ch is  $\#\backslash A$  through  $\#\backslash Z$ .

lower-case-p ch [function]

T if ch is  $\#\setminus a$  through  $\#\setminus z$ .

alphanumericp ch [function]

T if ch is  $\# \setminus 0$  through  $\# \setminus 2$  or  $\# \setminus 2$  through  $\# \setminus 2$ .

**char-upcase**ch [function]

convert the case of ch to upper.

**char-downcase**ch [function]

convert the case of ch to lower.

char string index [function]

returns indexth character in string.

schar string index [function]

extracts a character from *string*. Use **schar** only if the type of *string* is definitely known and no type check is required.

stringp object [function]

returns T if *object* is a vector of bytes (integers less than 256).

string-upcase str &key start end [function]

converts str to upper case string and returns a new string.

string-downcase str &key start end [function]

converts str to lower case string and returns a new string.

nstring-upcase str [function]

converts str to upper case string destructively.

nstring-downcase str Ekey start end [function]

converts str to lower case string destructively.

string= str1 str2 &key start1 end1 start2 end2 [function]

T if str1 is equal to str2. string = is case sensitive.

string-equal str1 str2 &key start1 end1 start2 end2 [function]

tests equality of str1 and str2. **string-equal** is not case sensitive.

string object [function]

gets string notation of *object*. If *object* is a string, the *object* is returned. If *object* is a symbol, its pname is copied and returned. Note that (equal (string 'a) (symbol-pname 'a))==T, but (eq (string 'a) (symbol-pname 'a))==NIL. If object is number its string representation is returned (this is incompatible with Common Lisp). In order to get string representation for more complex objects, use **format** with NIL in the first argument.

string< str1 str2 [function]

string <= str1 str2 [function]

string> str1 str2 [function]

string >= str1 str2 [function]

string-left-trim baq str

## string-right-trim bag str

[function]

str is scanned from the left(or right), and its elements are removed if it is included in the bag list. Once a character other than the ones in the bag is found, further scan is aborted and the rest of str is returned.

string-trim bag str [function]

Bag is a sequence of character codes. A new copy of str which does not contain characters specified in bag in its both end is made and returned.

substringp sub string [function]

T if string sub is contained in string as a substring. Not case sensitive.

## 8.5 Foreign Strings

A foreign-string is a kind of byte-vector whose entity is held somewhere outside EusLisp's heap. While a normal string is represented by a sequence of bytes and its length, a foreign-string holds the length and the address of the string entity. Although foreign-string is a string, some string and sequence functions cannot be applicable. Only **length**, **aref**, **replace**, **subseq** and **copy-seq** recognize the foreign-string, and application of other functions may cause a crash.

A foreign-string may refer to a part of I/O space usually taken in /dev/a??d?? special file where ?? is either 32 or 16. In case the device attached in one of these I/O space only responds to byte access, **replace** always copies element byte by byte, which is relatively slow when a large chunk of memory is accessed consecutively.

# make-foreign-string address length

[function]

makes an instance of foreign-string located at *address* and spanning for *length* bytes. For example, (make-foreign-string (unix:malloc 32) 32) makes a reference to a 32-byte memory located

outside EusLisp's heap.

## 8.6 Hash Tables

Hash-table is a class to search for the value associated with a key, as accomplished by **assoc**. For a relatively large problem, hash-table performs better than assoc, since time required for searching remains constant even the number of key-value pairs increases. Roughly speaking, hash-table should be used in search spaces with more than 100 elements, and assoc in smaller spaces.

Hash-tables automatically expands if the number of elements in the table exceeds rehash-size. By default, expansion occurs when a half of the table is filled. **sxhash** function returns a hash value which is independent of memory address of an object, and hash values for **equal** objects are always the same. So, hash tables can be re-loadable since they use sxhash as their default hashing functions. While sxhash is robust and safe, it is relatively slow because it scans all the elements in a sequence or a tree. For faster hashing, you may choose another hash function appropriate for your application. To change the hash function, send :hash-function message to the hash-table. In simple cases, it is useful to change hash function from #'sxhash to #'sys:address. This is possible because the addresses of any objects never change in a EusLisp process.

sxhash obj [function]

calculates the hash value for *obj*. Two objects which are **equal** are guaranteed to yield the same hash value. For a symbol, hash value for its pname is returned. For numbers, their integer representations are returned. For a list, sum of hash values for all its elements is returned. For a string, shifted sum of each character code is returned. For any other objects, **sxhash** is recursively called to calculate the hash value of each slot, and the sum of them is returned.

make-hash-table &key (size 30) (test #'eq) (rehash-size 2.0) [function] creates a hash table and returns it.

gethash key htab [function]

gets the value that corresponds to *key* in *htab*. **Gethash** is also used to set a value to key by combining with **setf**. When a new entry is entered in a hash table, and the number of filled slots in the table exceeds 1/rehash-size, then the hash table is automatically expanded to twice larger size.

remhash key htab

removes a hash entry designated by key in htab.

maphash function htab [function]

maps function to all the elements of htab.

**hash-table-p**x [function]

T if x is an instance of class hash-table.

hash-table [Class]

:super object

:slots (key value count

hash-function test-function rehash-size empty deleted)

defines hash table. Key and value are simple-vectors of the same size. Count is the number of filled slots in key and value. Hash-function is defaulted to **sxhash** and test-function to **eq**. Empty and deleted are uninterned symbols to indicate slots are empty or deleted in the key vector.

#### :hash-function newhash

[method]

changes the hash function of this hash table to *newhash*. *Newhash* must be a function with one argument and returns an integer. One of candidates for *newhash* is **system:address**.

# 8.7 Queue

A queue is a data structure that allows insertion and retrieval of data in the FIFO manner, i.e. the first-in first-out order. Since the queue class is defined by extending the cons class, ordinary list functions can be applied to a queue. For example, caar retrieves the next element to be dequeued, and cadr gets the element that is queued most recently.

queue [Class]

:super cons :slots (car cdr)

defines queue (FIFO) objects.

:init [method]

initializes the queue to have no elements.

:enqueue val

puts val in the queue as the most recent element.

:dequeue &optional (error-p nil)

[method]

retrieves the oldest value in the queue, and removes it of the queue. If the queue is empty, it reports an error when error-p is non-nil, or returns NIL otherwise.

:empty?

returns T if the queue is empty.

:length [method]

returns the length of the queue.

:trim s [method]

discard old entries to keep the size of this queue to s.

:search item &optional (test #'equal)

[method]

find element which is equal to item. the search is performed by equal, which can be altered by test

:delete item &optional (test #'equal) (count 1)

[method]

eliminate count occurrences of item in this queue.

:first [method]

returns the first entry (oldest value) of this queue.

:last [method]

returns tha last entry (newest value) of this queue.

# 9 Streams and Input/Output

#### 9.1 Streams

Echo-streams and concatenated-streams are not available. Predefined streams are following:

```
*standard-input* stdin fd=0
```

\*standard-output\* stdout fd=1

\*error-output\* stderr fd=2 bufsize=1

\*terminal-io\* two-way stream made of \*standard-input\* and \*standard-output\*

streamp object [function]

Any object created from **stream**, **io-stream**, or their subclasses returns T.

input-stream-p object [function]

T if *object* is a stream and capable of reading.

output-stream-p object [function]

T if *object* is a stream and capable of writing.

io-stream-p object [function]

T if *object* is a two-way stream.

**open** [function]

```
path & key (direction :input)
(if-exists :new-version)
(if-does-not-exist 'default)
(permission #o644)
(buffer-size 512)
```

Open makes a stream associated with a file designated by path. path may either be a string or a pathname. Direction should be one of :input, :output or :io. Several open options, :append, :new-version, :overwrite, :error and nil are allowed for :if-exists parameter. However, this parameter is ignored when direction is :input. Alternatives for :if-does-not-exist are :error, :create and nil. :new-version, :rename and :supersede are not recognized. By default, the file is overwritten if direction is either :output or :io when the file exists. For :input files, an error is reported when the file does not exist. To know the existence of a file, probe-file can be used. Default value for buffer-size is 512 bytes, and #O644 for :permission. SunOS4 allows to open as many as sixty files at the same time.

## with-open-file (svar path &rest open-options) &rest forms

[macro]

A file named *path* is opened with *open-options* and the stream is bound to *svar*. Then *forms* are evaluated. The stream is automatically closed when evaluation of *forms* finishes or exits with **throw**, **return-from** or error. **With-open-file** is a macro defined by **unwind-protect** with **close** in its clean-up forms.

close stream [function]

closes the *stream*, and returns T if successful. The stream may have already been closed, in which case nil is returned. Streams are automatically closed by GC if there is no reference to that stream object.

# ${\bf make\text{-}string\text{-}input\text{-}stream}\ \textit{string}$

[function]

makes an input stream from a string.

## $\mathbf{make\text{-}string\text{-}output\text{-}stream}\ \mathscr{C}optional\ size$

[function]

makes an output stream to a string of *size* length. Actually, the length is automatically expanded, so *size* is only advisory information to allocate string at initialization.

# ${f get} ext{-output-stream-string}$ $string ext{-stream}$

[function]

gets a string out of a string-stream.

## $\mathbf{make\text{-}broadcast\text{-}stream} \ \mathscr{C}\mathit{rest} \ \mathit{output\text{-}streams}$

[function]

makes a broad-cast stream which forwards all the messages written to this stream to each of *output-streams*.

#### 9.2 Reader

Reader's global variables:

```
*read-base* number base to be read; default is decimal ten
```

\*readtable\* current readtable which determines reader syntax

Reader's default macro characters:

```
read list
```

- " read string
- read quoted expression
- # dispatch macro
- ; comment until end of line
- back-quote
- , list-time eval
- @ append
- % read C-like mathematical forms

#### Escape characters:

```
\ single character escape |...| multiple character escape
```

When an unescaped symbol is read, all the constituent characters are converted to upcase by default, and upcase-character symbol is stored internally. For example, 'abc and 'ABC are regarded as the same symbol. Escape is necessary to distinguish between them. 'ABC, 'ABC and 'abc are identical, while 'abc and 'abc are different symbols. By default, even if you enter a symbol with upcase letters, When symbols are printed, EusLisp's printer converts them into lowercase from internal upcase representation. This conversion is suppressed by setting \*print-case\* to :UPCASE.

Note that 10. is read as integer 10, not floating 10.0. Since ':' is reserved for package marker, it must be escaped when used as a constituent of a symbol, like |g:pcube|. This restriction is imposed not by the syntax of the character ':', but by the attribute which determines the alphabetical order and the meaning of the letter. The attributes of characters are hardwired in the reader. Thus, although you may change the syntax of a certain character by creating a new readtable by **copy-readtable** and resetting the syntactic meaning for the character by **set-syntax-from-char**, you cannot change its attribute anyway. In other words, digits are always digits, alphabets are alphabets, and we cannot use letters like '#\$\%\text{@}' to represent numbers.

String is denoted by two double quotes "" at the beginning and at the end. No case conversion is taken inside the quotes. A back-slash 'is used as an escape to include a double quote. Therefore, "He said, I like Lisp." is read as a string including two double quotes. To enter a back-slash, two back-slashes are needed. Note that shift-JIS encoding of Japanese text is inadequate for this read-string convention, since some characters happen to have the code of a back-slash (#x5c) as their second byte. Use of EUC coding is preferrable.

% is an extended read-macro character specific to EusLisp. Preceding % to a mathematical formula written in infix notation, the formula is converted to lisp's prefix form. For an instance, %(1 + 2 \* 3 / 4.0) is

transformed to (+ 1 (/ (\* 2 3) 4.0)) and 2.5 is resulted. C-like function calls and array references are converted to lisp forms, too, thus,  $\%(\sin(x) + a[1])$  is evaluated to (+ (sin x) (aref a 1)). Functions having more than one arguments and arrays of more than two dimeisions are notated as func(a b c ...) and ary[1 2 3 ...], not func(a,b,c) nor ary[1][2][3]. Relative expressions and assignments are also properly handled, so, %(a < b) is converted to (< a b), and %(a[0] = b[0] \* c[0]) is to (setf (aref b 0) (\* (aref b 0) (aref c 0))). A simple optimization is performed to reduce duplicated function calls and array references.  $\%(\sin(x) + \cos(x) / \sin(x))$  is converted into (let\* ((temp (sin x))) (+ temp (/ (cos x) temp))).

Dispatch macros are preceded by the # character. A number (integer) argument can be given between # and a dispatch macro character. This means that any digits (0 .. 9) cannot be defined as dispatch macro characters. Reader's standard dispatch macro characters follow:

```
#nA(..) array
#B binary number
#D degree to radian conversion; \#D180 = 3.14
#F(...) floatvector
#nF((...)) float array; \#2F((...) (..)) is matrix
#I(...) integer-vector
#nI((...)) integer array
#J(...) general object #J(myclass ...); obsolete
#0 octal number
#P pathname
#R radian to degree conversion; \#R3.14 = 180.0
#S(classname slotname1 val1 slotname2 val2 ...) structure (any object)
\#V(...) vector \#V(\text{vectorclass }...)
#X hexadecimal number
#(...) vector
#n# label reference
#n= label definition
#' FUNCTION; compiled-code or lambda-closure
#\ character
#, read-time evaluation
#+ conditional read (positive)
#- conditional read (negative)
#* bit vector
```

#### #: uninterned symbol

#### #|...|# comment; can be nested

Some reader functions have *eof-error-p*, *eof-value* and *recursive-p* parameters. The first two parameters control the behavior when the reader encounters with end-of-file. The default of *eof-error-p* is t, which causes an error at eof. If you want to know the occurrence of eof and don't want the system's error-handler to snatch control, specify nil to *eof-error-p*. Thus, when an eof appears during reading, the reader returns the *eof-value* instead of entering an error loop. *Eof-value* is defaulted to nil. So, you cannot know if nil is actually read, or eof appears. To distinguish them, give a value which can never appear in the stream. Use **cons** or **gensym** to make such unique data object.

Recursive-p is often used in read-macro functions, which call reader recursively. Non-nil value of recursive-p tells the reader that the read operation has been started somewhere else and it should not reset the internal table for reading forms labeled by #n= and #n#.

read & optional stream (eof-error-p t) (eof-value nil) recursive-p reads one S-expression.

[function]

#### read-delimited-list delim-char & optional stream recursive-p

[function]

reads s-expression which is delimited by delim-char. This is useful to read comma-separated list, or to read a sequence terminated by a special character like #\].

## read-line & optional stream (eof-error-p t) (eof-value nil)

[function]

reads a line which is terminated by a #\newline. The string returned does not contain the last newline character.

#### read-char & optional stream (eof-error-p t) (eof-value nil)

[function]

reads one character and returns its integer representation.

## read-from-string string &optional (eof-error-p t) (eof-value nil)

[function]

reads one s-expression from *string*. Only the first s-expression can be read. If successive read operations need to be performed on a string containing more than one expression, use string-stream made by **make-string-input-stream**.

# $\mathbf{unread\text{-}char}\ \mathit{char}\ \mathit{\mathfrak{Coptional}\ stream}$

[function]

puts the *char* back to the *stream*. More than one characters cannot be put back successively.

### peek-char & optional stream (eof-error-p t) (eof-value nil)

[function]

reads a character from the *stream* without removing it from the buffer of the *stream*. This is equivalent to a *read-char* followed by a *unread-char*.

## y-or-n-p Coptional format-string Crest args

[function]

prints format-string and args on your terminal, and asks "y-or-n". Repeat query until your response begins with either of "y" or "n", and returns T or NIL. Case does not matter.

## yes-or-no-p & optional stream

[function]

prints format-string and args on your terminal, and asks "yes-or-no". Repeat query until your response is either of "yes" or "no", and returns T or NIL. Case does not matter.

In the readtable manipulating functions, the default value of readtable is the value of the global variable \*readtable\*.

 $\mathbf{readtablep} \ x$  [function]

T if x is an readtable.

# ${\bf copy-readtable}\ {\it Eoptional}\ from\ -readtable\ to\ -readtable$

[function]

If no *to-readtable* is specified, a new one is created. All the information in *from-readtable* is transferd to *to-readtable*. The information included is, syntax table, read-macro table and dispatch-macro table, each of which has 256 elements.

set-syntax-from-char from-char to-char & optional to-readtable from-readtable [function] copies syntax and read-macro definition of from-char in from-readtable to that of to-char in to-readtable.

**set-macro-character** char func & optional non-teminating-p readtable defines func as the read-macro function for char.

[function]

## get-macro-character char &optional readtable

[function]

returns the read-macro function for *char*.

 $\mathbf{set\text{-}dispatch\text{-}macro\text{-}character}\ \mathit{dispchar}\ \mathit{char}\ \mathit{func}\ \mathcal{C}\mathit{optional}\ \mathit{readtable}$ 

[function]

defines func as the dispatch read-macro function for the combination of dispchar and char.

 $\mathbf{get\text{-}dispatch\text{-}macro\text{-}character}\ \mathit{dispchar}\ \mathit{char}\ \mathcal{C}optional\ \mathit{readtable}$ 

[function]

returns the dispatch read-macro function for the combination of dispchar and char.

#### 9.3 Printer

The followings are special variables controlling printer's behaviors.

\*print-case\* if this is :downcase, all symbols are printed in lowercase althought symbols are represented in uppercase internally unless they are escaped.

\*print-circle\* print objects preserving recursive refernce

\*print-object\* print the details of all objects

\*print-structure\* print objects using #s format.

\*print-level\* printable depth of a sequence

\*print-length\* printable length of a sequence

\*print-escape\* currently not used

\*print-pretty\* currently not used

\*print-base\* number base in printing; defaulted to decimal ten

In order to print objects containing recursive references so that they can be read back again, print the objects with both \*print-circle\* and \*print-structure\* set to T. Although most of the user defined objects can be printed in re-readable forms, classes, compiled-codes and packages cannot be dumped in that way, because classes and compiled-code include unrelocatable executable codes, and the rereading packages damages the consistency among symbols.

print obj &optional stream

[function]

is **prin1** followed by **terpri**.

prin1 obj &optional stream

[function]

outputs one s-expression in the format that they can be read back again by **read**. The format includes slashes (escapes) and quotation marks.

princ obj &optional stream

[function]

same as **print** except that **princ** does not add escape or quote. Objects printed by **princ** cannot be read back. For example, the output of (princ 'abc) is identical with that of (princ "abc") and the reader cannot distinguish between them.

terpri & optional stream

[function]

outputs #\newline and flush stream.

 $\textbf{finish-output} \ \mathcal{C}optional \ stream$ 

[function]

flushes output stream.

**princ-to-string** x & optional (l 16)

[function]

prin1-to-string x & optional (l 16)

[function]

makes a string-output-stream, writes to it, and get-output-stream-string.

format stream format-string &rest args

[function]

Format only recognizes  $\sim A(ascii)$ ,  $\sim S(S-expression)$ ,  $\sim D(decimal)$ ,  $\sim X(hexadicimal)$ ,  $\sim O(octal)$ ,  $\sim$ C(character),  $\sim$ F(floating),  $\sim$ E(exponential),  $\sim$ G(general float),  $\sim$ V(dynamic number parameter),  $\sim$ T(tab) and  $\sim$ %(newline) format specifiers. (format t "~s ~s ~a ~a ~10,3f~%" "abc" 'a#b "abc" 'a#b 1.2) ---> "abc" |A#B| abc a#b 1.200 pprint obj &optional (stream \*standard-output\*) (tab 0) (platen 75) [function] pretty-prints obj. print-functions file &rest fns [function] write the "defun" forms of function definitions of fns out to file. write-byte integer stream [function] [function] write-word integer stream [function] write-long integer stream write *integer* as a one-, two- or four-byte binary. spaces n &optional stream [function] outputs spaces n times. **pf** func &optional stream \*standard-output\*) [macro] pretty-prints a function. Compiled function cannot be printed. pp-method class selector &optional (stream \*standard-output\*) [function]

[function]

[function]

pretty-prints the method defined in *class* by the name of *selector*.

tprint obj tab &optional (indent 0) (platen 79) (cpos 0)

returns inexact length of obj when it is printed.

print obj in tabular format.

print-size obj

## 9.4 InterProcess Communication and Network

EusLisp provides four kinds of IPC facilities, shared memory, message-queue, FIFO and socket. <sup>2</sup> Normally, efficiency decreases in this order. If you are using multithread facility, synchronization functions described in the section 12 are also used for communications. Availability of these facilities depends on the configuration and the version of Unix.

## 9.4.1 Shared Memory

EusLisp supports the shared memory provided by SunOS's mmap, not by System5's shmem. Shared memory is allocated by the **map-file** function. **Map-file** maps a file into the EusLisp process memory space and an instance of **foreign-string** is returned. Data can be written and retrieved using string functions on this foreign-string. Since shared memory is allocated at system-dependent page boundary, you should not specify the map address. Mapping a file with the **:share** keyparameter set to NIL or **:private** set to T means the file should be accessed privately (exclusively). Since this is not useful for the purpose of memory sharing, the default value of **:share** key is T. When a file is shared between two users, the read/write permission must be properly set for both users. Unfortunately, SunOS does not support file sharing through networks between different workstations.

Example programs to share a file of 64 byte length between two euslisp are shown below.

```
;; Create a file of 64 bytes
(with-open-file (f "afile" :direction :output) (princ (make-string 64) f))
;; Map it
(setq shared-string1 (map-file "afile" :direction :io))
;;
;; In another process
(setq shared-string2 (map-file "afile" :direction :io))
```

Then, data written to shared-string1 immediately appears in shared-string2, and vice versa. Writing to a foreign string can be made by replace or setf in conjunction with aref.

```
map-file filename & (direction:input) length (offset 0) (share t) (address 0) [function] maps the file named filename to memory space. Filename can be either of a local file, an NFS-mounted remote file, or a memory device in /dev. A foreign-string, whose elements can be accessed by aref, is returned. Writing data into a foreign-string mapped by map-file with direction=:input will result a segmentation fault.
```

#### 9.4.2 Message Queues and FIFOs

A message-queue is created by **make-msgq-input-stream** or **make-msgq-output-stream**. Each of these returns an instance of file-stream, which can then accept read and print operations like other streams connected to files. The **fname** slot of message-queue stream is set to the key when it is created.

To make a stream to FIFO, you first create a FIFO node with **unix:mknod** function by setting its second argument *mode*=#o10000, and you open it as a normal file. Message-queues and FIFOs are created locally on a machine and only provide communication channels within the machine.

<sup>&</sup>lt;sup>2</sup>Since the pipe, the traditional process communication mechanism in Unix, is always used in conjunction with 'fork', EusLisp provides the **piped-fork** function explained in the section 11.3.

Note that message-queues and FIFOs are not removed from the system even after the owner process terminates. Explicit use of **unix:msgctl** or **ipcrm** command is needed to delete them.

```
make-msgq-input-stream key & optional (buffer-size 128) [function]
returns an input file-stream which is connected to a message-queue identified by key.

make-msgq-output-stream key & optional (buffer-size 128) [function]
returns an output file-stream which is connected to a message-queue identified by key.
```

#### 9.4.3 Sockets

The socket is more versatile than other communication mechanisms because it can operate either host-locally (in unix domain) or network-widely (in internet domain). Connection-oriented socket (SOCK\_STREAM) and unconnected socket (SOCK\_DGRAM) are supported. In both cases, you must first create a socket address object by make-socket-address function, which returns an instance of socket-address. In unix domain, a socket address is specified by a path-name in the unix file system. In internet domain, the address is specified by combining the host machine name, the port number, and optionally the protocol number. If the port number is defined in /etc/services, it can be referred through the symbol specified by the service name. The function unix:getservbyname can be used to retrieve the port number from the symbolic service name. Port numbers less than 1024 are reserved for root users, and non-priviledged users are advised to use port numbers greater than 1024 for their private sockets.

Although connected streams provide bidirectional communication channels, the connection establishment operation is asymmetric. One endpoint is referred to server and other to client. The endpoint on the behalf of the server (service access point) must be first established. It is created by **make-socket-port** function which returns an instance of **socket-port**. The socket-port object is then used to accept connections from one or more clients by **make-server-socket-stream**. A call to **make-server-socket-stream** may be blocked until a connection request from a client really happens. Clients can make socket streams by **make-client-socket-stream** specifying a socket-address.

```
;;; an example of IPC through a socket stream:
;;; server side
(setq saddr (make-socket-address :domain af_inet :host "etlic2" :port 2000))
(setq sport (make-socket-port saddr))
(setq sstream (make-server-socket-stream sport))
;;;
;;; client side
(setq caddr (make-socket-address :domain af_inet :host "etlic2" :port 2000))
(setq cstream (make-client-socket-stream caddr))
```

In applications like a database or an environment simulator for mobile robots, multiple connection service between one server and many clients is required. This type of server can be programmed by the **open-server** function. From the current host name and given port number, **open-server** creates a socket port (service access point) on which connection requests are listened for. Since this port is attributed to be asynchronous, **open-server** is not blocked and returns immediately. Thereafter, each connection request interrupts EusLisp's main loop, and an socket-stream is created asynchronously. This socket-stream also works in asynchronous mode: the asynchronous input processing function which is the second argument to

**open-server** is invoked whenever new data appear in this stream. Up to 30 connections can be established so that as many clients can access the server's data at the same time.

```
;; server side
(defun server-func (s)
    (case (read s) ... ; do appropriate jobs according to inputs
(open-server 3000 #'server-func)
... do other jobs in parallel
;; client-1 through client-N
(setq s (connect-server "etlmmd" 3000))
(format s "..." ...) (finish-output s) ;issue a command to the server
(read s) ;receive response
```

In contrast to the *connection-oriented* streams which provide reliable communication channels, the *connectionless* sockets are unreliable: messages may be lost, duplicated, and may arrive out-of-order. The *connectionless* sockets, however, have advantages that they do not need to assign file descriptor to each connection, and sending process is never blocked even if the receiver is not reading data and the buffer overflows.

To make connectionless sockets, use the following procedures. Messages are transferred by the **unix:sendto** and **unix:recvfrom**.

```
;;; receiver side
(setq saddr (make-socket-address :domain af_inet :host "etlic2" :port 2001))
(setq sock
             (make-dgram-socket saddr))
(unix:recvfrom sock)
;;;
;;; client side
(setq caddr (make-socket-address :domain af_inet :host "etlic2" :port 2001))
(setq sock (unix:socket (send caddr :domain) 2 0))
(unix:sendto sock caddr "this is a message")
;;; how to use echo service which is registered in /etc/services.
(setq caddr (make-socket-address :domain af_inet :host "etlic2"
                                 :port (car (unix:getservbyname "echo"))))
(setq echosock (unix:socket (send caddr :domain) 2 0))
(unix:sendto echosock caddr "this is a message")
(unix:recvfrom echosock) --> "this is a message"
```

make-socket-address &key domain pathname host port proto service

[function]

makes a sockaddr structure.

```
make-socket-port sockaddr
```

[function]

makes a server-side socket port which is used to establish a connection with a client.

```
make-server-socket-stream sockport &optional (size 100)
```

[function]

accepts a connection from a client and returns a two-way stream.

make-client-socket-stream sockaddr &optional (timeout 5) (size 512)

[function]

connects to a server port and returns a two-way stream.

## open-server port remote-func

[function]

prepares a socket port designated by the host name and *port* in internetnet domain, and waits for the connection requests asynchronously. Each time a connection is requested, it is accepted and a new socket-stream is opened. When a message arrives at the socket-port, *remote-func* is invoked with the socket port as the argument.

# connect-server host port

[function]

This is a shorhand of successive calls to make-socket-address and make-client-socket-stream. A socket-stream for a client to communicate with the server specified by *host* and *port* is returned. The port is made in internet domain.

# 9.5 Asynchronous Input/Output

### select-stream stream-list timeout

[function]

finds a list of streams which are ready for input operation, in *stream-list*. NIL is returned if *timeout* seconds have expired before any streams become ready. **Select-stream** is useful when you choose active streams out of a list of input-streams on which input operation becomes possible asynchronously. *Timeout* specifies the time when the select operation is aborted. It can be a float number. If no timeout is specified, select-stream blocks until input arrives at least one stream. If *timeout* is specified and no input appears on any streams, select-stream aborts and returns NIL.

# def-async stream function

[macro]

defines function to be called when data arrives at stream. stream is either a file-stream or a socket-port. When data comes to the file-stream or a connection request appears on the socket-port, function is invoked with the stream as its argument. This macro installs a SIGIO handler that dispatches to user supplied function which is expected to perform actual input operation, and uses unix:fcntl on stream to issue SIGIO asynchronously when stream becomes ready to be read.

# 9.6 Pathnames

Pathnames give the way to analyze and compose file names OS-independently. A typical path name is assumed to be consisted of following components: host:device/directory1/.../directory-n/name.type.version. Since EusLisp only runs on Unix, host, device and version fields are ignored. The **pathname** function decomposes a string into a list of directory components, name and type, and returns a pathname object, which is printed as a string prefixed by #P.

pathnamep name

[function]

returns T if *name* is a pathname.

pathname name

[function]

name is pathname or string. name is converted to pathname. To indicate the last name is a directory name, don't forget to suffix with "/". The inverse conversion is performed by namestring.

# pathname-directory path

[function]

returns a list of directory names of *path*. Root directory (/) is represented by :ROOT. *path* can be either of string or pathname.

### pathname-name path

[function]

returns the file-name portion of path. path can be either of string or pathname.

## pathname-type path

[function]

extracts the file-type portion out of path. path can be either of string or pathname.

make-pathname Ekey host device directory name type version defaults

[function]

makes a new pathname from *directory*, name and type. On unix, other parameters are ignored.

merge-pathnames name & optional (defaults \*default-pathname-defaults\*)

[function]

namestring path

[function]

returns string representation of path.

parse-namestring name

[function]

truename path

[function]

tries to find the absolute pathname for the file named path.

# 9.7 URL-Pathnames

URL-Pathname is an extension of pathname to have slots for a protocol and a port. A URL is composed of six components; protocol, server, port, directories, filename, and file-type, like http://shock2.etl.go.jp/matsui/inc

### url-pathname name

[function]

name is pathname or string. name is converted to pathname. To indicate the last name is a directory name, don't forget to suffix with "/". The inverse conversion is performed by namestring.

# 9.8 File-name generation

# digits-string n digits & optional (base 10))

[function]

generates a string representing the integer n in n columns of digits. Zeros are padded before the number if n is too small to represent in digits.

## sequential-file-name head num extension & optional (digits 4))

[function]

generates a filename string with an advancing number part. This is similar to gentemp, but differs in that an extension can be specified and the result is a string.

# $\mathbf{timed\text{-}file\text{-}name}\ \textit{head}\ \textit{extension}\ \mathcal{C}optional\ (\textit{dt}\ (\textit{unix:localtime})))$

[function]

generates a filename string that consists of head, hour, minute, second, and extension. For example, (timed-file-name "img" "jpg") generates "img191015.jpg" at 7:10:15 pm.

## dated-file-name head extension & optional (dt (unix:localtime)))

[function]

generates a filename string formatted as "headyymmmdd.extension", where yy is the lower two digits of the year, mmm is the abbreviated month name, and dd is the date.

# 9.9 File System Interface

### **probe-file** path

[function]

checks if a file named path exists.

# file-size path

[function]

returns the size of the file named path in bytes.

# directory-p path

[function]

returns T if path is a directory, NIL otherwise even path does not exist.

## find-executable file

[function]

returns the full pathname for the Unix command named file. Find-executable provides almost the same functionality with Unix's 'which' command that searches the executable file in your path list.

# ${\bf file\text{-}write\text{-}date}\ file$

[function]

returns the integer representation of the time when the *file* was last modified. String representation can be obtained by (unix:asctime (unix:localtime (file-write-date *file*)))

### file-newer new old

[function]

returns T if the *new* file is modified more recently than the *old* file.

### object-file-p file

[function]

returns T if the file is an object file by looking at the file's magic number in the header.

### directory & optional (path ".")

[function]

makes a list of all the files in the path.

# dir &optional (dir ".")

[function]

prints file names in the specified directory.

# 10 Evaluation

### 10.1 Evaluators

In order to specify the behaviors upon an error and an interrupt(signal), set an appropriate function to each of the special variables \*error-handler\* and \*signal-handler\* in advance. There is no correctable or continue-able error. After analyzing errors you must abort the current execution by reset or appropriate throw to upper level catchers. reset is equivalent to (throw 0 NIL), since EusLisp's top-level creates catch frame named 0.

Error handlers should be programmed as functions with three or four arguments: code msg1 form &optional (msg2). Code is the error code which identifies system defined errors, such as 14 for 'mismatch argument' or 13 for 'undefined function'. These mappings are described in "c/eus.h". msg1 and msg1 are messages displayed to the user. form is the S-expression which caused the error.

Signal handlers should be programmed as functions receiving two arguments: *sig* and *code*. *Sig* is the signal number ranging from 1 to 31, and *code* is the minor signal code defined in signal-number dependent manners.

^D (end-of-file) at the top-level terminates eus session. This is useful when eus is programmed as a filter.

**Eval-dynamic** is the function to find the dynamic value bound to a symbol used as a let or lambda variable. This is useful for debugging.

identity obj

returns obj itself. Note the difference between **identity** and **quote**. **identity** is a function whereas **quote** is a special form. Therefore, (identity 'abc) is evaluated to abc and (quote 'abc) == (quote (quote abc)) is evaluated to 'abc. **Identity** is often used as the default value for :key parameters of many generic sequence functions.

### eval form Coptional environment

[function]

evaluates form and returns its value. Hook function can be called before entering the evaluation, if \*evalhook\* is set to some function that accept form and environment.

# apply func &rest args

[function]

func is applied to args. Func must be evaluated to be a function symbol (a symbol which has a function definition), a lambda form, or a closure. Macros and special forms cannot be applied. The last element of args must be a list of arguments while other args should be bare arguments. Thus, if the last args is NIL, then apply is almost equivalent to funcall, except that apply has one more arguments than funcall. (apply #'max 2 5 3 '(8 2)) --> 8.

## funcall func &rest args

[function]

applies func to args. The number of args must coincide to the number of arguments the func requests.

# quote obj

[special]

evaluates to obj itself.

### function func

[special]

makes a function closure. If func is a symbol, its function definition is retrieved.

# evalhook hookfunc form Coptional env

[function]

evaluates form once after binding hookfunc to \*evalhook\*.

eval-dynamic variable [function]

finds the value of *variable* (symbol) on the stack.

macroexpand form [function]

expands form if it is a macro call. If form is expanded to a macro call again, expansion is repeated until non macro call results.

# eval-when situation &rest forms

[special]

Situation is a list of compile, load and eval. Forms are evaluated when the current execution mode matches with situation. eval-when is important to control the behavior and environment of the compiler. If compile is specified, forms are evaluated by the compiler so that the result will affect the consequent compilation. For example, defmacro should be evaluated by the compiler in order to let the compiler expand macro calls at compile time. If load is given in the situation list, forms are compiled to be loaded (evaluated) at load time, i.e., compiled functions are defined at load time. This is the normal effect that we expect to the compiler. load situation is used to control the compiler's environment. If eval is included in situation list, forms are evaluated when their source code is loaded.

the type form [special]

Declares form is of type. type is either a class object, :integer, :fixnum, or :float.

declare & rest declarations [special]

Each *declaration* is a list of a declaration specifier and an integer or target symbols. Declarations are important to let the compiler produce faster code.

special declares special variables

type declares the type of variables; (type integer count); valid type specifiers are integer, :integer fixnum, :float and float. The type keyword may be omitted if type specifier is either one listed here. So (integer count) is a correct declaration. Other types (classes) such as float-vector, integer-vector, etc. need to be preceded by type, as (type float-vector vec1).

ftype declares the result type of functions

optimize set \*optimize\* parameter (0-3) of the compiler

safety set \*safety\* parameter (0-3) of the compiler

space set \*space\* parameter (0-3) of the compiler

inline not recognized

not-inline not recognized

# ${\bf proclaim} \ proclamation$

[function]

globally declares the types of variables and compiler options. The same declarations are accepted as described for **declare** special form. However, **proclaim** is a function of one argument and proclamation is evaluated.

## warn format-string &rest args

[function]

prints warning-message given as format-string and args to \*error-output\*.

### error format-string &rest args

[function]

calls the current error-handler function bound to \*error-handler\*. The default error-handler 'euserror' first prints arguments to \*error-output\* using format, then enters a new top level session. The prompt shows you the depth of your error session. Throwing to the number, you can go back to the lower level error session.

In the multithread EusLisp, special variables are shared among threads and the same \*error-handler\* is referenced by different threads. To avoid this inconvenience, multithread EusLisp provides the install-error-handler function which installs different error handler for each thread.

# ${\bf lisp::install\text{-}error\text{-}handler}\ \textit{handler}$

[function]

installs the handler as the error handler of the current thread.

# 10.2 Top-level Interaction

EusLisp's standard top-level read-eval-print loop is controlled by **eustop**. When EusLisp is invoked, **eustop** tries to load the file named ".eusrc" in your home directory or the file specified by the EUSRC environment variable. It also tries to load a file named ".eusrc" in the current working directory. So, if you are in your home directory, note that .eusrc is loaded twice. Then EusLisp loads files specified in its argument list. After these loading, **eustop** enters normal interactive session.

When \*standard-input\* is connected to user's tty, eustop prints prompt generated by the toplevel-prompt function. The default toplevel-prompt prints "eus\$ ". The effect of changing the definition of toplevel-prompt appears when eustop is invoked next time. One way to change the prompt from the first time is to define toplevel-prompt in your .eusrc file.

Inputs are read from \*terminal-io\* stream. If the input is parenthesized, it is taken as a lisp form and is evaluated by eval. Else if the first symbol of the input line has function definition, the line is automatically parenthesized and evaluated. If no function definition is found, then its special value is examined and the value is printed. If the symbol is unbound, the line is regarded as UNIX command and passed to sh (Bourn's shell). If sh cannot find corresponding unix command, "command unrecognized" message is printed. Thus, eustop works both as a lisp interpreter and as a unix shell. If you do not wish to execute the input as UNIX command, you may escape the form by preceeding a comma', at the begining of the line. This is also useful to see the dynamic value binding when an error occurred in the interpretive execution. Since EusLisp adopts lexical scope, we cannot examine the value of local variables outside of the scope unless they are declared special.

If the environment variable, USE\_TOP\_SELECTOR, is defined, the toplevel input is read in an asynchronous manner using the select library call. The input stream (\*standard-input\*) is registered to the \*top-selector\*, which is an instance of the port-selector class, together with the read-eval-print function (repsel) Therefore arrival of key inputs invokes the evaluation of the repsel. This feature is particularly useful when EusLisp is to handle multiple events, i.e., key inputs, X window events, and socket connection requests, at the same time. In order to exploit this asynchronous toplevel interaction, users should never write a code that blocks at the read operation. Instead, the input stream should be registered to the \*top-selector\* with its handler function by using the :add-port method. The handler function is expected to read from the stream, which is already known ready to return the input without blocking.

Note that Xwindow event handlers are defined to use the \*top-selector\* implicitly when USE\_TOP\_SELECTOR is defined, and user programs do not have to call x:window-main-loop at all to catch X events.

Using the time-out of the select call, users may define a timer handler. Each time the select call times out, the function bound to \*timer-job\* is invoked with no argument. The timer interval is defined by \*top-selector-interval\*, which is defaulted to 10.0 second. Note that the timer function invokation is not precisely periodic when there are inputs to the \*top-selector\*.

In the toplevel interaction, each line input is remembered in \*history\* vector with a sequence number. You can recall a specific input by! function as if you were in csh. The difference from csh's history is, you need at least one white space between the exclamation mark and the sequence number since! is a function.

^D (EOF) terminates EusLisp normally. To return abnormal termination code to upper level (usually a csh), use **exit** with an appropriate condition code.

**eustop** sets a signal handler only for SIGINT and SIGPIPE, and other signals are not caught. Thus, signals such as SIGTERM or SIGQUIT cause EusLisp to terminate. In order to catch these signals to avoid termination, use **unix:signal** function to set user-defined signal handlers.

[variable] current input. [variable] +previous input. [variable] old input. +++ [variable] ancient input. [variable] previous result. [variable] old result. \*\*\* [variable] ancient result. \*prompt-string\* [variable] prompt string used by **eustop**. \*program-name\* [variable] the command that invoked this EusLisp, possibly eus, eusx, eusxview or user-saved euslisp. eustop &rest argv [function] is the default toplevel loop.  $\mathbf{eussig}\ sig\ code$ [function] is the default signal hander for SIGPIPE. eussig prints signal number upon its arrival and enters another toplevel loop.  $sigint-handler \ sig \ code$ [function] is the default signal handler for SIGINT (control-C). It enters a new top level session. euserror code message &rest arg [function] the default error handler that prints message and enters a new error session. [function] resetquits error loop and goes back to the outermost eustop session. [function] exit & optional termination-code terminates EusLisp process and returns termination-code (0..255) as the process status code (0..255). \*top-selector\* [variable] The port-selector object to handle asynchronous function invocation according to inputs from multiple streams. h [function]

prints all the inputs remembered in \*history\* vector with associated sequence numbers.

[function]

! Eoptional (seq 0)

recalls the input line associated with the sequence number seq. When seq is 0, the most recent command is recalled, and if seq is negative, the line is specified relatively to the current input. The recalled line is printed and the cursor is located at the end of the line. You can go backward by control-H (backspace) or control-B, go forward by control-F or control-K, go to the beginning of line by control-A, to the end of line by control-L control-C cancels the line editing. control-M (carriage-return) or control-J (line-feed) finishes editing the line and starts evaluation of the edited line. If seq is not a number and is a symbol or a string, the history list is searched toward old input, and a command line which include the symbol or a string as a substring is returned.

new-history depth [function]

initializes \*history\* vector to have depth length. Depth input lines are remembered. All the input lines recorded in the current \*history\* are discarded.

# 10.3 Compilation

EusLisp compiler is used to speed the execution of Lisp programs. You can expect 5 to 30 times faster execution and notable reduction of garbage collection time elapsed by macro expansion.

Euscomp does optimization for arithmetic operation and vector access. Sometimes proper type declarations are needed to inform the compiler applicability of optimization.

Compile-function compiles functions one by one. Compile-file compiles an entire source file. During the execution of Compile-file, each form in a file is read and evaluated. This may change the current EusLisp environment. For examples, defparameter may set a new value to a symbol and defun may substitute the existing compiled function with its non-compiled version. To avoid these unexpected effects, use the eval-when special form without compile time situation, or use euscomp command to run the compiler as a separate process.

**Euscomp** is a unix command, which is usually a symbolic link to **eus**. It recognizes several options. -O flag indicates optimization of the C compiler. Each of -O1,-O2, -O3 indicates optimization level of EusLisp compiler, which is equivalent to proclaiming (optimize 1 or 2 or 3). Each of -S0, -S1, -S2, -S3 set 0,1,2 and 3 to compiler:\*safety\*. If \*safety\* is less than 2, no code for checking interrupt is emitted, and you will lose control if the program enters an infinite loop. If \*safety\* is zero, the number of required arguments is not checked. -V flag is used to print function names when they are compiled (verbose). -c flag prevents from forking and exec'ing cc. -D pushes next argument to the \*features\* list, which can be used for conditional compilation in conjunction with #- and #+ read-macro.

The compiler translates EusLisp source program named as "xxx.l" into the intermediate C program file named "xxx.c" and the header file named "xxx.h". Then the C compiler is run and "xxx.o" is generated. Intermediate files "xxx.c" and "xxx.h" are left for the purpose of cross compilation: usually you only need to compile "xxx.c" files by cc unix command when you wish to use the code on machines of different architecture. Compiled code is loaded to EusLisp by '(load "xxx")'.

Each intermediate file refers to the "eus.h" header file, which is supposed to be located in the \*eusdir\*/c directory. \*eusdir\* is copied from the EUSDIR environment variable. If none is set, /usr/local/eus/ is taken as the default directory.

When compiled, intermediate C programs are usually much bigger than the original source code. For example, 1,161 lines of "l/common.l" lisp source expands to 8,194 lines of "l/common.c" and 544 lines of "l/common.h". Compiling 1,000 lines of lisp source is not a hard task, but optimized compililation of nearly 10,000 lines of C program not only takes long time (several minutes), but also consumes much disk space. So if you are compiling relatively big programs, be sure your machine has sufficient /var/tmp disk, otherwise CC may die. Setting the TEMPDIR environment variable to a bigger disk slice may help.

As the linkage is performed at load-time or at run-time, no recompilation is required even the eus kernel is updated. On the other hand, run-time linkage may impose you another inconvenience. Suppose you have two functions A and B in a file "x.l" and A calls B. After compiling "x.l", you load "x.o" and try to call A which internally calles B. Then you find a bug in B, and probably you would redefine B. Here, you have compiled A and non-compiled B. You may call A again, but nothing will change, since A still calls old compiled B which is rigidly linked when A first called B. To avoid this problem, A must be redefined again, or B must be redefined just after "x.o" is loaded and before A is called.

When a compiled-code is loaded, its top level code, which is normally a series of defun, defmethod, etc., is executed. This top level code is defined as the entry function of the load module. The compiler names the entry function, and the loader has to know the exact name of this function. To make the situation simple, both the compiler and the loader assume the entry function name is identical to the basename of the object

file. For example, if you compile and load "fib.l", the compiler produces "fib(...)" as the entry function of "fib.c", and the loader looks for "fib" in the "fib.o" object file. Since the final object file is produced by "cc" and "ld" of unix, this entry function name has to satisfy the naming rule of C functions. Therefore, you have to avoid C's reserved keywords such as "int", "struct", "union", "register", "extern", etc., or the private identifiers defined in "c/eus.h" such as "pointer", "cons", "makeint", etc., to be used as the name of the file. If you have to use one of these reserved words as the name of the source file, you specify it as :entry arguments of the compiler and the loader.

A restriction exists for the usage of closure: **return-from** special form in closures and clean-up forms in unwind-protect is not always correctly compiled.

**Disassemble** is not implemented. In order to analyze compiled code, see the intermediate C program or use adb.

# euscomp &rest filename

[unix-command]

Invokes EusLisp compiler.

compile-file

[function]

```
srcfile &key (verbose nil)

(optimize 2) (c-optimize 1) (safety 1) ; optimization level

(pic t) ; position independent code

(cc t) ; run c compiler

(entry (pathname-name file))
```

compiles a file. ".l" is assumed for the suffix of the *srcfile*. If *:verbose* is T, names of functions and methods being compiled are printed to make it easy to find the expressions where errors occurred. *:Optimize*, *:c-optimize* and *:safety* specifies the optimization levels. *:Pic* should be set T, unless the module is hard-linked in the EusLisp core during the make stage.

compile function [function]

compiles a function. **Compile** first prints the function definition into a temporary file. The file is compiled by **compile-file** and then is loaded by **load**. Temporary files are deleted.

### compile-file-if-src-newer srcfile &key compiler-options

[function]

compiles the *srcfile* if it is newer (more recently modified) than its corresponding object file. The object file is supposed to have the ".o" suffix.

# compiler:\*optimize\*

[variable]

controls optimization level.

### compiler:\*verbose\*

[variable]

When set to non-nil, the name of a function or a method being compiled, and the time required for the compilation are displayed.

# compiler:\*safety\*

[variable]

controls safety level.

# 10.4 Program Loading

load [function]

```
fname &key (verbose *load-verbose*)
(package *package*)
(entry (pathname-name fname))
(symbol-input nil)
(symbol-output "")
(print nil)
(ld-option "")
```

Load is the function to read either a source file or a compiled object file into the EusLisp process. If the file specified by *fname* exists, it is loaded. Whether the file is source or binary is automatically checked by seeing its magic number. If the file does not exist but a file with the file type '.o' exists, the file is loaded as an object file. Else if a file with the '.l' suffix is found, it is loaded as a source program. Therefore, there is a case where you specified "foo.so" expecting "foo.l" is already compiled, but "foo.l" is actually loaded, since it has not yet been compiled in reality. In other words, if you just specify a base-name of a file, its compiled version is first tried to be loaded, and the source file suffixed by ".l" is tried later. If the file name is not specified in the absolute path by prefixing the name with a slash "/", load searches for the file in the directories specified by the \*load-path\* global variable.

For example, if \*load-path\* is ("/user/eus/" "/usr/lisp/"), and "llib/math" is given as fname, load tries to find "/user/eus/llib/math.o", "/usr/lisp/llib/math.o", "/user/eus/llib/math.l" and "/usr/lisp/llib/math.l" in this order. If no appropriate file could be found, an error is reported.

:entry option specifies the entry address to initialize the load module. For example, :entry "\_myfunc" option means that the execution begins at \_myfunc. Default entry is the basename of the file loaded as described in the section 10.3. Library module names can be specified in :ld-option option string. For example, in order to link a module which uses suncore libraries, :ld-option "-lsuncore -lsunwindow -lpixrect -lm -lc" should be given. On non Solaris systems, ld runs twice when libraries are included; once to determine the size of the linked module, and again to link them actually with a proper memory allocation.

:symbol-input and :symbol-output options are used to solve references from one object module to another or to avoid duplicated loading of libraries. Suppose you have two object modules A and B which has reference to symbols defined in A. You first load the module A specifying :symbol-output = "a.out". Symbol information generated by this linking is written to a.out. In order to load the module B, you have to specify :symbol-input = "a.out" to solve the references from B to A.

On Solaris2 OS, the loading of compiled code is done by calling *dlopen* in the dynamic loader library. Application of *dlopen* is restricted to shared objects which are compiled position independently with "-K pic" option. Also, since *dlopen* cannot open the same file twice, load first does *dlclose* on the file already loaded.

:print option decides whether load should produce output to \*standard-output\* for each input expression. This option is provided to find which expression (usually defun, defmethod, etc.) results error in loading.

[function]

loads files successively with setting :verbose to T.

\*modules\* [variable]

holds a list of names of the modules that have been loaded so far.

# $\mathbf{provide}\ module\text{-}name\ \mathcal{E}rest\ version\text{-}info$

[function]

adds the concatenation of *module-name* and *version-info* to \*modules\* as the name of the module being loaded. *module-name* should be a symbol or a string. Calls to **require** should appear at the beginning of files that compose a complete modules.

# require module-name &rest load-arg

[function]

loads file given by module-name or the first argument or load-arg unless module-name is found in \*modules\*. provide and require control dependency among modules and are used to avoid duplicated loading of basic modules. Suppose you have one basic module named "A" and two application modules named "B" and "C" which are independent from each other but rely on "A" module. At the beginning of each file, module name is declared by provide. Since "A" module does not depend on any other modules it does not require anything. (require "A" "a.o") follows calls to provide in "B" and "C". If you load "B" (more precisely, "b.o"), "a.o" is also loaded since it is found in \*modules\* and two module names "A" and "B" are added to \*modules\*. Then if you load "C", "A" module is not loaded and "C" is added to \*modules\*.

system:binload

[function]

```
opath qpath & optional (entry (pathname-name opath))
(symfile "/usr/local/bin/eus")
(symout "a.out")
(ldopt "")
```

link-load a binary file.

system::txtload fname

[function]

# 10.5 Debugging Aid

**describe** obj &optional (stream \*standard-output\*)

[function]

**Describe** prints the contents of an object slot by slot.

describe-list list &optional (stream \*standard-output\*)

[function]

describes each element in list.

 $\mathbf{inspect}\ obj$ 

**Inspect** is the interactive version of **describe**. It accepts subcommands to print each slot of an object, to go deeper into a slot, or set a new value to a slot, etc. Use '?' command to see the subcommand menu.

more & function [function]

After evaluating forms with the binding of \*standard-output\* to a temporary file, the temporary file is output to \*standard-output\* with Unix's 'more' command. More is useful to see a long output generated by functions like **describe**.

break &optional (prompt ":: ")

[function]

Enters a break loop. Since the current binding context is in effect, local variables can be seen by prefixing "," to an input. To end break, type control-D.

help topic [function]

Help prints the brief description on the topic which is usually a function symbol. The help description has been created from the reference manual (this document). The environment variable LANG is referrenced to determine one of two reference manuals, Japanese or English. If LANG is constituted either with "ja", "JA", "jp", or "JP", Japanese is selected. Otherwise, English. This determination is made when EusLisp start up. The actual reading of the help document is made at the first time when the 'help' is invoked to save memory if unnecessary.

### apropos strng &optional pack

[function]

**Apropos** is useful when you forget the exact name of a function or a variable and you only know its partial or ambiguous name. It prints all the symbols whose symbol-names include the *strng* as a substring. If *pack* is provided, only prints symbols that belong to this package instead. Case insensitive.

### apropos-list strng &optional pack

[function]

is similar to apropos but does no printing and returns the result as a list.

constants &optional (string "") (pkg \*package\*)

[function]

lists every symbol in pkg which has defined constant and matches with string.

variables & optional (string "") (pkg \*package\*)

[function]

lists every symbol in pkg which has global value assigned and matches with string.

functions & optional (string "") (pkg \*package\*)

[function]

lists every symbol in pkg which has global function defined and matches with string.

btrace & optional (depth 10)

[function]

prints call history of depth levels.

step-hook form env

[function]

step form [function]

Step and trace work correctly only for functions, and not for macro or special forms.

trace & rest functions [function]

begins tracing of functions. Each time functions are called, their arguments and results are prited.

untrace &rest functions

[function]

stops tracing.

timing count &rest forms

[macro]

executes forms count times, and calculates time required for one execution of forms.

time function [macro]

begins measurement of time elapsed by function.

sys:list-all-catchers [function]

returns a list of all catch tags.

sys:list-all-instances aclass &optional scan-sub

[function]

scans in the overall heap, and collects all the instances of the specified class. If scan-sub is NIL, then instances of exactly the aclass are listed, otherwise, instances of aclass or its subclasses are collected.

sys:list-all-bindings [function]

scans bind stack, and returns a list of all the accessible value bindings.

sys:list-all-special-bindings

[function]

scans the stack and list up all value bindings.

# 10.6 Dump Objects

EusLisp's reader and printer are designed so that they can write any objects out to files in the forms that are rereadable. The objects may have mutual or recursive references. This feature is enabled when \*print-circle\* and \*print-object\* are set to T. Following functions set these variables to T, open a file, and print objects. The most important application of these functions is to dump the structures of 3D models that have mutual references.

dump-object file &rest objects

[function]

dump-structure file &rest objects

[function]

dumps objects to file in a format as they can be read back again.

# dump-loadable-structure file &rest symbols

[function]

dumps objects bound to symbols to file. The file can be read back again by simply loading it.

```
(setq a (make-cube 1 2 3))
;; sample for dump-object
(dump-object "a-cube.1" a)
(with-open-file
  (f "a-cube.l" :direction :input)
  (setq a (read f)))
(print a)
;; sample for dump-structure
(dump-structure "a-cube.1" a)
(with-open-file
  (f "a-cube.l" :direction :input)
  (setq a (read f)))
(print a)
;; sample for dump-loadable-structure
(dump-loadable-structure "a-cube.1" a)
(load "a-cube.1")
(print a)
```

### 10.7 Process Image Saving

This process image saving is no longer supported on Solaris2 based EusLisp, since it heavily depends on Solaris's dynamic loading facility which loads shared objects position-independently above the sbrk point.

```
sys:save path &optional (symbol-file "") starter
```

[function]

Save dumps the current EusLisp process environment to a file which can be invoked as a Unix command later. If a function name is specified for *starter*, the function is evaluated when the command begins execution. Each command line argument is coerced to string in EusLisp and they are passed to

starter as its arguments, so that it can parse the command line. Be sure that you have closed all the streams except \*standard-input\* and \*standard-output\*. File open states cannot be saved. Also, be sure you have not attempted mmap, which unnoticeably happens when you make internetwork socket-stream. Sun's network library always memory-maps NIS information such as host-by-name table and locates them at the uppermost available location of a process that cannot be saved. When the saved image is run later, any access to the network library fails and causes core dump. Note that Xwindow also uses this library, thus you cannot save your process image once you opened connection to Xserver.

# 10.8 Customization of Toplevel

When EusLisp is invoked from Unix, execution is initiated by the toplevel function bound to \*toplevel\*. This function is eustop in eus and xtop in eusx. You can change this toplevel function by specifying your own function to the third argument to save.

The toplevel function should be programmed to accept arbitrary number of arguments. Each argument on the command line is coerced to a string and transferred to the toplevel function. The program below repeatedly reads expressions from the file given by the first argument and pretty-prints them to the second argument file.

Once you defined these functions in EusLisp, (save "ppcopy" "" 'pprint-copy-top) creates a unix executable command named ppcopy.

In Solaris based EusLisp, the toplevel evaluator cannot change in this manner, since **save** is not available. Instead, edit lib/eusrt.l to define the custom toplevel evaluator and set it to \*toplevel\*. lib/eusrt.l defines initialization procedures evaluated at every invocation of the EusLisp.

### 10.9 Miscelaneous Functions

## lisp-implementation-type

[function]

returns "EusLisp".

## lisp-implementation-version

[function]

returns the name, the version and the make-date of this EusLisp. This string is also printed at the opening of a session. "MT-EusLisp 7.50 X 1.2 for Solaris Sat Jan 7 11:13:28 1995"

# 第II部

# **EusLisp Extension**

# 11 System Functions

# 11.1 Memory Management

The design of memory management scheme affects much to the flexibility and efficiency of object-oriented languages. EusLisp allocates memory to any sort of objects in a unified manner based on the *Fibonacci buddy method*. In this method, each of large memory pools called chunks is split into small cells which are unequally sized but aligned at Fibonacci numbers. A memory chunk is a homogeneous data container for any types of objects such as symbol, cons, string, float-vector, etc. as long as their sizes fit in the chunk. A chunk has no special attributes, like static, dynamic, relocatable, alternate, etc. EusLisp's heap memory is the collection of chunks, and the heap can extend dynamically by getting new chunks from UNIX. The expansion occurs either automatically on the fly or on user's explicit demand by calling system:alloc function. When it is managed automatically, free memory size is kept about 25% of total heap size. This ratio can be changed by setting a value between 0.1 and 0.9 to the sys:\*gc-margin\* parameter.

When all the heap memory is exhausted, mark-and-sweep type garbage collection runs. Cells accessible from the root (packages, classes and stacks) remain at the same place where they were. Other inaccessible cells are reclaimed and linked to the free-lists. No copying or compactification occurs during GC. When a garbage cell is reclaimed, its neighbor is examined whether it is also free, and they are merged together to form a larger cell if possible. This merging, however, is sometimes meaningless, since cons, which is the most frequently called memory allocator, requests the merged cell to be divided to the smallest cell. Therefore, EusLisp allows to leave a particular amount of heap unmerged to speed up cons. This ratio is determined by sys:\*gc-merge\* parameter, which is set to 0.3 by default. With the larger sys:\*gc-merge\*, the greater portion of heap is left unmerged. This improves the performance of consing, since buddy-cell splitting rarely occurs when conses are requested. This is also true for every allocation of relatively small cells, like three dimensional float-vectors.

**SYS:GC** invokes garbage collector explicitly, returning a list of two integers, numbers of free words and total words (not bytes) allocated in the heap. **SYS:\*GC-HOOK\*** is a variable to hold a function that is called upon the completion of a GC. The hook function should receive two arguments representing the sizes of the free heap and the total heap.

If "fatal error: stack overflow" is reported during execution, and you are convinced that the error is not caused by a infinite loop or recursion, you can expand the size of the Lisp stack by **sys:newstack**. **reset** should be performed before **sys:newstack**, since it discards everything in the current stack such as special bindings and clean-up forms of *unwind-protect*. After a new stack is allocated, execution starts over from the point of printing the opening message. The default stack size is 65Kword. The Lisp stack is different from the system stack. The former is allocated in the heap, while the latter is allocated in the stack segment by the operating system. If you get "segmentation fault" error, it might be caused by the shortage of the system stack. You can increase the system stack size by the limit csh command.

Sys:reclaim and sys:reclaim-tree function put cells occupied by objects back to the memory manager, so that they can be reused later without invoking garbage collection. You must be assured that there remains no reference to the cell.

memory-report and room function display statistics on memory usage sorted by cell sizes and classes

respectively.

address returns the byte address of the object and is useful as a hash function when used with hash-table, since this address is unique in the process.

**Peek** and **poke** are the functions to read/write data directly from/to a memory location. The type of access should be either of :char, :byte, :short, :long, :integer, :float and :double. For an instance, (SYS:PEEK (+ 2 (SYS:ADDRESS '(a b))) :short) returns class id of a cons cell, normally 1.

There are several functions prefixed with 'list-all-'. These functions returns the list of a system resource or environment, and are useful for dynamic debugging.

sys:gc [function]

starts garbage collection, and returns a list of the numbers of free words and total words allocated.

sys:\*gc-hook\* [variable]

Defines a function that is called upon the completion of a GC.

sys:gctime [function]

returns a list of three integers: the count of gc invoked, the time elapsed for marking cells (in 1/60 sec. unit), and the time elapsed for reclamation (unmarking and merging).

sys:alloc size [function]

allocates at least size words of memory in the heap, and returns the number of words really allocated.

sys:newstack size [function]

relinquishes the current stack, and allocates a new stack of size words.

sys:\*gc-merge\* [variable]

is a memory management parameter. \*gc-merge\* is the ratio the ratio of heap memory which is left unmerged at GC. This unmerged area will soon filled with smallest cells whose size is the same as a cons. The default value is 0.3. The larger values, like 0.4, which specifies 40% of free heap should be unmerged, favors for consing but do harm to instantiating bigger cells like float-vectors, edges, faces, etc.

sys:\*gc-margin\* [variable]

is a memory management parameter. \*gc-margin determines the ratio of free heap size versus the total heap. Memory is acquired from UNIX so that the free space does not go below this ratio. The default value 0.25 means that 25% of free space is maintained at every GC.

sys:reclaim object [function]

relinquishes *object* as a garbage. It must be guaranteed that it is no longer referenced from any other objects.

sys:reclaim-tree object [function]

reclaims all the objects except symbols traversable from object.

sys::bktrace num [function]

prints the back-trace information of *num* depth on the Lisp stack.

sys:memory-report & optional strm [function]

prints a table of memory usage report sorted by cell sizes to the *strm* stream.

sys:room output-stream [function]

outputs memory allocation information ordered by classes.

sys:address object [function]

returns the address of *object* in the process memory space.

### sys:peek [vector] address type

[function]

reads data at the memory location specified by *address* and returns it as an integer. *type* is one of **:char, :byte, :short, :long, :integer, :float**, and **:double**. If no *vector* is given, the address is taken in the unix's process space. For example, since the a.out header is located at #x2000 on SunOS4, (sys:peek #x2000 :short) returns the magic number (usually #o403). Solaris2 locates the ELF header at #10000, and (sys:peek #x10000 :long) returns #xff454c46 whose string representation is "ELF".

If *vector*, which can be a foreign-string, is specified, address is recognized as an offset from the vector's origin. (sys:peek "123456" 2 :short) returns short word representation of "34", namely #x3334 (13108).

Be careful about the address alignment: reading short, integer, long, float, double word at odd address may cause bus error by most CPU architectures.

# sys:poke value [vector] address value-type

[function]

writes *value* at the location specified by *address*. Special care should be taken since you can write to anywhere in the process memory space. Writing to outside the process space surely causes segmentation fault. Writing short, integer, long, float, double word at odd address causes bus error.

sys:list-all-chunks [function]

list up all allocated heap chunks. Not useful for other than the implementor.

sys:object-size obj

counts the number of cells and words accessible from *obj*. All the objects reference-able from obj are traversed, and a list of three numbers is returned: the number of cells, the number of words logically allocated to these objects (i.e. accessible from users), and the number of words physically allocated including headers and extra slots for memory management. Traversing stops at symbols, i.e. objects referenced from a symbol such as property-list or print-name string are not counted.

# 11.2 Unix System Calls

EusLisp assorts functions which directly correspond to the system calls and library functions of UNIX operating system. For further detail of these functions, consult UNIX system interface reference (2). These low-level functions defined in \*unix-package\* are sometimes dangerous. Use higher level functions defined in other packages if possible. For example, use IPC facilities described in the section 9.4 instead of unix:socket, unix:bind, unix:connect, and so on.

### 11.2.1 Times

unix:ptimes [function]

a list of five elements, elapsed time, system time, user time, subprocess's system time, subprocess's user time, is returned. Unit is always one sixtieth second. This function is obsolete and use of unix:getrusage is recommended.

unix:runtime [function]

Sum of the process's system and user time is returned. Unit is 1/60 second.

unix:localtime [function]

Current time and date is returned in an integer vector. Elements are second, minute, hour, day-of-amonth, month (zero-based), year (the number of years since 1900), weekday (the number of days since Sunday, in the range 0 to 6), day-in-the-year (the number of days since January 1, in the range 0 to 365), daylight-saving-time-is-set (a flag that indicates whether daylight saving time is in effect at the time described) and supported-time-zone.

ex.) unix:localtime => #(10 27 12 8 10 116 2 312 nil (''JST'' ''JST''))

### unix:asctime tm\_intvector

[function]

Converts localtime represented with an integer-vector into a string notation.

(unix:asctime (unix:localtime)) returns a string representation of the current real time.

# 11.2.2 Process

unix:getpid [function]

returns the process id (16bit integer) of this process.

unix:getppid [function]

returns the process id of the parent process.

unix:getpgrp [function]

returns the process group id.

unix:setpgrp [function]

sets a new process group id.

unix:getuid [function]

gets user id of this process.

unix:geteuid [function]

returns the effective user id of this process.

unix:getgid [function]

returns the group id of this process.

unix:getegid [function]

returns the effective group id of this process.

unix:setuid integer [function]

sets effective user id of this process.

unix:setgid integer [function]

sets the effective group id of this process.

unix:fork [function]

creates another EusLisp. 0 is returned to the subprocess and the pid of the forked process is returned to the parent process. Use **system:piped-fork** described in section 11.3 to make a process connected via pipes.

unix:vfork [function]

forks another EusLisp, and suspends the parent process from execution until the new EusLisp process terminates.

unix:exec path [function]

replaces executing EusLisp with another program.

unix:wait [function]

waits for the completion of one of subprocesses.

unix::exit code [function]

terminates execution and returns code as its completion status. Zero means normal termination.

sys:\*exit-hook\* [variable]

Defines a function that is called just before the process is exited.

unix:getpriority which who

returns the highest priority (nice value) enjoyed by this process. Which is one of 0(process), 1(process-group) or 2(user).

unix:setpriority which who priority

[function]

[function]

sets priority of the resource determined by which and who. which is one of 0(process), 1(process-group) or 2(user). who is interpreted relative to which (a process identifier for which = 0, process group identifier for which = 1, and a user ID for which = 2. A zero value of who denotes the current process, process group, or user. To lower the priority (nice value) of your EusLisp process, (unix:setpriority 0 0 10) will sets the nice value to 10. Bigger nice value makes your process get less favored.

unix:getrusage who [function]

returns list of system resource usage information about *who* process. Elements are ordered as follows: More comprehensive display is obtained by **lisp:rusage**.

```
float ru_utime (sec.) /* user time used */
float ru_stime (sec.) /* system time used */
```

```
/* maximum resident set size */
int ru_maxrss;
int ru_ixrss;
                    /* currently 0 */
int ru_idrss;
                    /* integral resident set size */
int ru_isrss;
                    /* currently 0 */
int ru_minflt;
                    /* page faults without physical I/O */
int ru_majflt;
                    /* page faults with physical I/O */
int ru_nswap;
                    /* number of swaps */
int ru_inblock;
                    /* block input operations */
int ru_oublock;
                    /* block output operations */
int ru_msgsnd;
                     /* messages sent */
                    /* messages received */
int ru_msgrcv;
int ru_nsignals;
                    /* signals received */
                     /* voluntary context switches */
int ru_nvcsw;
                     /* involuntary context switches */
int ru_nivcsw;
```

## unix:system &optional command

[function]

executes command in a sub shell. command must be recognizable by Bourn-shell.

### unix:getenv env-var

[function]

gets the value for the environment variable env-var.

## unix:putenv env

[function]

adds *env* in the process's environment variable list. *env* is a string which equates var to value like "VARIABLE=value".

### unix:sleep time

[function]

suspends execution of this process for time seconds.

### unix:usleep time

[function]

suspends execution of this process for *time* micro-seconds (**u** represents micro). **Usleep** is not available on Solaris2 or other Sys5 based systems.

### 11.2.3 File Systems and I/O

### unix:uread stream Coptional buffer size

[function]

reads *size* bytes from *stream*. *stream* may either be a stream object or an integer representing fd. If *buffer* is given, the input is stored there. Otherwise, input goes to the buffer-string in *stream*. Therefore, if *stream* is fd, *buffer* must be given. **unix:uread** never allocates a new string buffer. **unix:uread** returns the byte count actually read.

## unix:write stream string &optional size

[function]

writes size bytes of string to stream. If size is omitted, the full length of string is output.

unix:fcntl stream command argument

[function]

unix:ioctl stream command buffer

[function]

unix:ioctl\_stream command1 command2

[function]

unix:ioctl\_R stream command1 command2 buffer &optional size

[function]

unix:ioctl\_W stream command1 command2 buffer &optional size [function] unix:ioctl\_WR stream command1 command2 buffer &optional size [function] unix:uclose fd[function] close a file specifying its file descriptor fd. unix:dup fd [function] returns the duplicated file descriptor for fd. [function] unix:pipe creates a pipe. An io-stream for this pipe is returned. unix:lseek stream position Coptional (whence 0) [function] sets the file pointer for stream at position counted from whence. unix:link path1 path2 [function] makes a hard link. unix:unlink path [function] removes a hard link to the file specified by path. If no reference to the file lefts, it is deleted. unix:mknod path mode [function] makes inode in a file system. path must be a string, not a pathname object. [function] unix:mkdir path mode makes directory in a file system. path must be a string, not a pathname object. [function] unix:access path mode checks the access rights to path. [function] unix:stat path gets inode information of path and returns a list of integers described below. st\_ctime ; file last status change time st\_mtime ; file last modify time st\_atime ; file last access time st\_size; total size of file, in bytes st\_gid; group ID of owne st\_uid ; user ID of owner st\_nlink; number of hard links to the file st\_rdev ; the device identifier (special files only) st\_dev ; device file resides on st\_ino; the file serial number st\_mode ; file mode [function] unix:chdir path

[function]

[function]

changes the current working directory to path.

gets current working directory.

unix:getwd

unix:chmod path integer

changes access mode (permission) for path.

## unix:chown path integer

[function]

changes the owner of the file path.

### unix:isatty stream-or-fd

[function]

returns T if stream-or-fd is connected to a tty-type device (a serial port or a pseudo tty).

## unix:msgget key mode

[function]

creates or allocates a message queue which is addressed by key.

unix:msgsnd qid buf &optional msize mtype flag

[function]

unix:msgrcv qid buf &optional mtype flag

[function]

### unix:socket domain type &optional proto

[function]

creates a socket whose name is defined in *domain* and whose abstract type is *type*. *type* should be one of 1 (SOCK\_STREAM), 2 (SOCK\_DGRAM), 3 (SOCK\_RAW), 4 (SOCK\_RDM) and 5 (SOCK\_SEQPACKET).

### unix:bind socket name

[function]

associates name to socket. name should be a unix path-name if the socket is defined in unix-domain.

### unix:connect socket addr

[function]

connects socket to another socket specified by addr.

# unix:listen socket &optional backlog

[function]

begins to accept connection request on *socket*. *backlog* specifies the length of the queue waiting for the establishment of connection.

### unix:accept socket

[function]

accepts the connection request on *socket* and returns a file-descriptor on which messages can be exchanged bidirectionally.

### unix:recvfrom socket Coptional mesg from flag

[function]

receives a datagram message from *socket*. The socket must be assigned a name by **unix:bind**. *mesg* is a string in which the incoming message will be stored. If *mesg* is given, **recvfrom** returns the number of bytes received. If it is omitted, a new string is created for the storage of the message and returned.

### unix:sendto socket addr mesg &optional len flag

[function]

sends a datagram message to another socket specified by *addr. Socket* must be a datagram-type socket which has no name assigned. *Mesg* is a string to be sent and *len* is the length of the message counting from the beginning of the string. If omitted, whole string is sent.

# ${\bf unix:getservbyname}\ service name$

[function]

returns the service number (integer) for servicename registered in /etc/services or in NIS database.

### unix:gethostbyname hostname

[function]

returns the list of ip address of hostname and its address type (currently always AF\_INET==2).

### unix:syserrlist errno

[function]

returns a string describing the error information for the error code errno.

### 11.2.4 Signals

## unix:signal signal func &optional option

[function]

installs the signal handler func for signal. In BSD4.2 systems, signals caught during system call processing cause the system call to be retried. This means that if the process is issuing a read system call, signals are ignored. If option=2 is specified, signals are handled in the system-5 manner, which causes the system call to fail.

# unix:kill pid signal

[function]

sends a signal to a process named by pid.

unix:pause [function]

suspends execution of this process until a signal arrives.

unix:alarm time [function]

sends an alarm clock signal (SIGALRM 14) after *time* seconds. Calling **unix:alarm** with *time*=0 resets the alarm clock.

unix:ualarm time [function]

same as **unix:alarm** except that the unit of *time* is micro seconds. **ualarm** is not available on Solaris2 or on other Sys5 based systems.

## unix:getitimer timer

[function]

One Unix process is attached with three interval timers, i.e., a real-time timer that decrements as the real time passes, a virtual-timer that decrements as the process executes in the user space, and a prof-timer that decrements as the kernel executes on behalf of the user process. *timer* is either 0 (ITIMER\_REAL), 1 (ITIMER\_VIRTUAL), or 2(ITIMER\_PROF). A list of two elements is returned, the value of the timer in second and the interval. Both are floating-point numbers.

# unix:setitimer timer value interval

[function]

sets value and interval in timer. timer is eiterh 0 (ITIMER\_REAL), 1 (ITIMER\_VIRTUAL), or 2(ITIMER\_PROF). ITIMER\_REAL delivers SIGALRM when value expires. ITIMER\_VIRTUAL delivers SIGVTALRM, and ITIMER\_PROF delivers SIGPROF.

# unix:select inlist outlist exceptlist timeout

[function]

inlist, outlist and exceptlist are bitvectors indicating file descriptors whose I/O events should be tested. For example, if inlist=#b0110, outlist=#b100, and exceptlist=NIL, then whether it is possible to read on fd=1 or 2, or to write on fd=2 is tested. Timeout specifies seconds for which select is allowed to wait. Immediately after incoming data appear on one of the ports specified in inlist, or writing become available on one of the ports specified in outlist, or exceptional condition arises in one of the ports specified in exceptlist, select returns the number of ports that are available for I/O operation, setting ones for the possible port s in each of inlist, outlist and exceptlist.

# $\mathbf{unix} : \mathbf{select\text{-}read\text{-}} \mathit{fd} \ \mathit{read\text{-}} \mathit{fdset} \ \mathit{timeout}$

[function]

I/O selection is usually meaningful only for input operation. **unix:select-read-fd** is a short-hand for **select fdset nil nil timeout**. *Read-fdset* is not a bit-vector, but an integer that specifies the reading fd set.

### 11.2.5 Multithread

There is no way to create bound threads. Therefore only one signal stack and one interval timer are available in a EusLisp process. On Solaris2, the main top-level runs in a separated thread.

unix:thr-self [function]

returns the id (integer) of the thread currently running.

unix:thr-getprio id [function]

returns the execution priority of the thread specified by id.

## unix:thr-setprio id newprio

[function]

sets the execution priority of the thread specified by *id* to *newprio*. The smaller numerical value of *newprio* means the higher priority. In other words, a thread with a numerically greater *newprio* gets less access to CPU. Users cannot raise the execution priority higher than the process's nice value, which is usually 0.

## unix:thr-getconcurrency

[function]

returns the concurrency value (integer) which represents the number of threads that can run concurrently.

## unix:thr-setconcurrency concurrency

[function]

The concurrency value is the number of LWP in the process. If the concurrency is 1, which is the default, many threads you created are assigned to one LWP in turn even though all of them are runnable. If the program is running on a multi-processor machine and you want to utilize more than one CPU at the same time, you should set a value bigger than one to *concurrency*. Note that a big concurrency value let the operating system consume more resource. Usually *concurrency* should be smaller than or equal to the number of processors.

## unix:thr-create func arg-list & optional (size 64\*1024)

[function]

creates a new thread with *size* words of Lisp stack and *size* bytes of C stack, and let it apply *func* to *arg-list*. The thread cannot return any results to the caller. Use of this function is discouraged.

### 11.2.6 Low-Level Memory Management

unix:malloc integer

[function]

allocates memory outside EusLisp memory space.

unix:free integer

[function]

deallocates a memory block allocated by unix:malloc.

unix:valloc integer

[function]

unix:mmap address length protection share stream offset

[function]

unix:munmap address length

[function]

unix:vadvise integer [function]

### 11.2.7 IOCTL

Although Unix controls terminal device by a set of commands (second argument) to ioctl, EusLisp provides them in the forms of function to eliminate to reference the include files and or'ing argument with the command codes. For the detail, refer to the *termio* manual pages of Unix.

There are two sets of terminal io-controls: TIOC\* and TC\*. Be careful about the availability of these functions on your operating system. Basically, BSD supports TIOC\* io-controls and Sys5 supports TC\*.

SunOS 4.1 Both TIOC\* and TC\*

Solaris2 only TC\*

mips, ultrix? only TIOC\*

unix:tiocgetp stream & optional syttybuf [function] gets parameters.

unix:tiocsetp stream sgttybuf [function] sets parameters.

unix:tiocsetn stream Coptional sqttybuf [function]

unix:tiocgetd stream &optional sgttybuf [function]

unix:tiocflush stream [function]

flushes output buffer.

unix:tiocgpgrp stream integer [function]

gets process group id.

unix:tiocspgrp stream integer [function]

sets process group id.

unix:tiocoutq stream integer [function]

unix:fionread stream integer [function]

unix:tiocsetc stream buf [function]

unix:tioclbis stream buf [function]

unix:tioclbic stream buf [function]

unix:tioclset stream buf [function] unix:tioclget stream buf [function] unix:tcseta stream buffer [function] sets terminal parameters immediately. unix:tcsets stream buffer [function] sets terminal parameters. [function] unix:tcsetsw stream buffer sets terminal parameters after all characters queued for output have been transmitted. [function] unix:tcsetsf stream buffer sets terminal parameters after all characters queued for output have been transmitted and all characters queued for input are discarded. unix:tiocsetc stream buffer [function] unix:tcsetaf stream buffer [function] [function] unix:tcsetaw stream buffer unix:tcgeta stream buffer [function] unix:tcgets stream buffer [function] [function] unix:tcgetattr stream buffer [function] unix:tcsetattr stream buffer

## 11.2.8 Keyed Indexed Files

Recent Unix provides with the *dbm* or *ndbm* library for the management of keyed index files. Making use of this library, you can build a data base that is composed of many pairs of key and datum association. Following functions are defined in clib/ndbm.c. On Sun, it should be compiled by cc -c -Dsun4 -Bstatic, and loaded into EusLisp by (load "clib/ndbm" :ld-option "-lc").

### dbm-open dbname mode flag

[function]

**Dbm-open** must be called first to create a data base file, and to begin read/write operations to the data base. *Dbname* is the name of the data base. Actually, ndbm manager creates two files which have

suffixes ".pag" and ".dir". *Mode* specifies file-open mode; 0 for read-only access, 1 for write-only, and 2 for read-write; also #x200 should be *ored* when you create the file at the first time. *Flag* gives access permission that is changed by chmod. #o666 or #o664 is good for *flag*. **Dbm-open** returns an integer that identifies the data base in the process. This value is used by other dbm functions to identify the data base. In other words, you can open several data bases at the same time.

### dbm-store db key datum mode

[function]

stores key-datum association in db. Db is an integer to identify the data base. Key and datum are strings. Mode is 0 (insert) or 1 (replace).

**dbm-fetch** db key [function]

retrieves datum that is associated with key in db.

## 11.3 Unix Processes

In order to launch unix commands from EusLisp, use the **unix:system** function. **Piped-fork** creates a subprocess whose standard input and standard output are connected to EusLisp's bidirectional stream through pipes. **Piped-fork** returns the stream. Following is a function to count the number of lines contained in a file by using "wc".

```
(defun count-lines (file) (read (piped-fork "wc" file)))
```

The next example creates eus process on another workstation identified by "etlic0" and provides a port for distributed computation.

```
(setq ic0eus (piped-fork "rsh" "etlic0" "eus"))
(format ic0eus "(list 1 2 3)~%")
(read ic0eus) --> (1 2 3)
```

For source code editing, you can call **ez** from the EusLisp. The screen editor ez communicates with EusLisp through message-queues. If you have an ez process already running in parallel with the EusLisp, **ez** restarts ez and it gains the terminal control. By issuing esc-P or esc-M commands in ez, texts are sent back and evaluated by EusLisp. This is useful for the debugging since entire file does not need to be loaded when you add a little modification to the file. Similar function is available on emacs by M-X run-lisp command.

```
cd & optional (dir (unix:getenv "HOME"))
changes the current working directory.
```

ez Eoptional key [function]

[function]

[function]

enters display editor ez, and reads Lisp forms from it, and evaluates them.

```
piped-fork & optional (exec) & rest args
```

forks a process, and makes a two-way stream between the current EusLisp and the subprocess. Exec is the file name of a unix command and args are arguments to the command. If exec (string) includes one or more space, it is assumed a shell command, and executed by /bin/sh calling the unix:system function. If no exec is given, another euslisp is created as the subprocess.

```
xfork exec &key (stdin *standard-input*) (stdout *standard-output*)
(stderr *error-output*) (args nil)

[function]
```

forks a process, replaces its stdin, stdout, and stderr streams to specified ones, and exec's "exec" with the args arguments. piped-fork is roughly equivalent to (xfork exec :stdin (unix:pipe) :stdout (unix:pipe)) Though xfork returns an io-stream to stdin and stdout with their directions reversed, it is not always useful unless they are pipes. The name of this function, xfork (cross-fork), comes from this reversed io-stream, namely, the io-stream's input comes from the stdout of the subprocess and the output comes from the stdin.

```
rusage [function]
```

prints resource usage of this process.

# 11.4 Adding Lisp Functions Coded in C

Programs that heavily refer to C include files or frequently access arrays perform better or are more clearly described if written in C or other languages rather than in EusLisp. EusLisp provides the way to link programs coded in C.

If you want to define EusLisp function written in C, each EusLisp-callable C-function must be coded to accept three arguments: the context pointer, the number of arguments and the pointer to the Lisp argument block. These arguments must be named as ctx, n and argv, since the macros in c/eus.h assume these names. The C program must include \*eusdir\*/c/eus.h. The programmer should be familiar with the types and macros described there. The entry function should be named by the basename of the source file.

A sample code for C function AVERAGE which computes the arithmetic average of arbitrary number of floats is shown below. In this example, you can see how to get float values from arguments, how to make the pointer of a float, how to set a pointer in the special variable AVERAGE, and how to define a function and a symbol in the entry function ave. Compile this program by 'cc -c -Dsun4 -DSolaris2 -K pic'. -Dsun4 and -DSolaris2 are needed to chose proper definitions in c/eus.h. -K pic is needed to let the c compiler generate position independent code necessary for the loadable shared object. Then the resulted '.o' file can be loaded into EusLisp. More complete examples can be found in \*eusdir\*/clib/\*.c, which are defined and loaded in the same manner described here.

```
/* ave.c */
/* (average &rest numbers) */
#include "/usr/local/eus/c/eus.h"
static pointer AVESYM;
pointer AVERAGE(ctx,n,argv)
context *ctx;
int n;
pointer argv[];
{ register int i;
  float sum=0.0, a, av;
 pointer result;
 numunion nu;
 for (i=0; i<n; i++) {
    a=ckfltval(argv[i]);
    sum += a;} /*get floating value from args*/
  av=sum/n;
 result=makeflt(av);
  AVESYM->c.sym.speval=result; /*kindly set the result in symbol*/
  return(result);}
ave(ctx,n,argv)
context *ctx;
int n;
pointer argv[];
{ char *p;
 p="AVERAGE";
  defun(ctx,p,argv[0],AVERAGE);
  AVESYM=intern(ctx,p,strlen(p),userpkg); /* make a new symbol*/
```

}

# 11.5 Foreign Language Interface

Functions written in C without concern about linking with EusLisp can be loaded onto EusLisp, too. These functions are called foreign functions. Such programs are loaded by load-foreign macro which returns an instance of foreign-module. External symbol definitions in the object file is registered in the module object. **Defforeign** is used to make entries to C functions to be called from EusLisp. **Defun-c-callable** defines lisp functions callable from C. C-callable functions have special code piece called *pod-code* for converting parameters and transferring control to the corresponding EusLisp function. **Pod-address** returns the address of this code piece which should be informed to C functions.

Here is an example of C program and its interface functions to EusLisp.

```
/* C program named cfunc.c*/
static int (*g)(); /* variable to store Lisp function entry */
double sync(x)
double x;
{ extern double sin();
 return(sin(x)/x);
char *upperstring(s)
char *s;
{ char *ss=s;
  while (*s) { if (islower(*s)) *s=toupper(*s); s++;}
 return(ss);}
int setlfunc(f)
                    /* remember the argument in g just to see */
int (*f)();
                     /* how Lisp function can be called from C */
{ g=f;}
int callfunc(x)
                     /* apply the Lisp function saved in g to the arg.*/
int x;
{ return((*g)(x));}
;;;; Example program for EusLisp's foreign language interface
;;;; make foreign-module
(setq m (load-foreign "cfunc.o"))
;; define foreign functions so that they can be callable from lisp
(defforeign sync m "sync" (:float) :float)
(defforeign toupper m "upperstring" (:string) :string)
(defforeign setlfunc m "setlfunc" (:integer) :integer)
(defforeign callfunc m "callfunc" (:integer) :integer)
```

Data representations in EusLisp are converted to those of C in the following manners: EusLisp's 30-bits integer (including character) is sign-extended and passed to a C function via stack. 30-bit float is extended to double and passed via stack. As for string, integer-vector and float-vector, only the address of the first element is passed on the stack, and the entire array remains uncopied. The string can either be a normal string or a foreign-string. A string may contain null codes, though it is guaranteed that the string also has a null code at the end. EusLisp does not know how to pass arrays of more than one dimension. Every array of more than one dimension has correspoiding one dimensional vector that holds the entire elements linearly. This vector is obtained by the **array-entity** macro. Also, note that a two-dimensional matrix should be transposed if it is sent to the FORTRAN subroutines, since rows and columns are ordered oppositely in FORTRAN.

Since EusLisp's representation of floating-point numbers is always single precision, conversion is required when you pass a vector of double precision floating point numbers. For this purpose, the conversion functions, double2float and float2double are provided by clib/double.c. For an instance, if you have a 3x3 float-matrix and want to pass it to a C function named cfun as a matrix of double, use the following forms.

```
(setq mat (make-matrix 3 3))
(cfun (float2double (array-entity mat)))
```

Struct in C can be defined by the **defcstruct** macro. **Defcstruct** accepts struct-name followed by field definition forms.

```
(defcstruct <struct-name>
     {(<field> <type> [*] [size])}*)
```

For example, following struct definition is represented by the next defestruct.

```
/* C definition */
struct example {
   char a[2];
   short b;
   long *c;
   float *d[2];};

/* equivalent EusLisp definition */
(defcstruct example
   (a :char 2)
```

```
(b :short)
(c :long *)
(d :float * 2))
```

load-foreign objfile &key symbol-input symbol-output (symbol-file objfile) ld-option) [macro]

loads an object module written in languages other than EusLisp. In Solaris2, load-foreign just calls load with a null string as its :entry parameter. A compiled-code object is returned. This result is necessary to make entries to the functions in the module by defforeign called later on. Libraries can be specified in ld-option. However, the symbols defined in the libraries cannot be captured in the default symbol-output file. In order to allow EusLisp to call functions defined in the libraries, symbol-output and symbol-file must be given explicitly. (These arguments are not needed if you are not going to call the library functions directly from EusLisp, i.e. if you are referring them only from functions in objfile). Load-foreign links objfile with libraries specified and global symbols in EusLisp which is in core, and writes the linked object in symbol-output. Then, symbols in symbol-file are searched and listed in the foreign-module. Since symbol-file is defaulted to be objfile, only the symbols defined in objfile are recognized if symbol-file is not given. To find all the global entries both in objfile and libraries, the linked (merged) symbol table resulted from the first link process of load-foreign must be examined. For this reason, an identical file name must be given both to symbol-output and to symbol-file.

As shown below, the intermediate symbol file can be removed by unix:unlink. However, if you are loading more than one foreign modules both of which refer to the same library, and if you want to avoid loading the library duplicatedly, you have to use *symbol-input* argument. Suppose you have loaded all the functions in "linpack.a" in the above example and you are going to load another file "linapp.o" that calls functions in "linpack.a". The following call of load-foreign should be issued before you unlink "euslinpack". (load-foreign "linapp.o" :symbol-input "euslinpack") See \*eusdir\*/llib/linpack.1 for more complete examples of load-foreign and defforeign.

defforeign functione module chame paramspec resulttype

[macro

makes a function entry in a foreign language module. funcname is a symbol to be created in EusLisp. module is a compiled-code object returned by load-foreign. cname is the name of the C-function defined in the foreign program. It is a string like "\_myfunc". paramspec is a list of parameter type specifications which is used for the data type conversion and coercion when arguments are passed from EusLisp to the C function. Paramspec can be NIL if no data conversion or type check is required. One of :integer, :float, :string, or (:string n) must be given to resulttype. :Integer means that the c function returns either char, short or int (long). :Float should be specified both for float and double. :String means the C function returns a pointer to a string, and EusLisp should add a long-word header to the string to accommodate it as a EusLisp string. The length of the string is found by strlen. Note that the writing a header just before the string may cause a disastrous result. On the other hand, (:string n) is safer but slower because a EusLisp string of length n is newly created and the contents of C string is copied there. (:string 4) should be used for a C function that returns a pointer to an

11. VxWorks 102

integer. The resulted integer value of the result can be obtained by (sys:peek result :long), where result is a variable set to the result of the C function. You may also specify (:foreign-string [n]) for C functions that return a string or a struct. The result is a foreign-string whose content is held somewhere outside EusLisp control. If the result string is null-terminated and the length of the string is known by strlen, you don't need to specify the length [n]. However, if the result contains null codes, which is usual for structs, the length of the foreign-string should be explicitly given. Whether you should use (:string n) or (:foreign-string n) is not only the matter of speed, but the matter of structure sharing. The difference is whether the result is copied or not.

Fortran users should note that every argument to a Fortran function or a subroutine is passed by callby-reference. Therefore, even a simple integer or float type argument must be put in a integer-vector or a float-vector before it is passed to Fortran.

#### **defun-c-callable** function paramspec resulttype & rest body

[macro]

defines a EusLisp function that can be called from foreign language code. funcname is a symbol for which a EusLisp function is defined. paramspec is a list of type specifiers as in **defforeign**. Unlike **defforeign**'s paramspec, **defun-c-callable**'s paramspec cannot be omitted unless the function does not receive any argument. :integer should be used for all of int, short and char types and :float for both of float and double. resulttype is the type of the Lisp function. resulttype can be omitted unless you need type check or type coercion from integer to float. body is lisp expressions that are executed when this function is called from C. The function defined by **defun-c-callable** can be called from Lisp expressions, too. **Defun-c-callable** returns funcname. It looks like a symbol, but it is not, but an instance of **foreign-pod** which is a subclass of symbol.

#### pod-address functione

[function]

returns the address of a foreign-to-EusLisp interface code of the c-callable Lisp function *function* defined by **defun-c-callable**. This is used to inform a foreign language program of the location of a Lisp function.

#### array-entity array-of-more-than-one-dimension

[macro]

returns one-dimensional vector which holds all the elements of a multi-dimensional array. This is needed to pass a multi-dimensional or general array to a foreign function, although a simple vector can be passed directly.

## float2double float-vector & optional doublevector

[function]

converts *float-vector* to double precision representation. The result is of type float-vector but the length is twice as much as the first argument.

## ${\bf double 2 float} \ \textit{double vector} \ \mathcal{C}optional \ \textit{float-vector}$

[function]

A vector of double precision numbers is converted to single precision float-vector.

#### 11.6 VxWorks

ホストと VxWorks との通信機能が"vxworks/vxweus.l"ファイルで提供されている。VxWorks 上に vxwserv サーバを常駐させることにより、ホスト上の EusLisp から vxwserv にコネクションを張り、vxws プロトコルに従ったコマンドを送ることにより、VxWorks の関数を起動し、引数を送り、結果を受け取ることができる。

VxWorks のソフトは Sun の c コンパイラによって開発することができる上、データ表現が sun3, sun4, VME147 の間で共通であることを利用して、vxws プロトコルは、バイナリモードで動作することができる。

11. VxWorks 103

#### 11.6.1 VxWorks 側の起動

VxWorks にログインし、"\*eusdir\*/vxworks/vxwserv.o"をロードする。その後、vxwserv タスクを spawn する。vxwserv は VxWorks 上の 2200 番ポートを listen する。2200 が塞がっている場合、2201, 2202, ... を 試す。正しく bind されたポート番号が表示される。

```
% rlogin asvx0 (あるいはetlic2上であれば、% tip asvx[01] も可能)
-> cd "atom:/usr/share/src/eus/vxworks"
-> ld <vxwserv.o
-> sp vxwserv
port 2200 is bound.
```

VxWorks の i コマンドで、vxwserv タスクが常駐したことを確かめる。同じ要領で、eus から呼び出したい VxWorks のプログラムを VxWorks 上にロードする。その後、Euslisp と VxWorks とのコネクションが張られると、vxwserv を走らせた TTY に、次のようなメッセージが出力される。

```
CLIENT accepted: sock=9 port = 1129: family = 2: addr = c01fcc10: VxWserv started with 16394 byte buffer
```

## 11.6.2 ホスト側の起動

任意のマシンの上で eus を起動し、"vxworks/vxweus"をロードする。connect-vxw 関数を用いて vxwserv に接続する。接続後、ソケットストリームが\*vxw-stream\*にバインドされる。以下に、コネクトの例を示す。この例では、VxWorks 上の sin, vadd 関数を euslisp の関数 VSIN,VAD として定義している。

```
(load "vxworks/vxweus")
(setq s (connect-vxw :host "asvx0" :port 2200 :buffer-size 1024))
(defvxw VSIN "_sin" (theta) :float)
(defvxw VAD "_vadd" (v1 v2) (float-vector 3))
```

VxWorks 上に作成される関数が、vxws を通じて呼び出されるためには、次の条件を満たさなければならない。

- 1. 引数は、32 個以内であること、引数に受け取るベクタの容量の合計が connect-vxw の:buffer-size で指定した値を越えないこと
- 2. struct を引数にしないこと、必ず struct へのポインタを引数にすること
- 3. 結果は、int, float, double または、それらの配列のアドレスであること
- 4. 配列のアドレスを結果とする場合、その配列の実体は、関数の外部に取られていること

connect-vxw [関数]

&key (host "asvx0") (port 2200) (buffer-size 16384) (priority 1280) (option #x1c) 11. VxWorks 104

:host に対して vxws プロトコルによる通信のためのソケットストリームを作成し、そのストリームを返す。:host には、ネットワークにおける VxWorks のアクセス番号あるいはアクセス名を指定する。:port には、VxWorks 上の vxwserv がバインドしたポートを捜すための最初のポート番号を指定する。このポート番号から、増加方向に接続を試行する。:option のコードについては、VxWorks の、spawn 関数を参照のこと。コネクションは、同時に複数張ってよい。

## vxw vxw-stream entry result-type args

[function]

vxw は、vxw-stream に接続されている VxWorks の関数 entry を呼び出し、その関数に引き数 args を与えて result-type で指定された結果を得る。vxw-stream には、connect-vxw で作成したソケットストリームを与える。entry には、VxWorks の関数名をストリングで指定するか、あるいは関数のアドレスを整数で指定する。関数のアドレスを知るには、VxWorks の findsymbol を呼び出す。知りたいシンボルは、通常、"\_"で始まることに注意。entry がストリングの場合、VxWorks 上でシンボルテーブルの逐次探索が行われる。result-type には、結果のデータ型 (:integer または:float)、あるいはデータを受け取るベクタ型を指定する。ベクタは、float-vector、integer-vector、string のインスタンスである。general vector(lisp の任意のオブジェクトを要素とするベクタ) は指定できない。結果型は、必ず、実際の VxWorks 関数の結果型と一致しなければならない。args には、entry に与える引き数を指定する。引数に許される EusLisp データは、integer、float、string、integer-vector、float-vector、integer-matrix、float-matrix である。ポインタを含んだ一般のオブジェクト、一般のベクトルは送れない。また、送られたベクトルデータは、一旦 vxwserv が獲得したバッファの中に蓄積される。例えば、VxWorks に定義された関数"sin"を呼び出すためには、次のように実行すればよい。(vxw \*vxw-stream\* "sin":float 1.0)

## **defvxw** eus-func-name entry args & optional (result-type :integer)

[macro]

defvxw は、findsymbol を用いて vxw を呼び出して、VxWorks の関数の高速な呼び出しを実現するためのマクロである。VxWorks の関数 entry を呼び出すための Euslisp の関数 eus-func-name を定義する。このマクロを実行後は、eus-func-name を呼び出すことにより、VxWorks の関数を呼び出すことができる。このとき、呼び出しに使用されるソケットストリームは\*vxw-stream\*に固定されている。ただし、VxWorks 側で、関数をコンパイルし直して再ロードした場合、新しい関数定義が呼ばれるようにするためには、eus 側で、defvxw をもう一度実行し直して、最新のエントリアドレスが指定されるようにする必要がある。

## 12 Multithread

The multithread is the concurrent and asynchronous programming facility on the Solaris operating system. Asynchronous programming is required for programs to respond to external events via multiple sensors occurring independently of the program's state. Parallel programming is effective to improve performance of computation bound processing such as image processing and interference checking in path planning.

## 12.1 Design of Multithread EusLisp

#### 12.1.1 Multithread in Solaris 2 operating system

Multithread EusLisp (MT-Eus) runs on the Solaris 2 operating system with one or more processors. Solaris's threads are units for allocating CPU in a traditional UNIX process, having shared memory and different contexts. The thread library provided by the Solaris OS allocates each thread to a single LWP (light weight process), which is a kernel resource. The Unix kernel schedules the allocation of LWPs to one or more physical CPUs based on thread priorities assigned to each thread. Fig.5 depicts the relations between threads, LWPs, and CPUs. Two major changes in the design of the contexts and the memory management of EusLisp have been made to upgrade it to multithread capabilities.

#### 12.1.2 Context Separation

MT-Eus allocates private stacks and contexts to each threads so that they can run independently of each other. Objects such as symbols and conses are allocated in the shared heap memory as in sequential EusLisp. Therefore, thread-private data such as block labels, catch tags, and local variables are protected from other threads, whereas values (objects) pointed by global variables are visible to all threads allowing information exchange among threads.

A context consists of a C-stack, a binding-stack and frame pointers that chain lexical blocks such as lambda, block, catch, let, flet, and so on, and is established when a new thread is created. Since more than one context can be active at the same time on a real multi-processor machine, we cannot hold a single pointer to the current context in a global variable. Rather we have to add one more argument to every internal function to transfer the context pointer from the topmost eval to the memory manager at the bottom.

## 12.1.3 Memory Management

EusLisp adopts a Fibonacci buddy memory management scheme in a single heap for every type of object. After running programs having different memory request characteristics, we have been convinced that Fibonacci buddy can allocate objects of various sizes equally fast, garbage-collects quickly without copying, and exhibits high memory utilization (the internal loss is 10 to 15% and the external loss is negligible). For multithreading, the second point, i.e., non-copying GC, is very important. If addresses of objects were changed by copying-GC, pointers in the stack and CPU registers of all thread contexts would have to be redirected to new locations, which is impossible or very difficult.

All memory allocation requests are handled by the alloc function at the lowest level. Alloc does mutex-locking because it manipulates the global database of free lists. Since we cannot predict when a garbage collection begins and which thread causes it, every thread must prepare for sporadic GCs. All pointers to living objects have to be arranged to be accessible by the GC anytime to prevent them from being reclaimed

as garbage. This is done by storing the pointers to the most recently allocated objects in fixed slots of each context, instead of trusting they are maintained on the stacks.

Fig. 6 illustrates flow of threads requesting memory and forked inside GC to process marking and sweeping in parallel. Note that threads that do not request memory or manipulate pointers can run in parallel with the GC, improving real-time response of the low-level tasks such as signal processing and image acquisition.

## 12.2 Asynchronous and Parallel Programming Constructs

#### 12.2.1 Thread Creation and Thread Pool

In order for Solaris to execute a program in parallel on many processors, the program needs to be written as a collection of functions, each of which is executed by a thread dynamically created in a process. Although the time required for thread creation is faster than process creation, it takes a few mili-seconds for EusLisp to start off a thread after allocating stacks and setting a page attribute for detecting stack-overflow. Since this delay, which should be compared to a function invocation, is intolerable, sufficient number of threads are created by the make-thread function beforehand and put in the system's thread pool, eliminating the need for system calls at evaluation time. Each thread in the thread pool is represented by a thread object, as depicted in Fig.7, consisted of thread-id, several semaphores for synchronization, and slots for argument and evaluation result transfer.

#### 12.2.2 Parallel Execution of Threads

For the allocation of parallel computation to threads, the thread function is used. Thread takes one free thread out of the thread pool, transfers arguments via shared memory, wakes up the thread by signaling the semaphore as indicated in fig. 7, and returns a thread object to the caller without blocking. The woken-up thread begins evaluation of the argument running in parallel to the calling thread. The caller uses wait-thread to receive the evaluation result from the forked thread. The plist macro is a more convenient form to describe parallel evaluation of arguments. Plist attaches threads to evaluate each argument and lists up results after waiting for all threads to finish evaluation.

## 12.2.3 Synchronization primitives

MT-Eus has three kinds of synchronization primitives, namely mutex locks, condition variables, and semaphores. Mutex locks are used to serialize accesses to shared variables between threads. Condition variables allow a thread to wait for a condition to become true in a mutex-locked section by temporarily releasing and re-acquiring the lock. Semaphores are used to inform occurrences of events, or to control sharing of finite resources. These synchronization primitives cause voluntary context switching, while the Solaris kernel generates involuntary task switching on a time-sliced scheduling basis.

## 12.2.4 Barrier synchronization

Barrier-synch is a mechanism for more than two threads to synchronize at the same time (Fig. 8). For this purpose, an instance of the barrier class is created and threads that participate in the synchronization register themselves in the object. Then, each thread sends the :wait message to the barrier object, and the thread is blocked. When the last thread registered in the object sends its :wait message, the waits

are released and all waiting threads get a return value of T. Barrier-sync plays an important role of global clocking in a multi-robot simulation.

#### 12.2.5 Synchronized memory port

Synchronized memory port is a kind of stream to exchange data between threads (Fig. 8). Since all threads in a process share the heap memory, if one thread binds an object to a global variable, it instantly becomes visible to other threads. However, shared memory lacks capability to send events that the global data is updated. Synchronized memory port ensures this synchronization for accessing a shared object. A synchronized memory port object consists of one buffer slot and two semaphores used for synchronizing read and write.

#### 12.2.6 Timers

Real-time programs often require functions to execute at predetermined timing or to repeat in particular intervals. Sequential EusLisp could run user' functions triggered by signals generated periodically by Unix's interval timers. This preemption can cause deadlock in MT-Eus, because interruption may occur within a mutex-ed block. Therefore, control must be transferred at secured points such as at the beginning of eval. To avoid delays caused by the above synchronization, MT-Eus also provides signal-notification via semaphores. In other words, the signal function takes either a function or a semaphore that is called or posted upon the signal arrival. Since the semaphore is posted at the lowest level, latency for synchronization is minimal.

The following a example image processing program coded by using the multithread facilities. Image input thread and filtering threads are created. samp-image takes image data periodically by waiting for samp-sem to be posted every 33msec. Two threads synchronize via read-and-write of a thread-port. Filter-image employs two more threads for parallel computation of filtering.

## 12.3 Measured Parallel Gains

Table. 3 shows the parallel execution performance measured on a Cray Supserserver configured with 32 CPUs. Linear parallel gain was obtained for the compiled Fibonacci function, because there is no shared

processors	1	2	4	8	GC (ratio)
(a) compiled Fibonacci	1.0	2.0	4.0	7.8	0
(b) interpreted Fibonacci	1.0	1.7	2.7	4.4	0
(c) copy-seq	1.0	1.3	0.76	0.71	0.15
(d) make-cube	1.0	0.91	0.40	0.39	0.15
(e) interference-check	1.0	0.88	0.55	0.34	0.21

表 3: Parallel gains of programs executed on multi-processors

memory access and the program code is small enough to be fully loaded onto the cache memory of each processor. Contrally, when the same program was interpreted, linearly high performance could not be attained, since memory access scatters. Further, some programs that frequently refer to shared memory and request memory allocation cannot exhibit better performance than a single processor execution. This can be understood as the result of frequent cache memory purging.

## 12.4 Thread creation

A thread is a unit for assigning computation, usually evaluation of a lisp form. Threads in EusLisp are represented by instances of the **thread** class. This object is actually a control port of a thread to pass arguments and result, and let it start evaluation, rather than the thread's entity representing the context.

## sys:make-thread num & optional (lsize 32\*1024) (csize lsize)

[function]

creates *num* threads with *lsize* words of Lisp stack and *csize* words of C stack, and put them in the system's thread pool. All the threads in the thread pool is bound to sys:\*threads\*, which is extended each time **make-thread** is called. By the **thread** function, a computation is assigned to one of free threads in the thread pool. Therefore it is not a good idea to change stack sizes from thread to thread, since you cannot control which thread is assigned to a specific computation.

sys:\*threads\* [variable]

returns the list of all the threads created by make-threads.

## sys::free-threads [function]

returns the list of threads in the free thread pool. If the result is NIL, new commitment of a task to a thread is blocked until any currently running threads finish evaluation or new threads are created by **make-thread** in the free thread pool.

#### sys:thread func &rest args

[function]

picks up one free thread from the thread pool, and assigns it for evaluation of (func. args). Sys:thread can be regarded as asynchronous funcall, since sys:thread applies func to the spread list of args but it does not accept the result of the function application. Rather, sys:thread returns the thread object assigned to the funcall, so that the real result can be obtained later by sys:wait-thread.

```
(defun compute-pi (digits) ...)
(setq trd (sys:thread \#'compute-pi 1000)) ;assign compute-pi to a thread
... ;; other computation
(sys:wait-thread trd) ;get the result of (compute-pi 1000)
```

sys:thread-no-wait func &rest args

[function]

assigns computation to one of free threads. The thread is reclaimed in the free thread pool when it finishes evaluation without being **wait-thread**'ed.

## sys:wait-thread thread [function]

waits for *thread* to finish evaluation of funcall given by the **sys:thread** function, and retrieves the result and returns it. **Sys:wait-thread** is mandatory if the thread is assigned evaluation by **sys:thread** because the thread is not returned to the free thread pool until it finishes transferring the result.

sys:plist & rest forms [macro

evaluates *forms* by different threads in parallel and waits for the completion of all evaluation, and the list of results is returned. **Sys:plist** may be regarded as *parallel-list* except that each form listed must be a function call.

## 12.5 Synchronization

Among Solaris operating systems four synchronization primitives for multithread programs, EusLisp provides mutex locks, conditional variables, and semaphores. Reader-writer lock is not available now.

Based on these primitives, higher level synchronization mechanisms, such as synchronized memory port and barrier synchronization, are realized.

sys:make-mutex-lock [function]

makes a mutex-lock and returns it. A mutex-lock is represented by an integer-vector of six elements.

## sys:mutex-lock mlock

[function]

locks the mutex lock *mlock*. If the *mlock* is already locked by another thread, *mutex-lock* waits for the lock to be released.

## $sys:mutex-unlock \ mlock$

[function]

releases *mlock* and let one of other threads waiting for this lock resume running.

#### sys:mutex mlock &rest forms

[macro]

Mutex-lock and mutex-unlock have to be used as a pair. **Mutex** is a macro that brackets a critical section. *Mlock* is locked before evaluating *forms* are evaluated, and the lock is released when the evaluation finishes. This macro expands to the following progn form. Note that **unwind-protect** is used to ensure unlocking even an error occurs during the evaluation of *forms*.

```
(progn
    (sys:mutex-lock mlock)
    (unwind-protect
          (progn . forms)
          (sys:mutex-unlock mlock)))
```

sys:make-cond [function]

makes a condition variable object which is an integer vector of four elements. The returned condition variable is in unlocked state.

#### sys:cond-wait condvar mlock

[function]

waits for condvar to be signaled. If condvar has already been acquired by another thread, it releases mlock and waits for condvar to be signaled.

sys:cond-signal condvar

[function]

signals the *condvar* condition variable.

sys:make-semaphore

[function]

makes a semaphore object which is represented by an integer vector of twelve elements.

sys:sema-post sem

[function]

signals sem.

sys:sema-wait sem

[function]

waits for the *sem* semaphore to be posted.

## sys:barrier-synch

[Class]

:super propertied-object

:slots threads n-threads count barrier-cond threads-lock count-lock

represents a structure for barrier-synchronization. Threads waiting for the synchronization are put in threads which is mutually excluded by threads-lock. When a barrier-synch object is created, count is initialized to zero. Synchronizing threads are put in the threads list by sending :add message. Sending :wait to this barrier-sync object causes count to be incremented, and the sending thread is put in the wait state. When all the threads in threads send the :wait message, the waits are unblocked and all threads resume execution. The synchronization is implemented by the combination of the count-lock mutex-lock and the barrier-cond condition-variable.

:init [method]

initializes this barrier-synch object. Two mutex-lock and one condition-variable are created.

:add thr

adds the thr thread in the threads list.

: remove thr

removes the *thr* thread of the *threads* list.

:wait [method]

waits for all threads in the threads list to issue :wait.

## sys:synch-memory-port

[Class]

:super **propertied-object** 

:slots sema-in sema-out buf empty lock

realizes the one-directional synchronized memory port, which synchronizes for two threads to transfer datum via this object. Control transfer is implemented by using semaphores.

:read [method]

reads datum buffered in this synch-memory-port. If it has not been written yet, the :read blocks.

:write datum

writes *datum* in the buffer. Since only one word of buffer is available, if another datum has already been written and not yet read out, :write waits for the datum to be transferred by :read.

:init [method]

initializes this synch-memory-port where two semaphores are created and :write is made acceptable.

## 13 Geometric Functions

#### 13.1 Float-vectors

A float-vector is a simple vector whose elements are specialized to floating point numbers. A float-vector can be of any size. When *result* is specified in an argument list, it should be a float-vector that holds the result.

#### float-vector &rest numbers

[function]

makes a new float-vector whose elements are *numbers*. Note the difference between (float-vector 1 2 3) and #F(1 2 3). While the former create a vector each time it is called, the latter does when it is read.

#### float-vector-p obj

[function]

returns T if *obj* is a float-vector.

v+ fltvec1 fltvec2 &optional result

[function]

adds two float-vectors.

## v- fltvec1 & optional fltvec2 result

[function]

subtract float-vectors. If fltvec2 is omitted, fltvec1 is negated.

v. fltvec1 fltvec2

[function]

computes the inner product of two float-vectors.

## v\* fltvec1 fltvec2 &optional result

[function]

computes the outer product of two float-vectors.

## v.\* fltvec1 fltvec2 fltvec3

[function]

computes the scaler triple product [A,B,C]=(V. A (V\* B C))=(V. (V\* A B) C).

v< fltvec1 fltvec2

[function]

returns T if every element of fltvec1 is smaller than the corresponding element of fltvec2.

**v**> fltvec1 fltvec2

[function]

returns T if every element of fltvec1 is larger than the corresponding element of fltvec2.

vmin &rest fltvec

[function]

finds the smallest values for each dimension in *fltvec*, and makes a float-vector from the values. **Vmin** and **vmax** are used to find the minimal bounding box from coordinates of vertices.

vmax &rest fltvec

[function]

finds the greatest values for each dimension in fltvec, and makes a float-vector from the values.

## minimal-box v-list minvec maxvec $\mathscr{C}optional$ err

[function]

computes the minimal bounding box for a given vertex-list, and stores results in *minvec* and *maxvec*. If a floating number err is specified, the minimal box is grown by the ratio, i.e. if the err is 0.01, each element of minvec is decreased by 1% of the distance between minvec and maxvec, and each element of maxvec is increased by 1%. **Minimal-box** returns the distance between minvec and maxvec.

## scale number fltvec Coptional result

[function]

the scaler *number* is multiplied to the every element of fltvec.

**norm** fltvec [function]

|fltvec|

norm2 fltvec [function]

[function]

 $|fltvec|^2 = (\mathbf{v}.fltvecfltvec)$ 

normalize-vector fltvec Coptional result

normalizes fltvec to have the norm 1.0.

distance fltvec1 fltvec2 [function]

returns the distance |fltvec - fltvec2| between two float-vectors.

distance2 fltvec1 fltvec2 [function]

 $|fltvec - fltvec2|^2$ 

homo2normal homovec & optional normalvec [function]

A homogeneous vector *homovec* is converted to its normal representation.

homogenize normalvec & optional homovec [function]

A normal vector *normalvec* is converted to its homogenous representation.

midpoint p p1 p2 & optional result [function]

P is float, and p1 and p2 are float-vectors of the same dimension. A point (1-p)p1 + pp2, which is the point that breaks p1-p2 by the ratio p:(1-p), is returned.

rotate-vector fltvec theta axis & optional result [function]

rotates 2D or 3D fltvec by theta radian around axis. Axis can be one of :x, :y, :z, 0, 1, 2 or NIL. When axis is NIL, fltvec is taken to be two dimensional. To rotate a vector around an arbitrary axis in 3D space, make a rotation matrix by the **rotation-matrix** function and multiply it to the vector.

## 13.2 Matrix and Transformation

A matrix is a two-dimensional array whose elements are all floats. In most functions a matrix can be of any size, but the **v\***, **v.\***, **Euler-angle** and **rpy-angle** functions can only handle three dimensional matrices. **Transform**, **m\*** and **transpose** do not restrict the matrices to be square, and they operate on general n\*m size matrices.

Functions that can accept result parameter places the computed result there, and no heap is wasted. All matrix functions are intended for the transformation in the normal coordinate systems, and not in the homogeneous coordinates.

The **rpy-angle** function decomposes a rotation matrix into three components of rotation angles around z, y and x axes of the world coordinates. The **Euler-angle** function is similar to **rpy-angle** but decomposes into rotation angles around local z, y and again z axes. Both of these functions return two solutions since angles can be taken in the opposite directions.

```
; Mat is a 3X3 rotation matrix.
(setq rots (rpy-angle mat))
(setq r (unit-matrix 3))
(rotate-matrix r (car rots) :x t r)
(rotate-matrix r (cadr rots) :y t r)
```

```
(rotate-matrix r (caddr rots) :z t r)
;--> resulted r is equivalent to mat
```

To keep track of pairs of a position and a orientation in 3D space, use the **coordinates** and **cascaded-coords** classes detailed in the section 13.4.

matrix & rest elements [function]

makes a new matrix from *elements*. Row x Col = (number of elements) x (length of the 1st element). Each of *elements* can be of any type of sequence. Each sequence is lined up as a row vector in the matrix.

## make-matrix rowsize columnsize Goptional init

[function]

makes a matrix of  $rowsize \times columnsize$ .

matrixp obj

T if obj is a matrix, i.e. obj is a two dimensional array and its elements are floats.

#### matrix-row mat row-index

[function]

extracts a row vector out of matrix *mat*. **matrix-row** is also used to set a vector in a particular row of a matrix using in conjunction with **setf**.

#### matrix-column mat column-index

[function]

extracts a column vector out of *mat*. **matrix-column** is also used to set a vector in a particular column of a matrix using in conjunction with **setf**.

#### m\* matrix1 matrix2 &optional result

[function]

concatenates matrix1 and matrix2.

## transpose matrix & optional result

[function]

transposes matrix, i.e. columns of matrix are exchanged with rows.

# unit-matrix dim makes an identity matrix of $dim \times dim$ .

[function]

·

## ${\bf replace\text{-}matrix}\ \textit{dest src}$

[function]

replaces all the elements of dest matrix with ones of src matrix.

#### scale-matrix scalar mat

[function]

multiplies scaler to all the elements of mat.

#### copy-matrix matrix

[function]

makes a copy of matrix.

## transform matrix fltvector & optional result

[function]

multiplies matrix to fitvector from the left.

## transform fltvector matrix & optional result

[function]

multiplies matrix to fltvector from the right.

## rotate-matrix matrix theta axis & optional world-p result

[function]

multiplies a rotation matrix from the left (when world-p is non-nil) or from the right (when world-p is nil). When a matrix is rotated by **rotate-matrix**, the rotation axis :x, :y, :z or 0,1,2 may be taken either in the world coordinates or in the local coordinates. If world-p is specified nil, it means rotation

along the axis in the local coordinate system and the rotation matrix is multiplied from the right. Else if worldp is non-nil, the rotation is made in the world coordinates and the rotation matrix is multiplied from the left. If NIL is given to axis, matrix should be two dimensional and the rotation is taken in 2D space where world-p does not make sense.

#### rotation-matrix theta axis &optional result

[function]

makes a 2D or 3D rotation matrix around *axis* which can be any of :x, :y, :z, 0, 1, 2, a 3D float-vector or NIL. When you make a 2D rotation matrix, axis should be NIL.

## rotation-angle rotation-matrix

[function]

extracts a equivalent rotation axis and angle from *rotation-matrix* and a list of float and float-vector is returned. NIL is returned when *rotation-matrix* is a unit-matrix. Also if the rotation angle is too small, the result may have errors. When *rotation-matrix* is 2D, the single angle value is returned.

## rpy-matrix ang-z ang-y ang-x

[function]

makes a rotation matrix defined by roll-pitch-yaw angles. First, a unit-matrix is rotated by ang-x radian along X-axis. Next, ang-y around Y-axis and finally ang-z around Z-axis. All the rotation axes are taken in the world coordinates.

rpy-angle matrix

[function]

extracts two triplets of roll-pitch-yaw angles of matrix.

## Euler-matrix ang-z ang-y ang2-z

[function]

makes a rotation matrix defined by three Euler angles. First, a unit-matrix is rotated ang-z around Z-axis, next, ang-y around Y-axis and finally ang2-z again around Z-axis. All the rotation axes are taken in the local coordinates.

## Euler-angle matrix

[function]

extracts two tuples of Euler angles.

## 13.3 LU decomposition

lu-decompose and lu-solve are provided to solve simultaneous linear equations. First, lu-decompose decomposes a matrix into a lower triangle matrix and an upper triable matrix. If the given matrix is singular, LU-decompose returns NIL, otherwise it returns the permutation vector which should be supplied to LU-solve. Lu-solve computes the solution for a LU matrix with a given constant vector. This method is efficient if solutions for many combinations of different constant vectors and the same factor matrix are required. Simultaneous-equation would be more handy when you wish to get only one solution. Lu-determinant computes a determinant of a lu-decomposed matrix. Inverse-matrix function computes an inverse matrix using lu-decompose once, and lu-solve n times. Computation time for a 3\*3 matrix is estimated to be 4 milli-sec.

#### lu-decompose matrix & optional result

[function]

performs lu-decomposition of matrix.

#### lu-solve lu-mat perm-vector bvector & optional result

[function]

solves a linear simultaneous equations which has already been lu-decomposed. *perm-vector* should be the result returned by **lu-decompose**.

## ${\bf lu\text{-}determinant}\ \textit{lu-mat perm-vector}$

[function]

computes the determinant value for a matrix which has already been lu-decomposed.

## ${f simultaneous-equation}\ mat\ vec$

[function]

solves a linear simultaneous equations whose coefficients are described in mat and constant values in vec.

inverse-matrix mat [function]

makes the inverse matrix of the square matrix, mat.

pseudo-inverse mat [function]

computes the pseudo inverse matrix using the singular value decomposition.

## 13.4 Coordinates

Coordinate systems and their transformations are represented by the **coordinates** class. Instead of 4\*4 (homogeneous) matrix representation, coordinate system in EusLisp is represented by a combination of a 3\*3 rotation matrix and a 3D position vector mainly for speed and generality.

coordinates

:super propertied-object :slots (pos :type float-vector rot :type array)

defines a coordinate system with a pair of a position vector and a 3x3 rotation matrix.

coordinates-p obj [function]

returns T when obj is an instance of coordinates class or its subclasses.

:rot [method]

returns the 3X3 rotation matrix of this coords.

:pos [method]

returns the 3-D position vector of this coords.

:newcoords newrot &optional newpos

[method]

updates the coords with newrot and newpos. Whenever a condition that changes the state of this coords occurs, this method should be called with the new rotation matrix and the position vector. This message may invoke another :update method to propagate the event. If newpos is not given, newrot is given as a instance of coordinate class.

:replace-coords newrot &optional newpos

[method]

changes the rot and pos slots to be updated without calling newcoords method. If newpos is not given, newrot is given as a instance of coordinate class.

:coords [method]

 $\textbf{:} \textbf{copy-coords} \ \mathscr{C}optional \ dest$ 

[method]

If dest is not given, copy-coords makes another coordinates object which has the same rot and pos slots. If dest is given, rot and pos of this coordinates is copied to the dest coordinates.

:reset-coords [method]

forces the rotation matrix of this coords to be identity matrix, and pos vector to be all zero.

:worldpos [method]

:worldrot [method]

:worldcoords [method]

Computes the position vector, the rotation matrix and the coordinates of this object represented in the world coordinates. The coordinates class is always assumed to be represented in world, these method can simply return pos, rot and self. These methods are provided for the compatibility with

cascaded-coords class which cannot be assumed to be represented in world.

## $\textbf{:} \textbf{copy-worldcoords} \ \mathscr{C}optional \ dest$

[method]

First, worldcoords is computed, and it is copied to dest. If no dest is specified, a coordinates object to store the result is newly created.

:rotate-vector vec [method]

A vector is rotated by the rotation of this coords, i.e., an orientation vector represented in this coords is converted to the representation in the world. The position of this coords does not affect rotation.

:transform-vector vec [method]

A vector in this local coords is transformed to the representation in the world.

#### :inverse-transform-vector vec

[method]

A vector in the world is inversely transformed to the representation in this local coordinate system.

## :transform trans &optional (wrt :local)

[method]

Transform this coords by the trans represented in wrt coords. Trans must be of type coordinates, and wrt must be one of keywords:local, :parent, :world or an instance of coordinates. If wrt is :local, the trans is applied from the right to this coords, and if wrt is :world or :parent, the trans is multiplied from the left. Else, if wrt is of type coordinates, the trans represented in the wrt coords is first transformed to the representation in the world, and it is applied from the left.

## :move-to trans &optional (wrt :local)

[method]

Replaces the rot and pos of the coords with trans represented in wrt.

#### :translate p & optional (wrt :local)

[method]

changes the position of this object relatively with respective to wrt coords.

## :locate p & optional (wrt :local)

[method]

Changes the location of this coords with the parameter represented in wrt. If wrt is :local, then the effect is identical to :translate with wrt=:local.

#### :rotate theta axis & optional (wrt :local)

[method]

Rotates this coords relatively by theta radian around the axis. Axis is one of axis-keywords (:x, :y and :z) or an arbitrary float-vector. Axis is considered to be represented in the wrt coords. Thus, if wrt=:local and axis=:z, the coordinates is rotated around the z axis of this local coords, and wrt=:world or :parent, the coords is rotated around the z axis of world coords. In other words, if wrt=:local, a rotation matrix is multiplied from the right of this coords, and if wrt=:world or :parent, a rotation matrix is multiplied from the left. Note that even wrt is either :world or :parent, the pos vector of this coordinates does not change. For the true rotation around the world axis, an instance of coordinates class representing the rotation should be given to :transform method.

## :orient theta axis &optional (wrt :local)

[method]

forces setting rot. This is an absolute version of :rotate method.

#### :inverse-transformation

[method]

makes a new coords that is inverse to self.

## :transformation coords (wrt :local)

[method]

makes the transformation (an instance of coordinates) between this coords and the coords given as the argument. If wrt=:local, the result is represented in local coords, i.e., if the resulted transformation

is given as an argument to :transform with wrt=:local, this coords is transformed to be identical with the coords.

:Euler az1 ay az2 [method]

sets rot with Euler angles, that are, rotation angles around z (az1, y (ay) and again z az2 axis of this local coordinates system.

## $\textbf{:roll-pitch-yaw} \ \ roll \ \ pitch \ \ yaw$

[method]

sets rot with roll-pitch-yaw angles: rotation angles around x (yaw), y (pitch) and z (roll) axes of the world coordinate system.

## :4x4 &optional mat44

[method]

If a matrix of 4x4 is given as mat/4, it is converted to coordinates representation with a 3x3 rotation matrix and a 3D position vector. If mat/4 is not given, this coordinates is converted to 4x4 matrix representation.

:init [method]

```
\&key \text{ (pos } \#f(0\ 0\ 0))
(rot \#2f((1\ 0\ 0)\ (0\ 1\ 0)\ (0\ 0\ 1)))
```

 $\begin{array}{ccc} \text{rpy} & \text{; roll pitch yaw} \\ \text{euler} & \text{; az ay az2} \\ \text{axis} & \text{; rotation-axis} \\ \text{angle} & \text{; rotation-angle} \\ 4\text{X4} & \text{; } 4\text{x4 matrix} \end{array}$ 

coords ; another coordinates properties ; list of (ind . value) pair

name; name property

initializes this coordinates object and sets rot and pos. The meaning of each keyword follows:

```
:dimension 2 or 3 (default is 3)
```

**:pos** specifies a position vector (defaulted to  $\#f(0\ 0\ 0)$ )

:rot specifies a rotation matrix (defaulted to a unit-matrix)

:euler gives a sequence of three elements for Euler angles

:rpy gives a sequence of three elements for roll-pitch-yaw

:axis rotation axis (:x,:y,:z or an arbitrary float-vector)

**:angle** rotation angle (used with :axis)

:wrt where the rotation axis is taken (default is :local)

:4X4 4X4 matrix is used to specify both pos and rot

:coords copies pos and rot from coords

:name set :name property

:Angle can only be used in conjunction with the :axis that is determined in the :wrt coordinates. Without regard to :wrt, :Euler always specifies the Euler angles, az1, ay and az2, defined in the local coordinates, and :rpy specifies the angles around z, y and x axes of the world coordinates. Two or more of :rot, :Euler, :rpy, :axis and :4X4 cannot be specified simultaneously, although no error is reported. Sequences can be supplied to the :axis and :angle parameters, which mean successive rotations around the given axes. List of pairs of an attribute and its value can be given as :properties argument. These pairs are copied in the plist of this coordinates.

#### 13.5 CascadedCoords

cascaded-coords [Class]

:super coordinates

:slots (parent descendants worldcoords manager changed)

defines a linked coordinates. Cascaded-coords is often abbreviated as cascoords.

:inheritance [method]

returns the inheritance tree list describing all the descendants of the cascoords. If a and b are the direct descendants of this coords, and c is a descendant of a, ((a (c)) (b)) is returned.

## $\textbf{:assoc} \ \textit{childcoords} \ \mathcal{C}optional \ \textit{relative-coords}$

[method]

childcoords is associated to this casecoords as a descendant. If childcoords has been already assoc'ed to some other casecoords, first childcoords is dissoc'ed since each casecoords can have only one parent. The orientation or location of childcoords in the world does not change.

:dissoc childcoords [method]

dissociates (removes) *childcoords* from the descendants list of this coords. The orientation or location of childcoords in the world does not change.

:changed [method]

informs this coords that the coordinates of parent has changed, and the re-computation of worldcoords is needed when it is requested later.

:update [method]

is called by the :worldcoords method to recompute the current worldcoord.

:worldcoords [method]

returns a coordinates object which represents this coord in the world by concatenating all the cascoords from the root to this coords. The result is held in this object and reused later. Thus, you should not modify the resulted coords.

:worldpos [method]

returns rot of this coordinates represented in the world.

:worldrot [method]

returns pos of this coordinates represented in the world.

:transform-vector vec [method]

Regarding vec represented in this local coords, transforms it to the representation in the world.

## :inverse-transform-vector vec

[method]

vec represented in the world is inversely transformed into the representation in this local coords.

## :inverse-transformation [method]

makes an instance of coordinates which represents inverse transformation of this coord.

:transform trans & optional (wrt :local) [method]

:translate fltvec &optional (wrt :local) [method]

:locate fltvec &optional (wrt :local)

[method]

:rotate theta axis &optional (wrt :local)

[method]

:orient theta axis &optional (wrt :local)

[method]

Refer to the descriptions in class coordinates.

make-coords &key pos rot rpy Euler angle axis 4X4 coords name

[function]

make-cascoords &key pos rot rpy Euler angle axis 4X4 coords name

[function]

coords &key pos rot rpy Euler angle axis 4X4 coords name

[function]

cascoords &key pos rot rpy Euler angle axis 4X4 coords name

[function]

All these functions make new coordinates or cascaded-coordinates. For the keyword parameter, see :init method of class coordinates.

transform-coords coords1 coords2 &optional (coords3 (coords))

[function]

Coords1 is applied (multiplied) to the coords2 from the left. The product is stored in coords3.

transform-coords\* & rest coords

[function]

concatenates transformations listed in *coords*. An instance of coordinates that represents the concatenated transformation is returned.

wrt coords vec [function]

transforms *vec* into the representation in *coords*. The result is equivalent to (send *coords* :transform-vector *vec*).

## 13.6 Relationship between transformation matrix and coordinates class

Relationship between transformation matrix and coordinates class is described, where a transformation matrix T represents a  $4 \times 4$  (homogeneous) matrix as below.

$$T = \begin{pmatrix} \mathbf{R}_T & \mathbf{p}_T \\ \mathbf{0} & 1 \end{pmatrix}$$

 $\mathbf{R}_T$  is a  $3 \times 3$  matrix, and  $\mathbf{p}_T$  is a  $3 \times 1$  matrix (a float-vector which has 3 elements in euslisp). Coordinates class has slot variables rot and pos. They are  $\mathbf{R}_T$  and  $\mathbf{p}_T$  respectively.

## Getter method for rotation matrix and position

 ${f R}$  and  ${f p}$  can be obtained using methods of the coordinates class.

T is an instance of the coordinate class.

 $egin{aligned} ( ext{send T :rot}) \ &\Rightarrow \mathbf{R}_T \ \end{aligned} \ egin{aligned} ( ext{send T :pos}) \ &\Rightarrow \mathbf{p}_T \end{aligned}$ 

## Methods for transforming vectors

 $\mathbf{v}$  is 3-D position vector.

 $egin{aligned} ( ext{send } \mathbf{T} : & ext{rotate-vector } \mathbf{v}) \ & \Rightarrow \mathbf{R}_T \mathbf{v} \end{aligned}$ 

(send T : inverse-rotate-vector v) $\Rightarrow \mathbf{v}^T \mathbf{R}_T$ 

(send T :transform-vector v)

 $\Rightarrow \mathbf{R}_T \mathbf{v} + \mathbf{p}_T$ 

Converts a vector represented in a local coordinate system T to a vector represented in the world coordinate system.

(send T : inverse-transform-vector v)

$$\Rightarrow \mathbf{R}_{T}^{-1}\left(\mathbf{v}-\mathbf{p}_{T}\right)$$

Converts a vector represented in the world coordinate system. to a vector represented in a local coordinate system T.

## Methods returing coordinates without modifying itself

(send T:inverse-transformation)

$$\Rightarrow T^{-1}$$

Returns inverse matrix.

$$T^{-1} = \begin{pmatrix} \mathbf{R}_T^{-1} & -\mathbf{R}_T^{-1} \mathbf{p}_T \\ \mathbf{0} & 1 \end{pmatrix}$$

## (send T :transformation A (&optional (wrt :local)))

when wrt ==:local,  $T^{-1}A$  is returned.

when wrt == :world,  $AT^{-1}$  is returned.

when wrt == W (coordinates class),  $W^{-1}AT^{-1}W$  is returned.

## Methods modifying itself

A is an instance of the coordinates class.

 $\Leftrightarrow$  represents that slot variables (pos or rot) refer to a given instance (matrix or float vector). Please note that when one is changed, the other also reflects the change.

 $\leftarrow$  represents substitution.

## (send T :newcoords A)

 $\mathbf{R}_T \Leftrightarrow \mathbf{R}_A$ 

 $\mathbf{p}_T \Leftrightarrow \mathbf{p}_A$ 

## (send T :newcoords R p)

 $\mathbf{R}_T \Leftrightarrow \mathbf{R}$ 

 $\mathbf{p}_T \Leftrightarrow \mathbf{p}$ 

## (send T :move-to A (&optional (wrt :local)))

when wrt == :local, $T \leftarrow TA$ 

when wrt == :world, $T \Leftrightarrow A$ 

when wrt == W (coordinates class),  $T \leftarrow WA$ 

## (send T :translate v (&optional (wrt :local)))

when wrt == :local,  $\mathbf{p}_T \leftarrow \mathbf{p}_T + \mathbf{R}_T \mathbf{v}$ 

when wrt == :world,  $\mathbf{p}_T \leftarrow \mathbf{p}_T + \mathbf{v}$ 

when wrt == W (coordinates class),  $\mathbf{p}_T \leftarrow \mathbf{p}_T + \mathbf{R}_W \mathbf{v}$ 

## (send T :locate v (&optional (wrt :local)))

when wrt == :local,  $\mathbf{p}_T \leftarrow \mathbf{p}_T + \mathbf{R}_T \mathbf{v}$ 

when wrt == :world,  $\mathbf{p}_T \leftarrow \mathbf{v}$ 

when wrt == W (coordinates class),  $\mathbf{p}_T \leftarrow \mathbf{p}_W + \mathbf{R}_W \mathbf{v}$ 

#### (send T:transform A (&optional (wrt:local)))

when wrt ==:local,  $T \leftarrow TA$ 

when wrt == :world,  $T \leftarrow AT$ 

when wrt == W (coordinates class),  $T \leftarrow (WAW)^{-1} T$ 

## 14 Geometric Modeling

EusLisp adopts *Brep* (Boundary Representation) as the internal representation of 3D geometric models. Components in Breps are represented by classes **edge**, **plane**, **polygon**, **face**, **hole**, and **body**. Primitive body creating functions and body composition functions create new instances of these classes. In order to use your private geometric classes having more attributes, set special variables \*edge-class\*, \*face-class\* and \*body-class\* to your class objects.

## 14.1 Miscellaneous Geometric Functions

vplus vector-list [function]

returns a newly created float-vector that is the sum of all the elements of vector-list. The difference from  $\mathbf{v}$ + is that  $\mathbf{vplus}$  computes the sum of more than two arguments and no result vector can be specified.

vector-mean vector-list [function]

returns the mean vector of vector-list.

**triangle**  $a \ b \ c \ \mathcal{E}optional \ (normal \ \#f(0 \ 0 \ 1))$  [function]

a, b, c are float-vectors representing 2 or 3 dimensional points. normal is the normal vector of the plane on which a, b, and c lie. **Triangle** returns 2\*area of a triangle formed by a, b, c. **Triangle** is positive if a, b, and c turn clockwise when you are looking in the same direction as *normal*. In other words, if **triangle** is positive, c locates at the left hand side of line a-b, and b lies at the right side of ac.

triangle-normal a b c [function]

finds a normal vector which is vertical to the triangle defined by three points a, b, and c.

vector-angle v1 v2 &optional (normal (v\*v1 v2)) [function]

Computes an angle between two vectors, denoted by  $atan(normal \cdot (v1 \times v2), v1 \cdot v2)$ . v1,v2 and normal must be normalized vectors. When normal is not given, a normalized vector commonly perpendicular to v1 and v2 is used, in which case the result is always a positive angle in the range between 0 and  $\pi$ . In order to obtain a signed angle, normal must be specified explicitly.

face-normal-vector vertices [function]

Computes surface normal vector from a list of float-vectors which lie on the same plane.

farthest p points [function]

finds the farthest point from p in the list of 3D float-vectors, points.

farthest-pair points [function]

finds the farthest point pair in the list of 3D float-vectors, points.

maxindex 3D-floatvec [function]

Finds the index of the absolute maximum value of three elements.

random-vector & optional (range 1.0) [function]

Generates a random vector which is distributed homogeneously in 3D Cartesian space.

random-normalized-vector *&optional (range 1.0)* [function]

returns a normalized-3D random vector.

#### random-vectors count range

[function]

returns a list of random vectors.

#### line-intersection p1 p2 p3 p4

[function]

p1, p2, p3 and p4 are all float-vectors of more than two dimensions. p1-p2 and p3-p4 define two lines on a plane. **line-intersection** returns a list of two parameters of the intersection point for these two lines. When used in three dimension, p1, p2, p3 and p4 must be coplanar.

## **collinear-p** p1 p2 p3 & optional tolerance

[function]

p1, p2, p3 are all three-dimensional float-vectors representing three point locations. **Collinear-**  $\mathbf{p}$  returns the parameter for p2 on the line p1-p3 if  $norm((p2-p1)\times(p3-p1))$  is smaller than \*coplanar-threshold\*, otherwise NIL.

## find-coplanar-vertices p1 p2 p3 vlist

[function]

p1, p2, p3 are all three-dimensional float-vectors representing a plane. **Find-coplanar-vertices** looks for coplanar points in *vlist* that lie on the plane.

#### find-connecting-edge vertex edgelist

[function]

finds an edge in edgelist that connects to vertex.

### make-vertex-edge-htab bodfacs

[function]

bodfacs is a body or a list of faces. **make-vertex-edge-htab** makes a hash-table which allows retrieving of edges connected to a vertex.

#### left-points points p1 p2 normal

[function]

Assume points, p1, and p2 lie on the plane whose normal vector is normal. **Left-points** searches in points and collects ones lying in the left hand side of the line passing on p1, p2.

#### right-points points p1 p2 normal

[function]

Assume points, p1, and p2 lie on the plane whose normal vector is normal. **Right-points** searches in points and collects ones lying in the right hand side of the line determined by p1, p2.

## left-most-point points p1 p2 normal

[function]

Assume points, p1, and p2 lie on a plane whose normal vector is normal. **left-points** searches in points which lie in the left-hand side of the line determined by p1, p2 and returns the farthest one.

## right-most-point points p1 p2 normal

[function]

Assume points, p1, and p2 lie on a plane whose normal vector is normal. **right-most-point** searches in points which lie in the right-hand side of the line determined by p1, p2 and returns the farthest one.

#### eps= num1 num2 & optional (tolerance \*epsilon\*)

[function]

compares two float numbers num1 and num2 for equality with the tolerance of \*epsilon\*.

## eps< num1 num2 & optional (tolerance \*epsilon\*)

[function]

returns T if num1 is apparently less than num2, i.e. num1 < num2 - tolerance.

## eps<= num1 num2 &optional (tolerance \*epsilon\*)

[function]

returns T if num1 is possibly less than or equal to num2, i.e. num1 < num2 + tolerance.

## eps> num1 num2 & optional (tolerance \*epsilon\*)

[function]

returns T if num1 is apparently greater than num2, i.e. num1 > num2 + tolerance.

eps>= num1 num2 &optional (tolerance \*epsilon\*)

[function]

returns T if num1 is possibly greater than or equal to num2, i.e. num1 > num2 - tolerance.

bounding-box

[Class]

 $: \mathbf{super} \qquad \mathbf{object}$ 

:slots (minpoint maxpoint)

defines a minimal rectangular-parallel-piped which is bounded by the planes parallel to xy-, yz- and zx-planes. **Bounding-box** can be used in any dimension according to the dimension of vectors given at the initialization. Bounding-box had been defined by the name of surrounding-box.

:box [method]

returns this bounding-box object itself.

:volume [method]

returns the volume of this bounding box.

:grow rate [method]

increases or decreases the size of this box by the rate. When rate is 0.01, the box is enlarged by 1%.

:inner point [method]

returns T if *point* lies in this box, otherwise nil.

:intersection box2 &optional tolerance

[method]

returns the intersectional bounding box of this box and box2. If tolerance is given, the box is enlarged by it. If there is no intersection, NIL is returned.

:union box2 [method]

returns the union of bounding box of this box and box2.

:intersection box2 [method]

returns T if this box has the intersection with the box2, NIL otherwise. This method is faster than **:intersection** because no new instance of bounding-box is created.

:extreme-point direction

[method]

returns one of the eight corner points yielding the largest dot-product with direction.

:corners [method]

returns the list of all vertices of this box. If this box defines 2D bounding-box, then 4 points are returned, 3D, 8, and so on.

:below box2 & optional (direction #(0 0 1)

[method]

returns T if this box is below box2 in direction. This is used to check whether two box intersects when this box is moved toward direction.

:body [method]

returns a body object that represents a cube bounded by this box.

:init vlist &optional tolerance

[method]

sets minpoint and maxpoint slots looking in vlist. If tolerance (float) is specified, the box is grown by the amount.

make-bounding-box points &optional tolerance

[function]

finds the minimum and maximum coordinates in the list of points, and make an instance of bounding-box.

- **bounding-box-union** boxes  $\mathscr{C}$ optional (tolerance \*contact-threshold\*) [function] makes an instance of the surrounding-box representing the union of boxes. The resulted box is expanded by the tolerance.
- bounding-box-intersection boxes &optional (tolerance \*contact-threshold\*) [function] makes an instance of the surrounding-box representing the intersection of boxes. The resulted box is expanded by the tolerance.

## 14.2 Line and Edge

The direction of the vertex loop or the edge loop is defined so that the vertices or edges are arranged in the counter-clockwise order when the body is observed from outside. *Pvertex* and *nvertex*, and *pface* and *nface* are determined so that an edge is oriented from *pvertex* toward *nvertex* when *pface* is located at the left of the edge observing them from outside.

line [Class]

:super propertied-object

:slots ((pvert :type float-vector) (nvert :type float-vector))

defines a line passing on pvert and nvert. The line is directed from *pvert* to *nvert* in the parametric representation:  $t \cdot pvert + (1-t)nvert$ .

:vertices [method]

returns the list of *pvert* and *nvert*.

[method]

returns a three dimensional float-vector that corresponds to the p parameter on this line.  $parameter \cdot pvert + (1 - parameter)nvert$ 

:parameter point [method]

Computes the parameter for *point* on this line. This is the inverse method of :point.

:direction [method]

returns a normalized vector from **pvert** to **nvert**.

[method]

returns the other end-point of this line, i.e. if v is eq to pvert, nvert is returned, if v is eq to nvert, pvert is returned, otherwise NIL.

:box [method]

creates and returns a **bounding-box** of this line.

:boxtest box

checks intersection between box and the bounding-box of this line.

:length [method]

returns the length of this line.

:distance point-or-line [method]

returns the distance between the *point-or-line* and this line. If the foot of the vertical line from the *point* to this line does not lie between pvertex and nvertex, the distance to the closest end-point is returned. Using this method to calculate the distance between two lines, interference between two cylinders can be tested.

:foot point [method]

finds the parameter for the point which is the foot of the vertical line from point to this line.

## :common-perpendicular l [method]

finds the line which is vertical both to this line and to l and returns a list of two 3D float-vectors.

:project plane

returns a list of two points that are the projection of pvert of nvert onto *plane*. When two lines are in parallel and a common perpendicular line cannot be determined uniquely, parallel is returned.

## :collinear-point point & optional (tolerance \*coplanar-threshold\*)

[method]

128

checks whether *point* is collinear to this line with the tolerance of *tolerance* using **collinear-p**. If *point* is collinear to this line, the parameter for the point on the line is returned, otherwise NIL.

## $\textbf{:on-line-point} \ \ point \ \ \mathscr{C}optional \ \ (tolerance \ \ ^*coplanar-threshold ^*)$

[method]

checks whether the *point* is collinear to this line, and the *point* lies on the part of the line between *pvert* and *nvert*.

## :collinear-line ln &optional (tolerance \*coplanar-threshold\*)

[method]

checks if ln is collinear to this line, i.e. if the two end-points of ln lie on this line. T or NIL is returned.

## :coplanar ln &optional (tolerance \*coplanar-threshold\*)

[method]

checks if this line and ln are coplanar. Two end-points of this line and one end-point of ln defines a plane. If another end-point of ln is on the plane, T is returned, otherwise NIL.

:intersection ln [method]

*ln* is a line coplanar with this line. :Intersection returns a list of two parameters for the intersection point of these two lines. A parameter may be any float number, but a parameter between 0 and 1 means an actual intersection on the line segmented by two end-points. NIL if they are in parallel.

:intersect-line ln [method]

*ln* is a line coplanar with this line. Two parameters of the intersecting point is returned along with symbolic information such as :parallel, :collinear, and :intersect.

edge [Class]

represents an edge defined as the intersection between two faces. Though *pface* and *nface* are statically defined in the slots, their interpretations are relative to the direction of this edge. For example, *pface* represents the correct pface when this edge is considered to goes from *pvert* toward *nvert*. So, pvert and nvert in your interpretation must be given to the **:pface** and **:nface** methods to select the appropriate face.

## make-line point1 point2

:body

[function]

creates an instance of **line** whose pvert is *point1* and nvert is *point2*.

:pvertex pf

[method]

[method]

[method]

returns prertex when *face* is regarded as the pface of this edge.

:nvertex face

returns nvertex regarding face as the pface of this edge.

returns the body object that defines this edge.

:pface  $pv \ nv$  [method]

returns pface when the pv and nv are interpreted as the virtual pface and nface of this edge, respectively.

:nface pv nv

returns nface when the pv and nv are interpreted as the virtual pface and nface of this edge, respectively.

:binormal aface [method]

finds the direction vector which is perpendicular both to this line and to the normal of aface.

:angle [method]

returns the angle between two faces connected with this edge.

:set-angle [method]

computes the angle between two faces connected with this edge and stores it in the angle slot.

:invert [method]

:set-face  $pv \ nv \ f$ 

sets the f face as a pface regarding pv as the pvertex and nv as the nvertex. Note that this may change either pface or nface of this edge.

:contourp viewpoint [method]

T if this is a contour edge, i.e., either pface or nface of this edge is visible and the other is invisible from *viewpoint*.

:approximated-p [method]

T if this edge is an approximated edge representing curved surface like the side of a cylinder. Approximated edges are needed to represent curves by segmented straight lines.

## :set-approximated-flag &optional (threshold 0.7)

[method]

In EusLisp, every curved surface is approximated with many planar faces. The LSB of flags is used to indicate that the faces on the both sides of this edge are curved faces. :set-approximated-flag sets this flag to T, if the angle between two faces is greater than threshold.

:init &key pface nface pvertex nvertex

[method]

#### 14.3 Plane and Face

A plane object is represented by the normal vector on the plane and the distance from the coordinates origin to the plane. Two pairs of such normal vectors and distances are recorded in a plane object. One represents the current status after transformations, while the other represents the original normal and distance when the plane is defined.

plane [Class]

defines plane-equation. A plane is considered to have no boundaries and extend infinitely.

:normal [method]

returns this polygon's normal vector which is always normalized.

:distance point [method]

computes distance between this plane and point.

:coplanar-point point [method]

returns T if *point* lies on this plane.

:coplanar-line line [method]

returns T if *line* lies on this plane.

:intersection point1 point2

computes the intersection point between this plane and the line determined by two end points, *point1* and *point2*, and returns the parameter for the intersection on the line. If the line and this plane are parallel, :parallel is returned.

[method]

:intersection-edge edge [method]

Returns the parameter of the intersection point for this plane and a line represented by point1 and point2, or edge.

:foot point [method]

Returns a 3D vector which is the orthogonally projection of *point* onto this plane.

:init normal point [method]

Defines a plane with the *point* on the plane and the *normal* vector. *Normal* must be a normalized vector, |normal| = 1.

polygon [Class]

**Polygon** represents a loop on a plane. *Convexp* is a boolean flag representing the convexity of the loop. *Edges* is a list of edges forming the contour of this loop, and *vertices* is a list of vertices.

#### :box &optional tolerance

[method]

returns a bounding-box for this polygon.

#### :boxtest box2 &optional tolerance

[method]

makes a bounding-box for this polygon, and returns the intersection of the bounding-box and box2. If there is no intersection, NIL is returned.

:edges [method]

returns the list of edges (circuit) of this polygon. The list is ordered clockwise when the polygon is viewed along the normal vector of this plane. If you think of the normal vector as a screw, the edges are ordered in the rotation direction for the screw to screw in. When polygon or face is used for the surface representation of a solid object, the normal vector is directed to its outside region. When a polygon is viewed from the outside of the object, edges are ordered counter-clockwise.

 $: \mathbf{edge} \ n$  [method]

returns the n-th element of edges.

:vertices [method]

returns the vertices of this polygon ordered in the same manner as edges. Note that the first vertex is copied duplicatedly at the end of the list and the list is always longer by one than the actual number of vertices. This is for the ease of edge traversal by using the vertices list.

:vertex n [method]

returns the n-th element of vertices.

#### :insidep point & optional (tolerance \*epsilon\*)

[method]

returns :inside, :outside or :border according to the location of *point* relative to this region.

## :intersect-point-vector point vnorm

[method]

Computes the intersection with the semi-line defined by the *point* and the normalized direction vector, *vnorm*.

:intersect-line p1 p2 [method]

Computes intersection point with a line specified by p1 and p2. The result is nil(no intersection) or list of the parameter and the intersection position.

:intersect-edge edge [method]

Computes intersection point with a line specified by the *edge*. The result is nil(no intersection) or list of the parameter and intersection position.

## :intersect-face aregion

[method]

Returns T if this region intersects with aregion.

:transform-normal [method]

:reset-normal [method]

recomputes the surface normal vector of this polygon from the current vertices list.

:invert [method]

:area [method]

returns the area of this polygon.

:init &key vertices edges normal distance

[method]

face [Class]

:super **polygon** 

:slots (holes mbody primitive-face id)

defines a face which may have holes. *Pbody* and *type* represent the primitive body and the type (:top, :bottom, :side) of the face in the body.

:all-edges [method]

:all-vertices [method]

Returns all the edges or vertices of the contour of this face and all the inner loops (holes). Note that **:edges** and **:vertices** methods only return edges and vertices composing the contour.

:insidep point [method]

decides whether the point is inside of this face or not. If the point is inside the outer contour of this face but also inside the loop of any holes, it is classified as outside.

:area [method]

returns the area of this face, that is the area surrounded by external edges subtracted by the areas of holes.

## :centroid &optional point

[method]

returns a list of the floating-point number and the float-vector representing the center-of-gravity of this face. If *point* is not given, the first number represents the area of this polygon, and the second float-vector the location of center-of-gravity of this polygon. If *point* is given, it is taken as the top vertex of the cone whose bottom face is formed by this polygon, and the volume of this cone and its center-of-gravity are returned.

:invert [method]

flips the direction of this face. The normal vector is inverted, and the order of edge loop is reversed.

:enter-hole hole [method]

adds a hole in this face.

:primitive-body [method]

returns the primitive-body which has defined this face.

:id [method]

returns one of (:bottom), (:top) and (:side seq-no.).

:face-id [method]

returns a list of the type of primitive-body and the face type. For example, a side face of a cylinder returns ((:cylinder radius height segments) :side id).

:body-type [method]

returns primitive body which has defined this face.

 $\textbf{:init} \ \textit{\&key normal distance edges vertices holes}$ 

[method]

hole [Class]

:super **polygon** :slots (myface)

hole is a polygon representing an inner loop of a face. A face may have a list of holes in its holes slot.

:face [method]

returns a face that contains this hole.

:enter-face face [method]

makes a link to a face which surrounds this hole. This method is only used in conjunction with the :enter-hole method of the face class.

:init &key normal distance edges vertices face

[method]

#### 14.4Body

body [Class]

:super cascaded-coords

(faces edges vertices model-vertices box convexp evertedp csg) :slots

defines a three dimensional shape.

:magnify rate [method]

changes the size of this body by rate. Magnification is recorded in csg list.

:translate-vertices vector [method]

translates model-vertices. Vector should be given in the local coordinates. Translation is recorded in csg list.

:rotate-vertices angle axis [method]

rotates model-vertices angle radian around axis. Rotation is recorded in csg list.

:reset-model-vertices [method]

:newcoords rot &optional pos [method]

changes coordinates. If pos is not given, rot is given as a instance of coordinate class.

:vertices [method]

returns the list of all vertices of this body.

:edges [method]

returns the list of all edges of this body.

:faces [method]

returns the list of all the faces composing this body.

:box [method]

returns the bounding-box of this body.

:Euler [method]

calculates Euler number of this body, that is faces + vertices - edges - 2 - holes. This should equal to -2rings.

[method] :perimeter

returns the sum of length of all the edges.

**:volume** & optional (reference-point #f(0 0 0)) [method]

returns the volume of this body.

:centroid &optional (point #f(0 0 0) [method]

returns the location of center-of-gravity assuming that this body is homogeneously solid.

:possibly-interfering-faces box [method]

:common-box body [method]

Returns common minimal box for this body and another body. If there is interference between two bodies, the intersection must exist in this common-box.

:insidep point [method]

returns :inside if *point* resides in this body, :border if *point* lies on a surface of this body, and :outside otherwise.

:intersect-face face [method]

returns T if there is an interference between the faces of this body and face.

:intersectp body [method]

Checks intersection with another body.

:evert [method]

reverse the directions of all the faces and edges so that the inside of this body becomes outside.

#### :faces-intersect-with-point-vector point direction

[method]

collects all faces that intersect with a vector casted from *point* towards em direction.

:distance target

target may either be a float-vector or a plane object. :distance finds the closest face from target and returns a list of the face and the distance.

:csg [method]

returns csg body construction history.

:primitive-body [method]

returns a list of primitive bodies which have constructed this body.

:primitive-body-p [method]

T if this body is a primitive body created by one of functions listed in 14.5.

:creation-form [method]

returns a Lisp expression to create this body.

:body-type [method]

returns a list of creation parameters if this body is a primitive body, or an expression indicating this body is a complex (composed) body.

:primitive-groups [method]

returns a list of two elements. The first is a list of primitive bodies that is added (body+) to compose this body. The latter is a list of subtracted primitive-bodies.

## :get-face &optional body face id

[method]

body is an instance of body that has composed this body, one of primitive-body types such as :cube, :cylinder, :prism, :cone, :solid-of-revolution, etc., or nil. If neither face nor id is given, all the faces that matches body is returned. If face is given, further filtering is performed. face must be one of :top, :bottom and :side. (send abody :get-face :cylinder :top) returns all the top faces of cylinders that compose abody. If face is :side, you can pick up faces that are numbered as id. (send abody nil :side 2) returns all the third (id begins from zero) side faces for any primitive-type bodies.

#### :init &key faces edges vertices

[method]

initializes this body from :faces. :face is a required argument. Since face, edge and vertex must

maintain consistent relation to define a complete solid model, it is meaningless to call this method with inconsistent arguments. In order to create bodies, use the primitive body creating functions described in section 14.5 and the body composition functions in section 14.6.

: $\operatorname{constraint} b$  [method]

returns self's constraint when self is in contact with b. Details of are given in section 14.8.

## 14.5 Primitive Body Creation

#### make-plane &key normal point distance

[function]

Makes a plane object which is oriented to *normal*, and passes *point*. Instead of giving *point*, *distance* can be specified.

\*xy-plane\* [variable]

\*yz-plane\* [variable]

\*zx-plane\* [variable]

## make-cube xsize ysize zsize &key name color

[function]

makes a cuboid whose sizes in x, y and z directions are *xsize*, *ysize* and *zsize*. The coordinates origin of this cuboid locates at the center of the body.

#### make-prism bottom-points sweep-vector &key name color

[function]

Makes a prism by lifting the shape defined by bottom-points along sweep-vector. If the sweep-vector is a number, not a float-vector, it is taken as the height of the prism in the z direction. Bottom points must be ordered as they define the bottom face of the body. For example, (make-prism '(#f(1 1 0) #f(1 -1 0) #f(-1 1 0)) 2.0) makes a cube of height 2.0.

## make-cylinder radius height &key (segments 12) name color

[function]

Makes a cylinder with specified *radius* and *height*. The bottom face is defined on xy-plane and the coordinates origin is located at the center of the bottom face.

## make-cone top bottom &key (segments 16) color name

[function]

makes a cone body whose summit is the *top* and bottom face is the *bottom*. *Top* is a 3D float-vector. *Bottom* is either a list of vertices of the bottom face or a radius (scalar). If it is the vertices list, it is order sensitive. (make-cone #f(0 0 10) (list #f(10 0 0) #f(0 10 0) #f(-10 0 0) #f(0 -10 0))) makes a cone of a square bottom.

## make-solid-of-revolution points &key (segments 16) name color

[function]

Points are revolted along z-axis in the clock wise direction. If two end points in the points list do not lie on z axis, those points make circular faces. Thus, (make-solid-of-revolution '(#f(0 0 1) #f(1 0 0))) makes a cone, and (make-solid-of-revolution '(#f(1 0 1) #f(1 0 0))) makes a cylinder. The points are order-sensitive, and are expected to be arranged from higher z coordinate to lower z.

#### make-torus points &key (segments 16) name color

[function]

makes a torus, a donuts like object. Points is a list of vertices on a cross-section.

#### make-icosahedron & optional (radius 1.0)

[function]

Makes a regular body of twenty faces. Each face is a regular triangle.

## make-dodecahedron & optional (radius 1.0)

[function]

Makes a regular body of twelve faces. Each face is a regular pentagon.

14. Geometric Modeling 138

make-gdome abody [function]

By subdividing triangle faces of abody into four subfacets, makes a geodesic dome as a new body. Abody should be an icosahedron initially, and then the result of make-gdome can be given to make-gdome recursively. At each call, the number of faces of the Gdome increases by the factor of four, i.e. 20, 80, 320, 1280, 5120, etc.

```
(setq g0 (make-icosahedron 1.0)); 20 facets
(setq g1 (make-gdome g0)); 80 facets
(setq g2 (make-gdome g1)); 320 facets
```

**grahamhull** vertices & optional (normal #f(0 0 1))

[function]

Computes convex-hull for 2D points by Graham's algorithm. Slower than quickhull.

quickhull vertices & optional (normal #f(0 0 1))

[function]

Computes convex-hull for 2D points by the binary search method.

convex-hull-3d vertices

[function]

Computes convex-hull for 3D points by gift-wrapping method.

make-body-from-vertices vertices-list

[function]

creates a body from lists of vertices each of which define a loop of a face in the consistent order.

## 14.6 Body Composition

face+ face1 face2 [function]

face\* face1 face2 [function]

face1 and face2 are coplanar faces in 3D space. face+ composes union of these faces and returns a face object. If there is no intersection, original two faces are returned. face\* returns intersection of these faces. If there is no intersection, NIL is returned.

 ${\bf cut\text{-}body}\ body\ cutting\text{-}plane$ 

[function]

Cuts a body by the *cutting-plane* and returns a list of faces made at the cross-section.

body+ body1 body2 &rest more-bodies

[function]

body- body1 body2 [function]

body\* body1 body2 [function]

Computes join, difference or intersection of two or more bodies. Each body is copied before each body+, body- and body\* operation, and original bodies are unchanged. The new coordinates of the resulted body is located and oriented at the same location and orientation as the world coordinates. Even when two bodies are touching face by face, these functions are expected to work correctly if threshold parameters \*coplanar-threshold\*, \*contact-threshold\*, and \*parallel-threshold\*

14. Geometric Modeling

139

are properly set. However, if a vertex of a body is in contact with an edge or a face of the other body, any composition operation fails.

body/ body plane [function]

Cut the body by a plane which is an instance of class plane (made by **make-plane**). A newly created body is returned.

## $\textbf{body-interference} \ \mathscr{C}rest \ bodies$

[function]

Checks interference between each one-to-one combination in *bodies*. Returns a list of two bodies that are intersecting.

## 14.7 Coordinates-axes

Class coordinates-axes defines 3D coordinates-axes drawable on a screen. Each axis and an arrow at the tip of z-axis are defined by line objects. Since the coordinates-axes class inherits cascaded-coords, a coordinates-axes object can be attached to another cascaded-coords originated object such as a body. This object is used to see the coordinates-axes of a body or a relative coordinates to another coordinates.

coordinates-axes [Class]

:super cascaded-coords

:slots (size model-points points lines)

Defines drawable 3-D coordinates-axes.

#### 14.8 Bodies in Contact

The method and functions described in this subsection require **contact/model2const.l**, **contact/inequalities.l**, **contact/drawconst.l**.

constrained-motion c [function]

returns the possible motions which satisfy the constraint c.

returns the force which is applicable from the constrained body to the constraining body.

draws the constraint c.

**draw-motion**m a b [function]

draws the possible motions of a in contact with b. Type the return key for drawing.

Example

```
;;
        peg in a hole with 6 contact points
;;
;;
(in-package "GEOMETRY")
(load "view")
(load "../model2const.1" :package "GEOMETRY")
(load "../inequalities.l" :package "GEOMETRY")
(load "../drawconst.l" :package "GEOMETRY")
(setq x (make-prism '(#f(50 50 0) #f(50 -50 0) #f(-50 -50 0) #f(-50 50 0))
                    #f(0 0 200)))
(setq x1 (copy-object x))
(send x1: translate #f(0 0 -100))
(send x1 :worldcoords)
(setq a1 (make-prism '(#f(100 100 -150) #f(100 -100 -150)
                       #f(-100 -100 -150) #f(-100 100 -150))
                     #f(0 0 150)))
(setq ana (body- a1 x1))
(send x : translate #f(0 -18.30127 -18.30127))
(send x:rotate -0.523599:x)
(send x :worldcoords)
(setq c (list (send x :constraint ana)))
(setq m (constrained-motion c))
(setq f (constrained-force m))
(hidd x ana)
(draw-constraint c)
(draw-motion m)
```

# object

header slot 1 slot 2 . . .

## vector


header
size
element 1
element 2

## header


31 30 29 27 26 24 23 16 15 ... m b elmt bid mark cid

m: memory bit for buddy b: buddy bit for buddy mark(3bit): GC, copy and print elmt(3bits): type of vector elements bid(8bits): buddy id (1..31) cid(16bits): class id (0..255)


```
object
     cons
          queue
     propertied-object
          symbol ---- foreign-pod
          package
          stream
               file-stream
               broadcast-stream
          io-stream ---- socket-stream
          metaclass
               vectorclass
                   cstructclass
          read-table
          array
          thread
          barrier-synch
          synch-memory-port
          coordinates
               cascaded-coords
                    body
                    sphere
                    viewing
                         projection
                              viewing2d
                              parallel-viewing
                              perspective-viewing
                    coordinates-axes
               viewport
          line --- edge --- winged-edge
          plane
               polygon
                    hole
               semi-space
          viewer
          viewsurface ---- tektro-viewsurface
     {\tt compiled-code}
          foreign-code
          closure
          load-module
     label-reference
     vector
          float-vector
          integer-vector
          string
               socket-address
               cstruct
          bit-vector
          foreign-string
     socket-port
     pathname
     hash-table
     surrounding-box
     stereo-viewing
```




 $\ensuremath{\boxtimes}$  5: Solaris operating system's thread model



 $\ensuremath{\boxtimes}$  6: Parallel threads requesting memory and GC running in parallel



☑ 7: Thread-object for transferring control and data between threads (left) and the collection of threads put in the thread-pool.



 $\ensuremath{\boxtimes}$ 8: Barrier synchronization and synchronozed memory port








図 9: Arrangements of vertices, edges, and faces




The following figures shows examples of constraints. The small arrows in the figures designate the constraints for the pegs.













The following figures shows an example of the possible motions of a peg in a hole. The example corresponds to the above program.









## 14.9 Voronoi Diagram of Polygons

Author: Philippe PIGNON, ETL Guest Researcher

153

The program is written in COMMON LISP. I used the method of Fortune, "A sweepline algorithm for Voronoi diagrams", in Proceedings of the 2nd Annual ACM symposium on computational geometry, 1986, 313-322. I adapted it to the polygonal case. This is a sample file with short explanations This program was written under Electrotechnical EUSLISP environment, so graphic connections are provided for it. However, you can use it with any COMMON-LISP; you'll then have to write your own display functions to replace those given in utilities.l file (see below)

**PURPOSE:** Computation of the voronoi diagram of a set of polygons. Please read the above quoted reference to understand the vocabulary and method used. No explanations about the program itself will be given here.

INPUT: A list of polygons coordinates plus an enclosing frame.

Enclosing frame can occur anywhere in data, and should be clockwise enumerated for outside-inside marking consistency (see below). Polygons must be simple, non intersecting. Aligned or flat edges are not accepted. Neither are isolated points or segments.

**OUTPUT:** \*diagram\*: a list of doubly connected edges list (cf utilities.l file). Each edge is a symbol, with property list including the following fields:

```
(start <pointer to a vertex>)
      (end <pointer to a vertex>)
      (pred <pointer to an edge>)
      (succ <pointer to an edge>)
      (left <pointer to a site>)
      (right <pointer to a site>)
      (type <:endpoint or :point-point or :segment-segment or :point-segment>)
      (outflag <t or nil>)
```

A vertex is a symbol whose property list contains the field "pos". This field itself contains a cons (xy), (real) planar coordinates of the vertex. Pred and succ field give counterclockwise predecessor and successor according to the dcel formalism (see Shamos and Preparata, Computational Geometry: An introduction, 1985, pp 15-17). A site is also a symbol, whose property list also contains relevant information. Sites describe original input data; they can be of type :point (a polygon vertex) or segment (a polygon edge).

Type is the gender of the bisector, determined by the type of the sites it separates. By convention, outside is the right side of a start-end edge. The voronoi diagram computes ouside as well as inside bisectors. Sort on outflag to keep the ones you want.

**SAMPLE:** In order to run the program on a short sample, please perform the following steps: 0- Copy the following files in your environment:

utilities.l Geometric utility functions, plus EUSX graphic functions

polygonalvoronoi.l The program.

testdata.l Demonstration data, with the above format.

- 1- If you do not use EUS, edit the utilities.l file and modify the "compatibility package" according to the instructions.
- 2- Compile and/or load the following 3 files:

utilities.l

 ${\it polygonal voronoi.l}$ 


testdata.l This file contains demonstration data, with the above format

3- (pv demoworld) run the program on demonstration data. The global variable \*diagram\* contains the bisectors of the voronoi diagram.

Under EUSX only (eus with XWindow interface), do the following to display the resulting diagram:

pv data [function]

Compute the Voronoi diagram of polygons from the data with the above format.



☑ 13: viewing coords and projection planes

# 15 Viewing and Graphics

## 15.1 Viewing

A viewing object manages viewing coordinate system whose origin is located at the position of a virtual camera, -z axis is oriented to the objects observed, and xy-plane is the projection screen. Since viewing inherits class cascaded-coords, it accepts coordinates transformation message such as :translate, :rotate and :transform. Also, it can be attached to another object derived from cascaded-coords, allowing the simulation of the camera-on-mobile-object system. The main purpose of viewing is to transform vectors represented in the world to the camera coordinates system. The transformation is taken in the opposite direction against usual coordinate transformation where vectors in the local coordinates are transformed into the representation in the world. Therefore, viewing holds the inversed left-handed transformation in the viewcoords slot, which is usually referred as the viewing coordinate system.

viewing [Class]

:super cascaded-coords :slots (viewcoords)

defines the viewing transformation.

:viewpoint [method]

returns the position vector of the origin of this viewing.

:view-direction [method]

returns the vector from the origin of the viewing to the center of screen. This is the z-axis direction

of the viewing coordinates.

:view-up [method]

returns y-axis vector of this viewing represented in the world coords. Y-axis is the upward direction in the viewport.

:view-right [method]

returns x-axis vector of this viewing represented in the world coords. X-axis is in horizontal direction to the right in the viewport.

```
:look from &optional (to #f(0 0 0))
```

[method]

:look conveniently sets the viewing coords as the eye is located at from and looking at to point.

:init [method]

```
Ekey (target \#f(0\ 0\ 0))
(view-direction nil)
(view-up \#f(0.0\ 0.0\ 1.0))
(view-right nil)
&allow-other-keys
```

Since viewing inherits cascaded-coords, all the *:init* parameters such as *:pos, :rot, :Euler, :rpy,* etc. can be used to specify the location and the orientation of the viewing coordinates. However, viewing's *:init* provides easier way to determine the rotation. If only *:target* is given, view-line (-z axis) is determined to pass the viewpoint and *:target* point, and the *:view-right* vector is determined so that the x-axis is parallel to the xy-plane of the world coordinates. You may specify *:view-direction* instead of *:target* to get the same effect. If you give *:view-up* or *:view-right* parameter in addition to *:target* or *:view-direction*, you can determine all the three rotation parameters by yourself.

# 15.2 Projection

Class parallel-projection and perspective-projection process projection transformation, which is represented with a 4X4 matrix, i.e., the transformation is taken in the three dimensional homogeneous coordinates. Class projection is an abstract class for both of these. Since these projection classes inherit the viewing class, two coordinates transformation, world-to-viewing and projection can be performed at the same time. By sending the :project3 message with a 3D vector to a projection object, a float-vector of four elements is returned. Homo2normal function is used to convert this homogeneous vector to the normal representation. The result is a vector represented in so called normalized device coordinates (NDC), in which a visible vector ranges within -1 to 1 in each of x,y, and z dimensions. For the simulation of real cameras in a robot world, the perspective projection is used more often than the parallel-projection. Perspective-projection defines a few more parameters. Screenx and screeny are the sizes of the window on the viewing plane on which observed objects are projected, and with the larger screen, the wider space is projected. Viewdistance which defines the distance between the viewpoint and the viewplane also concerns with the viewing angle. The larger viewdistance maps the smaller region to the window on the view plane. Hither and yon parameters determine the distance to the front and back depth clipping planes. Objects outside these two planes are clipped out. Actually, this clipping procedure is performed by the viewport object.

projection [Class]

:slots (screenx screeny hither you projection-matrix)

defines projection transformation with a 4x4 matrix.

## :projection &optional pmat

[method]

if *pmat* is given, it is set to the *projection-matrix* slot. **:projection** returns the current 4x4 projection matrix.

:project vec

Vec is a three-dimensional homogeneous float-vector of four elements. Vec is transformed by projection-matrix, and the resulted homogeneous representation is returned.

:project3 vec [method]

Vec is a normal 3D float-vector. Vec is homogenized and transformed by projection-matrix, and the resulted homogeneous representation is returned.

:view vec [method]

applies viewing transformation and projection transformation to *vec* successively. The resulted homogeneous representation is returned.

## :screen xsize (&optional (ysize xsize))

[method]

changes the size of the viewing screen. The larger the size, the wider view you get.

#### $\textbf{:hither} \ \textit{depth-to-front-clip-plane}$

[method]

determines the distance from the viewpoint to the front-clipping plane. Objects before the front-clipping (hither) plane are clipped out.

## :yon depth-to-back-clip-plane

[method]

changes the distance between the viewpoint and the back-clipping plane. Objects behind the back-clipping (yon) plane are clipped out.

## :aspect &optional ratio

[method]

Aspect ratio is the ratio between screen-y and screen-x. If *ratio* is given, the aspect ratio is changed by setting screen-y to screen-x \* *ratio*. :aspect returns the current aspect ratio.

:init [method]

```
&key (hither 100.0)
(yon 1000.0)
(aspect 1.0)
(screen 100.0)
(screen-x screen)
(screen-y (* screen-x aspect))
&allow-other-keys
```

initializes viewing and projection.

# parallel-viewing

[Class]

:super **projection** :slots

defines parallel projection. Hid (the hidden-line elimination function) cannot handle parallel projec-

tion.

:make-projection [method]

# perspective-viewing

[Class]

:super **projection** :slots (viewdistance)

defines a perspective projection transformation.

:make-projection [method]

[method]

returns the normalized direction-vector pointing (u,v) on the normalized screen from the viewpoint.

#### :viewdistance &optional vd

[method]

Viewdistance is the distance between viewpoint and the screen. If vd is given, it is set to viewdistance. The viewdistance corresponds to the focal length of a camera. The greater the viewdistance, the more zoomed-up view you get. :viewdistance returns the current viewdistance.

#### :view-angle &optional ang

[method]

set screen size so that the prospective angle of the diagonal of the screen becomes *ang* radian. Note that angles somewhat between 20 degree (approx. 0.4 rad.) and 50 degree (0.9 rad.) can generate a natural perspective view. Wider angle generates a skewed view, and narrower a flat view like orthogonal (parallel) viewing. :view-angle returns current or new view angle in radian.

:zoom & optional scale [method]

If *scale* is given, the screen is changed relatively to the current size by *scale* (the viewdistance is unchanged). If you give 0.5 for *scale*, you get two times as wide view as before. **:zoom** returns new view angle in radian.

## :lookaround $alfa\ beta$

[method]

translates and rotates the viewpoint. The center of rotation is taken at the midst of the hither plane and the you plane on the viewline. The viewing coordinates is rotated *alfa* radian around world's z-axis and *beta* radian around x-axis locally. :lookaround allows you to move around the object in the center of viewing.

## :look-body bodies [method]

changes view direction, screen sizes, and hither/yon so that all the *bodies* fit in the viewport. Viewpoint does not change. View direction is chosen so that the viewing line penetrate the center of the bounding box of all bodies.

:init &key (viewdistance 100.0) &allow-other-keys

[method]

## 15.3 Viewport

Class **viewport** performs three-dimensional viewport clipping in the normalized device coordinates, and maps the result into the device dependent coordinates. The viewport is the term representing the visible rectangular area on a screen. The physical size (dots in x and y) of a viewport should be given with **:init** message as the *:width* and *:height* arguments. *:xcenter* and *:ycenter* arguments determine the physical location of the viewport. These two parameters actually decide the location where objects are drawn on the screen when you are using a primitive display device like tektronics 4014 on which every dimension must be given absolutely to the origin of the screen. If you are using more sophisticated display device like Xwindows where locations can be determined relatively to the parent window, you need not to change viewport's parameters to move the viewport. These parameters are independent of the actual display location.

Viewport class assumes the origin of the viewport at the lower-left corner of the rectangular area and y-axis extends to the upper direction. Unfortunately, in many window systems and display devices, the origin is taken at the upper-left corner and y-axis extends to the lower direction. To work around this problem, a negative value should be given to the *:height* parameter.

## homo-viewport-clip v1 v2

[function]

V1 and v2, which are two homogeneous vectors with four elements, represent a line in 3-D space. The line is clipped at the boundary of x = -1, x = 1, y = -1, y = 1, z = 0, z = 1, and a list of two vectors are returned. If the line lies completely outside the viewport, NIL is returned.

viewport [Class]

:super coordinates

:slots

viewport transformation maps the NDC (normalized device coordinates) to device specific coordinates. Inheriting the **coordinates** class, the **viewport** defines the size and the relative position of the projection screen.

:xcenter &optional xcenter

[method]

X coordinates of the center of this viewport.

:ycenter &optional ycenter

[method]

Y coordinates of the center of this viewport.

:size &optional size

[method]

List of sizes in x direction and y direction.

:width &optional width

[method]

width of this viewport.

:height &optional height

[method]

height of this viewport.

## :screen-point-to-ndc p

[method]

p is a float-vector representing the location in the physical screen. p is transformed into the representation in the normalized-device coordinates.

## :ndc-point-to-screen p

[method]

NDC representation in this viewport, p, is transformed into the physical address on the screen.

## :ndc-line-to-screen p1 p2 &optional (do-clip t)

[method]

Two 3D float-vectors, p1 and p2, define a line in NDC. These two end points are transformed to the representation in the screen space. If do-clip is non-nil, the line is clipped.

:init &key (xcenter 100) (ycenter 100) (size 100) (width 100) (height 100) makes a new viewport object.

[method]

#### 15.4 Viewer

To get a drawing on a screen, four objects are needed: (1) objects to be drawn, (2) a viewing which defines the viewing coordinates and the projection, (3) a viewport for clipping in NDC and the transformation from NDC to physical screen coordinates, and (4) a viewsurface which performs drawing functions on a physical display device. A **viewer** object holds a viewing, a viewport and a viewsurface object, and controls successive coordinates transformation. Functions **draw** and **hid** described in section 15.5 use the instances of viewer.

viewer [Class]

:super object

:slots (eye :type viewint)

(port :type viewport) (surface :type viewsurface)

defines the cascaded coordinates transformation from the viewing via the viewport to the viewsurface.

:viewing &rest msg

If msg is given, msg is sent to the **viewing(eye)** object, Otherwise, the **viewing(eye)** object is returned.

:viewport & rest msq [method]

If msg is given, msg is sent to the **viewport(port)** object, Otherwise, the **viewport(port)** object is returned.

:viewsurface & rest msg

If msg is given, msg is sent to the **viewsurface**(surface) object, Otherwise, the **viewsurface**(surface) object is returned.

:adjust-viewport [method]

When the size of viewsurface has been changed, **:adjust-viewport** changes viewport transformation sending a proper message to port.

:resize width height [method]

changes the size of viewsurface by sending :resize message to the viewsurface and :size message to viewport.

## :draw-line-ndc p1 p2 &optional (do-clip t)

[method]

draws a line whose two end points p1, p2 are defined in NDC.

## :draw-polyline-ndc polylines &optional color

[method]

draws polylines whose end points are defined in NDC.

:draw-star-ndc center &optional (size 0.01) color [method] draws a cross mark in NDC. :draw-box-ndc low-left up-right Goptional color [method] draws a rectangle in NDC. :draw-arc-ndc point width height angle1 angle2 &optional color [method] draws an arc in NDC. The viewsurface object bound in this viewer must accept :arc message. :draw-fill-arc-ndc point width height angle1 angle2 &optional color [method] draws a filled-arc in NDC. :draw-string-ndc position string &optional color [method] draws string at position defined in NDC. [method] :draw-image-string-ndc position string Goptional color :draw-rectangle-ndc position width height Goptional color [method] :draw-fill-rectangle-ndc point width height &optional color [method] :draw-line p1 p2 & optional (do-clip t) [method] draws a line whose two end points p1, p2 are defined in the world coordinates. :draw-star position &optional (size 0.01) color [method] draws a cross at *position* located in the world. :draw-polyline vlist &optional color [method] draws polylines whose end points *vlist* are defined in the world. :draw-box center &optional (size 0.01) [method] draws a rectangular at *center* in the world. [method] :draw-arrow p1 p2 draws an arrow from p1 to p2. [method] :draw-edge edge:draw-edge-image edge-image [method] :draw-faces face-list &optional (normal-clip nil) [method] :draw-body body &optional (normal-clip nil) [method] :draw-axis coordinates &optional size [method] draws coordinates axes whose length is size.

:draw & rest things

draws 3D geometric objects. If the object is a 3D float-vector, a small cross is drawn at the position. If it is a list of 3D float-vectors, it is taken as a polyline. If *thing* accepts :draw message, the method is invoked with this viewer as its argument. If the object defines :drawners method, the :draw message is sent to the result of :drawners. Line, edge, polygon, face, and body objects are drawn by corresponding :draw-xxx methods defined in viewer.

 $\textbf{:erase} \ \mathscr{C}rest \ things \\ [method]$ 

draws things with background color.

:init &key viewing viewport viewsurface

[method]

sets viewing, viewport and viewsurface to eye, port, and surface slots of this viewer.

view [function]

```
&key (size 500) (width size) (height size)
(x 100) (y 100)
(title "eusx")
(border-width 3)
(background 0)
(viewpoint #f(300 200 100)) (target #f(0 0 0))
(viewdistance 5.0) (hither 100.0) (yon 10000.0)
(screen 1.0) (screen-x screen) (screen-y screen)
(xcenter 500) (ycenter 400)
```

creates a new viewer and pushes it in \*viewers\* list.

## 15.5 Drawings

#### draw &optional viewer &rest thing

[function]

draws things in viewer. Thing can be any of coordinates, body, face, edge, float-vector, list of two float-vectors. If you are running eusx, (progn (view) (draw (make-cube 10 20 30))) draws a cube in a xwindow.

#### draw-axis &optional viewer size &rest thing

[function]

draws coordinate-axes of *things* in *viewer* with *size* as the length of each coordinates-axis. *Thing* can be any object derived from coordinates.

#### draw-arrow p1 p2

[function]

draws an arrow pointing from p1 to p2 in \*viewer\*.

## hid Goptional viewer Grest thing

[function]

draws hidden-line eliminated image in viewer. Thing can be of face or body.

#### hidd &optional viewer &rest thing

[function]

is same as  $\mathbf{hid}$ , except that  $\mathbf{hidd}$  draws hidden lines with dashed-lines.

## hid2 body-list viewing

[function]

Generate hidden-line eliminated image represented by edge-image objects. The result is bound to \*hid\*.

# render &key bodies faces (viewer \*viewer\*) (lights \*light-sources\*) (colormap \*render-colormap\*) (y 1.0)

[function]

does ray-tracing for bodies and faces and generates hidden-surface removed images. viewing, viewport, and viewsurface are taken from viewer. lights is a list of light-source objects. colormap is xwindow's colormap object. Each of bodies and faces must have color attribute assigned. This can be done by sending :color message with the name of color LUT defined in the colormap. Currently this function works only in Xlib environment. See examples in demo/renderdemo.1.

#### make-light-source pos & optional (intensity 1.0)

[function]

make a light-source object located at *pos. intensity* is magnifying ratio which multiplies default light intensity. In order to determine the intensity more precisely, use :intensity method of a light-source.

#### tektro file &rest forms

[macro]

opens file for \*tektro-port\* stream, and evaluates forms. This is used in order to redirect the output of tektro drawings to a file.

#### kdraw file &rest forms

[macro]

Kdraw is a macro to produce a [ik]draw-readable postscript file. Kdraw opens file in :output mode, makes a kdraw-viewsurface and a viewport with which \*viewer\* is replaced, and evaluates forms. Each of forms is a call to any of drawing functions like draw or hid. Drawing messages from these forms are redirected to a kdraw-viewsurface, which transforms the messages into postscript representations that idraw or kdraw can recognize, and stores them in file. When idraw or kdraw is invoked and file is opened, you see the identical figure you drew in a EusViewer window. The figure can be modified by idraw's facilities, and the final drawing can be incorporated into a IATEX document using the epsfile environment.

#### pictdraw file &rest forms

[macro]

Pictdraw is a macro to produce picture files for Macintosh in PICT format. Pictdraw opens file in :output mode makes a pictdraw-viewsurface and a viewport with which \*viewer\* is replaced, and evaluates forms. Each of forms is a call to any of drawing functions like draw or hid. Drawing messages from these forms are redirected to a kdraw-viewsurface, which transforms the messages into PICT format that macdraw or teachtext of Macintosh can recognize, and stores them in file.

#### hls2rgb hue lightness saturation & Optional (range 255)

[function]

Color representation in HLS (Hue, Lightness, and Saturation) is converted to RGB representation. HLS is often referred to as HSL. *Hue* represents a color around a rainbow circle (from 0 to 360). 0 for red, 45 for yellow, 120 for green, 240 for blue, 270 for magenta, and 360 again for red, etc. *Lightness* is a value between 0.0 and 1.0, representing from black to white. The color of lightness value of 0 is always black regardless to the hue and saturation, and the lightness value 1.0 is always white. *Saturation* is a value between 0.0 and 1.0, and represents the strength of the color. The greater the saturation value, the divider the color, and small saturation values generate weak, dull tone colors. *Range* limits the RGB values. If you are using a color display which can assign 8bit value to each of red, green and blue, *range* should be 255. If you use Xwindow, which virtually assigns 16bits integers to RGB, you should specify *range* to 65535. Note the difference between HSV and HLS. In HLS, vivid (rainbow) colors are defined with lightness=0.5.

rgb2hls red green blue &optional (range 255)

[function]

RGB representation of a color is converted into the corresponding representation in HLS.

## 15.6 Animation

EusLisp's animation facility provides the pseudo real-time graphics on stock workstations without graphics accelerators. The basic idea is the quick playback of a series of images which have been generated after long computation. Images are retained in two ways: one is to keep a number of xwindow pixmaps each of which holds a complete pixel image, and the other is to keep line segment data obtained by hidden-line elimination. The former is faster and the only way for rendered images, but not suitable for a long animation since it requires much memory in the X server. The latter is more memory efficient and suitable for storing data in disks, but the performance is degraded when the number of line segments increases.

In either way, the user provide a function which gives new configurations to the objects to be drawn and generates drawing on \*viewer\*. pixmap-animation calls this function as many times as specified by the *count* argument. After each call, the content of \*viewsurface\*, which is assumed to be an xwindow, is copied to a newly created Xwindow pixmap. These pixmaps are played back by playback-pixmaps. Similarly, hid-lines-animation extracts visible line segments from the result of hid, and accumulates them in a list. The list is then played back by playback-hid-lines.

Following functions are defined in llib/animation.1, and demo/animdemo.1 contains a sample animation program using hid-lines-animation on the ETA3 manipulator model.

## pixmap-animation count &rest forms

[macro]

forms are evaluated count times. After each evaluation, the content of \*viewsurface\* is copied in a new pixmap. A list of count pixmaps is returned.

## playback-pixmaps pixmaps & optional (surf \*viewsurface\*)

[function]

Each pixmap in the pixmaps list is copied to surf successively.

# $\textbf{hid-lines-animation} \ \ count \ \ \mathscr{C}rest \ forms$

[macro]

forms, which are assumed to include call(s) to **hid**, are evaluated count times. After each evaluation, the result of **hid** held in \*hid\* is scanned and visible segments are collected in a list of point pairs. A list of length count is returned.

## playback-hid-lines lines & optional (view \*viewer\*)

[function]

lines is a list of lists of point pairs. draws lines successively on view. Double buffering technique allocating another pixmap is used to generate flicker-free animation.

## list-visible-segments hid-result

[function]

collects visible segments from the list of edge-images hid-result.

## 16 Xwindow Interface

The Xwindow interface on EusLisp becomes available when EusLisp is invoked by the name of 'eusx'. The "DISPLAY" environment variable should be properly set to your Xserver, since eusx tries to connect to Xserver referencing the "DISPLAY" environment variable when it starts up.

EusLisp defines three levels of xwindow interface: (1) Xlib functions, (2) Xlib classes, and (3) XToolKit classes. All the xwindow functions described in this section and the following XToolKit section are contained in the "X" package. The function names of the original Xlib are changed so that all constituent letters are converted to upcase and the first 'X' prefix is removed. For example, XdefaultGC is named X:DEFAULTGC, not X:XDEFAULTGC.

The Xlib functions are defined as foreign functions as the lowest level interface to Xwindow system. These Xlib functions should be used carefully, since parameter type check or parameter number check is not performed. For an instance, all the Xlib call requests x:\*display\* argument to identify the connection to Xserver, and if you forget it, Xlib reports an error and the process dies. The second level interface, Xlib classes are provided to avoid this inconvenience and to make the interface object-oriented. This section focuses on this second level interface. Even higher level xwindow library called XToolKit is explained in the next section.

Classes described in this section have the following inheritance hierarchy.

```
propertied-object
  viewsurface
    x:xobject
    x:gcontext
    x:xdrawable
        x:xpixmap
        x:xwindow
colormap
```

## 16.1 Xlib global variables and misc functions

```
x:*display*
                                                                                                     [variable]
      X's display ID (integer).
x:*root*
                                                                                                     [variable]
      default root window object.
x:*screen*
                                                                                                     [variable]
      default screen ID (integer).
x:*visual*
                                                                                                     [variable]
      default visual ID (integer).
x:*blackpixel*
                                                                                                     [variable]
      black pixel = 1
x:*whitepixel*
                                                                                                     [variable]
```

<sup>&</sup>lt;sup>3</sup>Eusx is a symbolic link to eus.

white pixel = 0

x:\*fg-pixel\* [variable]

default foreground pixel referenced at window creation, normally \*blackpixel\*.

x:\*bg-pixel\* [variable]

background pixel referenced at window creation, normally \*whitepixel\*.

x:\*color-map\* [variable]

the system's default color-map.

x:\*defaultGC\*

the default geontext referenced at pixmap creation.

x:\*whitegc\*

GC whose foreground color is white.

x:\*blackgc\*

GC whose foreground color is black.

\*gray-pixmap\* [variable]

the result of (make-gray-pixmap 0.5).

\*gray25-pixmap\* [variable]

16x16 pixmap, a quarter of pixels are \*fg-pixel\* and three quarters \*bg-pixel\*.

\*gray50-pixmap\* [variable]

16x16 pixmap, a half of pixels are \*fg-pixel\*.

\*gray75-pixmap\* [variable]

16x16 pixmap, three quarters of pixels are black.

\*gray25-gc\* [variable]

25% gray GC made from \*gray25-pixmap\*.

\*gray50-gc\* [variable]

50% gray GC made from \*gray50-pixmap\*.

\*gray75-gc\* [variable]

75% gray GC made from \*gray75-pixmap\*.

\*gray\* [variable]

"#b0b0b0"

\*bisque1\* [variable]

"#ffe4c4"

\*bisque2\* [variable]

"#eed5b7"

\*bisque3\* [variable]

"#cdb79e"

\*lightblue2\* [variable]

"#b2dfee" \*lightpink1\* [variable] "#ffaeb9" \*maroon\* [variable] "#b03060" \*max-intensity\* [variable] 65535 font-cour8 [variable] (font-id "\*-courier-medium-r-\*-8-\*") font-cour10 [variable] (font-id "\*-courier-medium-r-\*-10-\*") font-cour12 [variable] (font-id "\*-courier-medium-r-\*-12-\*") font-cour14 [variable] (font-id "\*-courier-medium-r-\*-14-\*") font-cour18 [variable] (font-id "\*-courier-medium-r-\*-18-\*") [variable] font-courb12 (font-id "\*-courier-bold-r-\*-12-\*") font-courb14 [variable] (font-id "\*-courier-bold-r-\*-14-\*") font-courb18 [variable] (font-id "\*-courier-bold-r-\*-18-\*") font-helvetica-12 [variable] (font-id "\*-Helvetica-Medium-R-Normal-\*-12-\*") [variable] font-lucidasans-bold-12 (font-id "lucidasans-bold-12") font-lucidasans-bold-14 [variable] (font-id "lucidasans-bold-14") font-helvetica-bold-12 [variable] (font-id "\*-Helvetica-Bold-R-Normal-\*-12-\*") [variable] font-a14 (font-id "\*-fixed-medium-r-normal-\*-14-\*") x:\*xwindows\* [variable] a list of all windows including subwindows created and maintained by EusLisp.

[variable]

x:\*xwindow-hash-tab\*

a hash table to look up the xwindow object by its drawable ID. In the event structure obtained by x:nextevent is a window ID, and x:window-main-loop calls x:event-window to know the corresponding xwindow object using this table.

xflush [function]

sends all commands retained in the Xlib command buffer to Xserver. Since Xlib buffers output to Xserver, commands you issued commands to Xserver are not executed immediately. This is necessary to decrease network traffic and the frequency of process switching. To flush the command buffer to see the effects of the commands, use **xflush** or send **:flush** message to xwindow objects.

find-xwindow subname [function]

Each xwindow may have name specified at the creation time. Find-xwindow looks in the \*xwindows\* list and returns a list of windows that have 'subname' as a substring of its name.

## 16.2 Xwindow

Xobject [Class]

:super **geometry:viewsurface** 

:slots

The common super class for all the Xwindow related classes. Currently, no slots variables and methods are defined.

Xdrawable

:super Xobject

:slots (drawable ; drawable ID

gcon ; this drawable's default graphic context object

bg-color ; background color

width height ; horizontal and vertical dimensions in dots

**Xdrawable** defines rectangular regions where graphics objects such as lines and strings can be drawn. **Xdrawable** is an abstract class to define common methods for xwindow and xpixmap, and instantiation of this class has no effect.

:init id [method]

Id is set to the *drawable* slot as the ID of this drawable. A new GC (graphic context) is created and set to *gcon* as the default GC of this drawable object.

:drawable [method]


returns drawable id.

:flush [method]

flushes commands retained in the Xlib's buffer.

:geometry [method]

returns the list of seven geometric attributes, root-window-id, x-position, y-position, width, height, border-width and visual's depth.



☑ 14: drawing primitives

:height [method]

returns the height (dots in y direction) of this drawable.

:width [method]

returns width (dots in x direction) of this drawable.

:gc &rest newgc

If no *newgc* is given, the current gc object is returned. If *newgc* is an instance of gcontext, it is set to the gc of this drawable. Otherwise, *newgc* is regarded as a message and sent to the current gc.

:pos [method]

returns an integer vector representing the position of this drawable. The position is always defined relative to the parent window, and windows created as direct subwindows of the root window under the intervention of the window manager return the constant coordinates in their surrounding title window regardless to their true position in the root.

:x [method]

returns the x coordinate of this drawable relatively to the parent window.

 $\mathbf{y}$  [method]

returns the y coordinate of this drawable relatively to the parent window.

:copy-from drw [method]

Drw is another drawable object (xwindow or pixmap). The contents of drw is copied to this drawable.

**:point** x y & optional (gc gccon)

[method]

draws a point at (x, y) with optional gc.

:line x1 y1 x2 y2 &optional (gc gcon)

[method]

draw a line from (x1, y1) to (x2, y2) with optional gc. x1, y1, x2, and y2 must be integers.

:rectangle x y width height &optional (gc gcon)

[method]

draws a rectangle whose center is located at (x, y) and size is specified by width and height.

:arc x y width height angle1 angle2 &optional (gc gcon)

[method]

draws an elliptic arc whose center is (x, y) and starting angle at angle 1 and ending angle at angle 2.

Angles should be given by radian.

:fill-rectangle x y width height &optional (gc gcon)

[method]

fills in a rectangular region.

:fill-arc x y width height angle1 angle2 &optional (gc gcon)

[method]

fills in an arc.

**:string** x y str &optional (gc gcon)

[method]

displays the string str starting at (x, y). The background is not filled.

:image-string x y str &optional (gc gcon)

[method]

displays an imagestring of str. Imagestring fills background.

**:getimage** &key x y width height (mask #fffffff) (format 2)

[method]

gets ximage from the server and returns the pixel data in a string. The pixel data sent from the server is once stored in Xlib's ximage structure, then copied to the string row by row. The ximage structure is automatically destroyed. The image string obtained by :getimage can be used to make a pixel-image, which can be written to a file in the pbm formats as described in section ??.

:putimage image &key src-x src-y dst-x dst-y width height (gc gcon)

[method]

puts *image* to the specified location in this drawable. *image* is a string or a address pointing to an ximage structure.

:draw-line from to

[method]

is same as :line method, and provided for the compatibility with other viewsurface classes.

:line-width &optional dots

[method]

sets line-width of this drawable's default GC. Use of the :gc :line-width message is recommended.

:line-style &optional dash

[method]

sets line-style of this drawable's default GC. Use of the :gc :line-style is preferable.

:color &optional c

[method]

sets color of this drawable.

:clear

[method]

clears full screen. this method calls :clear-area

:clear-area  $\mathcal{C}$ key x y width height gc

[method]

clears a rectangle using the :fill-rectangle method.

**Xpixmap** 

[Class]

:super Xdrawable

:slots

Pixmap is a drawable that is often used as a picture buffer or a background pattern. Unlike xwindow, pixmap itself is not visible until it is copied to xwindow or pixmap does not generate any event.

:init id

[method]

initializes this pixmap.

:create &key (width 500) (height 500) (depth 1) (gc \*defaultgc\*)

[method]

creates a width x height pixmap with gc as its default GC.

## $: {\bf create\text{-}from\text{-}bitmap\text{-}file}\ fname$

[method]

creates a pixmap from a bitmap file.

## :write-to-bitmap-file fname

[method]

writes the contents of this pixmap into a bitmap file, which can be read back to create a pixmap by :create-from-bitmap-file method.

:destroy [method]

destroys this pixmap and frees X resources.

Xwindow

:super Xdrawable

:slots (parent subwindows backing-pixmap event-forward)

Xwindow defines visible rectangular regions of the screen. It is inherited not only by **text-window** and **canvas** where any graphics objects can be drawn, but also by many **panel-items** and **scroll-bars**, which look like graphics objects rather than windows.

:create [method]

```
&key ((parent *root*)
(x 0) (y 0) (size 256) (width size) (height size) (border-width 2)
(save-under nil) (backing-store :always) (backing-pixmap nil)
(border *fg-pixel*) (background *bg-pixel*)
(map T) (gravity :northwest)
(title "WINDOW") (name title)
(font)
```

event-mask (:key :button :enterLeave :configure :motion)

creates and initializes a xwindow. When parent is given, this window is created as a subwindow of parent, and is registered in the subwindows list of the parent. X, y, size, width, height and borderwidth determine the location and the dimensions of this window. Save-under and backing-store control the Xserver's behaviors taken upon when the window is re-mapped. Save-under is either T or NIL, while backing-store is either :notUseful, :WhenMapped, or :Always. When backing-pixmap is T, a pixmap of the same size as this window is created by EusLisp, and maintained as a backing-store in case the Xserver does not have the capability of backing-store. Border and background specify the border\_pixel and background\_pixel attributes, respectively. Map should be set NIL, if this window should not appear immediately after its creation, as is the case many small windows are created as panel-buttons in a panel. Title is the window title which appears in the title bar of the window. Name is the name of the window stored in the property-list of this xwindow object and printed by the printer. X's events reported to this window are determined by Event-mask, that is, either an integer representing a bit-coded event-mask or a list of the following symbols: :key, :button, :enterLeave, :motion and :configure. If more precise control is needed, the following symbols for each event can be specified: :keyPress, :keyRelease, :ButtonPress, :ButtonRelease, :Enter-Window, :LeaveWindow, :PointerMotion, :PointerMotionHint, :ButtonMotion, :KeyMapState, :Exposure, :VisibilityChange, :StructureNotify, :ResezeRedirect, :SubstructureNotify, :SubstructureRedirect, :FocusChange, :PropertyChange, :ColormapChange and :OwnerGrabButton. :Key enables both :keyPress and :KeyRelease, and :button enables both :ButtonPress and :ButtonRelease. When an event is sent from the server, window-main-loop analyzes the event structure and send the

:KeyPress, :KeyRelease, :buttonPress, :ButtonRelease, :EnterNotify, :LeaveNotify, :MotionNotify:ConfigureNotify message to the window where the event occurred.

:map [method]

makes this xwindow and all the subwindows visible.

:unmap [method]

makes this xwindow and all the subwindows invisible.

#### : selectinput event-mask

[method]

*Event-mask* is either an integer or a list of eventmask symbols. Each event corresponding to the bit turned-on or enumerated in the *event-mask* list becomes to be reported to this window.

:destroy [method]

destroys this xwindow and frees X resource. The corresponding entries in \*xwindows\* and \*xwindow-hash-tab\* are also deleted so that this window object could be garbage-collected. All subwindows are also deleted by sending :destroy. This window is dissociated from the subwindow list of the parent window. The drawable ID is set to NIL.

:parent [method]

returns the parent window object.

:subwindows [method]

returns the list of all the subwindows. The subwindow most recently created comes first in the list. Only the direct subwindows of this window are listed and subwindows of the subwindows are not.

:associate child [method]

register the *child* window as a subwindow of this window.

:dissociate child [method]

removes the *child* window of the *subwindows* list.

title title [method]

changes the title of this window. Though the title is in the Xserver, it is maintained and displayed by the window manager.

:attributes [method]

returns an integer-vector representing the attributes of this window.

:visual [method]

returns the visual resource id for this window.

:screen [method]

returns the screen resource id for this window.

:root [method]

returns the root window id.

:location [method]

returns a two dimensional integer-vector describing the x and y coordinates of this window.

:depth [method]

returns the depth (number of color planes) of this window.

:size [method]

returns the size (width and height) of this window.

:colormap [method]

returns colormap resource id for this window.

:move newx newy [method]

changes the location of this window to (newx, newy). The coordinates are given relative to the parent window.

:resize width height

changes the size of this window. Probably because the size parameters are cached in the Xlib on the client side, :geometry message immediately after :resize may return wrong (old) result.

:raise [method]

brings this window upfront.

:lower [method]

pushes this window to the back.

:background pixel [method]

changes the background pixel value (the index in the color map) to *pixel*. The *pixel* value is also stored in the *bg-color* slot. :Clear operation is performed to fill the current background with the specified *pixel*.

#### :background-pixmap pixmap

[method]

[method]

[method]

[function]

changes the background with given pixmap.

:border pixel

sets the color of the border to pixel.

:set-colormap cmap

sets colormap.

:clear [method]

clears the entire xwindow.

:clear-area  $\&key \ x \ y \ width \ height$ 

clears the specified rectangular area of this xwindow.

make-xwindow & rest args

makes x-window.

init-xwindow & optional (display (getenv "DISPLAY")) [function]

is the first function to call when eusx start up. Init-xwindow connects to the Xserver specified by display, and initializes default variables described in the section 16.1. Init-xwindow also loads default fonts and sets them to global variables, such as font-courb12, lucidasans-bold-12, etc. This font loading causes the delay at the start-up time. Reduction of the number of fonts loaded or specifying the exact font-names without using the wild-card character "\*" will shorten the delay.

# 16.3 Graphic Context

gcontext [Class]

:super Xobject

:slots (gcid GCValues)

defines the graphic context. In EusLisp, every xwindow has its default GC.

:create [method]

&key (drawable defaultRootWindow)

(foreground \*fg-pixel\* (background \*bg-pixel\*)

function plane-mask

line-width line-style cap-style join-style

font dash

creates a gc with given attributes. *Drawable* is used by the Xserver to know the screen and depth of the screen. The resulted GC can be used in any drawables as long as they are created on the same screen.

:gc [method]

returns X's GC id.

:free [method]

frees this GC.

[method]

makes a copy of this GC.

:foreground &optional color

[method]

if color is given, it is set to the foreground color. Color is a pixel value.

:background & optional color

[method]

if color is given, it is set to the background color. Color is a pixel value.

:foreback fore back

sets foreground and background colors at once.

:planemask &optional plane-mask

[method]

[method]

sets plane-mask.

:function x [method]

sets drawing function. X should either be one of the following numbers or keywords: 0=Clear, 1=And, 2=AndReverse, 3=Copy, 4=AndInverted, 5=NoOp, 6=Xor, 7=Or, 8=Nor, 9=Equiv,

10=Invert, 11=XorReverse, 12=CopyInverted, 13=OrInverted, 14=Nand, 15=Set, :clear, :and,

: and Reverse, : copy, : and Inverted, : NoOp, : Xor, : Or, : Nor, : Equiv, : Invert,

:XorReverse, :CopyInverted, :OrInverted, :Nand, :Set.

:font x [method]

sets the font attribute of this GC. X is either a font-name or a font-ID. If x is a font name (string), :font calls x:LoadQueryFont to decide the font-id. If not found, "no such font ..." is warned. If x is NIL (not given), the current font-ID of this GC is returned.

: line-width x [method]

sets the line width in pixel.

:line-style x [method]

sets the line-style (solid, dashed, etc.).

:dash  $\mathscr{E}rest\ x$  [method]

Each component of X is an integer. :Dash sets the dash pattern of the line-style.

:tile pixmap [method]

sets the tile of this GC to pixmap.

:stipple pixmap [method]

sets the stipple of this GC to pixmap.

 $: \mathbf{get-attribute} \ attr \\ [\mathbf{method}]$ 

gets attribute. Attris one of :function, :plane-mask, :foreground, :background, :line-width, :line-style, :cap-style, :join-style, :fill-style, :fill-rule, :font. An integer value representing the attribute is returned.

:change-attributes [method]

 $\ensuremath{\mathscr{C}\!\mathit{key}}$  function plane-mask foreground background line-width line-style cap-style join-style font dash

change attributes. More than one attributes are changed at the same time.

font-id fontname [function]

If fontname is integer, it is returned regarding it as font-id. If fontname is string, font-structure is inquired by using x:LoadQueryFont, and its font-id is returned. Fontname can be a shorthand of exact name, such as "\*-courier-24-\*" for any 24-point courier font. If the font could not be found, can't load font warning is printed.

textdots str font-id [function]

returns a list of three integers representing (ascent descent width) of the str (string) in dots.

### 16.4 Colors and Colormaps

colormap

:super object

:slots (cmapid planes pixels LUT-list)

defines an xwindow colormap and application oriented color look-up tables. A color is represented by RGB values from 0 through 65535. Color cells in a color map are addressed by their indices, which are between 0 and 255 on 8-bit pseudo color display.

Here we assume your display device has 8bit pseudo color capability which allows you to choose 256 colors at the same time. Basically there are two ways in the use of color maps: to share the system's default color map or to create private color maps. If you use the system's default color map, you have to be careful not to use up all the color cells in the map, since the map is shared among many processes. If you use private color maps, you can allocate all 256 color entries in the map without worrying about other processes, but

the map has to be explicitly attached to your private windows. The color map is activated by the window manager when the mouse pointer is moved somewhere in the window.

The system's default color map is set up in x:\*color-map\* which is an instance of the x:colormap class when eusx begins execution. If you use private color maps, you create instances of x:colormap. These instances correspond to the colormap object defined in the x server and are identified by the cmapid stored in each instance.

When you use the system's default color map, you can define read-only colors which are shared with other processes or define read-write colors which are private to your EusLisp. Read-only means that you can define arbitrary color when you allocate the color cell, but you cannot change it after the allocation. On the other hand, read-write colors can be altered even after you defined them. Shared colors are read-only since other processes expect the colors to be unchanged. This read-only or read-write attribute is attached to each color entry (often referred to as color cell).

A colormap object defines translation from a color id to a physical representation that is a triplet of red, green and blue components. However, these logical color ids cannot be chosen arbitrarily, especially when you use the the system's default color map. The color id (often referred to as 'pixel') is an index of a particular color in a color map and Xlib chooses one of free indices for a shared color when allocation is requested. Therefore, there is no way, for example, to guarantee many levels of gray colors to be allocated contiguously or to begin from the first (zeroth) index.

From the viewpoint of applications, more logical color naming is needed. For example, a number of gray levels should be referred to with their brightness as indices. A ray trace program may wish to assign contiguous indices to a group of colors of different brightness defined in HLS model.

To cope with this problem, EusLisp's colormap provides another translation table called LUT (look-up table). For a logical group of colors, you can define a LUT and attach a symbolic name to it. More than one LUTs can be defined in a colormap. LUT is an integer vector for the translation of application specific logical color indices into physical pixel values that the Xserver can recognize.

:id [method]

returns the cmap id.

:query pix [method]

gets RGB values for the specific pixel number.

:alloc r q b

this method is the same as :store nil r g b. A new color cell is allocated in this colormap and is assigned with the specified RGB values.

store pix r q b

sets RGB values to the pixth color cell.

:store pix color-name [method]

:Store is the lowest level method to set a color in a color map. In the first form, you specify the color with the red, green and blue components between 0 and 65535 inclusively. In the second form, you specify the color by name like "red" or "navy-blue". If no such color-name is found, nil is returned. Pixel is either an integer which is the index in a color map or nil. If it is integer, the color cell must be read-write-able. If it is nil, a shared read-only color cell is allocated. :Store returns the index of the color cell in the color map.

:store-hls pix hue lightness saturation

[method]

stores the color specified in HLS (Hue, Lightness and Saturation) model in the *pix*th entry of this colormap. If *pix* is NIL, a shared read-only color cell is allocated. :Store-hls returns the index to the allocated color cell.

:destroy [method]

destroys this colormap and frees resource.

:pixel LUT-name id [method]

looks up in the LUT for the id'th entry and returns its pixel value. LUT-name is the name of the look-up-table you defined by :define-LUT.

## : allocate-private-colors num

[method]

allocates num color cells in the private color map.

### :allocate-colors rgb-list &optional private

[method]

Each element of rgb-list is a list of red, green and blue components. Color cells are allocated for each rgb value and an integer-vector whose elements are pixel values is returned.

## :define-LUT LUT-name rgb-list &optional private

[method]

Colors described in rgb-list are allocated, and an LUT is registered by the symbolic name of LUT-name. In order to define private color cells, set private to T.

### :define-gray-scale-LUT LUT-name levels &optional private

[method]

allocates levels of color cells that represent linear gray scale colors and returns LUT. For example, (send x:\*color-map\* :define-gray-scale-LUT 'gray8 8) allocates eight gray colors in the system's default color map, and returns an integer vector such as #i(29 30 31 48 49 50 51 0). Physical pixel values can be inquired by sending the :pixel message, for example, (send x:\*color-map\* :pixel 'gray8 2) returns 31.

### $\textbf{:define-rgb-LUT} \ \textit{LUT-name red green blue \&optional private}$

[method]

defines an LUT for shrunk RGB representation. For example, if red=green=blue=2, totally  $2^{2+2+2} = 2^6 = 64$  color cells are allocated.

:define-hls-LUT LUT-name count hue low-brightness high-brightness saturation & optional private [method] allocates count colors using the HLS model. Colors of the given hue (0..360), saturation (0..1), and different levels of brightness between low-brightness and high-brightness are stored in the color map. A LUT named LUT-name is also created.

:define-rainbow-LUT LUT-name & optional (count 32) (hue-start 0) (hue-end 360) (brightness 0.5) (saturation 1.0) private [method]

allocates count colors using the HLS model. Colors of the given brightness (0..1), saturation (0..1), and different hues between hue-start and hue-end are stored in the color map. A LUT named LUT-name is also created.

:LUT-list [method]

returns all LUT list defined in this color map. Each entry in the list is a pair of the LUT-name and an integer vector.

:LUT-names [method]

returns the name list of all LUT in this colormap.

:LUT name

returns the integer-vector (LUT) identified by name.

:size LUT [method]

returns the length of LUT

:planes [method]

returns planes of this colormap.

:set-window xwin [method]

associates this colormap to the xwin window. This colormap is activated when the cursor enters in xwin.

:free pixel-or-LUT [method]

frees a specific color cell addressed by pixel, or all the entries in LUT.

:init & optional cmapid [method]

initializes this color map with cmap id. All the LUTs registered are discarded.

:create &key (planes 0) (colors 1) (visual \*visual\*) contiguous [method] creates a new color map object.

XColor [Class]

defines a color in the RGB model. Use **setf** to assign value to each slots. The RGB values are sign extended and the greatest value is represented as -1.

:red [method]

returns the red value of this XColor.

:blue [method]

returns the blue value of this XColor.

:green [method]

returns the green value of this XColor.

:rgb [method]

returns the list of red, green and blue values of this XColor.

:init pix R G B & optional (f ?) [method]

initializes XColor.

find-visual type depth Coptional (screen 0) [function]

finds the visual-ID of the specified *type* and *depth*. *Type* should be either :StaticGray, :GrayScale, :StaticColor, :pseudoColor, :TrueColor or :DirectColor. Usually the *depth* should be either 1, 8 or 24.

# 17 XToolKit

XToolKit is the highest level X window interface to facilitate composing GUI (Graphical User Interface) by using GUI components such as buttons, pulldown menus, textWindows, etc., as building blocks. The major differences from the Xlib classes are, the XToolKit invokes user-supplied interaction routines corresponding to the Xevents sent from the Xserver, and provides consistent appearance of those interaction-oriented window parts. Classes consisting the XToolKit has the following inheritance structure.

```
xwindow.
     panel
          menubar-panel
          menu-panel
          filepanel
          textviewpanel
          confirmpanel
     panel-item
          button-item
               menu-button-item
               bitmap-button-item
          text-item
          slider-item
          choice-item
          joystick-item
     canvas
     textwindow
          buffertextwindow
               scrolltextwindow
          textedit
     scroll-bar
          horizontal-scroll-bar
```

Just below the xwindow class are the five basic XToolKit classes: panel, panel-item, canvas, textWindow and scroll-bar. Menubar-panel and menu-panel are defined under the panel. A basic strategy to build a new application window and to make it run upon events is the following:

- 1. **define an application class** An application window class should be defined as a subclass of **panel** that has the capability to lay out XToolKit components.
- 2. **define event handlers** In the application class, event handlers that are called upon when buttons are pressed or menu items are selected are defined. An event handler ought to be defined as a method with panel-item specific arguments.
- 3. **define subpanels** If you use a menubar-panel, it is placed at the top of the application window, therefore it should be created first by :create-menubar. Similarly menu-panels needs to be defined before the menu-button-items to which menu-panels are associated.
- 4. **create panel-items** Panel-items such as button-item, text-item, slider-item, etc., can be created by (send-super :create-item class label object method). Event handlers defined above are connected to each panel-item. These initialization procedures should be defined in the :create method

of the application window class. Do not forget to define quit button to make the event dispatcher terminate whenever needed. Any textWindow and canvas can also be placed in the application window via the :locate-item method.

- 5. **create the entire window** Sending the :create message to the application class creates the application window with its XToolKit components properly placed in the window.
- 6. run the event dispatcher In order to receive events from the Xserver and delivers them to the corresponding xwindow, run window-main-loop. On Solaris2, window-main-thread, which delivers events in a different thread, is available. Window-main-thread keeps the toplevel interaction alive. Do not run more than one window-main-thread.

# 17.1 X Event

In the current implementation, an event structure is received in a fixed event buffer (an integer-vector of 25 elements) and the same buffer is reused on all events. The event structure has to be copied when more than one events need to be referenced at the same time.

Window-main-loop is the function which captures all events sent from the X server and delivers them to each window where the event happened.

event [variable]

a 25-element integer-vector holding the most recent event structure.

next-event [function]

stores the event structure in **event** and returns it if there is at least one pending event, NIL if there is no pending event.

event-type event [function]

returns the keyword symbol representing the event-type in the *event* structure. The event-type keywords are: :KeyPress (2), :KeyRelease (3), :ButtonPress (4), :ButtonRelease (5), :MotionNotify

- (6), :EnterNotify (7), :LeaveNotify (8), :FocusIn (9), :FocusOut (0), :KeymapNotify (1), :Expose
- (12), :GraphicsExpose (13), :NoExpose (14), :VisibilityNotify (15), :CreateNotify (16), :DestroyNotify
- (17), :UnmapNotify (18), :MapNotify (19), :MapRequest (20), :ConfigureNotify (22), :ConfigureRequest
- (23), :GravityNotify (24), :ResizeRequest (25), :CirculateNotify (26), :CirculateRequest (27),
- $: \texttt{PropertyNotify} \ (28), \ : \texttt{SelectionClear} \ (29), \ : \texttt{SelectionRequest} \ (30), \ : \texttt{SelectionNotify} \ (31), \ ($

:ColormapNotify (32), :ClientMessage (33), :MappingNotify (34), :LASTEvent (35).

event-window event [function]

returns the window object where the *event* occurred.

event-x event [function]

extracts the x coordinate, (i.e., the horizontal position of the mouse pointer relatively in the window) out of the event.

event-y event [function]

extracts the x coordinate, (i.e., the vertical position of the mouse pointer relatively in the window) out of the event.

event-width event [function]

returns the eighth element of the *event* structure which represents the width parameter at the :configureNotify event.

event-height event [function]

returns the ninth element of the *event* structure which represents the height parameter at the :configureNotify event.

event-state event [function]

returns a list of keywords representing the mouse button and modifier key state. Keywords are: shift, :control, :meta, :left, :middle and :right. For example, if left mouse button is pressed while shift key is down, (:shift :left) is returned.

display-events [function]

displays all xwindow events captured by x:nextevent. Control-C is the only way to terminate this

### window-main-loop &rest forms

[macro]

receives Xevents and delivers them to window objects where the event occurred. According to the event-type, methods in the window's class named :KeyPress, :KeyRelease, :ButtonPress, :ButtonRelease, :MotionNotify, :EnterNotify, :LeaveNotify and :ConfigureNotify are invoked with event as the argument. If forms is given, evaluates them each time event arrival is checked.

window-main-thread [function]

Do the same thing as window-main-loop in a different thread. Window-main-thread is only available on Solaris2. Window-main-thread installs an error handler which does not enter a read-eval-print loop. After printing the error information, the event processing continues.

### 17.2 Panel

panel

:super xwindow

slots (pos items fontid

rows columns ;total number of rows and columns

next-x next-y

item-width item-height)

Panel is a xwindow with the capability to lay out panel-items or any xwindows including other panel objects. A panel object supplies the default font for every panel-item created in the panel. Application windows should be defined as subclasses of the Panel.

:create [method]

Erest args & key (item-height 30) (item-width 50)

(font font-lucidasans-bold-12) (background \*bisque1\*)

&allow-other-keys

creates and initializes a panel. Since superclass's :create is invoked, all creation parameters for **xwindow**, such as *width*, *height*, *border-width*, etc., are allowed. *Item-height* and item-width give the minimum height and width for each panel-item.




図 15: Item lay-out in panel

:items [method]

returns the list of all items associated.

#### :locate-item item &optional x y

[method]

Item is any xwindow object, normally a panel-item. If x and y are given, the item is located there. Otherwise, item is located adjacent to the most recently located item. Items are located from top to bottom, from left to right, as shown in **Fig.** 15. :Locate-item also adds item in the items and subwindows list, and makes it visible by sending :map.

:create-item [method]

klass label receiver method &rest args

&key (font fontid)

&allow-other-keys

creates an instance of the panel-item class specified by *klass* (i.e., button-item, menu-button-item, slider-item, joystick-item, etc.), and place the item in the panel using :locate-item. *Args* are passed to klass's :create method. *Label* is the identification string drawn in the panel item. *Receiver* and *method* specify the event handler called upon the corresponding event.

:delete-items [method]

delete all panel-items.

:create-menubar [method]

&rest args

&key (font fontid)

&allow-other-keys

creates a menubar-panel and locates it at the top of the panel.

The following methods are provided to avoid "subclass's responsibility" warning message when events are sent to panels without event handlers. User applications should override these methods.

:quit  $\mathscr{E}rest\ a$  [method]

throws: window-main-loop and terminates event processing.

:KeyPress event [method]

returns NIL.

:KeyRelease event [method]

returns NIL.

:ButtonPress event [method]

returns NIL.

:ButtonRelease event [method]

returns NIL.

:MotionNotify event [method]

returns NIL.

:EnterNotify event [method]

returns NIL.

:LeaveNotify event [method]

returns NIL.

### 17.2.1 Subpanels (menu-panel and menubar-panel)

menu-panel [Class]

:super panel

:slots (items item-dots item-height

charwidth charheight

height-offset
highlight-item
color-pixels
active-color)

Menu-panel is a kind of panel that can locate only button-items and/or bitmap-button-items. Unlike panel, however, menu-panel is normally invisible and is exposed when the button-item to which the menu-panel is associated is pressed. If a menu-panel is made always visible, it becomes a pinned menu. The response of each button-item to mouse events is slightly different from button-items in other panels, as the mouse button has been pressed somewhere outside the button-item. Creation of a menu-panel should follow the order described below:

- 1. create a menu-panel by (instance menu-panel :create).
- 2. create button-items or/and bitmap-button-items and locate them in the menu-panel by (send aMenuPanel :create-item button-item "BTN" obj meth).
- 3. create a menu-button-item in another panel and associate the menu-panel with the menu-button-item by (instance menu-button-item :create "Option" obj meth :menu-window aMenuPanel).

:create [method]

Erest args & keyitems (border-width 0) (font font-courb12)



☑ 16: FilePanel window

(width 100) (height-offset 15) (color \*bisque1\*) (active \*bisque2\*) & allow-other-keys

create a menu-panel window. The size of the window is expanded each time new menu-item is added.

#### :create-item class label receiver method &rest mesg

[method]

adds a menu item in this menu-panel window and attatches the corresponding action. The receiver objects receives mesg when the mouse button is released on the item.

# menubar-panel

[Class]

:super panel :slots

Menubar-panel is a subpanel always located at the top of the parent panel. A menubar-panel resembles with the Macintosh desktop's menubar which lets out several pull-down menus. Panel-items placed in the menubar should be menu-button-items. A menubar-panel is created by the panel's :create-menubar method.

### 17.2.2 File Panel

The FilePanel is an application window for the interactive manipulation of files and directories. Using cd and go-up buttons, any directory can be visited and files contained in the directory are displayed in the ScrollTextWindow below. Text files can be displayed in different windows (textViewPanel). Files can also be printed, removed, and compiled by simply cliking buttons. When a file is printed, a2ps  $file \mid lpr$  commands are executed in a forked process.



☑ 17: TextViewPanel window

#### 17.2.3 Text View Panel

TextViewPanel is an application window class to display text files (Fig. 17). The program text is shown to demonstrate how one of the simplest application windows is described. In the :create method, the quit button and find button, and a text-item to feed the string to be searched for in the file are created. The view-window is a ScrollTextWindow that displays the file with the vertical and horizontal scroll-bars. The TextViewPanel captures :ConfigureNotify event to resize the view-window when the outermost title window is resized by the window manager.

```
(defclass TextViewPanel :super panel
        :slots (quit-button find-button find-text view-window))
(defmethod TextViewPanel
(:create (file &rest args &key (width 400) &allow-other-keys)
   (send-super* :create :width width args)
   (setq quit-button
          (send self :create-item panel-button "quit" self :quit))
   (setq find-button
          (send self :create-item panel-button "find" self :find))
   (setq find-text
          (send self :create-item text-item "find: " self :find))
   (setq view-window
            (send self :locate-item
                (instance ScrollTextWindow :create
                   :width (setq width (- (send self :width) 10))
                   :height (- (setq height (send self :height)) 38)
                   :scroll-bar t :horizontal-scroll-bar t
                                 :parent self)))
                   :map nil
   (send view-window :read-file file))
(:quit (event) (send self :destroy))
```

```
(:find (event)
   (let ((findstr (send find-text :value)) (found)
         (nlines (send view-window :nlines)))
       (do ((i 0 (1+ i)))
           ((or (>= i nlines) found))
          (if (substringp findstr (send view-window :line i)) (setq found i)))
       (when found
          (send view-window :display-selection found)
          (send view-window :locate found))))
(:resize (w h)
   (setq width w height h)
   (send view-window :resize (- w 10) (- h 38)))
(:configureNotify (event)
  (let ((newwidth (send self :width))
        (newheight (send self :height)))
       (when (or (/= newwidth width) (/= newheight height))
         (send self :resize newwidth newheight))) )
```

#### 17.3 Panel Items

panel-item [Class]

:super xwindow :slots (pos notify-object notify-method fontid label labeldots)

**Panel-item** is an abstract class for all kinds of panel-item windows to invoke *notify-object*'s *notify-method* when item-specific event occurs.

:notify &rest args

invokes notify-object's notify-method. Responsive events and arguments passed to notify-method are item specific:

**button-item** The button is pressed and released in the same button-item; the argument is the button-item object.

menu-button-item A menu item is selected; the argument is the menu-button-item object.

**choice-item** A new choice button is selected; the arguments are the choice-item object and the index number of the choice.

**text-item** A newline or return is entered; the arguments are the text-item object and the entire line (string).

slider-item The slider nob is grabbed and moved; the arguments are the slider-item object and the new value.

**joystick-item** The joystick is grabbed and moved; the arguments are the slider-item object, the new x and y values.

:create [method]

```
&key (width 100) (height 100) (font font-courb12) &allow-other-keys
```

creates a panel-item. As panel-item is an abstract class, this method should only be called by the subclasses via send-super.

button-item [Class]

:super panel-item :slots

**button-item** is the simplest panel-item. Button-item has a rectangular box and a label string in it. When clicked, button-item invokes *notify-object*'s *notify-method* with the panel-item object as the only argument.

:draw-label & optional (state :top) (color bg-color) (border 2) offset [method] draws button-item's label.

:create [method]

label revciever method &rest args
&keywidth height (font (send parent :gc :font))
 (background (send parent :gc :background))
 (border-width 0)
 (state :top)
&allow-other-keys

creates a button-item. If button's width and height are not given, the sizes are automatically set to accommodate the label string drawn with the given font. Though the border-width is defaulted to 0, pseudo 3D representation embosses the button. The background color and font are defaulted to the ones defined for the parent window, i.e. a panel.

:ButtonPress event [method]

changes the background color to gray, as if the button.

:ButtonRelease event [method]

changes event's background color to normal.

# menu-button-item [Class]

:super button-item

:slots (items item-dots item-labels

charwidth charheight

menu-window window-pos high-light)

defines a pulldown menu. Though a menu-button-item looks like a button-item, the menu-button-item activates associated menu-panel below the button when it is pressed, instead of sending an immediate message to the *notify-object*. The actual message is sent when the mouse button is released on one of the menu items.

:create [method]

label reciever method

&rest args

&key menu items (state :flat)

&allow-other-keys

creates a pulldown menu button. Receiver and method arguments has no effect.

:ButtonPress event [method]

reverses the appearance of the pulldown-menu and exposes the associated menu-panel below the button.

:ButtonRelease event [method]

unmaps the menu-panel below this button and reverts the appearance of the button.

# bitmap-button-item

[Class]

:super button-item :slots (pixmap-id bitmap-width bitmap-height)

Though bitmap-button-item's function is similar to the button-item, its appearance is different. Instead of drawing a simple label string on the button, as is the case for button-item, bitmap-button-item is drawn by a pixmap which is loaded from a bitmap-file when the button is created.

:draw-label &optional (state :flat) color bg-color (border 2)

[method]

draws a bitmap/pixmap on the button.

[method]

bitmap-file reciever method &rest args

&key width height

&allow-other-keys

 $creates \ bitmap-button-item. \ The \ first \ argument, \ \textit{bitmap-file} \ replaces \ the \ \textit{label} \ argument \ of \ \texttt{button-item}.$ 

:draw-label &optional (state :flat) (color bg-color) (border 2)

[method]

draw a bitmap/pixmap on the button.

#### :create-bitmap-from-file fname

[method]

creates pixmap from the bitmap file named fname, and stores its id in pixmap-id.

choice-item [Class]

:super button-item

:slots (choice-list active-choice transient-choice

choice-dots choice-pos button-size)

choice-item is a set of round choice buttons. One choice is always active, and only one choice can become active at the same time. choice-item provides the similar function as radio-buttons.

:create [method]

label reciever method &rest args &key (choices '("0" "1")) (initial-choice 0) (font (send parent :gc :font)) (button-size 13) (border-width 0)

create a choice-item-button. Each choice button is a circle of radius *button-size*. When a new choice is selected, *notify-object's notify-method* is invoked with the choice-item object and the index of the choice selected.

#### :value & optional new-choice invocation

[method]

If new-choice is given, it is set as the current active choice, and the corresponding circle is filled black. If invocation is also specified, notify-object's notify-method is invoked. :Value returns the current (or new) choice index.

:draw-active-button & optional (old-choice active-choice) (new-choice active-choice)
draw active button.

[method]

-----

:ButtonPress event [method]

If the mouse button is pressed on any of the choice buttons, its index is recorded in *transient-choice*. No further action is taken until the mouse button is released.

:ButtonRelease event [method]

If the mouse button is released on the same button which is already pressed, the *active-choice* is updated and *notify-object*'s *notify-method* is invoked.

slider-item [Class]

:super panel-item

:slots (min-value max-value value

minlabel maxlabel valueformat

bar-x bar-y bar-width bar-height valuedots label-base

nob-x nob-moving

charwidth)

While choice-item is used to select a discrete value, slider-item is used for the continuous value in the range between *min-value* and *max-value*. Each moment the value is changed, *notify-object*'s *notify-method* is invoked with the slider-item object and the new value as the arguments.

:create [method]

label reciever method &rest args &key (min 0.0) (max 1.0) parent (min-label "") (max-label "") (value-format " 4,2f") (font font-courb12) (span 100) (border-width 0) (initial-value min)

creates slider-item. The sliding knob is displayed as a small black rectangle on a bar. The left end represents the *min* value and the right end *max* value. The length of the bar stretches for the *span* dots. The current value is displayed to the right of the slider-item label in the *value-format*.

# :value &optional newval invocation

[method]

If newval is given, it is set as the current value, and the knob is slided to the corresponding location. If invocation is also specified non nil, notify-object's notify-method is invoked. :Value returns the current (or new) value.

# joystick-item [Class]

:super panel-item

:slots (stick-size min-x min-y max-x max-y

center-x center-y stick-x stick-y

value-x value-y

stick-return stick-grabbed

fraction-x fraction-y)

joystick-item can be regarded as the two-dimensional slider-item. Two continuous values can be specified by the moving black circle on the coaxial chart that looks like a web (Fig. 18).

[method]

```
name reciever method &rest args
&key (stick-size 5) return
(min-x -1.0) (max-x 1.0)
(min-y -1.0) (max-y 1.0)
&allow-other-keys
```

Stick-size is the radius of the stick's black circle. The sizes of the circles in the coaxial chart are determined according to the width and height of the joystick-item window. If return is non-NIL, the joystick returns to the origin when the mouse button is released. Otherwise, the joystick remains at the released position.

#### :value &optional news newy invocation

[method]

If both *newx* and *newy* are given, they are set as the current values, and the joystick moves to the corresponding location on the coaxial chart. If *invocation* is also specified non nil, *notify-object's notify-method* is invoked with the joystick-item object and x and y values as the arguments. :Value returns the list of current (or new) values.

The following short program shows how to use panel-items described above, and Fig. 18 depicts how they appear in a panel.

```
(in-package "X")
(defclass testPanel :super panel
        :slots (quit joy choi sli))
(defmethod testPanel
(:create (&rest args)
   (send-super* :create :width 210 :height 180
                 :font font-courb12 args)
   (send-super :create-item button-item "quit" self :quit :font font-courb14)
   (send-super :create-item choice-item "choice" self :choice
                :choices '(" A " " B " " C ")
                :font font-courb12)
   (send-super :create-item slider-item "slider" self :slider
                :span 90)
   (send-super :create-item joystick-item "joy" self :joy)
   self)
(:choice (obj c) (format t "choice: ~S ~d~%" obj c))
(:slider (obj val) (format t "slider: ~S ~s~%" obj val))
(:joy (obj x y) (format t "joy: ~S ~s ~s~%" obj x y)) )
(instance testPanel :create)
(window-main-thread)
```

text-item [Class]

:super panel-item :slots (textwin)



#### ☑ 18: Panel items created in a panel

Text-item is used to display or to input one short line of text, such as a file name. A text-item has a label string followed by a small textwindow on the right. When the pointer is put in the textwindow, key input is enabled and the characters typed are buffered. Line editing is available in the textwindow: control-F and control-B to move forward/backward by one character, del to delete the character on the left of the cursor, control-D to delete the character on the cursor, and any graphical character to insert it at the cursor position. Clicking a mouse button moves the cursor to the clicked character. Hitting an enter (newline) key causes the buffered text to be sent to the notify-object's notify-method.

:create [method]

label revciever method &rest args &key (font font-courb12) (columns 20) initial-value (border-width 0) &allow-other-keys

creates text-item. Though the linebuffer of the textwindow may have unlimited length, visible portion is restricted to the *columns* characters.

:getstring [method]

returns the string in the key buffer.

#### 17.4 Canvas

canvas [Class]

:super xwindow

:slots (topleft bottomright)

Canvas is a xwindow to interact with figures or images. Currently, only the region selection capability has been implemented. At the buttonPress event, the canvas begins to draw a rectangle with the topleft corner at the pressed position and bottomright corner at the current pointer. ButtonRelease causes the notify-method to be sent to the notify-object. Use Xdrawable's methods to draw figures or images in the canvas.

### 17.5 Text Window

There are three textwindow classes, TextWindow, BufferTextWindow and ScrollTextWindow.

textWindow [Class]

:super **xwindow** :slots (fontid

charwidth charheight charascent dots

win-row-max win-col-max

win-row win-col ;physical current position in window

ху

charbuf ; for charcode conversion

keybuf keycount ;for key input

echo

show-cursor cursor-on ;boolean

kill delete ;control character

notify-object notify-method

)

realizes virtual terminals usable for displaying messages. The displayed contents are not buffered and there is no way to retrieve a line or a character already displayed in the TextWindow. Basically, TextWindow has similar capabilities to the dumb terminals, that are, moving the cursor, erasing lines, erasing areas, scrolling displayed texts, inserting strings, etc. Also, the text cursor can be moved to the position designated by the mouse pointer.

:init id [method]

initializes idth text-window.

:create [method]

&rest args

&key width height (font font-courb14) rows columns

show-cursor notify-object notify-method

&allow-other-keys

creates text-window. The sizes of the window may be specified either by width and height or by rows and columns. Notify-object's notify-method is invoked when a newline character is typed in.

:cursor flag

The flag can either be :on, :off or :toggle. The text cursor is addressed by the win-row and win-col. The text cursor is displayed if flag is :on, is erased if flag is :off, or is reversed if flag is :toggle. This method must be invoked frequently whenever the character at the cursor is updated.

:clear [method]

clears text-window.

:clear-eol & optional (r win-row) (c win-col) (csr :on)

[method]

clears the rest of the line after the character addressed by r and c, including the character at the cursor.

:clear-lines lines &optional (r win-row)

[method]

clears multiple lines after r-th row.

:clear-eos & optional (r win-row) (c win-col)

[method]

clears the region after the character addressed by r and c till the end-of-the-screen.

:win-row-max [method]

returns the maximum number of lines displayable in this window.

:win-col-max [method]

returns the maximum number of columns displayable in this window.

:xy &optional (r win-row) (c win-col)

[method]

calculates the pixel coordinates of the character addressed by r and c.

**:goto** r c & optional (cursor :on)

[method]

moves the cursor to r-th row and c-th column.

:goback & optional (csr:on)

[method]

moves the cursor backward by one.

:advance &optional (n 1)

[method]

moves the cursor forward by n characters.

:scroll &optional (n 1)

[method]

scroll textwindow vertically by n lines.

:horizontal-scroll &optional (n 1)

[method]

[method]

horizontally scrolls the text by n columns.

:newline

moves cursor to the beginning of the next line.

:putch ch

inserts the character ch at the cursor position. The rest of the line is moved forward by one.

:putstring str &optional (e (length str))

[method]

places str at the cursor position.

:event-row event [method]

:event-col event

returns the text cursor position designated by (x, y) in the event.

:KeyPress event [method]

inserts the character entered at the cursor position. If the character is newline, notification is sent to the *notify-object*.

# textWindowStream

[Class]

:super stream :slots (textwin)

TextWindowStream is an output stream connected to a TextWindow. Characters or strings output to

this stream by using print, format, write-byte, etc., are displayed in the textwindow. As usual file streams, the output data are buffered.

:flush [method]

flushes buffered text string and send them to the textwindow. Finish-output or writing a newline character to this stream automatically calls this method.

#### $make-text-window-stream \ xwin$

[function]

makes text-window-stream and returns the stream object.

# **BufferTextWindow**

[Class]

:super TextWindow

:slots (linebuf expbuf max-line-length row col)

maintains the line buffer representing the contents of the textwindow. Linebuf is the vector of lines. Expbuf holds tab-expanded text. Only lines displayable in the window are maintained. BufferTextWindows can be used as simple text editors which have several, often only one, lines of text. Text-item employs a BufferTextWindow as a displayable line buffer.

:line n [method]

returns the contents of the n-th line as a string.

:nlines [method]

returns number of lines in the linebuf.

:all-lines [method]

returns the linebuf, which is a vector of strings.

:refresh-line &optional (r win-row) (c win-col) [method]

redraws the r-th line after the c-th column.

:refresh &optional (start 0) [method]

redraws the lines after the *start*-th line inclusively.

:insert-string string [method]

inserts *string* at the cursor position.

:insert ch [method]

inserts the character at the cursor.

:delete n [method]

deletes n characters after the cursor.

expand-tab src & optional (offset 0) [function]

Src is a string possibly containing tabs. These tabs are replaced by spaces assuming the tab stops at every 8th position.

# ScrollTextWindow

[Class]

 $: super \qquad \textbf{BufferTextWindow}$ 

:slots (top-row top-col ;display-starting position

scroll-bar-window

horizontal-scroll-bar-window

#### selected-line)

ScrollTextWindow defines buffertextwindow with unlimited number of lines, and vertical and horizontal scroll-bars can be attached. ScrollTextWindow can handle :configureNotify event to resize itself and accompanying scroll-bar windows, and to redisplay texts. By clicking, a line can be selected.

:create &rest args &key scroll-bar horizontal-scroll-bar &allow-other-keys

[method]

When scroll-bars are needed, specify T to each keyword argument.

: $\mathbf{locate}\ n$ 

displays the buffered text by placing the n-th line at the top of the window.

#### :display-selection selection

[method]

Selection represents the location of the selected line. The entire selected line is displayed highlighted.

:selection [method]

returns the selected line (string).

:read-file fname [method]

reads the textfile specified by *fname* into the *linebuf*, expands tabs, and display in the window. The cursor is put at the beginning of the screen.

#### :display-string strings

[method]

Strings is a sequence of lines (strings). The strings are copied in the linebuf and displayed in the window.

:scroll n [method]

vertically scrolls n lines.

#### :horizontal-scroll n

[method]

horizontally scrolls n columns.

:buttonRelease event [method]

The line where the mouse pointer is located is selected. If notification is specified when the window is created, *notify-object*'s *notify-method* is invoked.

: resize w h

changes the size of the window and redisplays the contents according to the new size. The same message is sent to scroll-bars if attached.

# 第III部

# irteus Extension

# 18 Robot Modelling

## 18.1 Robot Data Structure and modeling

#### 18.1.1 Robot Data Structures and Forward Kinematics

The structure of a robot can be considered to consist of links and joints. As a way to divide the robot into joints and links

- (a)Include joints on the side of the disconnected link
- (b)Include joints in the torso or closer to the torso

can be considered. Considering the data structure of the computer, (a) is used. The reason is that in all links other than the body, The structure always contains one joint, and all links are handled by the same algorithm This is because it is possible to

A tree structure is used to represent the links divided in this way on a computer. It is possible. In general, when creating a tree structure, the data structure is divided into binary trees. The structure is often simplified.

As a method of obtaining the homogeneous transformation matrix in the robot link, Set  $\Sigma_j$  with the origin, and the rotation axis vector seen from the parent link coordinate system is The origin of  $a_j$  and  $\Sigma_j$  is  $b_j$ , and the joint angle of rotation is  $q_j$ .

At this time, the parent-link-relative homogeneous transformation matrix of  $\Sigma_i$  is

$${}^{i}T_{j} = \left[ \begin{array}{ccc} e^{\hat{a}_{j}q_{j}} & b_{j} \\ 0 & 0 & 0 & 1 \end{array} \right]$$

where  $e^{\hat{a}_j q_j}$  is the rotation generated by the angular velocity vector of constant velocity. It uses the following Rodrigues formula to give the transpose matrix. around the rotation axis a It is used as a rotation matrix that rotates by wt[rad].

$$e^{\hat{\omega}t} = E + \hat{a}sin(wt) + \hat{a}^2(1 - cos(wt))$$

Assuming that the position and orientation  $p_i$ ,  $R_i$  of the parent link are known, the homogeneous transformation matrix of  $\Sigma_i$  is

$$T_i = \left[ \begin{array}{cc} R_i & p_i \\ 0 \ 0 \ 0 & 1 \end{array} \right]$$

and from here

$$T_i = T_i^{\ i} T_i$$

can be calculated as this from the root link of the robot to all the links for the first time To calculate posture information from the joint angle information of the whole body of the robot by applying it sequentially This is called forward kinematics.

### 18.1.2 Geometric Information Modeling with EusLisp

Geometric modeling in EusLisp involves the generation of a basic model (body), the composition function of the body, There are three steps to creating a combined model (bodyset).

So far, we have seen that it is possible to generate and synthesize the following basic models.

A bodyset is a composite model introduced in irreus, which can handle multiple objects and It is for handling multiple colors.

#### 18.1.3 Sample Program Using Parent-Child Relationship of Geometric Information

```
(setq c1 (make-cube 100 100 100))
(setq c2 (make-cube 50 50 50))
(send c1 :set-color :red)
(send c2 :set-color :blue)
(send c2 :locate #f(300 0 0))
(send c1 :assoc c2)
(objects (list c1 c2))
(do-until-key
  (send c1 :rotate (deg2rad 5) :z)
  (send *irtviewer* :draw-objects)
  (x::window-main-one) ;; process window event
)
```

#### 18.1.4 Modeling a Robot (Multi-Link System) using bodyset-link and joints

irteus provides a class called bodyset-link (irtmodel.l) as a class for describing robot links. It has mechanical information and geometric information, and the structure of the robot is represented by a general tree structure. In addition, joint information is handled using the joint class.

```
(defclass bodyset-link
    :super bodyset
```

The joint class (irtmodel.l) is used for modeling joints. The joint class is a base class, and actually uses rotational-joint, linear-joint, etc. A joint created by a child class of joint can specify the joint angle with the :joint-angle method.

```
(defclass joint
  :super propertied-object
  :slots (parent-link child-link joint-angle min-angle max-angle
default-coords))
(defmethod joint
  (:init (&key name
                ((:child-link clink)) ((:parent-link plink))
                (min -90) (max 90) &allow-other-keys)
         (send self :name name)
         (setq parent-link plink child-link clink
               min-angle min max-angle max)
         self))
(defclass rotational-joint
  :super joint
:slots (axis))
(defmethod rotational-joint
  (:init (&rest args &key ((:axis ax) :z) &allow-other-keys)
         (setq axis ax joint-angle 0.0)
         (send-super* :init args)
         self)
  (:joint-angle
   (&optional v)
   (when v
        (setq relang (- v joint-angle) joint-angle v)
        (send child-link :rotate (deg2rad relang) axis)))
     joint-angle))
 Here we use joint, parent-link, child-links and defualt-coords.
 If you make a servo module as an example of a simple one-joint robot,
(defun make-servo nil
  (let (b1 b2)
    (setq b1 (make-cube 35 20 46))
    (send b1 :locate #f(9.5 0 0))
    (setq b2 (make-cylinder 3 60))
    (send b2 :locate #f(0 0 -30))
    (setq b1 (body+ b1 b2))
    (send b1 :set-color :gray20)
    b1))
(defun make-hinji nil
  (let ((b2 (make-cube 22 16 58))
        (b1 (make-cube 26 20 54)))
    (send b2 :locate #f(-4 0 0))
    (setq b2 (body- b2 b1))
    (send b1 :set-color :gray80)
    b2))
(setq h1 (instance bodyset-link :init (make-cascoords) :bodies (list (make-hinji))))
(setq s1 (instance bodyset-link :init (make-cascoords) :bodies (list (make-servo))))
(setq j1 (instance rotational-joint :init :parent-link h1 :child-link s1 :axis :z))
;; instance cascaded coords
(setq r (instance cascaded-link :init))
(send r :assoc h1)
```

```
(send h1 :assoc s1)
(setq (r . links) (list h1 s1))
(setq (r . joint-list) (list j1))
(send r :init-ending)
```

Here, a bodyset-link of h1 and s1 and a rotational-joint of j1 are created, and from here cascaded-link A model consisting of connecting links is generated. cascaded-link is a child class of cascaded-coords, so the parent-child relationship of r (cascaded-link), h1, and s1 is set using :assoc.

The notation (r . links) accesses links which is a slot variable (member variable) of the object r. here, Appropriate values are set for links and joint-list, and necessary initialization is performed as (send r :init-ending).

This will generate one object called r containing two links and one joint information. For example, instead of (objects (list h1 s1)), the robot can be displayed in the viewer as (objects (list r)). You can also use (send r :locate #f(100 0 0)).

The following is an example of using the methods of the cascaded-link class. Provides access to joint angle vectors, as well as accessors to joint and link lists such as :joint-list and :links The :angle-vector method is important. If you call this without arguments, you can get the current joint angles. If you call this with joint angle vectors as arguments, you can reflect the joint angle vectors indicated by the arguments in the robot model.

```
$ (objects (list r))
(#<servo-model #X628abb0 0.0 0.0 0.0 / 0.0 0.0 0.0)
;; useful cascaded-link methods
$ (send r :joint-list)
(#<rotational-joint #X6062990 :joint101067152>)
$ (send r :links)
(#<bodyset-link #X62ccb10 :bodyset103598864 0.0 0.0 0.0 / 0.0 0.0 0.0>
#<bodyset-link #X6305830 :bodyset103831600 0.0 0.0 / 0.524 0.0 0.0>)
$ (send r :angle-vector)
#f(0.0)
$ (send r :angle-vector (float-vector 30))
#f(30.0)
```

### 18.1.5 Modeling of Robot (Multi-Link System) Using cascaded-link

On the other hand, there is a class called cascaded-link as a class for modeling multi-link systems. It has slot variables such as links and joint-list, to which lists of instances of bodyset-link and joint are bound and used. The following is an example of how to define a child class of cascaded-link and perform initialization processing related to robot modeling here.

```
:super cascaded-link
 :slots (h1 s1 j1))
(defmethod servo-model
  (:init ()
   (let ()
     (send-super :init)
     (setq h1 (instance bodyset-link :init (make-cascoords) :bodies (list (make-hinji))))
     (setq s1 (instance bodyset-link :init (make-cascoords) :bodies (list (make-servo))))
     (setq j1 (instance rotational-joint :init :parent-link h1 :child-link s1 :axis :z))
     ;; instance cascaded coords
     (setq links (list h1 s1))
     (setq joint-list (list j1))
     (send self :assoc h1)
     (send h1 :assoc s1)
     (send self :init-ending)
    self))
     (send r :j1 :joint-angle 30)
  (:j1 (&rest args) (forward-message-to j1 args))
(setq r (instance servo-model :init))
```

If you define a class like this and run (setq r (instance servo-model :init)), you can create an instance of the robot model in the same way, and use the previous method. The advantage of defining a class is that the method definition (:j1 (&rest args) (forward-message-to j1 args)) provides an accessor to the instance of the joint model. This allows you to use (send r :j1 :joint-angle) or (send r :j1 :joint-angle 30) It is possible to instruct When moving this robot, just like the previous example

```
(objects (list r))
(dotimes (i 300)
    (send r :angle-vector (float-vector (* 90 (sin (/ i 100.0)))))
    (send *irtviewer* :draw-objects))

and so on.

(setq i 0)
(do-until-key
    (send r :angle-vector (float-vector (* 90 (sin (/ i 100.0)))))
    (send *irtviewer* :draw-objects)
        (incf i))
```

will keep the program running until the next time you press the keyboard.

In addition, an example of modeling a 3-link 2-joint robot using this by extending it a little is shown below. All joint angle sequences can be specified by giving a vector  $\#f(0\ 0)$  to the method :joint-angle.

```
(defclass hinji-servo-robot
    :super cascaded-link)
(defmethod hinji-servo-robot
    (:init
          ()
          (let (h1 s1 h2 s2 l1 l2 l3)
                (send-super :init)
               (setq h1 (make-hinji))
                (setq s1 (make-servo))
                (setq s2 (make-servo))
                (setq s2 (make-servo))
                 (send h2 :locate #f(42 0 0))
                 (send s1 :assoc h2)
                      (setq l1 (instance bodyset-link :init (make-cascoords) :bodies (list h1)))
```

```
(setq 12 (instance bodyset-link :init (make-cascoords) :bodies (list s1 h2)))
     (setq 13 (instance bodyset-link :init (make-cascoords) :bodies (list s2)))
     (send 13 :locate #f(42 0 0))
     (send self :assoc 11)
     (send 11 :assoc 12)
     (send 12 :assoc 13)
     (setq joint-list
           (list
            (instance rotational-joint
                      :init :parent-link 11 :child-link 12
                      :axis :z)
            (instance rotational-joint
                      :init :parent-link 12 :child-link 13
                      :axis :z)))
     (setq links (list 11 12 13))
     (send self :init-ending)
    )))
(setq r (instance hinji-servo-robot :init))
(objects (list r))
(dotimes (i 10000)
  (send r :angle-vector (float-vector (* 90 (sin (/ i 500.0))) (* 90 (sin (/ i 1000.0)))))
  (send *irtviewer* :draw-objects))
```

#### 18.1.6 Forward Kinematics Calculations in EusLisp

For forward kinematics calculations, use the :worldcoords method defined in the cascaded-corods, bodyset, and bodyset-link classes. The :worldcoords method performs a forward kinematics calculation by calling the :worldcoords method of the parent link backward until the root link is found (the parent link disappears) or until a link is found for which the slot variable changed is nil (a forward kinematics calculation has once been performed). The calculation is performed by calling the :worldcoords method of the parent link. In doing so, the slot variable changed is overwritten with nil. Therefore, the second call to the :worldcoords method does not calculate the forward kinematics of the link that has been calculated once, and the position and orientation information of the link can be retrieved immediately.

The :worldcoords method of the bodyset-link class can take a level argument, and if it is :coords, the forward kinematics calculation of the bodies slot variable of the link is not performed. If the bodies contains facesets that constitute the vertices of the link, then a significant speedup can be expected by omitting the forward kinematics calculation for these facesets. Since the initial value of the level argument is the analysis-level slot variable of the link, if you do not want to always calculate the forward kinematics of bodies, you can use (send 1 :analysis-level :coords) for the instance l of the link. for instance l of the link.

#### 18.2 Robot Motion Generation

#### 18.2.1 Inverse Kinematics

In inverse kinematics, the joint angle vector of the manipulator  $\boldsymbol{\theta} = (\theta_1, \theta_2, ..., \theta_n)^T$  is obtained from the end-effector's position and orientation  ${}_n^0 \boldsymbol{H}$ .

where position/orientation of end effector r In inverse kinematics, position/orientation of end effector  ${}^{0}_{n}H$  to joint of manipulator Find the angular vector  $\boldsymbol{\theta} = (\theta_1, \theta_2, ..., \theta_n)^T$ .

where position/orientation of end effector r is called the joint angle vector

$$r = f(\theta) \tag{1}$$

Equation 18.2.1 is Equation 18.2.1 and obtain the joint angle vector.

$$\boldsymbol{\theta} = \boldsymbol{f}^{-1}(\boldsymbol{r}) \tag{2}$$

 $f^{-1}$  in is generally a nonlinear function. Therefore, by differentiating with respect to time t, we get the linear expression

$$\dot{\mathbf{r}} = \frac{\partial \mathbf{f}}{\partial \boldsymbol{\theta}}(\boldsymbol{\theta})\dot{\boldsymbol{\theta}} \tag{3}$$

$$= J(\theta)\dot{\theta} \tag{4}$$

. where  $J(\theta)$  is the Jacobian matrix of  $m \times n$ . m is the dimension of vector  $\mathbf{r}$  and n is the dimension of vector  $\theta$ .  $\dot{\mathbf{r}}$  is the velocity/angular velocity vector.

When the Jacobian matrix is nonsingular, we can solve this linear equation using the inverse matrix  $J(\theta)^{-1}$  as follows.

$$\dot{\boldsymbol{\theta}} = \boldsymbol{J}(\boldsymbol{\theta})^{-1} \dot{\boldsymbol{r}} \tag{5}$$

However, since Jacobian matrices are generally nonsingular, The pseudo-inverse of the Jacobian matrix  $J^{\#}(\theta)$  is used (Equation 17).

$$\mathbf{A}^{\#} = \begin{cases} \mathbf{A}^{-1} & (m = n = rank\mathbf{A}) \\ \mathbf{A}^{T} & (\mathbf{A}\mathbf{A}^{T})^{-1}(n > m = rank\mathbf{A}) \\ (\mathbf{A}^{T}\mathbf{A})^{-1}\mathbf{A}^{T} & (m > n = rank\mathbf{A}) \end{cases}$$
(6)

Equation 15 is Equation 18 when m > n, Equation ?? as a problem of finding a least-squares solution to minimize, and obtain a solution.

$$\min_{\dot{\boldsymbol{\theta}}} \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right)^{T} \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right) \tag{7}$$

$$\begin{array}{ll}
\min & \dot{\boldsymbol{\theta}}^T \dot{\boldsymbol{\theta}} \\
\dot{\boldsymbol{\theta}} \\
s.t. & \dot{\boldsymbol{r}} = \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}}
\end{array} \tag{8}$$

The joint angular velocity is obtained as follows.

$$\dot{\boldsymbol{\theta}} = \boldsymbol{J}^{\#}(\boldsymbol{\theta})\dot{\boldsymbol{r}} + \left(\boldsymbol{E}_{n} - \boldsymbol{J}^{\#}(\boldsymbol{\theta})\boldsymbol{J}(\boldsymbol{\theta})\right)\boldsymbol{z}$$
(9)

However, when solving according to Equation 20,  $|\dot{\boldsymbol{\theta}}|$  becomes large and unstable behavior occurs. Therefore, Nakamura et al.'s SR-Inverse<sup>4</sup> avoids this singularity.

In this study, instead of the pseudo-inverse  $J^{\#}(\theta)$  of the Jacobian matrix, we use  $J^{*}(\theta)$  shown in Equation 21 .

$$\boldsymbol{J}^*(\boldsymbol{\theta}) = \boldsymbol{J}^T \left( \boldsymbol{J} \boldsymbol{J}^T + \epsilon \boldsymbol{E}_m \right)^{-1}$$
 (10)

This is obtained by solving an optimization problem that minimizes Equation 22 instead of Equation 18 .

$$\min_{\dot{\boldsymbol{\theta}}} \{ \dot{\boldsymbol{\theta}}^T \dot{\boldsymbol{\theta}} + \epsilon \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right)^T \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right) \} \tag{11}$$

The index of whether the Jacobian matrix  $J(\theta)$  is approaching a singularity is the manipulability  $\kappa(\theta)^5$  is used (Equation 23).

$$r = f(\theta) \tag{12}$$

Equation 18.2.1 is Equation 18.2.1 and obtain the joint angle vector.

$$\boldsymbol{\theta} = \boldsymbol{f}^{-1}(\boldsymbol{r}) \tag{13}$$

 $f^{-1}$  in is generally a nonlinear function. Therefore, by differentiating with respect to time t, the linear expression is obtained

$$\dot{\mathbf{r}} = \frac{\partial \mathbf{f}}{\partial \boldsymbol{\theta}}(\boldsymbol{\theta})\dot{\boldsymbol{\theta}} \tag{14}$$

$$= J(\theta)\dot{\theta} \tag{15}$$

where  $J(\theta)$  is the Jacobian matrix of  $m \times n$ . m is the dimension of vector  $\mathbf{r}$  and n is the dimension of vector  $\mathbf{\theta}$ .  $\dot{\mathbf{r}}$  is the velocity/angular velocity vector.

When the Jacobian matrix is nonsingular, we can solve this linear equation using the inverse matrix  $J(\theta)^{-1}$  as follows:

$$\dot{\boldsymbol{\theta}} = \boldsymbol{J}(\boldsymbol{\theta})^{-1} \dot{\boldsymbol{r}} \tag{16}$$

However, since the Jacobian matrix is generally nonsingular, the pseudo-inverse of the Jacobian matrix  $J^{\#}(\theta)$  is used (Equation 17).

$$\mathbf{A}^{\#} = \begin{cases} \mathbf{A}^{-1} & (m = n = rank\mathbf{A}) \\ \mathbf{A}^{T} & (\mathbf{A}\mathbf{A}^{T})^{-1}(n > m = rank\mathbf{A}) \\ (\mathbf{A}^{T}\mathbf{A})^{-1}\mathbf{A}^{T} & (m > n = rank\mathbf{A}) \end{cases}$$
(17)

<sup>&</sup>lt;sup>4</sup>Inverse kinematic solutions with singularity robustness for robot Manipulator control: Y. Nakamura and H. Hanafusa, Journal of Dynamic Systems, Measurement, and Control, vol. 108, pp 163-171, 1986

<sup>&</sup>lt;sup>5</sup>Robot Arm Manipulability, Tsuneo Yoshikawa, Journal of the Robotics Society of Japan, vol. 2, no. 1, pp. 63-67, 1984.

Equation 15 is Equation 18 when m > n, Equation ?? as a problem of finding a least-squares solution to minimize, and obtain a solution.

$$\min_{\dot{\boldsymbol{\theta}}} \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right)^{T} \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right) \tag{18}$$

$$\begin{array}{ll}
\min & \dot{\boldsymbol{\theta}}^T \dot{\boldsymbol{\theta}} \\
\dot{\boldsymbol{\theta}} \\
s.t. & \dot{\boldsymbol{r}} = \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}}
\end{array} \tag{19}$$

The joint angular velocity is obtained as follows:

$$\dot{\boldsymbol{\theta}} = \boldsymbol{J}^{\#}(\boldsymbol{\theta})\dot{\boldsymbol{r}} + \left(\boldsymbol{E}_{n} - \boldsymbol{J}^{\#}(\boldsymbol{\theta})\boldsymbol{J}(\boldsymbol{\theta})\right)\boldsymbol{z}$$
(20)

However, when solving according to Equation 20,  $|\dot{\boldsymbol{\theta}}|$  becomes large and unstable behavior occurs. Therefore, Nakamura et al.'s SR-Inverse<sup>6</sup> to avoid this singularity.

In this research, instead of the pseudo-inverse of the Jacobian matrix  $J^{\#}(\theta)$ , J shown in Equation 21 U se $^{*}(\theta)$ .

$$\boldsymbol{J}^*(\boldsymbol{\theta}) = \boldsymbol{J}^T \left( \boldsymbol{J} \boldsymbol{J}^T + \epsilon \boldsymbol{E}_m \right)^{-1}$$
 (21)

This is obtained by solving an optimization problem that minimizes Equation 22 instead of Equation 18.

$$\min_{\dot{\boldsymbol{\theta}}} \{ \dot{\boldsymbol{\theta}}^T \dot{\boldsymbol{\theta}} + \epsilon \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right)^T \left( \dot{\boldsymbol{r}} - \boldsymbol{J}(\boldsymbol{\theta}) \dot{\boldsymbol{\theta}} \right) \}$$
 (22)

The index of whether the Jacobian matrix  $J(\theta)$  is approaching a singularity is the manipulability  $\kappa(\theta)^7$  is used (Equation 23).

$$\kappa(\boldsymbol{\theta}) = \sqrt{\boldsymbol{J}(\boldsymbol{\theta})\boldsymbol{J}^T(\boldsymbol{\theta})} \tag{23}$$

Task space dimension selection matrix in differential kinematic equations<sup>8</sup> is omitted for the sake of clarity, but it should be noted in advance that it can be applied to all formulas derived below.

#### 18.2.2 Basic Jacobian Matrix

The Jacobian of a manipulator with a one-dimensional pair joint is the fundamental Jacobian matrix  $^9$ . The column vector  $J_j$  of the Jacobian corresponding to the j-th joint of the underlying Jacobian matrix is represented as:

$$J_{j} = \left\{ \begin{bmatrix} a_{j} \\ 0 \end{bmatrix} & \text{if linear joint} \\ a_{j} \times (p_{end} - p_{j}) \\ a_{j} \end{bmatrix} \text{ if rotational joint}$$

$$(24)$$

<sup>&</sup>lt;sup>6</sup>Inverse kinematic solutions with singularity robustness for robot Manipulator control: Y.Nakamura and H. Hanafusa, Journal of Dynamic Systems, Measurement, and Control, vol. 108, pp 163-171, 1986

<sup>&</sup>lt;sup>7</sup>Robot Arm Manipulability, Tsuneo Yoshikawa, Journal of the Robotics Society of Japan, vol. 2, no. 1, pp. 63-67, 1984.

<sup>&</sup>lt;sup>8</sup>Hybrid Position/Force Control: A Correct Formation, William D. Fisher, M. Shahid Mujtaba, The International Journal of Robotics Research, vol. 11, no. 4, pp. 299-311, 1992.

<sup>&</sup>lt;sup>9</sup>A unified approach for motion and force control of robot manipulators: The operational space formulation, O. Khatib, IEEE Journal of Robotics and Automation, vol. 3, no 1, pp. 43-53, 1987.

 $a_j$  and  $p_j$  are the joint axis unit vector and the position vector of the jth joint, respectively, and  $p_{end}$  is the Jacobian is the position vector of the end effector that controls. In the above, the 1-DOF pair revolute joints and prismatic joints were derived, but the Jacobian can also be defined as a matrix connecting these column vectors for other joints. The two-degree-of-freedom joints representing the motion of the non-omnidirectional bogie can be composed of forward and backward translational joints and rotary joints for turning. The 3-DOF joint that represents the motion of the omnidirectional cart consists of a translational 2-DOF prismatic joint and a rotary joint for turning. A ball-and-socket joint can be regarded as a combination of three rotary joints, assuming that the posture is the posture matrix and the posture change is the equivalent angular axis transformation.

#### 18.2.3 Inverse Kinematics Including Joint Angle Limit Avoidance

In the trajectory generation of the robot manipulator, it is important to consider the joint angle limit in the real machine experiment with the robot. In this section, Inverse kinematics, including avoidance of joint angle limits, is explained by citing formulas and sentences of the literature  $^{10}$   $^{11}$ 

We define the weighted norm as follows:

$$\left|\dot{\boldsymbol{\theta}}\right|_{\boldsymbol{W}} = \sqrt{\dot{\boldsymbol{\theta}}^T \boldsymbol{W} \dot{\boldsymbol{\theta}}} \tag{25}$$

where W is  $W \in \mathbb{R}^{n \times n}$ , the weighting coefficient matrix with all elements positive in the object. Using this W,  $J_{W}$ ,  $\dot{\theta}_{W}$  is defined in

$$J_{\mathbf{W}} = JW^{-\frac{1}{2}}, \dot{\boldsymbol{\theta}}_{\mathbf{W}} = W^{\frac{1}{2}}\dot{\boldsymbol{\theta}}$$
 (26)

Using this  $\boldsymbol{J_W}$ ,  $\boldsymbol{\dot{\theta}_W}$ , we obtain the following equation.

$$\dot{r} = J_W \dot{\theta}_W \tag{27}$$

$$\left|\dot{\boldsymbol{\theta}}\right|_{\boldsymbol{W}} = \sqrt{\dot{\boldsymbol{\theta}}_{\boldsymbol{W}}^T \dot{\boldsymbol{\theta}}_{\boldsymbol{W}}} \tag{28}$$

With this, the solution of the linear equation can be written from <sup>11</sup> as follows:

$$\dot{\boldsymbol{\theta}}_{\boldsymbol{W}} = \boldsymbol{W}^{-1} \boldsymbol{J}^T \left( \boldsymbol{J} \boldsymbol{W}^{-1} \boldsymbol{J}^T \right)^{-1} \dot{\boldsymbol{r}}$$
 (29)

Also, a function  $H(\theta)$  to evaluate how much margin the current joint angle  $\theta$  has relative to the joint angle limits  $\theta_{i,\max}, \theta_{i,\min}$  is given by  $\theta_{i,\max}$ .

$$H(\boldsymbol{\theta}) = \sum_{i=1}^{n} \frac{1}{4} \frac{(\theta_{i,\text{max}} - \theta_{i,\text{min}})^2}{(\theta_{i,\text{max}} - \theta_i)(\theta_i - \theta_{i,\text{min}})}$$
(30)

Next, consider a  $n \times n$  weighting coefficient matrix  $\boldsymbol{W}$  as shown in Equation 31 .

$$\mathbf{W} = \begin{bmatrix} w_1 & 0 & 0 & \cdots & 0 \\ 0 & w_2 & 0 & \cdots & 0 \\ \vdots & \vdots & \ddots & \vdots & \vdots \\ 0 & 0 & 0 & \cdots & w_n \end{bmatrix}$$
(31)

Exploiting Task Intervals for Whole Body Robot Control, Michael Gienger and Herbert Jansen and Christian Goeric In Proceedings of the 2006 IEEE/RSJ International Conference on Intelligent Robots and Systems (IROS'06), pp. 2484 - 2490, 2006

<sup>&</sup>lt;sup>11</sup> A weighted least-norm solution based scheme for avoiding jointlimits for redundant joint manipulators, Tan Fung Chan and Dubey R.V., Robotics and Automation, IEEE Transactions on, pp. 286-292,1995

<sup>&</sup>lt;sup>12</sup> Efficient gradient projection optimization for manipulators withmultiple degrees of redundancy, Zghal H., Dubey R.V., Euler J.A., 1990 IEEE International Conference on Robotics and Automation, pp. 1006-1011, 1990.

where  $w_i$  is

$$w_i = 1 + \left| \frac{\partial \boldsymbol{H}(\boldsymbol{\theta})}{\partial \theta_i} \right| \tag{32}$$

Furthermore, we get the following formula from Equation 30:

$$\frac{\partial H(\boldsymbol{\theta})}{\partial \theta_i} = \frac{(\theta_{i,\text{max}} - \theta_{i,\text{min}})^2 (2\theta_i - \theta_{i,\text{max}} - \theta_{i,\text{min}})}{4(\theta_{i,\text{max}} - \theta_i)^2 (\theta_i - \theta_{i,\text{min}})^2}$$
(33)

If the joint angle moves away from the joint angle limit, there is no need to change the weighting coefficient matrix, so redefine  $w_i$  as follows:

$$w_{i} = \begin{cases} 1 + \left| \frac{\partial \boldsymbol{H}(\boldsymbol{\theta})}{\partial \theta_{i}} \right| & if \left| \frac{\partial \boldsymbol{H}(\boldsymbol{\theta})}{\partial \theta_{i}} \right| \ge 0 \\ 1 & if \left| \frac{\partial \boldsymbol{H}(\boldsymbol{\theta})}{\partial \theta_{i}} \right| < 0 \end{cases}$$
(34)

By using  $w_i$  and W, we can solve inverse kinematics including joint angle limit avoidance.

#### 18.2.4 Inverse Kinematics Including Collision Avoidance

Self-collisions during robot motion and collisions with the environment model can be calculated if a geometric model exists. Efficient collision avoidance calculation proposed by Sugiura et al. <sup>13</sup> <sup>14</sup> In addition to the method of Sugiura et al., the actual implementation uses a point that allows the use of NullSpace in the task workspace to be controlled by a coefficient, and uses SR-Inverse instead of a pseudo-inverse matrix. Points that are robust to singularities have been added.

#### 18.2.5 Joint Angular Velocity Calculation Method for Collision Avoidance

The integration of the target task and collision avoidance in the inverse kinematics calculation is performed by a blending coefficient using the shortest distance between links. As a result, when collision avoidance is not required, the target task is strictly satisfied, and when collision avoidance is required, the target task is given up to perform joint angular velocity calculations for collision avoidance. The final joint angular velocity relation is obtained by Equation 35 . In the following, the subscript of ca represents the component for collision avoidance calculation, and the part of task represents the task goal other than collision avoidance calculation.

$$\dot{\boldsymbol{\theta}} = f(d)\dot{\boldsymbol{\theta}}_{ca} + (1 - f(d))\dot{\boldsymbol{\theta}}_{task} \tag{35}$$

The blending factor f(d) is calculated as a function of the distance between links d and the threshold values  $d_a$  and  $d_b$ . (Equation 36).

$$f(d) = \begin{cases} (d - d_a)/(d_b - d_a) & if d < d_a \\ 0 & otherwise \end{cases}$$
 (36)

 $d_a$  is the value to start collision avoidance calculation (yellow zone<sup>14</sup>), and  $d_b$  is the threshold for collision avoidance even if it hinders the target task (orange zone<sup>14</sup>).

<sup>&</sup>lt;sup>13</sup> Real-Time Self Collision Avoidance for Humanoids by means of Nullspace Criteria and Task Intervals, H. Sugiura, M. Gienger, H. Janssen, C. Goerick, Proceedings of the 2006 IEEE-RAS International Conference on Humanoid Robots, pp. 575-580, 2006

<sup>&</sup>lt;sup>14</sup> Real-time collision avoidance with whole body motion control for humanoid robots, Hisashi Sugiura, Michael Gienger, Herbert Janssen, Christian Goerick, In Proceedings of the 2007 IEEE/RSJ International Conference on Intelligent Robots and Systems (IROS'07), pp. 2053 - 2068, 2007

When the shortest distance and nearest point between two links for collision calculation can be calculated, the motion strategy for avoiding collision is derived from the virtual reaction potential acting between the two links.

Equation 37 describes the velocity calculation derived from the reaction force between two links using the vector  $\boldsymbol{p}$  connecting the nearest points between two links.

$$\delta \boldsymbol{x} = \begin{cases} 0 & if |\boldsymbol{p}| > d_a \\ (d_a/|\boldsymbol{p}| - 1)\boldsymbol{p} & else \end{cases}$$
 (37)

The joint angular velocity calculation using this is Equation 38 .

$$\dot{\boldsymbol{\theta}}_{ca} = \boldsymbol{J}_{ca}^{T} k_{joint} \boldsymbol{\delta x} + (\boldsymbol{E}_{n} - \boldsymbol{J}_{task}^{*} \boldsymbol{J}_{task}) \boldsymbol{J}_{ca}^{T} k_{null} \boldsymbol{\delta x}$$
(38)

 $k_{joint}$  and  $k_{null}$  are coefficients that control whether or not the reaction potential is distributed to the NullSpace of the target task.

#### 18.2.6 Conflict Avoidance Calculation Example

The following shows an example of collision avoidance using a robot model and an environment model. In this research, the collision detection library PQP (A Proximity Query Package) was used to detect collisions between links of robots or between links and objects.  $^{15}$ 

In the Fig.19  $d_a = 200[mm], d_b = 0.1*d_a = 20[mm]$ , We set  $k_{joint} = k_{null} = 1.0$ .

In this collision detection calculation, we devised to set the link as shown in the collision detection.

- 1. Register link list  $n_{ca}$
- 2. Compute all link pairs  $n_{ca}C_2$  from the list of registered links
- 3. Exclude pairs of adjacent links, pairs of links that always intersect, etc.

Fig.19 In the example, four links for collision detection are registered as "forearm link", "upper arm link", "trunk link", and "base link". In this case, adjacent links are excluded from the number of link pairs of  ${}_{4}C_{2}$ , and all link pairs are "forearm link-trunk link", "forearm link-base link", and "upper arm link-base link".

The three lines (1 red, 2 green) in Fig.19 are the shortest distance vectors that connect the closest points between the collision shape models. Of all link pairs, the red line is the pair with the shortest distance, and inverse kinematics calculations for collision avoidance are performed from this link pair.

# 18.2.7 Whole-body Coordinated Motion Generation by Non-Block Diagonal Jacobian


Humanoids have a complex structure with branches, and it is necessary to perform coordinated movements with multiple manipulators. (Fig. 20).

As an example of the operation of multiple manipulators, in the next section, we describe a non-block-diagonal Jacobian calculation method when there is overlap between links and a joint angular velocity calculation method using it. (Even if the former does not overlap, it can be calculated as part of the latter by the following calculation method):

<sup>&</sup>lt;sup>15</sup> Fast distance queries with rectangular swept sphere volumes, Larsen E., Gottschalk S., Lin M.C., Manocha D, Proceedings of The 2000 IEEE International Conference on Robotics and Automation, pp. 3719-3726, 2000.



☑ 19: Example of Collision Avoidance



☑ 20: Duplicate Link Sequence

- If there is no overlap between links

  About each manipulator Calculate the joint angular velocity using the Equation 16 formula. Alternatively, joint angular velocities can be obtained using an equation that combines multiple equations (the Jacobian is a block-diagonal matrix).
- If there are duplicates between links

  If there is duplication between links, it is necessary to consider the Jacobian considering the duplication between links. For example, when performing a double-arm motion, the link sequence of the manipulator of the left arm and the link sequence of the manipulator of the right arm overlap the trunk link sequence, and it is necessary to obtain the joint angular velocity by coordinating the left

and right parts.

### 18.2.8 Jacobian Calculation with Inter-Link Overlap and Joint Angle Calculation

The conditions for obtaining the differential kinematic equation are shown below:

- $\bullet$  Number of manipulators L
- $\bullet$  Total number of joints N
- • Tip velocity and angular velocity vector of manipulator [  $\pmb{\xi}_0^T,...,\pmb{\xi}_{L-1}^T]^T$
- Indexed union of joints  $S = \{0, ..., N-1\}$ However, using the index set  $S_i$  of the manipulator i, S can be expressed as  $S = S_0 \cup ... \cup S_{L-1}$ .
- Joint velocity vector  $[\dot{\theta}_0,...,\dot{\theta}_{N-1}]^T$  based on S

The kinematic relation is Equation 39.

$$\begin{bmatrix} \boldsymbol{\xi}_{0} \\ \vdots \\ \boldsymbol{\xi}_{L-1} \end{bmatrix} = \begin{bmatrix} \boldsymbol{J}_{0,0} & \dots & \boldsymbol{J}_{0,N-1} \\ \vdots & \boldsymbol{J}_{i,j} & \vdots \\ \boldsymbol{J}_{L-1,0} & \dots & \boldsymbol{J}_{L-1,N-1} \end{bmatrix} \begin{bmatrix} \dot{\theta}_{0} \\ \vdots \\ \dot{\theta}_{N-1} \end{bmatrix}$$
(39)

The minor matrix  $J_{i,j}$  is obtained as follows:

$$J_{i,j} = \begin{cases} J_j & \text{if } j\text{-th joint } \in i\text{-th link array} \\ \mathbf{0} & \text{otherwise} \end{cases}$$

$$\tag{40}$$

where  $J_j$  is for Equation 24.

Joint angular velocities can be obtained using Equation 39 as well as the inverse kinematics solution for a single manipulator using SR-Inverse.

The calculation method of the non-block diagonal Jacobian here can derive the Jacobian obtained from the kinematic relational expressions that appear in the motion generation of the arm and multifingered hand.

### 18.2.9 Whole-body Inverse Kinematics Method Using Base-Link Virtual Joints

In general, to express the motion of a robot with N joints, N+6 variables including the positions and orientations of the base links and the degrees of freedom of the joint angles are required. The formulation of the robot's motion using the position and orientation variables that serve as the base link is important not only for space robots<sup>17</sup>but also for humanoid robots <sup>18</sup>that are not fixed to the environment.

<sup>&</sup>lt;sup>16</sup> Grasping and Manipulation by Arm and Multifingered Hand Mechanism, Kiyoshi Nagai, Tsuneo Yoshikawa, Journal of the Robotics Society of Japan, vol. 13, no. 7, pp. 994-1005, 1995.

<sup>&</sup>lt;sup>17</sup> Resolved Velocity Control of Space Robot Manipulator Using Generalized Jacobian Matrix, Yoji Umetani, Kazuya Yoshida, Journal of the Robotics Society of Japan, vol. 4, no. 7, pp. 63-73, 1989.

<sup>&</sup>lt;sup>18</sup> Control of Free-Floating Humanoid Robots Through Task Prioritization, Luis Sentis and Oussama Khatib, Proceedings of The 2005 IEEE International Conference on Robotics and Automation, pp. 1718-1723, 2005

Here, we consider a manipulator configuration in which a linear joint with 3 degrees of freedom and a rotational joint with 3 degrees of freedom are virtually attached to the base link of manipulators such as arms and legs (Fig.21). In this study, we call the above virtual 6-DOF joint a base-link virtual joint. By using the base link virtual joints, the humanoid's waist moves and the whole body joints are driven, and it is expected that the kinematics and dynamics solution space will be expanded.




図 21: Concept of the Virtual Joint of the Base Link (Left figure) Overview of the Robot Model (Right figure) Skeleton Figure of Robot Model with the Virtual Joint

# 18.2.10 Base-Link Virtual Joint Jacobian

The Jacobian of the base-link virtual joint uses the calculation of the basic Jacobian matrix (Equation 24), A  $6 \times 6$  matrix that connects the prismatic joints around the absolute coordinate system x, y, and z axes and the rotational joints around the absolute coordinate system x, y, and z axes, respectively. By the way, the Jacobian of the root link virtual joint of the translation and rotation components can also be written as follows:

$$\boldsymbol{J}_{B,l} = \begin{bmatrix} \boldsymbol{E}_3 & -\hat{\boldsymbol{p}}_{B\to l} \\ \mathbf{0} & \boldsymbol{E}_3 \end{bmatrix}$$
 (42)

 $p_{B\to l}$  is the differential vector from the base link position to the position represented by the subscript l.

# 18.2.11 Mass Property Calculation

Integrate multiple mass-center-of-inertia matrices into a single set of mass-center-of-inertia matrices We define an arithmetic function to compute  $[m_{new}, c_{new}, I_{new}]$  as follows:

$$[m_{new}, \boldsymbol{c}_{new}, \boldsymbol{I}_{new}] = AddMassProperty([m_1, \boldsymbol{c}_1, \boldsymbol{I}_1], \dots, [m_K, \boldsymbol{c}_K, \boldsymbol{I}_K])$$
(43)

This is an operation such as:

$$m_{new} = \sum_{j=1}^{K} m_j \tag{44}$$

$$\boldsymbol{c}_{new} = \frac{1}{m_{new}} \sum_{j=1}^{K} m_j \boldsymbol{c}_j \tag{45}$$

$$\boldsymbol{I}_{new} = \sum_{j=1}^{K} (\boldsymbol{I}_j + m_j \boldsymbol{D} (\boldsymbol{c}_j - \boldsymbol{c}_{new}))$$
(46)

Here, let  $\mathbf{D}(\mathbf{r}) = \hat{\mathbf{r}}^T \hat{\mathbf{r}}$ .

# 18.2.12 Momentum/Angular Momentum Jacobian

Deriving momentum and angular momentum Jacobian for a serial link manipulator. The momentum and angular momentum around the origin are expressed by each joint variable, and the Jacobian row is calculated by the partial derivative.

Let  $\theta_j$  be the motion variable of the jth joint. First, we consider a 1-DOF joint of rotation and translation.

$$\mathbf{P}_{j} = \begin{cases} \mathbf{a}_{j}\dot{\theta}_{j} \times (\tilde{\mathbf{c}}_{j} - \mathbf{p}_{j})\tilde{m}_{j} & \text{if rotational joint} \\ \mathbf{a}_{j}\dot{\theta}_{j}\tilde{m}_{j} & \text{if linear joint} \end{cases}$$

$$(47)$$

$$L_{j} = \begin{cases} \tilde{c}_{j} P_{j} + \tilde{I}_{j} a_{j} \dot{\theta}_{j} & \text{if rotational joint} \\ 0 & \text{if linear joint} \end{cases}$$

$$(48)$$

Here,  $[\tilde{m}_j, \tilde{c}_j, \tilde{I}_j]$  is the AddMassProperty function with the mass property of the link on the distal side of the child link of the j joint, and is actually calculated by recursive calculation<sup>19</sup>. Dividing these by  $\dot{\theta}_j$  gives each column vector of the Jacobian.

$$\boldsymbol{m}_{j} = \begin{cases} \boldsymbol{a}_{j} \times (\tilde{\boldsymbol{c}}_{j} - \boldsymbol{p}_{j}) \tilde{m}_{j} & \text{if rotational joint} \\ \boldsymbol{a}_{j} \tilde{m}_{j} & \text{if linear joint} \end{cases}$$

$$(49)$$

$$h_{j} = \begin{cases} \tilde{\boldsymbol{c}}_{j} \times \boldsymbol{m}_{j} + \tilde{\boldsymbol{I}}_{j} \boldsymbol{a}_{j} & \text{if rotational joint} \\ \boldsymbol{0} & \text{if linear joint} \end{cases}$$

$$(50)$$

From this, the inertia matrix can be calculated as follows:

$$\boldsymbol{M}_{\dot{\boldsymbol{\theta}}} = [\boldsymbol{m}_1, \dots, \boldsymbol{m}_N] \tag{51}$$

$$\boldsymbol{H}_{\dot{\boldsymbol{\theta}}} = [\boldsymbol{h}_1, \dots, \boldsymbol{h}_N] - \hat{\boldsymbol{p}}_G \boldsymbol{M}_{\dot{\boldsymbol{\theta}}}$$
 (52)

Here, the total number of joints is set to N. The base link is considered to have prismatic joints x, y, and z axes, and rotational joints x, y, and z axes.

$$\begin{bmatrix} \mathbf{M}_B \\ \mathbf{H}_B \end{bmatrix} = \begin{bmatrix} M_r \mathbf{E}_3 & -M_r \hat{\mathbf{p}}_{B \to G} \\ \mathbf{0} & \tilde{\mathbf{I}} \end{bmatrix}$$
 (53)

Using this, the angular momentum and momentum around the center of gravity are as follows:

$$\begin{bmatrix} \mathbf{P} \\ \mathbf{L} \end{bmatrix} = \begin{bmatrix} \mathbf{M}_B & \mathbf{M}_{\dot{\boldsymbol{\theta}}} \\ \mathbf{H}_B & \mathbf{H}_{\dot{\boldsymbol{\theta}}} \end{bmatrix} \begin{bmatrix} \boldsymbol{\xi}_B \\ \dot{\boldsymbol{\theta}} \end{bmatrix}$$
 (54)

<sup>&</sup>lt;sup>19</sup> Resolved Momentum Control:Humanoid Motion Planning based on the Linear and Angular Momentum, S.Kajita, F.Kanehiro, K.Kaneko, K.Fujiwara, K.Harada, K.Yokoi,H.Hirukawa, In Proceedings of the 2003 IEEE/RSJ International Conference on Intelligent Robots and Systems (IROS'03), pp. 1644-1650, 2003

Here, total mass of humanoid  $M_r$ , centroid position  $p_G$ , the inertia tensor  $\tilde{I}$  is obtained from the mass property calculation of all links.

$$[M_r, \boldsymbol{p}_G, \tilde{\boldsymbol{I}}] = AddMassProperty([m_1, \boldsymbol{c}_1, \boldsymbol{I}_1], \dots, [m_N, \boldsymbol{c}_N, \boldsymbol{I}_N])$$
(55)

#### 18.2.13 Centroid Jacobian

Centroid JacobianThe center-of-mass Jacobian is the Jacobian between the center-of-mass velocity and the joint angular velocity. Since the base link virtual joint is used in this paper, it is assumed that the base link has a joint with 6 degrees of freedom. Specifically, the center-of-gravity jacobian is calculated by dividing the momentum jacobian of the base link component  $M_B$  and the component  $M'_{\dot{\theta}}$  extracted for the used joint by the total mass.

$$\boldsymbol{J}_{G} = \frac{1}{M_{r}} \begin{bmatrix} \boldsymbol{M}_{B} & \boldsymbol{M}_{\boldsymbol{\dot{\theta}}}^{\prime} \end{bmatrix}$$
 (56)

# 18.3 Motion Generation Programming for Robots

# 18.3.1 An Example of Jacobian and Inverse Kinematics Using A Three-Axis Jointed Robot

A robot with 3-axis joints is defined, and examples of inverse kinematics and Jacobian calculations are introduced

The definition of a robot is as follows:

```
(defclass 3dof-robot
  :super cascaded-link
  :slots (end-coords 11 12 13 14 j1 j2 j3))
(defmethod 3dof-robot
  (:init ()
   (let (b)
     (send-super :init)
     (setq b (make-cube 10 10 20))
     (send b :locate #f(0 0 10))
     (send b :set-color :red)
     (setq 14 (instance bodyset-link :init (make-cascoords) :bodies (list b) :name '14))
     (setq end-coords (make-cascoords :pos #f(0 0 20)))
     (send 14 :assoc end-coords)
     (send 14 :locate #f(0 0 100))
     (setq b (make-cube 10 10 100))
     (send b :locate #f(0 0 50))
     (send b :set-color :green)
     (setq 13 (instance bodyset-link :init (make-cascoords) :bodies (list b) :name '13))
     (send 13 :assoc 14)
     (send 13 :locate #f(0 0 100))
     (setq b (make-cube 10 10 100))
     (send b :locate #f(0 0 50))
     (send b :set-color :blue)
     (setq 12 (instance bodyset-link :init (make-cascoords) :bodies (list b) :name '12))
     (send 12 :assoc 13)
     (send 12 :locate #f(0 0 20))
     (setq b (body+ (make-cube 10 10 20 :pos #f(0 0 10)) (make-cube 300 300 2)))
     (send b :set-color :white)
     (setq 11 (instance bodyset-link :init (make-cascoords) :bodies (list b) :name '11))
     (send 11 :assoc 12)
     (setq j1 (instance rotational-joint :init :name 'j1
                 :parent-link 11 :child-link 12 :axis :y :min -100 :max 100)
```

Here, the coordinates of the robot's hands are stored in a slot variable called end-coords, and methods are provided to access them.

As before, it is possible to create a robot model, display it, and specify the joint angles.

```
(setq r (instance 3dof-robot :init))
(objects (list r))
(send r :angle-vector #f(30 30 30))
```

Moreover, it is possible to display the end-coords (end-coordinate system) of the robot.

```
(send (send r :end-coords) :draw-on :flush t)
```

But it disappears when a mouse event occurs. For permanent display, use:

```
(objects (list r (send r :end-coords)))
```

Here are some examples of Jacobian and inverse kinematics. First and foremost is the list of links obtained as . This returns a link that can be traced from the root (body) of the robot to the link that is the argument.

```
(send r :link-list (send r :end-coords :parent))
```

The :calc-jacobian-from-link-list method takes a list of links and can compute the Jacobian corresponding to the joints in each link. Also, the coordinate system of the end effector is specified by the :move-target keyword argument. Other keyword arguments are described later.

Here, the link length (number of joints) is 3, so a 6-by-3 Jacobian (j) is calculated. If the inverse matrix (j#) is created and the target velocity and angular velocity (#f(1 0 0 0 0 0)) of the 6 degrees of freedom in position and posture are given, the corresponding joint velocity (da) can be calculated, which is added to the current joint angle ((v+ (send r :angle-vector) da)).

Next, we show an example in which the position of the robot's endpoint work is adjusted, but the posture is not constrained and can be left as it is. Here, there are :rotation-axis and :translation-axis as optional arguments of :calc-jacobian-from-link-list, which indicate constraint conditions for position and orientation, respectively. t is triaxial constraint, nil is no constraint, and :x, :y, :z can be specified.

```
(setq translation-axis t)
(setq rotation-axis nil)
(dotimes (i 2000)
  (setq j (send r :calc-jacobian-from-link-list
                 (send r :link-list (send r :end-coords :parent))
                 :move-target (send r :end-coords)
                 :rotation-axis rotation-axis
                 :translation-axis translation-axis))
  (setq j# (sr-inverse j))
  (setq c (make-cascoords :pos (float-vector (* 100 (sin (/ i 500.0))) 0 200)))
  (setq dif-pos (send (send r :end-coords) :difference-position c))
  (setq da (transform j# dif-pos))
  (send r :angle-vector (v+ (send r :angle-vector) da))
  (send *irtviewer* :draw-objects :flush nil)
  (send c :draw-on :flush t)
  Here, the 3-by-3 Jacobian is calculated by constraining only the three axes of position, and the velocity
is given to the joints of the robot from the inverse matrix of this. Furthermore, here the target coordinates
are displayed and flash processing is performed.
  (send *irtviewer* :draw-objects :flush nil)
  The screen is drawn on *irtviewer* as
  (send c :draw-on :flush t)
  :inverse-kinematics is an inverse kinematics method that summarizes the above computations. Spec-
ify the target coordinate system in the first argument, and specify :move-target, :translation-axis,
:rotation-axis . Also, if :debug-view keyword argument is given with t, the state of the calculation is
presented visually as well as text.
(setq c (make-cascoords :pos #f(100 0 0) :rpy (float-vector 0 pi 0)))
(send r :inverse-kinematics c
      :link-list (send r :link-list (send r :end-coords :parent))
      :move-target (send r :end-coords)
      :translation-axis t
      :rotation-axis t
      :debug-view t)
  Let's look at the following program as an example of when reverse kinematics fails.
(dotimes (i 400)
  (setq c (make-cascoords
              :pos (float-vector (+ 100 (* 80 (sin (/ i 100.0)))) 0 0)
              :rpy (float-vector 0 pi 0)))
  (send r :inverse-kinematics c
         :link-list (send r :link-list (send r :end-coords :parent))
        :move-target (send r :end-coords) :translation-axis t :rotation-axis t)
  (x::window-main-one)
  (send *irtviewer* :draw-objects :flush nil)
  (send c :draw-on :flush t)
  When I run this program, I get the following error:
;; inverse-kinematics failed.
;; dif-pos : \#f(11.7826 \ 0.0 \ 0.008449)/(11.7826/1)
;; dif-rot : #f(0.0 2.686130e-05 0.0)/(2.686130e-05/0.017453)
    coords: #<coordinates #X4bcccb0 0.0 0.0 / 0.0 0.0 0.0>
;;
    angles: (14.9993 150 15.0006)
;;
      args: ((#<cascaded-coords #X4b668a0 39.982 0.0 0.0 / 3.142 1.225e-16 3.14
2>) :link-list (#<bodyset-link #X4cf8e60 12 0.0 0.0 20.0 / 0.0 0.262 0.0> #<body
set-link #X4cc8008 13 25.866 0.0 116.597 / 3.142 0.262 3.142> #<bodyset-link #X4
c7a0d0 14 51.764 0.0 20.009 / 3.142 2.686e-05 3.142>) :move-target;; #<cascaded-coords #X4c93640 51.764 0.0 0.009 / 3.142 2.686e-05 3.142> :translation-axis t :
rotation-axis t)
```

This is a situation in which the hand cannot reach the target position due to the limitation of the joint drive range. In such a situation, for example, :rotation-axis nil can be specified if the position of the hand can be ignored as long as it reaches the target position.

Also, :thre and :rthre can be used to specify the position and orientation error, which is the termination condition of the inverse kinematics calculation. In situations where exact calculations are not required, it is a good idea to use a value larger than the default 1, (deg2rad 1).

Also, if the inverse kinematics calculation fails, by default it will return to the posture before starting the inverse kinematics calculation, but if you specify nil for the keyword argument :revert-if-fail After repeating the calculation of the number of times, it exits the function with that posture. The specified number of times can also be specified with the keyword argument :stop.

```
(setq c (make-cascoords :pos #f(300 0 0) :rpy (float-vector 0 pi 0)))
(send r :inverse-kinematics c
    :link-list (send r :link-list (send r :end-coords :parent))
    :move-target (send r :end-coords)
    :translation-axis t
    :rotation-axis nil
    :revert-if-fail nil)
```

### 18.3.2 Example In The irteus Sample Program

The cascaded-coords class provides a method called:

- (:link-list (to &optional form))
- (:calc-jacobian-from-link-list (link-list &key move-target (rotation-axis nil)))

The former takes a link as an argument, calculates the path from the root link to this link, and returns it as a list of links. The latter takes this list of links as an argument and computes the Jacobian with respect to the move-target coordinate system.

concatenate result-type a b concatenates a b and converts it back to result-type type, scale a b multiplies all elements of vector b by a scalar a, and matrix-log computes the matrix logarithm function.

```
(if (not (boundp '*irtviewer*)) (make-irtviewer))
(load "irteus/demo/sample-arm-model.1")
(setq *sarm* (instance sarmclass :init))
(send *sarm* :reset-pose)
(setq *target* (make-coords :pos #f(350 200 400)))
(objects (list *sarm* *target*))
(do-until-key
  ;; step 3
  (setq c (send *sarm* :end-coords))
  (send c :draw-on :flush t)
  ;; step 4
  ;; step 4
  (setq dp (scale 0.001 (v- (send *target* :worldpos) (send c :worldpos))) ;; mm->m
        dw (matrix-log (m* (transpose (send c :worldrot)) (send *target* :worldrot))))
  (format t "dp = ~7,3f ~7,3f ~7,3f, dw = ~7,3f ~7,3f ~7,3f~%" (elt dp 0) (elt dp 1) (elt dp 2)
          (elt dw 0) (elt dw 1) (elt dw 2))
  ;; step 5
  (when (< (+ (norm dp) (norm dw)) 0.01) (return))
  (setq ll (send *sarm* :link-list (send *sarm* :end-coords :parent)))
  (setq j (send *sarm* :calc-jacobian-from-link-list
                11 :move-target (send *sarm* :end-coords)
                :trnaslation-axis t :rotation-axis t))
  (setq q (scale 1.0 (transform (pseudo-inverse j) (concatenate float-vector dp dw))))
  ;; step 7
  (dotimes (i (length 11))
    (send (send (elt ll i) :joint) :joint-angle (elt q i) :relative t))
```

```
;; draw
(send *irtviewer* :draw-objects)
(x::window-main-one))
```

In actual programming, a method called :inverse-kinematics is prepared, and functions such as singularity and joint limit avoidance and self-collision avoidance are added here.

#### 18.3.3 Real Robot Model

Let's take a look at a practical sample program that uses an actual robot and environment.

First, read the model files of the robot and the environment. These files are stored in \$EUSDIR/models, and a program that loads these files and creates instances can be written as follows. (room73b2) and (h7) are functions defined in these files. The robot model (robot-model) is defined in the irtrobot.1 file and is a child class of the cascaded-link class. A robot is defined as a tree of larm,rarm,lleg,rleg,head links, and (send \*robot\* :larm) or (send \*robot\* :head) can be used to access the limb of the robot, enabling usage such as inverse kinematics for the right hand and inverse kinematics for the left hand.

```
(load "models/room73b2-scene.1")
(load "models/h7-robot.1")
(setq *room* (room73b2))
(setq *robot* (h7))
(objects (list *robot* *room*))
```

The robot has a method called :reset-pose that can be used to take the initial pose.

```
(send *robot* :reset-pose)
```

Next, we want to move the robot around the room. Typical coordinates in the room can be obtained with (send \*room\*:spots). To obtain the desired coordinates from among these, call the :spot method with the name of the coordinates as an argument. By the way, the definition of this method is in prog/jskeus/irteus/irtscene.l.

```
(defmethod scene-model
  (:spots
   (&optional name)
   (append
    (mapcan
    #'(lambda(x)(if (derivedp x scene-model) (send x :spots name) nil))
    objs)
    (mapcan #'(lambda (o)
(if (and (eq (class o) cascaded-coords)
 (or (null name) (string= name (send o :name))))
    (list o)))
   objs)))
  (:spot
   (name)
   (let ((r (send self :spots name)))
     (case (length r)
       (0 (warning-message 1 "could not found spot(~A)" name) nil)
       (1 (car r))
       (t (warning-message 1 "found multiple spot ~A for given name(~A)" r name) (car r)))))
 )
```

Since the robot is also a child class of the coordinates class, it can use the :move-to method. Also, since the origin of this robot is at the waist, move using the :locate method so that the feet touch the ground.

```
(send *robot* :move-to (send *room* :spot "cook-spot") :world)
(send *robot* :locate #f(0 0 550))
```

Currently, the robot is small on the screen of \*irtviewer\*, so use the following method to adjust the robot so that it fills the screen.

```
(send *irtviewer* :look-all
          (geo::make-bounding-box
          (flatten (send-all (send *robot* :bodies) :vertices))))
```

Next, an object in the environment is selected. Here we use the :object method. This behaves like :spots, :spot, so you can find out what objects are by (send-all (send \*room\* :objects) :name). In addition to room73b2-kettle, use room73b2-mug-cup or room73b2-knife.

```
(setq *kettle* (send *room* :object "room73b2-kettle"))
```

Immediately after the environment model is initialized, the objects are assoc'd in the room, so the parentchild relationship is resolved as follows. If this is not done, there will be problems when grasping objects, etc.

```
(if (send *kettle* :parent) (send (send *kettle* :parent) :dissoc *kettle*))
```

There are the following methods for directing the robot's line of sight to the target object.

```
(send *robot* :head :look-at (send *kettle* :worldpos))
```

For the target object, the coordinate system that should be used to grasp the object may be described as a :handle method. Since this method returns a list, the coordinate system can be known as (car (send \*kettle\* :handle)) :draw-on :flush t)

Therefore, in order to reach this object, it becomes

```
(send *robot* :larm :inverse-kinematics
        (car (send *kettle* :handle))
        :link-list (send *robot* :link-list (send *robot* :larm :end-coords :parent))
        :move-target (send *robot* :larm :end-coords)
        :rotation-axis :z
        :debug-view t)
```

Here, we connect the coordinate systems of the robot's hand and the target object,


```
(send *robot* :larm :end-coords :assoc *kettle*)
```

It can be lifted by 100[mm] in the world coordinate system as follows.

:look-at-target is a command to keep looking at the target while moving.

### 18.3.4 Example of Specifying A Function for target-coords of inverse-kinematics

The argument target-coords of :inverse-kinematics can specify a function that returns a coordinates class other than the coordinates class. The program shown below uses two arms to shake a cocktail (Fig.22).




☑ 22: Example of Dual Arm InverseKinematics

```
(car (send *robot* :larm :links))))
     :translation-axis (list t)
     :rotation-axis (list nil))
(let* ((cnt 0.0))
  (do-until-key
   (incf cnt 0.1)
   (send *robot* :inverse-kinematics
         (list (make-coords :pos (float-vector (+ 400 (* 100 (sin cnt))) (* 50 (cos cnt)) 0))
               #'(lambda ()
                   (send (send *robot* :larm :end-coords) :copy-worldcoords)
                         :translate #f(0 0 100) :local)))
         :move-target
         (list (send *robot* :larm :end-coords)
               (send *robot* :rarm :end-coords))
         :link-list
         (list (send *robot* :link-list
                     (send (send *robot* :larm :end-coords) :parent)
                     (car (send *robot* :larm :links)))
               (send *robot* :link-list
                     (send (send *robot* :rarm :end-coords) :parent)
                     (car (send *robot* :rarm :links))))
         :translation-axis (list :z t)
         :rotation-axis (list nil :z))
   (send *obj* :newcoords (send (send *robot* :larm :end-coords) :copy-worldcoords))
   (send *irtviewer* :draw-objects)))
         (list (make-coords :pos (float-vector (+ 400 (* 100 (sin cnt))) (* 50 (cos cnt)) 0))
               #'(lambda ()
                   (send (send *robot* :larm :end-coords) :copy-worldcoords)
                         :translate #f(0 0 100) :local)))
```

The line actually specifies a function for target-coords. In this example, first determine the position of the left hand holding the cocktail. At this time, :translation-axis :z, :rotation-axis nil, so the amount of translation in the z-direction and the direction of rotation are not taken into account in the computation of the inverse kinematics of the left hand. Then, by evaluating the function for the determined left hand position, the right hand position is determined for the position 100 in the z direction as seen from the local coordinates of the hand. At this time, the constraint conditions for the right hand are :translation-axis t,

:rotation-axis :z, which means that inverse kinematics is solved in the z direction, i.e., with the cocktail's length direction as its axis and rotation about that axis allowed. In this way, it is necessary to treat target-coords as a function when solving inverse kinematics based on constraints.

### 18.3.5 Example of fullbody-inverse-kinematics Considering Center of Gravity Position



☑ 23: Example of InverseKinematics with root link virtual joint


:fullbody-inverse-kinematics is a function that solves the inverse kinematics driven base-link virtual joints in addition to the robot's joints. In the program shown below, both feet are fixed on the ground, the center of gravity is positioned above both feet, and the left hand moves to reach the target.

```
(load "irteus/demo/sample-robot-model.1")
(setq *robot* (instance sample-robot :init))
(send *robot* :reset-pose)
(setq *obj* (make-cylinder 10 600))
(send *obj* :rotate pi :x)
(send *obj* :set-color #f(1 1 0))
(objects (list *robot* *obj*))
(let* ((rleg-coords (send *robot* :rleg :end-coords :copy-worldcoords))
       (lleg-coords (send *robot* :lleg :end-coords :copy-worldcoords)))
  (send *robot* :torso :waist-p :joint-angle 10)
(send *robot* :fullbody-inverse-kinematics
        (list rleg-coords
               lleg-coords
               (make-coords:pos (float-vector 400 100 -600)))
        :move-target
        (list (send *robot* :rleg :end-coords)
               (send *robot* :lleg :end-coords)
               (send *robot* :larm :end-coords))
        :link-list
        (list (send *robot* :link-list (send *robot* :rleg :end-coords :parent))
               (send *robot* :link-list (send *robot* :lleg :end-coords :parent))
               (send *robot* :link-list (send *robot* :larm :end-coords :parent)))
        :translation-axis (list t t t)
        :rotation-axis (list t t nil)
        :target-centroid-pos (midpoint 0.5
                                          (send *robot* :rleg :end-coords :worldpos)
                                          (send *robot* :lleg :end-coords :worldpos))
        :cog-translation-axis :z)
```

line specifies the target positions and postures of the right foot, left foot, and left hand in target-coords. Since the right and left legs do not move, a copy of the current coordinates is given. At this time:translation-axis (list t t),:rotation-axis (list t nil), the position and posture of the right and left legs are completely constrained, and inverse kinematics is solved under the condition that the posture of the left hand is allowed to rotate.

The line specifies the inverse kinematics of the centroid. By using :cog-translation-axis :z to allow movement of the center of gravity in the z-direction, and by using :target-centroid-pos to give the coordinate between the two feet as the target position of the center of gravity, Inverse kinematics can be solved under the condition that the xy-coordinates of the center of gravity coincide with the middle of both feet. These arguments are default values and can be omitted.

### 18.3.6 Example of Solving fullbody-inverse-kinematics Considering External Forces



☑ 24: Example of InverseKinematics with external force

When the robot receives an external force or moment, it can be balanced by offsetting the center of gravity of the robot so as to balance the moment around the sole due to the external force. The program shown below uses inverse kinematics to find a posture in which both hands and feet reach their target positions and are balanced when external forces and moments are applied to both hands.

```
(load "irteus/demo/sample-robot-model.l")
(setq *robot* (instance sample-robot :init))
```

```
(send *robot* :reset-pose)
(setq *obj* (make-cylinder 10 600))
(objects (list *robot*))
(let* ((force-list '(#f(-20 0 0) #f(-20 0 0)))
       (moment-list '(#f(10 0 0) #f(10 0 0))))
  (send *robot* :fullbody-inverse-kinematics
        (list (send *robot* :rleg :end-coords :copy-worldcoords)
              (send *robot* :lleg :end-coords :copy-worldcoords)
              (make-coords :pos #f(400 -300 0))
              (make-coords :pos #f(400 300 0)))
        :move-target (mapcar #'(lambda (x)
                                  (send *robot* x :end-coords))
                             (list :rleg :lleg :rarm :larm))
        :link-list (mapcar #'(lambda (x)
                               (send *robot* :link-list (send *robot* x :end-coords :parent)))
                           (list :rleg :lleg :rarm :larm))
        :centroid-offset-func #'(lambda () (send *robot* :calc-static-balance-point
                                              :force-list force-list
                                             :moment-list moment-list))
        :target-centroid-pos (midpoint 0.5 (send *robot* :rleg :end-coords :worldpos)
                                             (send *robot* :lleg :end-coords :worldpos))
        :cog-translation-axis :z)
  (send *irtviewer* :draw-objects)
  ;; draw force
  (mapcar
  #'(lambda (f cc)
       (let* ((prev-color (send *viewer* :viewsurface :color))
              (prev-width (send *viewer* :viewsurface :line-width)))
         (send *viewer* :viewsurface :color #F(1 0.3 1))
         (send *viewer* :viewsurface :line-width 5)
         (send *irtviewer* :viewer :draw-arrow
               (send cc :worldpos)
               (v+ (send cc :worldpos) (scale 10 f)))
         (send *viewer* :viewsurface :color prev-color)
         (send *viewer* :viewsurface :line-width prev-width)))
  force-list
   (list (send *robot* :rarm :end-coords)
         (send *robot* :larm :end-coords)))
  (send *irtviewer* :viewer :viewsurface :flush)
  この例では、
:centroid-offset-func #'(lambda () (send *robot* :calc-static-balance-point
                                     :force-list force-list
                                      :moment-list moment-list))
```

In this example, external force and external moment are taken into account in the row. force-list is a list of external moments acting on the right hand and left hand, force-list is a list of external moments acting on the right hand and external moments acting on the left hand, and the units are [N] and [Nm], respectively. calc-static-balance-point is a function that returns the position of the sole pressure center that balances the external moment acting on the current positions of both hands and the gravity acting on the current position of the center of gravity. :centroid-offset-func can specify a function that returns a float-vector class, and uses the return value of this function instead of the current position of the center of gravity to reduce the distance to the target position of the center of gravity. By using :cog-translation-axis :z to allow movement of the center of gravity in the z-direction, and by specifying the coordinates in the middle of both feet as the target center of gravity position with :target-centroid-pos: Inverse kinematics can be solved to match the return value of centroid-offset-func, i.e. the xy coordinates of the center of the sole pressure that balances the external force, to the middle of both feet.

# 18.4 Robot Model

The body of the robot consists of links and joints, and the bodyset-link and joint classes are used to create a model picture. The robot's body generates a model as a connected link called cascaded-link that includes these elements.

joint is actually an abstract class Choose rotational-joint, linear-joint, wheel-joint, omniwheel-joint, sphere-joint, and for robots with limbs use the robot-model class instead of cascaded-link.

joint [Class]

:super propertied-object

:slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

:init [method]

&key (name (intern (format nil joint A (system:address self)) KEYWORD))

((:child-link clink))

((:parent-link plink))

 $(\min -90)$ 

 $(\max 90)$ 

((:max-joint-velocity mjv))

((:max-joint-torque mjt))

((:joint-min-max-table mm-table))

 $((:joint-min-max-target\ mm-target))$ 

&allow-other-keys

abstract class of joint, users need to use rotational-joint, linear-joint, sphere-joint, 6dof-joint, wheel-joint or omniwheel-joint.

use :parent-link/:child-link for specifying links that this joint connect to and :min/:min for range of joint angle in degree.

### :min-angle $\mathscr{C}optional\ v$

[method]

If v is set, it updates min-angle of this instance. :min-angle returns minimal angle of this joint in degree.

### :max-angle &optional v

[method]

If v is set, it updates max-angle of this instance. :max-angle returns maximum angle of this joint in degree.

# :parent-link &rest args

[method]

Returns parent link of this joint. if any arguments is set, it is passed to the parent-link.

### :child-link &rest args

[method]

Returns child link of this joint. if any arguments is set, it is passed to the child-link.

# :joint-dof Returns Degree of Freedom of this joint.

[method]

# :speed-to-angle &rest args

[method]

Returns values in deg/mm unit of input value in SI(rad/m) unit.

### :angle-to-speed &rest args

[method]

Returns values in SI(rad/m) unit of input value in deg/mm unit.

### :joint-velocity &optional jv

[method]

If jv is set, it updates joint-velocity of this instance. :joint-velocity returns velocity of this joint in SI(m/s, rad/s) unit.

### :joint-acceleration &optional ja

[method]

If ja is set, it updates joint-acceleration of this instance. :joint-acceleration returns acceleration of this joint in  $SI(m/s^2, rad/s^2)$  unit.

# :joint-torque $\&optional\ jt$

[method]

If jt is set, it updates joint-torque of this instance. :joint-torque returns torque of this joint in SI(N, Nm) unit.

# :max-joint-velocity $&optional\ mjv$

[method]

If mjv is set, it updates min-joint-velocity of this instance. :min-joint-velocity returns velocity of this joint in SI(m/s, rad/s) unit.

# :max-joint-torque &optional mjt

[method]

If mjt is set, it updates min-joint-torque of this instance. :min-joint-torque returns velocity of this joint in SI(N, Nm) unit.

:calc-dav-gain  $dav\ i\ periodic-time$ 

[method]

:calc-jacobian  $\mathcal{E}rest\ args$ 

[method]

:joint-min-max-table  $\ensuremath{\mathscr{C}optional}\ mm\text{-}table$ 

[method]

 $\textbf{:joint-min-max-target} \ \ \mathscr{C}optional \ mm\text{-}target$ 

[method]

 $: joint-min-max-table-angle-interpolate \ \textit{target-angle min-or-max}$ 

[method]

 $\textbf{:joint-min-max-table-min-angle} \ \mathscr{C}optional \ (target-angle \ (send \ joint-min-max-target \ :joint-angle))$ 

:joint-min-max-table-max-angle & optional (target-angle (send joint-min-max-target :joint-angle))

[method]

# :max-joint-torque &optional mjt

[method]

If mjt is set, it updates min-joint-torque of this instance. :min-joint-torque returns velocity of this joint in SI(N, Nm) unit.

### :max-joint-velocity &optional mjv

[method]

If mjv is set, it updates min-joint-velocity of this instance. :min-joint-velocity returns velocity of this joint in SI(m/s, rad/s) unit.

### :joint-torque & optional jt

[method]

If jt is set, it updates joint-torque of this instance. :joint-torque returns torque of this joint in SI(N, Nm) unit.

### :joint-acceleration &optional ja

[method]

If ja is set, it updates joint-acceleration of this instance. :joint-acceleration returns acceleration of this joint in  $SI(m/s^2, rad/s^2)$  unit.

### :joint-velocity &optional jv

[method]

If jv is set, it updates joint-velocity of this instance. :joint-velocity returns velocity of this joint in SI(m/s, rad/s) unit.

# :angle-to-speed $\&rest\ args$

[method]

Returns values in SI(rad/m) unit of input value in deg/mm unit.

# $\textbf{:speed-to-angle} \ \mathcal{E}rest \ args$

[method]

Returns values in deg/mm unit of input value in SI(rad/m) unit.

#### :joint-dof

[method]

Returns Degree of Freedom of this joint.

### :child-link &rest args

[method]

Returns child link of this joint. if any arguments is set, it is passed to the child-link.

# :parent-link &rest args

[method]

Returns parent link of this joint. if any arguments is set, it is passed to the parent-link.

# :max-angle $\mathscr{C}optional\ v$

[method]

If v is set, it updates max-angle of this instance. :max-angle returns maximum angle of this joint in degree.

# :min-angle $\mathcal{E}optional\ v$

[method]

If v is set, it updates min-angle of this instance. :min-angle returns minimal angle of this joint in degree.

:init

[method]

```
&key (name (intern (format nil joint A (system:address self)) KEYWORD))
((:child-link clink))
((:parent-link plink))
(min -90)
(max 90)
((:max-joint-velocity mjv))
((:max-joint-torque mjt))
((:joint-min-max-table mm-table))
((:joint-min-max-target mm-target))
&allow-other-keys
```

abstract class of joint, users need to use rotational-joint, linear-joint, sphere-joint, 6dof-joint, wheel-joint or omniwheel-joint.

use :parent-link/:child-link for specifying links that this joint connect to and :min/:min for range of joint angle in degree.

 $\textbf{:joint-min-max-table-max-angle} \ \mathscr{E}optional \ (target-angle \ (send \ joint-min-max-target \ :joint-angle)) \\$ 

[method]

:joint-min-max-table-min-angle & optional (target-angle (send joint-min-max-target :joint-angle))

[method]

:joint-min-max-table-angle-interpolate target-angle min-or-max

[method]

 $\textbf{:joint-min-max-target} \ \mathscr{C}optional \ mm\text{-}target$ 

[method]

:joint-min-max-table  $@optional \ mm\text{-}table$ [method] :calc-jacobian &rest args [method] :calc-dav-gain dav i periodic-time [method] rotational-joint [Class] :super joint :slots axis :init [method] & est args & key ((:axis ax) :z) ((:max-joint-velocity mjv) 5) ((:max-joint-torque mjt) 100) &allow-other-keys create instance of rotational-joint. :axis is either (:x, :y, :z) or vector. :min-angle and :max-angle takes in radius, but velocity and torque are given in SI units. :joint-angle [method]  $\mathcal{E}optional\ v\ \mathcal{E}key\ relative$ &allow-other-keys Return joint-angle if v is not set, if v is given, set joint angle. v is rotational value in degree. :joint-dof [method] Returns DOF of rotational joint, 1. : speed-to-angle  $\boldsymbol{v}$ [method] Returns degree of given input in radian :angle-to-speed v[method] Returns radian of given input in degree :calc-angle-speed-gain  $dav \ i \ periodic-time$ [method] :calc-jacobian  $\mathscr{C}rest\ args$ [method] :angle-to-speed v[method] Returns radian of given input in degree :speed-to-angle v[method] Returns degree of given input in radian :joint-dof [method] Returns DOF of rotational joint, 1. :joint-angle [method]  $\mathcal{E}optional\ v\ \mathcal{E}key\ relative$ 

:init [method]

Return joint-angle if v is not set, if v is given, set joint angle. v is rotational value in degree.

&allow-other-keys

:init

:joint-angle

[method]

```
& rest args & key ((:axis ax) :z)
        ((:max-joint-velocity mjv) 5)
        ((:max-joint-torque mjt) 100)
        &allow-other-keys
      create instance of rotational-joint. :axis is either (:x, :y, :z) or vector. :min-angle and :max-angle takes
      in radius, but velocity and torque are given in SI units.
:calc-jacobian &rest args
                                                                                                         [method]
:calc-angle-speed-gain day i periodic-time
                                                                                                         [method]
linear-joint
                                                                                                           [Class]
                     :super
                                joint
                     :slots
                                axis
                                                                                                        [method]
        & rest args & key ((:axis ax) :z)
        ((:max-joint-velocity mjv) (/ pi 4))
        ((:max-joint-torque mjt) 100)
        &allow-other-keys
      Create instance of linear-joint. :axis is either (:x, :y, :z) or vector. :min-angle and :max-angle takes in
      [mm], but velocity and torque are given in SI units.
:joint-angle
                                                                                                        [method]
                 \mathcal{E}optional\ v\ \mathcal{E}key relative
                 &allow-other-keys
      return joint-angle if v is not set, if v is given, set joint angle. v is linear value in [mm].
:joint-dof
                                                                                                        [method]
      Returns DOF of linear joint, 1.
:speed-to-angle v
                                                                                                        [method]
      Returns [mm] of given input in [m]
:angle-to-speed v
                                                                                                        [method]
      Returns [m] of given input in [mm]
:calc-angle-speed-gain dav \ i \ periodic-time
                                                                                                         [method]
:calc-jacobian \mathscr{C}rest\ args
                                                                                                         [method]
:angle-to-speed v
                                                                                                        [method]
      Returns [m] of given input in [mm]
:speed-to-angle v
                                                                                                        [method]
      Returns [mm] of given input in [m]
:joint-dof
                                                                                                        [method]
      Returns DOF of linear joint, 1.
```

 $\mathscr{C}optional\ v\ \mathscr{C}key$  relative

&allow-other-keys

return joint-angle if v is not set, if v is given, set joint angle. v is linear value in [mm].

:init [method]

Create instance of linear-joint. :axis is either (:x, :y, :z) or vector. :min-angle and :max-angle takes in [mm], but velocity and torque are given in SI units.

:calc-jacobian &rest args [method]

:calc-angle-speed-gain  $dav\ i\ periodic-time$ 

[method]

# wheel-joint

[Class]

[method]

:super **joint** :slots axis

:init [method]

```
&rest args &key (min (float-vector *-inf**-inf*)) (max (float-vector *inf**inf*)) ((:max-joint-velocity mjv) (float-vector (/ 0.08 0.05) (/ pi 4))) ((:max-joint-torque mjt) (float-vector 100 100)) &allow-other-keys
```

Create instance of wheel-joint.

:joint-angle [method]

 $\mathcal{E}optional\ v\ \mathcal{E}key\ relative$ 

&allow-other-keys

return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is (float-vector translation-x[mm] rotation-z[deg])

:joint-dof

Returns DOF of linear joint, 2.

:speed-to-angle dv [method]

Returns [mm/deg] of given input in SI unit [m/rad]

:angle-to-speed dv [method]

Returns SI unit [m/rad] of given input in [mm/deg]

:calc-angle-speed-gain dav i periodic-time

:calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3a tmp-v3b tmp-m33 [method]

:angle-to-speed dv [method]

Returns SI unit [m/rad] of given input in [mm/deg]

:speed-to-angle dv

[method]

[method]

Returns [mm/deg] of given input in SI unit [m/rad]

Returns DOF of linear joint, 2.

### :joint-angle

:joint-dof

[method]

 $\mathcal{E}optional\ v\ \mathcal{E}key$  relative

&allow-other-keys

return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is (float-vector translation-x[mm] rotation-z[deg])

:init

[method]

```
& Erest args & Wey (min (float-vector *-inf**-inf*)) (max (float-vector *inf**inf*)) ((:max-joint-velocity mjv) (float-vector (/ 0.08 0.05) (/ pi 4))) ((:max-joint-torque mjt) (float-vector 100 100)) & allow-other-keys
```

Create instance of wheel-joint.

:calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3b tmp-m33 [method]

:calc-angle-speed-gain dav i periodic-time

[method]

# omniwheel-joint

[Class]

:super **joint** :slots axis

 $: \! \mathbf{init}$ 

[method]

```
&rest args &key (min (float-vector *-inf**-inf**-inf**)) (max (float-vector *inf**inf**inf*)) ((:max-joint-velocity mjv) (float-vector (/ 0.08 0.05) (/ 0.08 0.05) (/ pi 4))) ((:max-joint-torque mjt) (float-vector 100 100 100)) &allow-other-keys
```

:joint-angle

[method]

 $\mathcal{E}optional\ v\ \mathcal{E}key$  relative

&allow-other-keys

create instance of omniwheel-joint.

return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is (float-vector translation-x[mm] translation-y[mm] rotation-z[deg])

:joint-dof

[method]

Returns DOF of linear joint, 3.

### :speed-to-angle dv

[method]

Returns [mm/deg] of given input in SI unit [m/rad]

[method] :angle-to-speed dvReturns SI unit [m/rad] of given input in [mm/deg] :calc-angle-speed-gain dav i periodic-time [method] :calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotationaxis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3a tmp-v3b tmp-m33 [method] :angle-to-speed dv[method] Returns SI unit [m/rad] of given input in [mm/deg] :speed-to-angle dv[method] Returns [mm/deg] of given input in SI unit [m/rad] :joint-dof [method] Returns DOF of linear joint, 3. :joint-angle [method]  $\mathcal{E}optional\ v\ \mathcal{E}key\ relative$ &allow-other-keys return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is (float-vector translation-x[mm] translation-y[mm] rotation-z[deg]) :init [method] & Erest args & Wey (min (float-vector \*-inf\*\*-inf\*\*)) (max (float-vector \*inf\*\*inf\*\*inf\*)) ((:max-joint-velocity mjv) (float-vector (/ 0.08 0.05) (/ 0.08 0.05) (/ pi 4))) ((:max-joint-torque mjt) (float-vector 100 100 100)) &allow-other-keys create instance of omniwheel-joint. :calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotationaxis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3a tmp-v3b tmp-m33 [method] :calc-angle-speed-gain dav i periodic-time [method] sphere-joint [Class] joint :super :slots axis :init [method] & est args & exert (min (float-vector \*-inf\*\*-inf\*))  $(\max (float\text{-vector }*inf**inf**inf*))$ ((:max-joint-velocity mjv) (float-vector (/ pi 4) (/ pi 4) (/ pi 4)))

Create instance of sphere-joint. min/max are defind as a region of angular velocity in degree.

:joint-angle [method]

 $\mathscr{C}optional\ v\ \mathscr{C}key$  relative &allow-other-keys

&allow-other-keys

((:max-joint-torque mjt) (float-vector 100 100 100))

return joint-angle if v is not set, if v is given, set joint angle.

v is joint-angle vector [deg] by axis-angle representation, i.e (scale rotation-angle-from-default-coords[deg] axis-unit-vector)

# :joint-angle-rpy $&optional\ v\ \&key\ relative$

[method]

Return joint-angle if v is not set, if v is given, set joint-angle vector by RPY representation, i.e. (float-vector yaw[deg] roll[deg] pitch[deg])

# :joint-dof

[method]

Returns DOF of linear joint, 3.

#### : speed-to-angle $\mathit{dv}$

[method]

Returns degree of given input in radian

# :angle-to-speed dv

[method]

Returns radian of given input in degree

# :joint-euler-angle

[method]

```
&key (axis-order '(:z :y :x))
((:child-rot m) (send child-link :rot))
```

Return joint-angle if v is not set, if v is given, set joint-angle vector by euler representation.

 $\hbox{:} \textbf{calc-angle-speed-gain} \ \textit{dav} \ \textit{i} \ \textit{periodic-time}$ 

[method]

 $\begin{array}{l} \textbf{:calc-jacobian} \ \textit{fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3b tmp-m33 \end{array} \\ \boxed{\text{[method]}}$ 

### :joint-euler-angle

[method]

```
&key (axis-order '(:z :y :x))
((:child-rot m) (send child-link :rot))
```

Return joint-angle if v is not set, if v is given, set joint-angle vector by euler representation.

### :angle-to-speed dv

[method]

Returns radian of given input in degree

### :speed-to-angle dv

[method]

Returns degree of given input in radian

# :joint-dof

[method]

Returns DOF of linear joint, 3.

### :joint-angle-rpy &optional v &key relative

[method]

Return joint-angle if v is not set, if v is given, set joint-angle vector by RPY representation, i.e. (float-vector yaw[deg] roll[deg] pitch[deg])

### :joint-angle

[method]

 $\mathcal{E}optional\ v\ \mathcal{E}key\ relative$ 

&allow-other-keys

return joint-angle if v is not set, if v is given, set joint angle.

v is joint-angle vector [deg] by axis-angle representation, i.e (scale rotation-angle-from-default-coords[deg] axis-unit-vector)

init

[method]

```
&rest args &key (min (float-vector *-inf**-inf**-inf*)) (max (float-vector *inf**inf**inf*)) ((:max-joint-velocity mjv) (float-vector (/ pi 4) (/ pi 4) (/ pi 4))) ((:max-joint-torque mjt) (float-vector 100 100 100)) &allow-other-keys
```

Create instance of sphere-joint. min/max are defind as a region of angular velocity in degree.

:calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3b tmp-m33 [method]

:calc-angle-speed-gain dav i periodic-time

[method]

# 6dof-joint

[Class]

:super **joint** :slots axis

:init [method]

Create instance of 6dof-joint.

&allow-other-keys

# :joint-angle [method]

 $\mathcal{E}optional\ v\ \mathcal{E}key$  relative

&allow-other-keys

Return joint-angle if v is not set, if v is given, set joint angle vector, which is 6D vector of 3D translation[mm] and 3D rotation[deg], i.e. (find-if #'(lambda (x) (eq (send (car x) :name) 'sphere-joint)) (documentation :joint-angle))

### :joint-angle-rpy &optional v &key relative

[method]

Return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is 6D vector of 3D translation[mm] and 3D rotation[deg], for rotation, please see (find-if #'(lambda (x) (eq (send (car x) :name) 'sphere-joint)) (documentation :joint-angle-rpy))

:joint-dof [method]

Returns DOF of linear joint, 6.

:calc-angle-speed-gain day i periodic-time

:angle-to-speed dv

# :speed-to-angle dv

[method]

Returns [mm/deg] of given input in SI unit [m/rad]

# Returns SI unit [m/rad] of given input in [mm/deg]

[method]

[method]

:calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3b tmp-m33 [method]

:angle-to-speed dv [method]

Returns SI unit [m/rad] of given input in [mm/deg]

:speed-to-angle dv [method]

Returns [mm/deg] of given input in SI unit [m/rad]

:joint-dof [method]

Returns DOF of linear joint, 6.

### :joint-angle-rpy &optional v &key relative

[method]

Return joint-angle if v is not set, if v is given, set joint angle. v is joint-angle vector, which is 6D vector of 3D translation[mm] and 3D rotation[deg], for rotation, please see (find-if #'(lambda (x) (eq (send (car x) :name) 'sphere-joint)) (documentation :joint-angle-rpy))

:joint-angle [method]

 $\mathcal{E}optional\ v\ \mathcal{E}key$  relative

&allow-other-keys

Return joint-angle if v is not set, if v is given, set joint angle vector, which is 6D vector of 3D translation[mm] and 3D rotation[deg], i.e. (find-if #'(lambda (x) (eq (send (car x) :name) 'sphere-joint)) (documentation :joint-angle))

:init [method]

```
& with the work of the work of
```

Create instance of 6dof-joint.

:calc-jacobian fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3a tmp-v3b tmp-m33 [method]

:calc-angle-speed-gain  $dav\ i\ periodic-time$ 

[method]

# bodyset-link

[Class]

:super bodyset

:slots joint parent-link child-links analysis-level default-coords weight acentroid inertia-tense

:init [method]

```
coords & rest args & key ((:analysis-level level) :body) ((:weight w) 1) ((:centroid c) \#f(0.0 0.0 0.0)) ((:inertia-tensor i) (unit-matrix 3)) & allow-other-keys
```

Create instance of bodyset-link.

# :worldcoords &optional (level analysis-level)

[method]

Returns a coordinates object which represents this coord in the world by concatenating all the cascoords

from the root to this coords.

:analysis-level  $\mathscr{C}optional\ v$ 

[method]

Change analysis level :coords only changes kinematics level and :body changes geometry too.

:weight &optional w

[method]

Returns a weight of the link. If w is given, set weight.

:centroid &optional c

[method]

Returns a centroid of the link. If c is given, set new centroid.

:inertia-tensor &optional i

[method]

Returns a inertia tensor of the link. If c is given, set new intertia tensor.

:joint &rest args

[method]

Returns a joint associated with this link. If args is given, args are forward to the joint.

:add-joint j

[method]

Set j as joint of this link

:del-joint

[method]

Remove current joint of this link

:parent-link

[method]

Returns parent link

:child-links

[method]

Returns child links

:add-child-links l

[method]

Add l to child links

Set l as parent link

:add-parent-link  $\mathit{l}$ 

[method]

:del-child-link l

[method]

Delete l from child links

:del-parent-link

[method]

Delete parent link

:default-coords &optional c

[method]

:del-parent-link

[method]

Delete parent link

:del-child-link  $\it l$ 

[method]

Delete l from child links

:add-parent-link l

[method]

Set l as parent link

:add-child-links  $\it l$ 

[method]

Add I to child links

:child-links

[method]

Returns child links

:parent-link [method]

Returns parent link

:del-joint [method]

Remove current joint of this link

:add-joint j [method]

Set j as joint of this link

:joint & rest args

Returns a joint associated with this link. If args is given, args are forward to the joint.

:inertia-tensor  $\mathscr{C}optional\ i$ 

Returns a inertia tensor of the link. If c is given, set new intertia tensor.

:centroid  $\mathscr{C}optional\ c$  [method]

Returns a centroid of the link. If c is given, set new centroid.

: weight  $\mathscr{C}optional\ w$  [method]

Returns a weight of the link. If w is given, set weight.

 $\textbf{:analysis-level} \ \mathscr{C}optional \ v \\ \textbf{[method]}$ 

Change analysis level :coords only changes kinematics level and :body changes geometry too.

:worldcoords & optional (level analysis-level)

[method]

[method]

Returns a coordinates object which represents this coord in the world by concatenating all the cascoords from the root to this coords.

:init [method]

coords & rest args & key ((:analysis-level level) :body) ((:weight w) 1) ((:centroid c)  $\#f(0.0\ 0.0\ 0.0)$ ) ((:inertia-tensor i) (unit-matrix 3)) & allow-other-keys

Create instance of bodyset-link.

cascaded-link [Class]

:super cascaded-coords

:slots links joint-list bodies collision-avoidance-links end-coords-list

:init [method]

Erest args Ekey name

&allow-other-keys

Create cascaded-link.

:init-ending [method]

This method is to called finalize the instantiation of the cascaded-link. This update bodies and child-

link and parent link from joint-list

:links &rest args

[method]

Returns links, or args is passed to links

:joint-list &rest args

[method]

Returns joint list, or args is passed to joints

:link name

[method]

Return a link with given name.

:joint name

[method]

Return a joint with given name.

:end-coords name

[method]

Returns end-coords with given name

:bodies &rest args

[method]

Return bodies of this object. If args is given it passed to all bodies

:faces

[method]

Return faces of this object.

:angle-vector & optional vec (angle-vector (instantiate float-vector (calc-target-joint-dimension joint-list)))
[method]

Returns angle-vector of this object, if vec is given, it updates angles of all joint. If given angle-vector violate min/max range, the value is modified.

### :link-list to &optional from

[method]

Find link list from to link to from link.

### :plot-joint-min-max-table joint0 joint1

[method]

Plot joint min max table on Euslisp window.

# $: calc\mbox{-}jacobian\mbox{-}from\mbox{-}link\mbox{-}list$

[method]

(transform-coords move-target)
(rotation-axis (cond ((atom move-target) nil) (t (make-list (length move-target))))
(translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) (col-offset 0)

 $(\dim \ (send \ self \ : calc-target-axis-dimension \ rotation-axis \ translation-axis))$ 

(fik-len (send self :calc-target-joint-dimension link-list))

fik

(tmp-v0 (instantiate float-vector 0))

link-list &rest args &key move-target

(tmp-v1 (instantiate float-vector 1))

(tmp-v2 (instantiate float-vector 2))

(tmp-v3 (instantiate float-vector 3))

(tmp-v3a (instantiate float-vector 3))

(tmp-v3b (instantiate float-vector 3))

(tmp-m33 (make-matrix 3 3))

&allow-other-keys

Calculate jacobian matrix from link-list and move-target. Jacobian is represented in :transform-coords. Unit system is [m] or [rad], not [mm] or [deg]. Joint order for this jacobian matrix follows link-list order. Joint torque[Nm] order is also the same. Ex1. One-Arm (setq \*rarm-link-list\*(send \*robot\*:link-list (send \*robot\*:rarm :end-coords :parent))) (send-all \*rarm-link-list\*:joint) Ex2. Two-Arm (setq \*arms-link-list\*(mapcar #'(lambda (l) (send \*robot\*:link-list (send \*robot\*! :end-coords :parent))) '(:rarm :larm)))

(send-all (send \*robot\*:calc-union-link-list \*arms-link-list\*) :joint)

(debug-view) (jacobi)

&allow-other-keys

## :move-joints-avoidance

[method]

```
union-vel & rest args & key union-link-list
link-list
(fik-len (send self :calc-target-joint-dimension union-link-list))
(weight (fill (instantiate float-vector fik-len) 1))
(null-space)
(avoid-nspace-gain 0.01)
(avoid-weight-gain 1.0)
(avoid-collision-distance 200)
(avoid-collision-null-gain 1.0)
(avoid-collision-joint-gain 1.0)
((:collision-avoidance-link-pair pair-list) (send self :collision-avoidance-link-pair-from-lin
(\cos-\sin 0.0)
(target-centroid-pos)
(centroid-offset-func)
(cog-translation-axis :z)
(cog-null-space nil)
(additional-weight-list)
(additional-nspace-list)
(tmp-len (instantiate float-vector fik-len))
(tmp-len2 (instantiate float-vector fik-len))
(tmp-weight (instantiate float-vector fik-len))
(tmp-nspace (instantiate float-vector fik-len))
(tmp-mcc (make-matrix fik-len fik-len))
(tmp-mcc2 (make-matrix fik-len fik-len))
```

:move-joints-avoidance is called in :inverse-kinematics-loop. In this method, calculation of joint position difference are executed and joint position are moved.

Optional arguments:

:weight

float-vector of inverse weight of velocity of each joint or a function which returns the float-vector or a list which returns the float-vector. Length of the float-vector should be same as the number of columns of the jacobian. If :weight is a function or a list, it is called in each IK loop as (funcall weight

union-link-list) or (eval weight). :weight is used in calculation of weighted norm of joint velocity for sr-inverse. Default is the float-vector filled with 1.

:null-space

float-vector of joint velocity or a function which returns the float-vector or a list which returns the float-vector. Length of the float-vector should be same as the number of columns of the jacobian. If :null-space is a function or a list, it is called in each IK loop as (funcall null-space) or (eval null-space). This joint velocity is applied in null space of main task in each IK loop. Default is nil.

:avoid-nspace-gain

gain of joint velocity to avoid joint limit applied in null space of main task in each IK loop. The avoiding velocity is calculated as  $(((t_{-}max + t_{-}min)/2 - t)/((t_{-}max - t_{-}min)/2))^2$ . Default is 0.01.

:avoid-weight-gain

gain of dH/dt in calcuration of avoiding joint limits weight. :weight is devided by this avoiding joint limits weight. Default is 1.0.

If :avoid-nspace-gain is 0, :weight is multipled by :weight instead.

:avoid-collision-distance

yellow zone. 0.1avoid-collision-distance is regarded as orange zone.

If :avoid-collision-joint-gain is smaller than or equal to 0.0, yellow zone and orange zone become inactive. Default is 200[mm].

:avoid-collision-null-gain

 $k\_null$ . Default is 1.0.

:avoid-collision-joint-gain

 $k_{-}joint$ . Default is 1.0.

:collision-avoidance-link-pair

(list link1 link2) (list link3 link4) ...) with any length. Collision between paired links is cared. Default is (send self :collision-avoidance-link-pair-from-link-list link-list :obstacles (cadr (memq :obstacles args))).

:additional-weight-list

(list (list target-link1 additional-weight1) (list target-link2 additional-weight2) ...) with any length. The component of :weight corresponding to the parent joint of target-link is scaled by additional-weight. additional-weight should be float (if 1 dof), float-vector with length of the joint dof, or a function which returns the float or float-vector. if additional-weight is a function, it is called in each IK loop as (funcall additional-weight). Default is nil.

:additional-nspace-list

(list (list target-link1 var1) (list target-link2 var2) ...) with any length. In each IK loop, the parent joint of target-link is moved by the amount of var in null space of main task. var should be float (if 1dof), float-vector with the same length of the target joint dof, or a function which returns the float or float-vector. If var is float-vector, it is called in each IK loop as (funcall var). Default is nil.

other-keys

:manipulability-limit

If manipulability of jacobian is smaller than manipulability-limit, diagonal matrix is added in calculation of sr-inverse. Default is 0.1.

:manipulability-gain

Weight of diagonal matrix in calculation of sr-inverse. Weight is calculated as (\*manipulability-gain (expt (- 1.0 (/ manipulability manipulability-limit)) 2)). Default is 0.001.

: collision-distance-limit

Threshold for collision detection. If collision is detected, the distance between the colliding links is considered to be :collision-distance-limit instead of actual distance. Default is 10[mm].

:move-joints-hook

A function which is called right after joints are moved in each IK loop as (funcall move-joints-hook). Default is nil.

### :inverse-kinematics-loop

[method]

```
dif-pos dif-rot &rest args &key (stop 1)
(loop 0)
link-list
move-target
(rotation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-
(translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :init
(thre (cond ((atom move-target) 1) (t (make-list (length move-target) :initial-element
(rthre (cond ((atom move-target) (deg2rad 1)) (t (make-list (length move-target) :init
(dif-pos-ratio 1.0)
(dif-rot-ratio 1.0)
union-link-list
target-coords
(jacobi)
(additional-check)
(additional-jacobi)
(additional-vel)
(centroid-thre 1.0)
(target-centroid-pos)
(centroid-offset-func)
(cog-translation-axis :z)
(cog-null-space nil)
(\text{cog-gain } 1.0)
(min-loop (/ stop 10))
```

:inverse-kinematics-loop is one loop calculation for :inverse-kinematics.

&allow-other-keys

debug-view ik-args

In this method, joint position difference satisfying workspace difference (dif-pos, dif-rot) are calculated and euslisp model joint angles are updated.

Optional arguments:

:dif-pos-ratio

Ratio of spacial velocity used in calculation of joint position difference to workspace difference (after :p-limit applied). Default is 1.0.

:dif-rot-ratio

Ratio of angular velocity used in calculation of joint position difference to workspace difference (after :r-limit applied). Default is 1.0.

:jacobi

A jacobian of all move-target or a function that returns the jacobian. When a function is given, It is called in every IK loop as (funcall jacobi link-list move-target translation-axis rotation-axis). Default is (send\*self:calc-jacobian-from-link-list link-list:translation-axis translation-axis:rotation-axis rotation-axis:move-target move-target method-args).

:additional-check

This argument is to add optional best-effort convergence conditions. Default is nil (no additional check). :additional-check should be function or lambda.

best-effort =>

In :inverse-kinematics-loop, 'success' is overwritten by '(and success additional-check)'

In :inverse-kinematics, 'success is not overwritten.

So, :inverse-kinematics-loop wait until ':additional-check' becomes 't' as possible,

but ':additional-check' is neglected in the final :inverse-kinematics return.

:cog-gain

Ratio of centroid velocity used in calculation of joint position difference to centroid position difference.  $\max 1.0$ . Default is 1.0.

:min-loop

Minimam loop count. Defalt (/ stop 10).

If integer is specified, :inverse-kinematics-loop does returns :ik-continues and continuing solving IK.

If min-loop is nil, do not consider loop counting for IK convergence.

(periodic-time 0.5) (check-collision) (additional-jacobi) (additional-vel)

other-kevs

:move-joints-avoidance is internally called and args are passed to it. See the explanation of :movejoints-avoidance.

:p-limit

Maximum spacial velocity of each move-target in one IK loop. Default is 100.0[mm].

:r-limit

Maximum angular velocity of each move-target in one IK loop. Default is 0.5[rad].

:inverse-kinematics

```
[method]
target-coords & rest args & key (stop 50)
(link-list)
(move-target)
(debug-view)
(warnp t)
(revert-if-fail t)
(rotation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-eleme
(translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-ele
(joint-args)
(thre (cond ((atom move-target) 1) (t (make-list (length move-target) :initial-element 1))))
(rthre (cond ((atom move-target) (deg2rad 1)) (t (make-list (length move-target) :initial-ele
(union-link-list)
(centroid-thre 1.0)
(target-centroid-pos)
(centroid-offset-func)
(cog-translation-axis :z)
(cog-null-space nil)
(dump-command:fail-only)
```

# &allow-other-keys

Move move-target to target-coords.

;; target-coords, link-list and move-target need to be given.

;; target-coords, move-target, rotation-axis, translation-axis, link-list

;; ->both list and atom OK.

:target-coords

The coordinate of the target, or a function that returns coordinates. When a function is given, it is called in every IK loop as (funcall target-coords). Use a list of targets to solve the IK relative to multiple end links simultaneously.

:stop

Maximum number for IK iteration. Default is 50.

:link-list

List of links to control. When the target-coords is list, this should be a list of lists.

:move-target

Specify end-effector coordinate. When the target-coords is list, this should be list too.

:debug-view

Set t to show debug message and visualization. Use :no-message to just show the irtview image. Default is nil.

:warnp

Set nil to not display debug message when the IK failed. Default is t.

:revert-if-fail

Set nil to keep the angle posture of IK solve iteration. Default is t, which return to original position when IK fails.

:rotation-axis

Use nil for position only IK. :x, :y, :z for the constraint around axis with plus direction, :-x :-y :-z for axis with minus direction. :zz :yy :zz for direction free axis. :xm :ym :zm for allowing rotation with respect to mirror direction. When the target-coords is list, this should be list too. Default is t.

:translation-axis

:x :y :z for constraint along the x, y, z axis. :xy :yz :zx for plane. Default is t. :joint-args

Arguments passed to joint as (send\*joint :joint-angle angle :relative t joint-args). Default nil. :thre

Threshold for position error to terminate IK iteration. Default is 1 [mm].

:rthre

Threshold for rotation error to terminate IK iteration. Default is 0.017453 [rad] (1 deg).

:union-link-list

a function that returns union of link-list called as (funcall union-link-list link-list). Default is (send self :calc-union-link-list link-list).

:centroid-thre

Threshold for centroid position error to terminate IK iteration. Default is 1 [mm].

: target-centroid-pos

The float-vector of the target centroid position. Default is nil.

:centroid-offset-func

A function that returns centroid position. This function is called in each IK loop as (funcall centroid-offset-func). Default is (send self :centroid).

:cog-translation-axis

:x:y:z for constraint along the x, y, z axis. :xy:yz:zx for plane. t for point. Default is :z. :cog-null-space

t: centroid position task is solved in null space of the main task. Default is nil.

:dump-command

should be t, nil, :always, :fail-only, :always-with-debug-log, or :fail-only-with-debug-log. Log are success/fail log and ik debug information log.

t or :always : dump log both in success and fail (for success/fail log).

:always-with-debug-log: dump log both in success and fail (for success/fail log and ik debug information log).

:fail-only: dump log only in fail (for success/fail log).

:always-with-debug-log: dump log only in fail (for success/fail log and ik debug information log).

nil: do not dump log.

:periodic-time

The amount of joint angle modification in each IK loop is scaled not to violate joint velocity limit times :periodic-time. Default is 0.5[s].

:check-collision

Set t to return false when self collision occurs at found IK solution. Default is nil. To avoid collision within IK loop, use set links to collision-avoidance-links slot of cascaded-link.

:additional-jacobi

The jacobian of the additional main task, or a function that returns the jacobian. When a function is given, it is called in every IK loop as (funcall additional-jacobi link-list). Use a list of additional-jacobi to solve the IK for multiple additional task. Default is nil.

:additional-vel

The velocity of additional main task, or a function that returns the velocity. When a function is given, it is called in every IK loop as (funcall additional-vel link-list). The velocity should be expressed in the same coordinates as corresponding additional-jacobi. When the additional-jacobi is list, this should be a list of same length. Default is nil.

other-keys

function: inverse-kinematics-loop is internally called and args are passed to it. See the explanation of: inverse-kinematics-loop.

:calc-grasp-matrix [method]

```
contact-points &key (ret (make-matrix 6 (*6 (length contact-points)))) (contact-rots (mapcar #'(lambda (r) (unit-matrix 3)) contact-points))
```

Calc grasp matrix.

Grasp matrix is defined as

```
— Е_3 0 Е_3 0 ... —
```

Arguments:

contact-points is list of contact points[mm].

contact-rots is list of contact coords rotation[rad].

If contact-rots is specified, grasp matrix as follow:

```
— R1 0 R2 0 ... —
```

```
— p1xR1 R1 p2xR2 R2 ... —
```

# :inverse-kinematics-for-closed-loop-forward-kinematics

[method]

(link-list)
(move-joints-hook)
(additional-weight-list)
(constrained-joint-list)
(constrained-joint-angle-list)
(min-loop 2)
&allow-other-keys

Solve inverse-kinematics for closed loop forward kinematics.

Move move-target to target-coords with link-list.

link-list loop should be close when move-target reaches target-coords.

constrained-joint-list is list of joints specified given joint angles in closed loop.

constrained-joint-angle-list is list of joint-angle for constrained-joint-list.

 $\begin{array}{l} \textbf{:calc-jacobian-for-interlocking-joints} \ \textit{link-list} \ \mathcal{C}\textit{key} \ (\textit{interlocking-joint-pairs} \ (\textit{send self:interlocking-joint-pairs}) \\ \textbf{[method]} \end{array}$ 

Calculate jacobian to keep interlocking joint velocity same.

 $dtheta_0 = dtheta_1 = > [... 0 1 0 ... 0 -1 0 ... ][...dtheta_0...dtheta_1...]$ 

 $\begin{array}{l} \textbf{:calc-vel-for-interlocking-joints} \ \textit{link-list} \ \&\textit{key} \ (\textit{interlocking-joint-pairs} \ (\textit{send self:interlocking-joint-pairs})) \\ [\text{method}] \end{array}$ 

Calculate 0 velocity for keeping interlocking joint at the same joint angle.

:set-midpoint-for-interlocking-joints &key (interlocking-joint-pairs (send self :interlocking-joint-pairs))
[method]

Set interlocking joints at mid point of each joint angle.

# :interlocking-joint-pairs

[method]

Interlocking joint pairs.

pairs are (list (cons joint0 joint1) ... )

If users want to use interlocking joints, please overwrite this method.

# : check-interlocking-joint-angle-validity

[method]

 $\mathcal{E}key$  (angle-thre 0.001)

(interlocking-joint-pairs (send self:interlocking-joint-pairs))

Check if all interlocking joint pairs are same values.

 $\textbf{:update-descendants}\ \mathcal{C}rest\ args$ 

[method]

:find-link-route to  $\operatorname{\mathscr{C}optional}$  from

[method]

:plot-joint-min-max-table-common  $joint0\ joint1$ 

[method]

 $: {\bf calc\text{-}target\text{-}axis\text{-}dimension}\ \ rotation\text{-}axis\ translation\text{-}axis$ 

[method]

:calc-union-link-list link-list

[method]

:calc-target-joint-dimension link-list

[method]

:calc-inverse-jacobian jacobi &rest args &key ((:manipulability-limit ml) 0.1) ((:manipulability-gain mg) 0.001) weight debugview ret wmat tmat umat umat2 mat-tmp mat-tmp-rc tmp-mrr tmp-mrr2 &allow-other-keys [method]

:calc-gradh-from-link-list link-list &optional (res (instantiate float-vector (length link-list)))

[method]

:calc-joint-angle-speed union-vel &rest args &key angle-speed (angle-speed-blending 0.5) jacobi jacobi# null-space i-j#j
debug-view weight wmat tmp-len tmp-len2 fik-len &allow-other-keys [method]

:calc-joint-angle-speed-gain union-link-list day periodic-time

[method]

:collision-avoidance-links  $\mathscr{C}optional\ l$ 

[method]

:collision-avoidance-args pair link-list

[method]

:move-joints union-vel &rest args &key union-link-list (periodic-time 0.05) (joint-args) (debug-view nil) (move-joints-hook) &allow-other-keys

 $: find-joint-angle-limit-weight-old-from-union-link-list \ union-link-list$ 

[method]

 $: {\bf reset\text{-}joint\text{-}angle\text{-}limit\text{-}weight\text{-}old} \ \textit{union\text{-}link\text{-}list}$ 

[method]

 $: {\bf calc\text{-}weight\text{-}from\text{-}joint\text{-}limit}} \ avoid\text{-}weight\text{-}gain\ fik\text{-}len\ link\text{-}list\ union\text{-}link\text{-}list\ debug\text{-}view\ weight\ tmp\text{-}weight\ tmp\text{-}len\ [method]$ 

:calc-inverse-kinematics-weight-from-link-list link-list & & key (avoid-weight-gain 1.0) (union-link-list (send self :calc-union-link-list)) (fik-len (send self :calc-target-joint-dimension union-link-list)) (weight (fill (instantiate float-vector fik-len)) (additional-weight-list) (debug-view) (tmp-weight (instantiate float-vector fik-len)) (tmp-len (instantiate float-vector fik-len)) [method]

[method]

:calc-inverse-kinematics-nspace-from-link-list link-list &key (avoid-nspace-gain 0.01) (union-link-list (send self :calc-union-link-list link-list)) (fik-len (send self :calc-target-joint-dimension union-link-list)) (null-space) (debug-view) (additional-nspace-list) (cog-gain 0.0) (target-centroid-pos) (centroid-offset-func) (cog-translation-axis :z) (cog-null-space nil) (weight (fill (instantiate float-vector fik-len) 1.0)) (update-mass-properties t) (tmp-nspace (instantiate float-vector fik-len)) [method]

 $\begin{array}{ll} \textbf{:inverse-kinematics-args} \ \, \textit{\&rest args} \ \, \textit{\&key union-link-list rotation-axis translation-axis additional-jacobi-dimension} \ \, \textit{\&colored} \\ \textbf{(method)} \end{array}$ 

:draw-collision-debug-view

[method]

:calc-vel-from-pos dif-pos translation-axis &rest args &key (p-limit 100.0) (tmp-v0 (instantiate float-vector 0)) (tmp-v1 (instantiate float-vector 1)) (tmp-v2 (instantiate float-vector 2)) (tmp-v3 (instantiate float-vector 3)) &allow-other-keys [method]

:collision-check-pairs &key ((:links ls) (cons (car links) (all-child-links (car links))))

[method]

:self-collision-check &key (mode :all) (pairs (send self :collision-check-pairs)) (collision-func 'collision-check)

[method]

 $\textbf{:plot-joint-min-max-table}\ joint 0\ joint 1$ 

:link-list to  ${\it @optional from}$ 

[method]

Find link list from to link to from link.

Plot joint min max table on Euslisp window.

:angle-vector & optional vec (angle-vector (instantiate float-vector (calc-target-joint-dimension joint-list)))
[method]

Returns angle-vector of this object, if vec is given, it updates angles of all joint. If given angle-vector violate min/max range, the value is modified.

:faces [method]

Return faces of this object.

:bodies & rest args

Return bodies of this object. If args is given it passed to all bodies

:end-coords name [method]

Returns end-coords with given name

:joint name [method]

Return a joint with given name.

:link name

Return a link with given name.

:joint-list & rest args [method]

Returns joint list, or args is passed to joints

:links &rest args

Returns links, or args is passed to links

:init-ending [method]

This method is to called finalize the instantiation of the cascaded-link. This update bodies and child-link and parent link from joint-list

:init [method]

&rest args &key name

&allow-other-keys

Create cascaded-link.

 $: \textbf{plot-joint-min-max-table-common} \ joint0 \ joint1$ 

[method]

 $\textbf{:find-link-route}\ \ to\ \ \mathscr{C}optional\ from$ 

[method]

:update-descendants &rest args

[method]

## :check-interlocking-joint-angle-validity

[method]

Ekey (angle-thre 0.001)

(interlocking-joint-pairs (send self:interlocking-joint-pairs))

Check if all interlocking joint pairs are same values.

### :interlocking-joint-pairs

[method]

Interlocking joint pairs.

pairs are (list (cons joint0 joint1) ... )

If users want to use interlocking joints, please overwrite this method.

:set-midpoint-for-interlocking-joints &key (interlocking-joint-pairs (send self :interlocking-joint-pairs))
[method]

Set interlocking joints at mid point of each joint angle.

 $\begin{array}{l} \textbf{:calc-vel-for-interlocking-joints} \ link\mbox{-}list \ \mathcal{C}key \ (interlocking\mbox{-}joint\mbox{-}pairs \ (send \ self : interlocking\mbox{-}joint\mbox{-}pairs)) \\ [method] \end{array}$ 

Calculate 0 velocity for keeping interlocking joint at the same joint angle.

:calc-jacobian-for-interlocking-joints link-list &key (interlocking-joint-pairs (send self:interlocking-joint-pairs)) [method]

Calculate jacobian to keep interlocking joint velocity same.

```
dtheta_0 = dtheta_1 = > [... 0 1 0 ... 0 -1 0 ... ][...dtheta_0...dtheta_1...]
```

### :inverse-kinematics-for-closed-loop-forward-kinematics

[method]

target-coords & test args & key (move-target)

(link-list)

(move-joints-hook)

(additional-weight-list)

(constrained-joint-list)

(constrained-joint-angle-list)

(min-loop 2)

&allow-other-keys

Solve inverse-kinematics for closed loop forward kinematics.

Move move-target to target-coords with link-list.

link-list loop should be close when move-target reaches target-coords.

constrained-joint-list is list of joints specified given joint angles in closed loop.

 $constrained\mbox{-}joint\mbox{-}angle\mbox{-}list\mbox{ is list of joint-angle for constrained-joint-list.}$ 

#### :calc-grasp-matrix

[method]

contact-points &key (ret (make-matrix 6 (\*6 (length contact-points)))) (contact-rots (mapcar #'(lambda (r) (unit-matrix 3)) contact-points))

```
Calc grasp matrix.
      Grasp matrix is defined as
      — Е_3 0 Е_3 0 ... —
      — p1x E_3 p2x E_3 ... —
     Arguments:
     contact-points is list of contact points[mm].
     contact-rots is list of contact coords rotation[rad].
     If contact-rots is specified, grasp matrix as follow:
      — R1 0 R2 0 ... —
      — p1xR1 R1 p2xR2 R2 ... —
:inverse-kinematics
                                                                                                     [method]
                          target-coords & rest args & key (stop 50)
                          (link-list)
                          (move-target)
                          (debug-view)
                          (warnp t)
                          (revert-if-fail t)
                          (rotation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-eleme
                          (translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-ele
                          (joint-args)
                          (thre (cond ((atom move-target) 1) (t (make-list (length move-target) :initial-element 1))))
                          (rthre (cond ((atom move-target) (deg2rad 1)) (t (make-list (length move-target) :initial-ele
                          (union-link-list)
                          (centroid-thre 1.0)
                          (target-centroid-pos)
                          (centroid-offset-func)
                          (cog-translation-axis :z)
                          (cog-null-space nil)
                          (dump-command:fail-only)
                          (periodic-time 0.5)
                          (check-collision)
                          (additional-jacobi)
                          (additional-vel)
                          &allow-other-keys
     Move move-target to target-coords.
      ;; target-coords, link-list and move-target need to be given.
     ;; target-coords, move-target, rotation-axis, translation-axis, link-list
      ;; ->both list and atom OK.
     :target-coords
```

The coordinate of the target, or a function that returns coordinates. When a function is given, it is called in every IK loop as (funcall target-coords). Use a list of targets to solve the IK relative to multiple end links simultaneously.

:stop

Maximum number for IK iteration. Default is 50.

:link-list

List of links to control. When the target-coords is list, this should be a list of lists.

:move-target

Specify end-effector coordinate. When the target-coords is list, this should be list too.

:debug-view

Set t to show debug message and visualization. Use :no-message to just show the irtview image. Default is nil.

:warnp

Set nil to not display debug message when the IK failed. Default is t.

:revert-if-fail

Set nil to keep the angle posture of IK solve iteration. Default is t, which return to original position when IK fails.

:rotation-axis

Use nil for position only IK. :x, :y, :z for the constraint around axis with plus direction, :-x :-y :-z for axis with minus direction. :zz :yy :zz for direction free axis. :xm :ym :zm for allowing rotation with respect to mirror direction. When the target-coords is list, this should be list too. Default is t.

:translation-axis

:x :y :z for constraint along the x, y, z axis. :xy :yz :zx for plane. Default is t.

:joint-args

Arguments passed to joint as (send\*joint :joint-angle angle :relative t joint-args). Default nil. :thre

Threshold for position error to terminate IK iteration. Default is 1 [mm].

:rthre

Threshold for rotation error to terminate IK iteration. Default is 0.017453 [rad] (1 deg).

:union-link-list

a function that returns union of link-list called as (funcall union-link-list link-list). Default is (send self:calc-union-link-list link-list).

:centroid-thre

Threshold for centroid position error to terminate IK iteration. Default is 1 [mm].

:target-centroid-pos

The float-vector of the target centroid position. Default is nil.

:centroid-offset-func

A function that returns centroid position. This function is called in each IK loop as (funcall centroid-offset-func). Default is (send self:centroid).

:cog-translation-axis

:x :y :z for constraint along the x, y, z axis. :xy :yz :zx for plane. t for point. Default is :z.

:cog-null-space

t: centroid position task is solved in null space of the main task. Default is nil.

:dump-command

should be t, nil, :always, :fail-only, :always-with-debug-log, or :fail-only-with-debug-log. Log are success/fail log and ik debug information log.

t or :always: dump log both in success and fail (for success/fail log).

:always-with-debug-log : dump log both in success and fail (for success/fail log and ik debug information log).

:fail-only : dump log only in fail (for success/fail log).

:always-with-debug-log: dump log only in fail (for success/fail log and ik debug information log).

nil: do not dump log.

:periodic-time

The amount of joint angle modification in each IK loop is scaled not to violate joint velocity limit

times :periodic-time. Default is 0.5[s]. :check-collision

Set t to return false when self collision occurs at found IK solution. Default is nil. To avoid collision within IK loop, use set links to collision-avoidance-links slot of cascaded-link. :additional-jacobi

The jacobian of the additional main task, or a function that returns the jacobian. When a function is given, it is called in every IK loop as (funcall additional-jacobi link-list). Use a list of additional-jacobi to solve the IK for multiple additional task. Default is nil.

:additional-vel

The velocity of additional main task, or a function that returns the velocity. When a function is given, it is called in every IK loop as (funcal additional-vel link-list). The velocity should be expressed in the same coordinates as corresponding additional-jacobi. When the additional-jacobi is list, this should be a list of same length. Default is nil.

other-keys

function: inverse-kinematics-loop is internally called and args are passed to it. See the explanation of :inverse-kinematics-loop.

#### :inverse-kinematics-loop

[method]

```
dif-pos dif-rot &rest args &key (stop 1)
(loop 0)
link-list
move-target
(rotation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :initial-
(translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) :init
(thre (cond ((atom move-target) 1) (t (make-list (length move-target) :initial-element
(rthre (cond ((atom move-target) (deg2rad 1)) (t (make-list (length move-target) :init
(dif-pos-ratio 1.0)
(dif-rot-ratio 1.0)
union-link-list
target-coords
(jacobi)
(additional-check)
(additional-jacobi)
(additional-vel)
(centroid-thre 1.0)
(target-centroid-pos)
(centroid-offset-func)
(cog-translation-axis:z)
(cog-null-space nil)
(\text{cog-gain } 1.0)
(\min-loop (/ stop 10))
```

:inverse-kinematics-loop is one loop calculation for :inverse-kinematics.

&allow-other-keys

debug-view ik-args

In this method, joint position difference satisfying workspace difference (dif-pos, dif-rot) are calculated and euslisp model joint angles are updated.

Optional arguments:

:dif-pos-ratio

Ratio of spacial velocity used in calculation of joint position difference to workspace difference (after :p-limit applied). Default is 1.0.

:dif-rot-ratio

Ratio of angular velocity used in calculation of joint position difference to workspace difference (after :r-limit applied). Default is 1.0.

:jacobi

A jacobian of all move-target or a function that returns the jacobian. When a function is given, It is called in every IK loop as (funcall jacobi link-list move-target translation-axis rotation-axis). Default is (send\*self:calc-jacobian-from-link-list link-list:translation-axis translation-axis:rotation-axis rotation-axis:move-target move-target method-args).

:additional-check

This argument is to add optional best-effort convergence conditions. Default is nil (no additional check). :additional-check should be function or lambda.

best-effort =>

In :inverse-kinematics-loop, 'success' is overwritten by '(and success additional-check)'

In :inverse-kinematics, 'success is not overwritten.

So, :inverse-kinematics-loop wait until ':additional-check' becomes 't' as possible,

but ':additional-check' is neglected in the final :inverse-kinematics return.

:cog-gain

Ratio of centroid velocity used in calculation of joint position difference to centroid position difference. max 1.0. Default is 1.0.

:min-loop

Minimam loop count. Defalt (/ stop 10).

If integer is specified, :inverse-kinematics-loop does returns :ik-continues and continuing solving IK.

If min-loop is nil, do not consider loop counting for IK convergence.

other-keys

:move-joints-avoidance is internally called and args are passed to it. See the explanation of :move-joints-avoidance.

:p-limit

Maximum spacial velocity of each move-target in one IK loop. Default is 100.0[mm].

:r-limit

Maximum angular velocity of each move-target in one IK loop. Default is 0.5[rad].

### :move-joints-avoidance

[method]

union-vel &rest args &key union-link-list link-list (fik-len (send self :calc-target-joint-dimension union-link-list)) (weight (fill (instantiate float-vector fik-len) 1)) (null-space) (avoid-nspace-gain 0.01) (avoid-weight-gain 1.0) (avoid-collision-distance 200) (avoid-collision-null-gain 1.0) (avoid-collision-joint-gain 1.0)

```
((:collision-avoidance-link-pair pair-list) (send self :collision-avoidance-link-pair-from-lin
(\cos-\sin 0.0)
(target-centroid-pos)
(centroid-offset-func)
(cog-translation-axis :z)
(cog-null-space nil)
(additional-weight-list)
(additional-nspace-list)
(tmp-len (instantiate float-vector fik-len))
(tmp-len2 (instantiate float-vector fik-len))
(tmp-weight (instantiate float-vector fik-len))
(tmp-nspace (instantiate float-vector fik-len))
(tmp-mcc (make-matrix fik-len fik-len))
(tmp-mcc2 (make-matrix fik-len fik-len))
(debug-view)
(jacobi)
&allow-other-keys
```

:move-joints-avoidance is called in :inverse-kinematics-loop. In this method, calculation of joint position difference are executed and joint position are moved.

Optional arguments:

:weight

float-vector of inverse weight of velocity of each joint or a function which returns the float-vector or a list which returns the float-vector. Length of the float-vector should be same as the number of columns of the jacobian. If :weight is a function or a list, it is called in each IK loop as (funcall weight union-link-list) or (eval weight). :weight is used in calculation of weighted norm of joint velocity for sr-inverse. Default is the float-vector filled with 1.

:null-space

float-vector of joint velocity or a function which returns the float-vector or a list which returns the float-vector. Length of the float-vector should be same as the number of columns of the jacobian. If :null-space is a function or a list, it is called in each IK loop as (funcall null-space) or (eval null-space). This joint velocity is applied in null space of main task in each IK loop. Default is nil.

:avoid-nspace-gain

gain of joint velocity to avoid joint limit applied in null space of main task in each IK loop. The avoiding velocity is calculated as  $(((t\_max + t\_min)/2 - t)/((t\_max - t\_min)/2))^2$ . Default is 0.01.

: a void-weight-gain

gain of dH/dt in calcuration of avoiding joint limits weight. :weight is devided by this avoiding joint limits weight. Default is 1.0.

If :avoid-nspace-gain is 0, :weight is multipled by :weight instead.

:avoid-collision-distance

yellow zone. 0.1avoid-collision-distance is regarded as orange zone.

If :avoid-collision-joint-gain is smaller than or equal to 0.0, yellow zone and orange zone become inactive. Default is 200[mm].

:avoid-collision-null-gain

 $k_{-}null$ . Default is 1.0.

:avoid-collision-joint-gain

 $k_{-}joint$ . Default is 1.0.

:collision-avoidance-link-pair

(list link1 link2) (list link3 link4) ...) with any length. Collision between paired links is cared. Default is (send self :collision-avoidance-link-pair-from-link-list link-list :obstacles (cadr (memq :obstacles args))).

:additional-weight-list

(list (list target-link1 additional-weight1) (list target-link2 additional-weight2) ...) with any length. The component of :weight corresponding to the parent joint of target-link is scaled by additional-weight. additional-weight should be float (if 1 dof), float-vector with length of the joint dof, or a function which returns the float or float-vector. if additional-weight is a function, it is called in each IK loop as (funcall additional-weight). Default is nil.

:additional-nspace-list

(list (list target-link1 var1) (list target-link2 var2) ...) with any length. In each IK loop, the parent joint of target-link is moved by the amount of var in null space of main task. var should be float (if 1dof), float-vector with the same length of the target joint dof, or a function which returns the float or float-vector. If var is float-vector, it is called in each IK loop as (funcall var). Default is nil.

other-keys

:manipulability-limit

If manipulability of jacobian is smaller than manipulability-limit, diagonal matrix is added in calculation of sr-inverse. Default is 0.1.

:manipulability-gain

Weight of diagonal matrix in calculation of sr-inverse. Weight is calculated as (\*manipulability-gain (expt (- 1.0 (/ manipulability manipulability-limit)) 2)). Default is 0.001.

:collision-distance-limit

Threshold for collision detection. If collision is detected, the distance between the colliding links is considered to be :collision-distance-limit instead of actual distance. Default is 10[mm].

:move-joints-hook

A function which is called right after joints are moved in each IK loop as (funcall move-joints-hook). Default is nil.

### :calc-jacobian-from-link-list

[method]

```
link-list &rest args &key move-target
(transform-coords move-target)
(rotation-axis (cond ((atom move-target) nil) (t (make-list (length move-target))))
(translation-axis (cond ((atom move-target) t) (t (make-list (length move-target) (col-offset 0)
(dim (send self :calc-target-axis-dimension rotation-axis translation-axis))
(fik-len (send self :calc-target-joint-dimension link-list))
fik
(tmp-v0 (instantiate float-vector 0))
(tmp-v1 (instantiate float-vector 1))
(tmp-v2 (instantiate float-vector 2))
(tmp-v3 (instantiate float-vector 3))
(tmp-v3a (instantiate float-vector 3))
(tmp-v3b (instantiate float-vector 3))
(tmp-w3b (instantiate float-vector 3))
&kallow-other-keys
```

Calculate jacobian matrix from link-list and move-target. Jacobian is represented in :transform-coords. Unit system is [m] or [rad], not [mm] or [deg].

Joint order for this jacobian matrix follows link-list order. Joint torque [Nm] order is also the same.

Ex1. One-Arm

(setq \*rarm-link-list\*(send \*robot\*:link-list (send \*robot\*:rarm :end-coords :parent))) (send-all \*rarm-link-list\*:joint)

Ex2. Two-Arm

(setq \*arms-link-list\*(mapcar #'(lambda (l) (send \*robot\*:link-list (send \*robot\*l :end-coords :parent))) '(:rarm :larm)))

(send-all (send \*robot\*:calc-union-link-list \*arms-link-list\*) :joint)

:self-collision-check &key (mode :all) (pairs (send self :collision-check-pairs)) (collision-func 'collision-check) [method]

:collision-check-pairs &key ((:links ls) (cons (car links) (all-child-links (car links))))

 $\begin{array}{ll} \textbf{:calc-vel-from-rot} \ dif-rot \ rotation-axis \ \mathscr{C}rest \ args \ \mathscr{C}key \ (r\text{-}limit \ 0.5) \ (tmp\text{-}v0 \ (instantiate \ float\text{-}vector \ 0)) \ (tmp\text{-}v1 \ (instantiate \ float\text{-}vector \ 1)) \ (tmp\text{-}v2 \ (instantiate \ float\text{-}vector \ 2)) \ (tmp\text{-}v3 \ (instantiate \ float\text{-}vector \ 3)) \ \mathscr{C}allow\text{-}other\text{-}keys \end{array}$ 

:calc-vel-from-pos dif-pos translation-axis &rest args &key (p-limit 100.0) (tmp-v0 (instantiate float-vector 0)) (tmp-v1 (instantiate float-vector 1)) (tmp-v2 (instantiate float-vector 2)) (tmp-v3 (instantiate float-vector 3)) &allow-other-keys [method]

 $\begin{array}{ll} \textbf{:ik-convergence-check} \ success \ dif\mbox{-}pos \ dif\mbox{-}rot \ rotation-axis \ translation-axis \ thre \ rthre \ centroid-thre \ target-centroid-pos \ centroid-offset-func \ cog-translation-axis \ \mathcal{E}key \ (update\mbox{-}mass\mbox{-}properties \ t) \end{array} \qquad \qquad \boxed{[method]}$ 

:draw-collision-debug-view

[method]

[method]

 $\begin{array}{l} \textbf{:inverse-kinematics-args} \ \, \textit{\&rest args} \ \, \textit{\&key union-link-list rotation-axis translation-axis additional-jacobi-dimension} \ \, \textit{\&continuous additional-j$ 

:calc-inverse-kinematics-nspace-from-link-list link-list &key (avoid-nspace-gain 0.01) (union-link-list (send self :calc-union-link-list link-list)) (fik-len (send self :calc-target-joint-dimension union-link-list)) (null-space) (debug-view) (additional-nspace-list) (cog-gain 0.0) (target-centroid-pos) (centroid-offset-func) (cog-translation-axis :z) (cog-null-space nil) (weight (fill (instantiate float-vector fik-len) 1.0)) (update-mass-properties t) (tmp-nspace (instantiate float-vector fik-len)) [method]

 $: {\bf calc\text{-}nspace\text{-}from\text{-}joint\text{-}limit}} \ \ avoid\text{-}nspace\text{-}gain \ union\text{-}link\text{-}list \ weight \ } debug\text{-}view \ tmp\text{-}nspace$ 

[method]

:calc-inverse-kinematics-weight-from-link-list link-list & & key (avoid-weight-gain 1.0) (union-link-list (send self :calc-union-link-list link-list)) (fik-len (send self :calc-target-joint-dimension union-link-list)) (weight (fill (instantiate float-vector fik-len)) (additional-weight-list) (debug-view) (tmp-weight (instantiate float-vector fik-len)) (tmp-len (instantiate float-vector fik-len)) [method]

:calc-weight-from-joint-limit avoid-weight-gain fik-len link-list union-link-list debug-view weight tmp-weight tmp-len [method]

 $: {\bf reset\text{-}joint\text{-}angle\text{-}limit\text{-}weight\text{-}old} \ \textit{union\text{-}link\text{-}list}$ 

[method]

 $: find-joint-angle-limit-weight-old-from-union-link-list \ union-link-list$ 

[method]

:move-joints union-vel &rest args &key union-link-list (periodic-time 0.05) (joint-args) (debug-view nil) (move-joints-hook) &allow-other-keys

 :collision-avoidance-args  $pair\ link$ -list [method] :collision-avoidance-calc-distance &rest args &key union-link-list (warnp t) ((:collision-avoidance-link-pair pair-list)) ((:collision-avoidance-link-pair pair-list)) distance-limit distance-limit) 10) & allow-other-keys [method] :collision-avoidance-link-pair-from-link-list link-lists &key obstacles ((:collision-avoidance-links collision-links) collisionavoidance-links) debug [method] :collision-avoidance-links &optional l [method] :calc-joint-angle-speed-gain union-link-list day periodic-time [method] :calc-joint-angle-speed union-vel &rest args &key angle-speed (angle-speed-blending 0.5) jacobi jacobi# null-space i-j#j debug-view weight wmat tmp-len tmp-len2 fik-len &allow-other-keys [method] :calc-gradh-from-link-list link-list &optional (res (instantiate float-vector (length link-list))) [method] :calc-inverse-jacobian jacobi & rest args & key ((:manipulability-limit ml) 0.1) ((:manipulability-gain mg) 0.001) weight debugview ret wmat tmat umat 2 mat-tmp mat-tmp-rc tmp-mrr tmp-mrr2 &allow-other-keys [method] :calc-target-joint-dimension link-list [method]  $: {\bf calc\text{-}union\text{-}link\text{-}} list\ link\text{-}list$ [method] :calc-target-axis-dimension rotation-axis translation-axis [method] eusmodel-validity-check robot [function] Check if the robot model is validate calc-jacobian-default-rotate-vector paxis world-default-coords child-reverse transform-coords tmp-v3 tmp-m33 calc-jacobian-rotational fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords  $rotation-axis\ translation-axis\ tmp-v0\ tmp-v1\ tmp-v2\ tmp-v3\ tmp-v3a\ tmp-v3b\ tmp-m33$ [function] calc-jacobian-linear fik row column joint paxis child-link world-default-coords child-reverse move-target transform-coords rotation-axis translation-axis tmp-v0 tmp-v1 tmp-v2 tmp-v3 tmp-v3a tmp-v3b tmp-m33 [function] calc-angle-speed-gain-scalar j dav i periodic-time [function] calc-angle-speed-gain-vector j day i periodic-time [function] all-child-links s &optional (pred #'identity) [function] calc-dif-with-axis dif axis Goptional tmp-v0 tmp-v1 tmp-v2 [function] calc-target-joint-dimension joint-list [function]  ${\bf calc\text{-}joint\text{-}angle\text{-}min\text{-}max\text{-}for\text{-}limit\text{-}calculation}\ j\ kk\ jamm$ [function] joint-angle-limit-weight j-l &optional (res (instantiate float-vector (calc-target-joint-dimension j-l))) [function] joint-angle-limit-nspace j-l & optional (res (instantiate float-vector (calc-target-joint-dimension j-l))) [function] calc-jacobian-from-link-list-including-robot-and-obj-virtual-joint link-list move-target obj-move-target robot &key (rotationaxis '(t t)) (translation-axis '(t t)) (fik (make-matrix (send robot :calc-target-axis-dimension rotation-axis translation-axis)  $(send\ robot\ : calc\mbox{-}target\mbox{-}joint\mbox{-}dimension\ link\mbox{-}list)))$ [function] append-multiple-obj-virtual-joint link-list target-coords &key (joint-class '(6dof-joint)) (joint-args '(nil)) (vplink) (vplinkcoords) (vclink-coords) [function] eusmodel-validity-check-one robot [function]

line [Class]

:super propertied-object

:slots pvert nvert

: world coords[method] Return a coordinates on the midpoint of the end points coordinates [Class] propertied-object :super :slots rot pos :difference-rotation coords &key (geometry::rotation-axis t) [method] return difference in rotation of given coords, rotation-axis can take (:x, :y, :z, :xx, :yy, :zz, :xm, :ym, :zm) :difference-position coords &key (geometry::translation-axis t) [method] return difference in position of given coords, translation-axis can take (:x, :y, :z, :xy, :yz, :zx).  $:\!\!\!\mathbf{axis}\ geometry::\!axis$ [method] coordinates [Class] propertied-object :super :slots rot pos :move-coords  $geometry::target\ geometry::at$ [method] fix 'at' coords on 'self' to 'target'  $\textbf{:transform} \ \textit{geometry::c} \ \mathscr{C}optional \ (\textit{geometry::wrt} : local)$ [method] :transformation geometry::c2 &optional (geometry::wrt :local) [method]  $\textbf{:move-to}\ geometry::c\ \&optional\ (geometry::wrt\ :local)\ \&oux\ geometry::cc$ [method] cascaded-coords [Class] :super coordinates :slots rot pos parent descendants worldcoords manager changed :move-to geometry::c &optional (geometry::wrt :local) &ux geometry::cc [method]  $\textbf{:transform} \ \textit{geometry::c} \ \mathscr{C}optional \ (\textit{geometry::wrt} : local)$ [method] :transformation geometry::c2 &optional (geometry::wrt :local) [method] :worldcoords [method] coordinates [Class]

propertied-object

rot pos

:super :slots

:worldcoords

:init

:draw-on &rest args

[method]

[method]

 $\textbf{:inverse-rotate-vector} \ geometry{::} v \ \mathscr{C}optional \ geometry{::} r$ [method] [method]  $: {\bf rotate\text{-}vector} \ geometry::v \ {\it \&optional} \ geometry::r$ cascaded-coords [Class] :super coordinates :slots rot pos parent descendants worldcoords manager changed  $\textbf{:inverse-rotate-vector} \ geometry{::}v \ \mathscr{C}optional \ geometry{::}r$ [method]  $: {\bf rotate\text{-}vector} \ geometry::v \ {\it \&optional} \ geometry::r$ [method] coordinates [Class] propertied-object :super :slots rot pos  $\textbf{:inverse-transform-vector} \ geometry::vec \ \mathscr{C}optional \ geometry::v3a \ geometry::v3b \ geometry::m33$ [method] cascaded-coords [Class] coordinates :super :slots rot pos parent descendants worldcoords manager changed  $\textbf{:inverse-transform-vector} \ geometry::v\ \mathcal{E}optional\ geometry::v\ 3a\ geometry::v\ 3b\ geometry::v\ 3$ [method] bodyset [Class] cascaded-coords :super (geometry::bodies :type cons) :slots :init [method] coords &rest args &key (name (intern (format nil bodyset A (system:address self)) KEYWORD)) ((:bodies geometry::bs)) &allow-other-keys Create bodyset object :bodies &rest args [method] :faces [method]

[method] coords &rest args &key (name (intern (format nil bodyset A (system:address self)) KEYWORD)) ((:bodies geometry::bs)) &allow-other-keys

Create bodyset object

:draw-on & rest args

:worldcoords [method]

:faces [method]

:bodies &rest args

midcoords geometry::p geometry::c1 geometry::c2

[function]

Returns mid (or p) coordinates of given two cooridnates c1 and c2

 $\begin{array}{lll} \textbf{orient-coords-to-axis} \ geometry::target-coords \ geometry::v \ \&optional \ (geometry::axis : z) \ (geometry::eps *epsilon*) \\ & [function] \end{array}$ 

orient 'axis' in 'target-coords' to the direction specified by 'v' destructively. 'v' must be non-zero vector.

### geometry::face-to-triangle-aux geometry::f

[function]

triangulate the face.

### geometry::face-to-triangle geometry::f

[function]

convert face to set of triangles.

**geometry::face-to-tessel-triangle** geometry::f geometry::num &optional (\*epsilon\*1.000000e-10) [function]

return polygon if triangable, return nil if it is not.

### body-to-faces geometry::abody

[function]

return triangled faces of given body

## $\mathbf{make\text{-}sphere}\ \textit{geometry::r}\ \mathcal{E}\textit{rest}\ \textit{args}$

[function]

make sphere of given r

make-ring geometry::ring-radius geometry::pipe-radius & geometry::segments 16) [function] make ring of given ring and pipe radius

## make-fan-cylinder

[function]

 $geometry::radius\ geometry::height\ {\mathcal E}rest\ args\ {\mathcal E}key\ ({\it geometry::segments}\ 12)$  (angle 2pi)

(geometry::mid-angle (/ angle 2.0))

make a cylinder whose base face is a fan. the angle of fan is defined by :angle keyword. and, the csg of the returned body is (:cylinder radius height segments angle)

#### $\mathbf{x} ext{-}\mathbf{of} ext{-}\mathbf{cube}$ geometry::cub

[function]

return x of cube.

## $\mathbf{y} ext{-}\mathbf{o}\mathbf{f} ext{-}\mathbf{c}\mathbf{u}\mathbf{b}$

[function]

return y of cube.

# $\mathbf{z} ext{-}\mathbf{of} ext{-}\mathbf{cube}$ geometry::cub

[function]

return z of cube.

:inverse-kinematics

[method]

[function] height-of-cylinder geometry::cyl return height of cylinder. radius-of-cylinder geometry::cyl [function] return radius of cylinder. radius-of-sphere geometry::sp [function] return radius of shape. geometry::make-faceset-from-vertices geometry::vs [function] create faceset from vertices. matrix-to-euler-angle geometry::m geometry::axis-order [function] return euler angle from matrix. [function] geometry::quaternion-from-two-vectors geometry::a geometry::b Compute quaternion which rotate vector a into b.  ${\bf transform\text{-}coords}\ geometry:: c1\ geometry:: c2\ @optional\ (geometry:: c3\ (let\ ((geometry:: dim\ (send\ geometry:: c1\ : dimension)))$ (instance coordinates :newcoords (unit-matrix geometry::dim) (instantiate float-vector geometry::dim)))) [function]  ${\bf geometry::} {\bf face-to-triangle-rest-polygon} \ {\it geometry::} f \ {\it geometry::} num \ {\it geometry::} edgs$ [function]  ${\bf geometry::} {\bf face\text{-}to\text{-}triangle\text{-}make\text{-}simple} \ \textit{geometry::} f$ [function] body-to-triangles geometry::abody &optional (geometry::limit 50) [function] geometry::triangle-to-triangle geometry::aface &optional (geometry::limit 50) [function] robot-model [Class] :super cascaded-link :slots larm-end-coords rarm-end-coords lleg-end-coords rleg-end-coords head-end-coords tor-[method] :camera sensor-name Returns camera with given name [method] :force-sensor sensor-name Returns force sensor with given name :imu-sensor sensor-name [method] Returns imu sensor of given name :force-sensors [method] Returns force sensors. :imu-sensors [method] Returns imu sensors. [method] :cameras Returns camera sensors. :look-at-hand l/r[method] look at hand position, l/r supports :rarm, :larm, :arms, and '(:rarm :larm)

```
target-coords & rest args & key look-at-target (move-target)
(link-list (if (atom move-target) (send self :link-list (send move-target :parent)) (mapcar #' & allow-other-keys
```

solve inverse kinematics, move move-target to target-coords

target-coords and move-target should be given.

link-list is set by default based on move-target ->root link link-list

:look-at-target

other-keys

target head looks at. This task is best-effort and only head joints are used. :look-at-target supports t, nil, float-vector, coords, list of float-vector, list of coords.

:inverse-kinematics internally calls :inverse-kinematics of cascaded-cords class and args are passed to it. See the explanation of :inverse-kinematics of cascaded-cords class.

#### :inverse-kinematics-loop

[method]

```
dif-pos dif-rot &rest args &key target-coords
debug-view
look-at-target
(move-target)
(link-list (if (atom move-target) (send self :link-list (send move-target :parent)) (mape
&allow-other-keys
```

move move-target using dif-pos and dif-rot,

look-at-target supports t, nil, float-vector, coords, list of float-vector, list of coords

link-list is set by default based on move-target ->root link link-list

:inverse-kinematics-loop internally calls :inverse-kinematics-loop function of cascaded-coords class. See the explanation of :inverse-kinematics-loop in cascaded-coords class.

## $\textbf{:look-at-target} \ \textit{look-at-target} \ \textit{\&key} \ (\textit{target-coords})$

[method]

move robot head to look at targets, look-at-target support t/nil float-vector coordinates, center of list of float-vector or list of coordinates

:init-pose [method]

Set robot to initial posture.

# :torque-vector

[method]

```
&key (force-list)
(moment-list)
(target-coords)
(debug-view nil)
(calc-statics-p t)
(dt 0.005)
(av (send self :angle-vector))
(root-coords (send (car (send self :links)) :copy-worldcoords))
(calc-torque-buffer-args (send self :calc-torque-buffer-args))
(distribute-total-wrench-to-torque-method (if (and (not (every #'null (send self :legs)))) (not (and
```

Returns torque vector

#### :calc-force-from-joint-torque

[method]

 $limb\ all\text{-torque}\ \mathcal{E}key\ (move\text{-target}\ (send\ self\ limb\ :end\text{-coords}))$  (use-torso)

Calculates end-effector force and moment from joint torques.

#### :fullbody-inverse-kinematics

[method]

target-coords &rest args &key (move-target)
(link-list)
(min (float-vector -500 -500 -500 -20 -20 -10))
(max (float-vector 500 500 25 20 20 10))
(root-link-virtual-joint-weight #f(0.1 0.1 0.1 0.1 0.5 0.5))
(target-centroid-pos (apply #'midpoint 0.5 (send self :legs :end-coords :worldpos)
(cog-gain 1.0)
(cog-translation-axis :z)
(centroid-offset-func nil)
(centroid-thre 5.0)
(additional-weight-list)
(joint-args nil)
(cog-null-space nil)
(min-loop 2)
&allow-other-keys

fullbody inverse kinematics for legged robot.

necessary args : target-coords, move-target, and link-list must include legs' (or leg's) parameters ex. (send \*robot\*:fullbody-inverse-kinematics (list rarm-tc rleg-tc lleg-tc) :move-target (list rarm-mt rleg-mt lleg-mt) :link-list (list rarm-ll rleg-ll lleg-ll)) :min

lower position limit of root link virtual joint (x y z roll pitch yaw). Default is #f(-500[mm] -500[mm] -20[deg] -20[deg] -10[deg]).

:max

upper position limit of root link virtual joint (x y z roll pitch yaw). Default is #f(500[mm] 500[mm] 25[mm] 20[deg] 20[deg] 10[deg]).

:root-link-virtual-joint-weight

float-vector of inverse weight of velocity of root link virtual joint or a function which returns the float-vector (x y z roll pitch yaw). This works in the same way as :additional-weight-list in cascaded-coords::inverse-kinematics. Default is  $\#f(0.1\ 0.1\ 0.1\ 0.1\ 0.5\ 0.5)$ .

:joint-args

list of other arguments passed to :init function of root link virtual joint (6dof-joint class).

:max-joint-velocity

limit of velocity of root link virtual joint (x y z roll pitch yaw). Default is  $\#f((/0.08\ 0.05)[m/s]\ (/0.08\ 0.05)[m/s]\ (/pi\ 4)[rad/s]\ (/pi\ 4)[rad/s]\ (/pi\ 4)[rad/s]))$  other-keys

:fullbody-inverse-kinematics internally calls :inverse-kinematics and args are passed to it. See the explanation of :inverse-kinematics.

#### :print-vector-for-robot-limb vec

[method]

Print angle vector with limb alingment and limb indent.

For example, if robot is rarm, larm, and torso, print result is:

```
#f(
rarm-j0 ... rarm-jN
larm-j0 ... larm-jN
torso-j0 ... torso-jN
)
```

#### :calc-zmp-from-forces-moments

[method]

forces moments &key (wrt :world)
(limbs (if (send self :force-sensors) (remove nil (mapcar #'(lambda (fs) (find-ic)))
(force-sensors (mapcar #'(lambda (l) (send self :force-sensor l)) limbs))
(fz-thre 0.001)
(limb-cop-fz-list (mapcar #'(lambda (fs f m cc) (let ((fsp (scale 0.001 (send fs

Calculate zmp[mm] from sensor local forces and moments

If force\_z is large, zmp can be defined and returns 3D zmp.

Otherwise, zmp cannot be defined and returns nil.

### :foot-midcoords &optional (mid 0.5)

[method]

Calculate midcoords of :rleg and :lleg end-coords.

In the following codes, leged robot is assumed.

## :fix-leg-to-coords

[method]

fix-coords & optional (l/r:both) & key (mid 0.5) & allow-other-keys

Fix robot's legs to a coords

In the following codes, leged robot is assumed.

#### :move-centroid-on-foot

[method]

leg fix-limbs &rest args &key (thre (mapcar #'(lambda (x) (if (memq x '(:rleg :lleg)) 1 (rthre (mapcar #'(lambda (x) (deg2rad (if (memq x '(:rleg :lleg)) 1 5))) fix-limbs)) (mid 0.5) (target-centroid-pos (if (eq leg :both) (apply #'midpoint mid (mapcar #'(lambda (tmp (fix-limbs-target-coords (mapcar #'(lambda (x) (send self x :end-coords :copy-worldcoords))

(nx-nmos-target-coords (mapcar # (lambda (x) (send send (root-link-virtual-joint-weight #f(0.1 0.1 0.0 0.0 0.0 0.5))

&allow-other-kevs

Move robot COG to change centroid-on-foot location,

leg: legs for target of robot's centroid, which should be: both, :rleg, and: lleg.

fix-limbs: limb names which are fixed in this IK.

#### :calc-walk-pattern-from-footstep-list

[method]

footstep-list &key (default-step-height 50)
(dt 0.1)
(default-step-time 1.0)
(solve-angle-vector-args)
(debug-view nil)
((:all-limbs al) (if (send self :force-sensors) (remove nil (mapcar #'(lambs))

((:all-limos al) (if (send self :force-sensors) (remove nii (mapcar #'(lamod ((:default-zmp-offsets dzo) (mapcan #'(lamoda (x) (list x (float-vector (init-pose-function #'(lamoda nil (send self :move-centroid-on-foot :botl

```
(start-with-double-support t)
(end-with-double-support t)
(ik-thre 1)
(ik-rthre (deg2rad 1))
(q 1.0)
(r 1.000000e-06)
(calc-zmp t)
```

Calculate walking pattern from foot step list and return pattern list as a list of angle-vector, root-coords, time, and so on.

footstep-list should be given.

:footstep-list

(list footstep1 footstep2 ...). :footstep-list can be any length. Each footstep indicates the destinations of swing legs in each step.

footstep should be list of coordinate whose :name is identical with one swing leg and whose coords is the destination of that leg. If number of swing legs in a step is one, the footstep can be a coordinate.

footstep1 is only for intialization and not executed.

:default-step-height

Height of swing leg cycloid trajectories. Default is 50[mm].

:dt

Sampling time of preview control and output walk pattern. Default is 0.1[s].

:default-step-time

Reference time of each step. The first 10 percent and the last 10 percent of default-step-time is double support phase. Default is 1.0[s].

:solve-angle-vector-args

:move-centroid-on-foot is used to solve IK in :calc-walk-pattern-from-footstep-list. :solve-angle-vector-args is passed to :move-centroid-on-foot in the form of (send\*self :move-centroid-on-foot ... solve-angle-vector-args). Default is nil.

:debug-view

Set t to show visualization. Default is nil.

:all-limbs

list of limb names. In each walking step, limbs in :all-limbs but not assigned as swing legs by :footstep-list are considered to be support legs. Default is '(:rleg :lleg) sorted in force-sensors order.

:default-zmp-offsets

(list limbname1 offset1 limbname2 offset2 ...). :default-zmp-offsets should include every limb in :all-limbs. offset is a float-vector[mm] and local offset of reference zmp position from end-coords. Default offset is  $\#F(0\ 0\ 0)[mm]$ .

:init-pose-function

A function which initialize robot's pose. Walking pattern is generated from this initial pose. :init-pose-function is called once at the start of walking pattern generation in the form of (funcial init-pose-function). Default is #'(lambda () (send self :move-centroid-on-foot :both '(:rleg :lleg))).

:start-with-double-support

At the start of walking pattern generation, the initial position of reference zmp is

t: midpoint of all-limbs.

nil: midpoint of swing legs of footstep1.

Default is t.

: end-with-double-support

At the end of walking pattern generation, the final position of reference zmp is t: midpoint of all-limbs. nil: midpoint of support legs of the last footstep. Default is t. :ik-thre Threshold for position error to terminate IK iteration. Default is 1[mm]. :ik-rthre Threshold for rotation error to terminate IK iteration. Default is (deg2rad 1)[rad]. Weight Q of the cost function of preview control. Default is 1.0. Weight R of the cost function of preview control. Default is 1e-6. :calc-zmp Set t to calculate resultant ZMP after IK. The calculated ZMP is visualized if :debug-view is t, and stored as czmp in return value. Default is t. [method] **:gen-footstep-parameter** &key (ratio 1.0) Generate footstep parameter :go-pos-params->footstep-list [method] xx yy th &key ((:footstep-parameter prm) (send self :footstep-parameter)) ((:default-half-offset defp) (cadr (memq :default-half-offset prm))) ((:forward-offset-length xx-max) (cadr (memq :forward-offset-length prm))) ((:outside-offset-length yy-max) (cadr (memq :outside-offset-length prm))) ((:rotate-rad th-max) (abs (rad2deg (cadr (memq :rotate-rad prm))))) (gen-go-pos-step-node-func #'(lambda (mc leg leg-translate-pos) (let ((cc (send Calculate foot step list from goal x position [mm], goal y position [mm], and goal yaw orientation [deg]. :go-pos-quadruped-params->footstep-list xx yy th &key (type :crawl) [method] Calculate foot step list for quadruped walking from goal x position [mm], goal y position [mm], and goal yaw orientation [deg]. :support-polygons [method] Return support polygons. [method] :support-polygon name Return support polygon. If name is list, return convex hull of all polygons. Otherwise, return polygon with given name

 $: \mathbf{make-default-linear-link-joint-between-attach-coords} \ attach-coords-0 \ attach-coords-1 \ end-coords-name \\ linear-joint-name \\ [\mathbf{method}]$ 

Make default linear arctuator module such as muscle and cylinder and append lins and joint-list. Module includes parent-link =>(j0) => l0 => (j1) => l1 (linear actuator) => (j2) => l2 => end-coords. attach-coords-0 is root side coords which linear actulator is attached to. attach-coords-1 is end side coords which linear actulator is attached to.

attach-coords-1 is end side coords which linear actulator is attached to. end-coords-name is the name of end-coords.

linear-joint-name is the name of linear actuator.

#### :calc-static-balance-point

[method]

Ekey (target-points (mapcar #'(lambda (tmp-arm) (send (send self tmp-arm :end-co (force-list (make-list (length target-points) :initial-element (float-vector 0 0 0))) (moment-list (make-list (length target-points) :initial-element (float-vector 0 0 0))) (static-balance-point-height (elt (apply #'midpoint 0.5 (send self :legs :end-coords :w (update-mass-properties t)

Calculate static balance point which is equivalent to static extended ZMP.

The output is expressed by the world coordinates.

target-points are end-effector points on which force-list and moment-list apply.

force-list [N] and moment-list [Nm] are list of force and moment that robot receives at target-points. static-balance-point-height is height of static balance point [mm].

:init-ending	[method]
:rarm-end-coords	[method]
:larm-end-coords	[method]
:rleg-end-coords	[method]
:lleg-end-coords	[method]
:head-end-coords	[method]
:torso-end-coords	[method]
:rarm-root-link	[method]
:larm-root-link	[method]
:rleg-root-link	[method]
:lleg-root-link	[method]
:head-root-link	[method]
:torso-root-link	[method]
:limb limb method &rest args	[method]
:inverse-kinematics-loop-for-look-at limb &rest args	[method]
:gripper limb &rest args	[method]
:get-sensor-method sensor-type sensor-name	[method]
$: {\bf get\text{-}sensors\text{-}method\text{-}by\text{-}limb} \ \ sensors\text{-}type \ \ limb$	[method]
:larm &rest args	[method]

```
:rarm &rest args
                                                                                                             [method]
:lleg &rest args
                                                                                                             [method]
:rleg &rest args
                                                                                                             [method]
:head &rest args
                                                                                                             [method]
:torso &rest args
                                                                                                             [method]
                                                                                                             [method]
:arms &rest args
:legs &rest args
                                                                                                             [method]
: distribute-total\text{-}wrench-to-torque-method-default\\
                                                                                                             [method]
\textbf{:joint-angle-limit-nspace-for-6dof} \ \textit{\&key} \ (avoid\textit{-nspace-gain} \ \textit{0.01}) \ (limbs \ \textit{'(:rleg::lleg)}) \\
                                                                                                             [method]
: joint-order \ limb \ {\it \&optional jname-list}
                                                                                                             [method]
:draw-gg-debug-view end-coords-list contact-state rz cog pz czmp dt
                                                                                                             [method]
:footstep-parameter
                                                                                                             [method]
: make-support-polygons
                                                                                                             [method]
                                                                                                             [method]
:make-sole-polygon name
:calc-zmp-from-forces-moments
                                                                                                            [method]
                                          forces moments &key (wrt :world)
                                           (limbs (if (send self :force-sensors) (remove nil (mapcar #'(lambda (fs) (find-
                                           (force-sensors (mapcar #'(lambda (l) (send self :force-sensor l)) limbs))
                                           (cop-coords (mapcar #'(lambda (l) (send self l :end-coords)) limbs))
                                           (fz-thre 0.001)
                                           (limb-cop-fz-list (mapcar #'(lambda (fs f m cc) (let ((fsp (scale 0.001 (send fs
      Calculate zmp[mm] from sensor local forces and moments
      If force_z is large, zmp can be defined and returns 3D zmp.
      Otherwise, zmp cannot be defined and returns nil.
:print-vector-for-robot-limb vec
                                                                                                            [method]
      Print angle vector with limb alingment and limb indent.
      For example, if robot is rarm, larm, and torso, print result is:
      #f(
      rarm-j0 ... rarm-jN
      larm-j0 ... larm-jN
      torso-j0 ... torso-jN
      )
:fullbody-inverse-kinematics
                                                                                                            [method]
```

target-coords & rest args & key (move-target)

```
(link-list)
(min (float-vector -500 -500 -500 -20 -20 -10))
(max (float-vector 500 500 25 20 20 10))
(root-link-virtual-joint-weight #f(0.1 0.1 0.1 0.1 0.5 0.5))
(target-centroid-pos (apply #'midpoint 0.5 (send self :legs :end-coords :worldpos)
(cog-gain 1.0)
(cog-translation-axis :z)
(centroid-offset-func nil)
(centroid-thre 5.0)
(additional-weight-list)
(joint-args nil)
(cog-null-space nil)
(min-loop 2)
&allow-other-keys
```

fullbody inverse kinematics for legged robot.

necessary args : target-coords, move-target, and link-list must include legs' (or leg's) parameters ex. (send \*robot\*:fullbody-inverse-kinematics (list rarm-tc rleg-tc lleg-tc) :move-target (list rarm-mt rleg-mt lleg-mt) :link-list (list rarm-ll rleg-ll lleg-ll)) :min

lower position limit of root link virtual joint (x y z roll pitch yaw). Default is #f(-500[mm] -500[mm] -20[deg] -20[deg] -10[deg]).

:max

upper position limit of root link virtual joint (x y z roll pitch yaw). Default is  $\#f(500[mm]\ 500[mm]\ 25[mm]\ 20[deg]\ 20[deg]\ 10[deg])$ .

:root-link-virtual-joint-weight

float-vector of inverse weight of velocity of root link virtual joint or a function which returns the float-vector (x y z roll pitch yaw). This works in the same way as :additional-weight-list in cascaded-coords::inverse-kinematics. Default is  $\#f(0.1\ 0.1\ 0.1\ 0.1\ 0.5\ 0.5)$ .

:joint-args

list of other arguments passed to :init function of root link virtual joint (6dof-joint class). :max-joint-velocity

limit of velocity of root link virtual joint (x y z roll pitch yaw). Default is  $\#f((/0.08\ 0.05)[m/s]\ (/0.08\ 0.05)[m/s]\ (/pi\ 4)[rad/s]\ (/pi\ 4)[rad/s]\ (/pi\ 4)[rad/s]))$  other-keys

:fullbody-inverse-kinematics internally calls :inverse-kinematics and args are passed to it. See the explanation of :inverse-kinematics.

#### :calc-force-from-joint-torque

[method]

limb all-torque &key (move-target (send self limb :end-coords)) (use-torso)

Calculates end-effector force and moment from joint torques.

:torque-vector [method]

&key (force-list) (moment-list) (target-coords)

```
(debug-view nil)
(calc-statics-p t)
(dt 0.005)
(av (send self :angle-vector))
(root-coords (send (car (send self:links)) :copy-worldcoords))
(calc-torque-buffer-args (send self :calc-torque-buffer-args))
(distribute-total-wrench-to-torque-method (if (and (not (every #'null (send self :legs))) (not (and
```

Returns torque vector

:init-pose [method]

Set robot to initial posture.

### :look-at-target look-at-target &key (target-coords)

[method]

move robot head to look at targets, look-at-target support t/nil float-vector coordinates, center of list of float-vector or list of coordinates

### :inverse-kinematics-loop

[method]

```
dif-pos dif-rot & rest args & key target-coords
debug-view
look-at-target
(move-target)
(link-list (if (atom move-target) (send self:link-list (send move-target:parent)) (mape
&allow-other-keys
```

move move-target using dif-pos and dif-rot,

look-at-target supports t, nil, float-vector, coords, list of float-vector, list of coords

link-list is set by default based on move-target ->root link link-list

:inverse-kinematics-loop internally calls :inverse-kinematics-loop function of cascaded-coords class. See the explanation of :inverse-kinematics-loop in cascaded-coords class.

:inverse-kinematics [method]

```
target-coords & rest args & key look-at-target
(move-target)
(link-list (if (atom move-target) (send self:link-list (send move-target:parent)) (mapcar #
&allow-other-keys
```

solve inverse kinematics, move move-target to target-coords

target-coords and move-target should be given.

link-list is set by default based on move-target ->root link link-list

:look-at-target

target head looks at. This task is best-effort and only head joints are used. :look-at-target supports t, nil, float-vector, coords, list of float-vector, list of coords. other-keys

:inverse-kinematics internally calls :inverse-kinematics of cascaded-cords class and args are passed to it. See the explanation of :inverse-kinematics of cascaded-cords class.

:look-at-hand l/r[method]

look at hand position, 1/r supports :rarm, :larm, :arms, and '(:rarm :larm)

[method] :cameras

Returns camera sensors.

:imu-sensors  Returns imu sensors.	[method]
:force-sensors  Returns force sensors.	[method]
:imu-sensor sensor-name Returns imu sensor of given name	$[\mathrm{method}]$
:force-sensor sensor-name  Returns force sensor with given name	[method]
:camera sensor-name  Returns camera with given name	[method]
:joint-order limb &optional jname-list	$[\mathrm{method}]$
:joint-angle-limit-nspace-for-6dof &key (avoid-nspace-gain 0.01) (limbs '(:rleg :lleg))	[method]
: distribute-total-wrench-to-torque-method-default	[method]
:legs &rest args	$[\mathrm{method}]$
:arms &rest args	$[\mathrm{method}]$
:torso &rest args	[method]
:head &rest args	[method]
:rleg &rest args	[method]
:lleg &rest args	[method]
:rarm &rest args	[method]
:larm &rest args	[method]
:get-sensors-method-by-limb sensors-type limb	[method]
:get-sensor-method sensor-type sensor-name	[method]
:gripper limb &rest args	[method]
:inverse-kinematics-loop-for-look-at $limb\ {\it \&rest\ args}$	[method]
:limb limb method &rest args	[method]
:torso-root-link	[method]
:head-root-link	[method]
:lleg-root-link	[method]

:rleg-root-link	$[\mathrm{method}]$
:larm-root-link	$[\mathrm{method}]$
:rarm-root-link	$[\mathrm{method}]$
:torso-end-coords	$[\mathrm{method}]$
:head-end-coords	[method]
:lleg-end-coords	[method]
:rleg-end-coords	$[\mathrm{method}]$
:larm-end-coords	$[\mathrm{method}]$
:rarm-end-coords	$[\mathrm{method}]$
:init-ending	$[\mathrm{method}]$
:calc-static-balance-point	[method]

Ekey (target-points (mapcar #'(lambda (tmp-arm) (send (send self tmp-arm :end-co (force-list (make-list (length target-points) :initial-element (float-vector 0 0 0))) (moment-list (make-list (length target-points) :initial-element (float-vector 0 0 0))) (static-balance-point-height (elt (apply #'midpoint 0.5 (send self :legs :end-coords :w (update-mass-properties t)

Calculate static balance point which is equivalent to static extended ZMP.

The output is expressed by the world coordinates.

target-points are end-effector points on which force-list and moment-list apply.

force-list [N] and moment-list [Nm] are list of force and moment that robot receives at target-points. static-balance-point-height is height of static balance point [mm].

 $: \mathbf{make-default-linear-link-joint-between-attach-coords} \ attach-coords-0 \ attach-coords-1 \ end-coords-name \\ linear-joint-name \\ [method]$ 

Make default linear arctuator module such as muscle and cylinder and append lins and joint-list.

Module includes parent-link => (j0) => l0 => (j1) => l1 (linear actuator) => (j2) => l2 => end-coords. attach-coords-0 is root side coords which linear actualtor is attached to.

attach-coords-1 is end side coords which linear actulator is attached to.

end-coords-name is the name of end-coords.

linear-joint-name is the name of linear actuator.

#### :support-polygon name

[method]

Return support polygon.

If name is list, return convex hull of all polygons.

Otherwise, return polygon with given name

## :support-polygons [method]

Return support polygons.

## :go-pos-quadruped-params->footstep-list $xx\ yy\ th\ \mathcal{E}key\ (type\ :crawl)$

[method]

Calculate foot step list for quadruped walking from goal x position [mm], goal y position [mm], and goal yaw orientation [deg].

#### :go-pos-params->footstep-list

[method]

```
xx yy th &key ((:footstep-parameter prm) (send self :footstep-parameter))
((:default-half-offset defp) (cadr (memq :default-half-offset prm)))
((:forward-offset-length xx-max) (cadr (memq :forward-offset-length prm)))
((:outside-offset-length yy-max) (cadr (memq :outside-offset-length prm)))
((:rotate-rad th-max) (abs (rad2deg (cadr (memq :rotate-rad prm)))))
(gen-go-pos-step-node-func #'(lambda (mc leg leg-translate-pos) (let ((cc (send
```

Calculate foot step list from goal x position [mm], goal y position [mm], and goal yaw orientation [deg].

### :gen-footstep-parameter &key (ratio 1.0)

[method]

Generate footstep parameter

#### : calc-walk-pattern-from-footstep-list

[method]

```
footstep-list &key (default-step-height 50)
(dt 0.1)
(default-step-time 1.0)
(solve-angle-vector-args)
(debug-view nil)
((:all-limbs al) (if (send self :force-sensors) (remove nil (mapcar #'(lambd (:default-zmp-offsets dzo) (mapcan #'(lambda (x) (list x (float-vector (init-pose-function #'(lambda nil (send self :move-centroid-on-foot :both (start-with-double-support t)
(end-with-double-support t)
(ik-thre 1)
(ik-rthre (deg2rad 1))
(q 1.0)
```

Calculate walking pattern from foot step list and return pattern list as a list of angle-vector, root-coords, time, and so on.

(r 1.000000e-06) (calc-zmp t)

footstep-list should be given.

:footstep-list

(list footstep1 footstep2 ...). :footstep-list can be any length. Each footstep indicates the destinations of swing legs in each step.

footstep should be list of coordinate whose :name is identical with one swing leg and whose coords is the destination of that leg. If number of swing legs in a step is one, the footstep can be a coordinate.

footstep1 is only for intialization and not executed.

:default-step-height

Height of swing leg cycloid trajectories. Default is 50[mm].

:dt

Sampling time of preview control and output walk pattern. Default is 0.1[s].

:default-step-time

Reference time of each step. The first 10 percent and the last 10 percent of default-step-time is double support phase. Default is 1.0[s].

:solve-angle-vector-args

:move-centroid-on-foot is used to solve IK in :calc-walk-pattern-from-footstep-list. :solve-angle-vector-args is passed to :move-centroid-on-foot in the form of (send\*self :move-centroid-on-foot ... solve-angle-vector-args). Default is nil.

:debug-view

Set t to show visualization. Default is nil.

:all-limbs

list of limb names. In each walking step, limbs in :all-limbs but not assigned as swing legs by :footstep-list are considered to be support legs. Default is '(:rleg :lleg) sorted in force-sensors order.

: default-zmp-offsets

(list limbname1 offset1 limbname2 offset2 ...). :default-zmp-offsets should include every limb in :all-limbs. offset is a float-vector[mm] and local offset of reference zmp position from end-coords. Default offset is  $\#F(0\ 0\ 0)[mm]$ .

:init-pose-function

A function which initialize robot's pose. Walking pattern is generated from this initial pose. :init-pose-function is called once at the start of walking pattern generation in the form of (funcall init-pose-function). Default is #'(lambda () (send self :move-centroid-on-foot :both '(:rleg :lleg))).

: start-with-double-support

At the start of walking pattern generation, the initial position of reference zmp is

t: midpoint of all-limbs.

nil: midpoint of swing legs of footstep1.

Default is t.

:end-with-double-support

At the end of walking pattern generation, the final position of reference zmp is

t: midpoint of all-limbs.

nil: midpoint of support legs of the last footstep.

Default is t.

:ik-thre

Threshold for position error to terminate IK iteration. Default is 1[mm].

:ik-rthre

Threshold for rotation error to terminate IK iteration. Default is (deg2rad 1)[rad].

:q

Weight Q of the cost function of preview control. Default is 1.0.

:1

Weight R of the cost function of preview control. Default is 1e-6.

:calc-zmp

Set t to calculate resultant ZMP after IK. The calculated ZMP is visualized if :debug-view is t, and stored as czmp in return value. Default is t.

#### :move-centroid-on-foot

[method]

leg fix-limbs &rest args &key (thre (mapcar #'(lambda (x) (if (memq x '(:rleg :lleg)) 1 (rthre (mapcar #'(lambda (x) (deg2rad (if (memq x '(:rleg :lleg)) 1 5))) fix-limbs)) (mid 0.5)

(target-centroid-pos (if (eq leg :both) (apply #'midpoint mid (mapcar #'(lambda (tmp (fix-limbs-target-coords (mapcar #'(lambda (x) (send self x :end-coords :copy-worldcoords-link-virtual-joint-weight # $f(0.1\ 0.1\ 0.0\ 0.0\ 0.5)$ )

#### &allow-other-keys

Move robot COG to change centroid-on-foot location,

leg: legs for target of robot's centroid, which should be:both,:rleg, and:lleg.

fix-limbs: limb names which are fixed in this IK.

#### :fix-leg-to-coords

[method]

fix-coords  $\mathscr{C}$ optional (l/r:both)  $\mathscr{C}$ key (mid 0.5)

&allow-other-keys

Fix robot's legs to a coords

In the following codes, leged robot is assumed.

## :foot-midcoords &optional (mid 0.5)

[method]

Calculate midcoords of :rleg and :lleg end-coords.

In the following codes, leged robot is assumed.

:make-sole-polygon name

[method]

:make-support-polygons

[method]

:footstep-parameter

[method]

:draw-gg-debug-view end-coords-list contact-state rz cog pz czmp dt make-default-robot-link len radius axis name &optional extbody [method] [function]

#### 18.5 Sensor Model

#### sensor-model

[Class]

:super body

:slots data profile

:profile &optional p

[method]

:signal rawinfo

[method]

 $: \mathbf{simulate} \ model$ 

[method]

:read

[method]

:draw-sensor  $\boldsymbol{v}$ 

[method]

:init shape &key name &allow-other-keys :init shape &key name &allow-other-keys [method]

:draw-sensor v

[method]

:read

[method]

[method]

```
: \mathbf{simulate} \ model
                                                                                                        [method]
                                                                                                        [method]
:signal rawinfo
:profile \&optional\ p
                                                                                                        [method]
bumper-model
                                                                                                         [Class]
                                sensor-model
                     :super
                     :slots
                                bumper-threshold
:init
                                                                                                       [method]
        b Erest args Ekey ((:bumper-threshold bt) 20)
        name
      Create bumper model, b is the shape of an object and bt is the threshold in distance[mm].
  \  \, : \mathbf{simulate} \ \mathit{objs} \\
                                                                                                       [method]
     Simulate bumper, with given objects, return 1 if the sensor detects an object and 0 if not.
:draw \ vwer
                                                                                                        [method]
:draw-sensor vwer
                                                                                                        [method]
                                                                                                       [method]
:simulate objs
     Simulate bumper, with given objects, return 1 if the sensor detects an object and 0 if not.
:init
                                                                                                       [method]
        b Erest args Ekey ((:bumper-threshold bt) 20)
      Create bumper model, b is the shape of an object and bt is the threshold in distance[mm].
:draw-sensor vwer
                                                                                                        [method]
:draw vwer
                                                                                                        [method]
camera-model
                                                                                                         [Class]
                                sensor-model
                     :super
                     :slots
                                (vwing:forward (:projection:newprojection:screen:view:viewpoint:view-direction:view-direction)
:init
                                                                                                       [method]
        b &rest args &key ((:width pw) 320)
        ((:height ph) 240)
        (view-up \#f(0.0 \ 1.0 \ 0.0))
        (viewdistance 100.0)
        (hither 100.0)
        (yon 10000.0)
        &allow-other-keys
      Create camera model. b is the shape of an object
```

:create-viewer &optional cv &key (no-window nil)

Create camera viewer, or set viewer

:width [method]

Returns width of the camera in pixel.

:height [method]

Returns height of the camera in pixel.

:fovy [method]

Returns field of view in degree

:cx [method]

Returns center x.

:cy [method]

Returns center y.

:fx [method]

Returns focal length of x.

:fy [method]

Returns focal length of y.

:screen-point pos [method]

Returns point in screen corresponds to the given pos.

:3d-point x y d [method]

Returns 3d position

[method]

Returns ray vector of given x and y.

:draw-on [method]

&rest args &key ((:viewer vwer) \*viewer\*) &allow-other-keys

Draw camera raw in irtviewer, ex (send cam :draw-on :flush t)

:draw-objects objs

Draw objects in camera viewer, expected type of objs is list of objects

:get-image [method]

&key (with-points) (with-colors)

Get image objects you need to call :draw-objects before calling this function

:select-drawmode mode objs [method]

Change drawmode for drawing with :draw-objects methods. mode is symbol of mode, 'hid is symbol for hidden line mode, the other symbols indicate default mode. objs is the same objects using :draw-objects.

:viewing &rest args [method]

:image-viewer & rest args

:width

Returns width of the camera in pixel.

[method]

:draw-sensor vwer &key flush (width 1) (color (float-vector 1 1 1)) [method] [method] :draw-objects-raw vwr objs :get-image-raw vwr &key (points) (colors) [method] :select-drawmode  $mode \ objs$ [method] Change drawmode for drawing with :draw-objects methods. mode is symbol of mode, 'hid is symbol for hidden line mode, the other symbols indicate default mode. objs is the same objects using :drawobjects. :get-image [method] &key (with-points) (with-colors) Get image objects you need to call :draw-objects before calling this function :draw-objects objs [method] Draw objects in camera viewer, expected type of objs is list of objects :draw-on [method] & Erest args & key ((:viewer vwer) \*viewer\*) &allow-other-keys Draw camera raw in irtviewer, ex (send cam :draw-on :flush t) [method] :ray x yReturns ray vector of given x and y. :3d-point x y d[method] Returns 3d position :screen-point pos [method] Returns point in screen corresponds to the given pos. :fy [method] Returns focal length of y. :fx [method] Returns focal length of x. [method] **:cy** Returns center y. [method] :cx Returns center x. :fovy [method] Returns field of view in degree :height [method] Returns height of the camera in pixel.

```
:create-viewer &optional cv &key (no-window nil)
                                                                                                             [method]
      Create camera viewer, or set viewer
:init
                                                                                                             [method]
         b &rest args &key ((:width pw) 320)
        ((:height ph) 240)
        (view-up \#f(0.0 \ 1.0 \ 0.0))
        (viewdistance 100.0)
        (hither 100.0)
        (yon 10000.0)
        &allow-other-keys
      Create camera model. b is the shape of an object
:get-image-raw vwr \ \mathcal{E}key \ (points) \ (colors)
                                                                                                              [method]
: \mathbf{draw-objects-raw} \ vwr \ objs
                                                                                                              [method]
:draw-sensor vwer &key flush (width 1) (color (float-vector 1 1 1))
                                                                                                              [method]
\textbf{:image-viewer} \ \ \mathscr{C}rest \ args
                                                                                                              [method]
:viewing &rest args
                                                                                                              [method]
make-camera-from-param
                                                                                                            [function]
                                    &key pwidth
                                    pheight
                                    fx
                                    fy
                                    cx
                                    су
                                    (tx 0)
                                    (ty 0)
                                    parent-coords
                                    name
                                    create-viewer
                                    (no-window nil)
      Create camera object from given parameters.
```

# 18.6 Environment Model

scene-model [Class]

:super cascaded-coords

:slots name objs

:init [method]

```
&rest args &key ((:name n) scene)
((:objects o))
((:remove-wall w))
&allow-other-keys
```

Create scene model

:objects [method]

Returns objects in the scene.

:add-objects objects [method]

Add objects to scene with identifiable names. Returns all objects.

:add-object obj

Add object to scene with identifiable name. Returns all objects.

:remove-objects objs-or-names [method]

Remove objects or objects with given names from scene. Returns removed objects.

:remove-object obj-or-name [method]

Remove object or object with given name from scene. Returns removed object.

:find-object name [method]

Returns objects with given name.

:add-spots spots [method]

Add spots to scene with identifiable names. All spots will be assoc with this scene. Returns T if added spots successfly, otherwise returns NIL.

:add-spot spot

Add spot to scene with identifiable name. The spot will be :assoc with this scene. Returns T if spot is added successfly, otherwise returns NIL.

:remove-spots spots [method]

Remove spots from this scene. All spots will be :dissoc with this scene. Returns removed spots.

:remove-spot spot

Remove spot from scene. the spot will be :dissoc with this scene. Returns removed spot.

:spots [method]

Return all spots in the scene.

:object name [method]

Return an object of given name.

:spot name [method]

Return a spot of given name.

:bodies [method]

:spot name [method]

Return a spot of given name.

:object name [method]

Return an object of given name.

[method]

:spots [method]

Return all spots in the scene.

:remove-spot spot [method]

Remove spot from scene. the spot will be :dissoc with this scene. Returns removed spot.

:remove-spots spots [method]

Remove spots from this scene. All spots will be :dissoc with this scene. Returns removed spots.

:add-spot spot

Add spot to scene with identifiable name. The spot will be :assoc with this scene. Returns T if spot is added successfly, otherwise returns NIL.

:add-spots spots [method]

Add spots to scene with identifiable names. All spots will be :assoc with this scene. Returns T if added spots successfly, otherwise returns NIL.

:find-object name [method]

Returns objects with given name.

:remove-object obj-or-name [method]

Remove object or object with given name from scene. Returns removed object.

:remove-objects objs-or-names

Remove objects or objects with given names from scene. Returns removed objects.

:add-object obj

Add object to scene with identifiable name. Returns all objects.

:add-objects objects [method]

Add objects to scene with identifiable names. Returns all objects.

:objects [method]

Returns objects in the scene.

:init [method]

&rest args &key ((:name n) scene)
((:objects o))
((:remove-wall w))
&allow-other-keys

Create scene model

:bodies [method]

## 18.7 Dynamics calculation/Walk motion generation

#### 18.7.1 Walking motion generation

A walking motion is generated using anticipatory control. Explained while quoting the formulas and sentences described in the literature.<sup>202122</sup>

A walking motion is generated by the following procedure.

- 1. Plan the positions and times at which the robot will land on the stride within the range where the inverse kinematics of the legs can be solved.
- 2. If the foot is not on the ground, cycloidal interpolation is performed to the next position.
- 3. Generate a center of gravity trajectory that matches the position of the foot on the ground as much as possible.
- 4. The joint angle trajectory that satisfies the planned trajectory of the foot and the center of gravity is obtained by inverse kinematics.

Here, the 3 steps are explained in detail.

First, consider the following control system for motion in the X direction. A similar argument can be made for motion in the Y direction.

$$\begin{cases} x_{k+1} = Ax_k + bu_k \\ p_k = cx_k \end{cases}$$

$$x_k \equiv \begin{bmatrix} x(k\Delta t) \\ \dot{x}(k\Delta t) \\ \dot{x}(k\Delta t) \end{bmatrix} \qquad u_k \equiv u(k\Delta t) \qquad p_k \equiv p(k\Delta t)$$

$$A \equiv \begin{bmatrix} 1 & \Delta t & \Delta t^2/2 \\ 0 & 1 & \Delta t \\ 0 & 0 & 1 \end{bmatrix} \qquad b \equiv \begin{bmatrix} \Delta t^3/6 \\ \Delta t^2/2 \\ \Delta t \end{bmatrix} \qquad c \equiv \begin{bmatrix} 1 & 0 & -z_c/g \end{bmatrix}$$

x is the position of the center of gravity of the robot, u is the time derivative (jerk) of the acceleration of the center of gravity, and p is the ZMP.

Next, replace this system with the following expansion system.

$$\begin{cases} x_{k+1}^* = \tilde{A}x_k^* + \tilde{b}\Delta u_k \\ p_k = \tilde{c}x_k^* \end{cases}$$

$$\Delta u_k \equiv u_k - u_{k-1} \quad \Delta x_k \equiv x_k - x_{k-1} \quad x_k^* \equiv \begin{bmatrix} p_k \\ \Delta x_k \end{bmatrix}$$

$$\tilde{A} \equiv \begin{bmatrix} 1 & cA \\ 0 & A \end{bmatrix} \quad \tilde{b} \equiv \begin{bmatrix} cb \\ b \end{bmatrix} \quad \tilde{c} \equiv \begin{bmatrix} 1 & 0 & 0 & 0 \end{bmatrix}$$

$$(58)$$

For this Equation 58 system, we obtain control inputs that minimize the following cost function.

$$J_k = \sum_{j=k}^{\infty} \{ Q(p_j^{ref} - p_j)^2 + R\Delta u_j^2 \}$$
 (59)

 $<sup>^{20}</sup>$  Humanoid Robot (in Japanese), Shuji Kajita, Ohmsha, 2005, ISBN 4-274-20058-2

<sup>&</sup>lt;sup>21</sup> Biped Walking Pattern Generation by using Preview Control of Zero-Moment Point, Shuji Kajita and Fumio Kanehiro and Kenji Kaneko and Kiyoshi Fujiwara and Kensuke Harada and Kazuhito Yokoi and Hirohisa Hirukawa, ICRA 2003, p.1620-1626, 2006

This is obtained as follows. First, consider the following cost function using a sufficiently large natural number M, then set  $M \to \infty$  to obtain the control input that minimizes Equation 59.

$$J_k^M = \sum_{j=k}^{M-1} \{ Q(p_j^{ref} - p_j)^2 + R\Delta u_j^2 \}$$
 (60)

Assuming that the minimum value of  $J_k^M$  is  $J_k^{M*}$ , the following relationship holds from Equation 60.

$$J_k^{M*} = \min_{\Delta u_k} \{ Q(p_k^{ref} - p_k)^2 + R\Delta u_k^2 + J_{k+1}^{M*} \}$$
(61)

Now put  $J_k^{M*}$  as follows.

$$J_k^{M*} = x_k^{*T} P_k^M x_k^* + \theta_k^{MT} x_k^* + \phi_k^M \tag{62}$$

Using this, the value obtained by partially differentiating the right side of Equation 61 with respect to  $\Delta u_k$  is 0, so the following equation is obtained.

$$0 = \frac{\partial}{\partial \Delta u_{k}} \{ Q(p_{k}^{ref} - p_{k})^{2} + R\Delta u_{k}^{2} + (\tilde{A}x_{k}^{*} + \tilde{b}\Delta u_{k})^{T} P_{k+1}^{M} (\tilde{A}x_{k}^{*} + \tilde{b}\Delta u_{k}) + \theta_{k+1}^{MT} (\tilde{A}x_{k}^{*} + \tilde{b}\Delta u_{k}) + \phi_{k+1}^{M} \}$$

$$0 = \Delta u_{k}^{T} R + \Delta u_{k}^{T} \tilde{b}^{T} P_{k+1}^{M} \tilde{b} + x_{k}^{*T} \tilde{A}^{T} P_{k+1}^{M} \tilde{b} + \frac{1}{2} \theta_{k+1}^{MT} \tilde{b}$$

$$\Delta u_{k} = -(\tilde{b}^{T} P_{k+1}^{M} \tilde{b} + R)^{-1} \tilde{b}^{T} P_{k+1}^{M} \tilde{A}x_{k}^{*} - \frac{1}{2} (\tilde{b}^{T} P_{k+1}^{M} \tilde{b} + R)^{-1} \tilde{b}^{T} \theta_{k+1}^{M}$$

$$(63)$$

By substituting this into Equation 61, we get:

$$x_{k}^{*T} P_{k}^{M} x_{k}^{*} + \theta_{k}^{MT} x_{k}^{*} + \phi_{k}^{M}$$

$$= x_{k}^{*T} (\tilde{c}^{T} Q \tilde{c} + \tilde{A}^{T} P_{k+1}^{M} \tilde{A} - \tilde{A}^{T} P_{k+1}^{M} \tilde{b} (\tilde{b}^{T} P_{k+1}^{M} \tilde{b} + R)^{-1} \tilde{b}^{T} P_{k+1}^{M} \tilde{A}) x_{k}^{*}$$

$$+ \{ -2 \tilde{c}^{T} Q p_{k}^{ref} + \tilde{A}^{T} \theta_{k+1}^{M} - \tilde{A}^{T} P_{k+1}^{M} \tilde{b} (\tilde{b}^{T} P_{k+1}^{M} \tilde{b} + R)^{-1} \tilde{b}^{T} \theta_{k+1}^{M} \}^{T} x_{k}^{*}$$

$$+ Q p_{k}^{ref2} - \frac{1}{4} \theta_{k+1}^{MT} \tilde{b} (\tilde{b}^{T} P_{k+1}^{M} \tilde{b} + R)^{-1} \tilde{b}^{T} \theta_{k+1}^{M} + \phi_{k+1}^{M}$$

$$(64)$$

Since this holds for any  $x_k^{*T}$ ,

$$P_k^M = \tilde{c}^T Q \tilde{c} + \tilde{A}^T P_{k+1}^M \tilde{A} - \tilde{A}^T P_{k+1}^M \tilde{b} (\tilde{b}^T P_{k+1}^M \tilde{b} + R)^{-1} \tilde{b}^T P_{k+1}^M \tilde{A}$$
 (65)

$$\theta_k^M = -2\tilde{c}^T Q p_k^{ref} + \{\tilde{A}^T - \tilde{A}^T P_{k+1}^M \tilde{b} (\tilde{b}^T P_{k+1}^M \tilde{b} + R)^{-1} \tilde{b}^T \} \theta_{k+1}^M$$
(66)

$$\phi_k^M = Q p_k^{ref2} - \frac{1}{4} \theta_{k+1}^{MT} \tilde{b} (\tilde{b}^T P_{k+1}^M \tilde{b} + R)^{-1} \tilde{b}^T \theta_{k+1}^M + \phi_{k+1}^M$$
(67)

Considering the boundary conditions, Equation 60 is  $J_{k+M}^{M*}=0$  at k=M, so Equation 62 at k=M is Considering the condition that holds identically for any  $x_M^*$ ,  $P_M^M=0$ ,  $\theta_M^M=0$ ,  $\phi_M^M=0$ . Therefore, for sufficiently small j,  $P_{k+j}^M$  becomes the stationary solution P of Equation 65, which satisfies the following equation.

$$P = \tilde{c}^T Q \tilde{c} + \tilde{A}^T P \tilde{A} - \tilde{A}^T P \tilde{b} (\tilde{b}^T P \tilde{b} + R)^{-1} \tilde{b}^T P \tilde{A}$$

$$(68)$$

Henceforth, we consider it as  $M \to \infty$ . Considering a natural number N and assuming  $p_{k+j}^{ref} = p_{k+N}^{ref}$  for j > N, Equation 66 can be expressed as (Equation 68 holds only for  $P_{k+j}$  for small enough j, but for large enough j ( $\tilde{A} - \tilde{b}K$ )<sup>Tj</sup>  $\to assumed$ 0 and ignored.)( $K \equiv (\tilde{b}^T P \tilde{b} + R)^{-1} \tilde{b}^T P \tilde{A}$ .)

$$\begin{aligned} \theta_{k} &= -2\tilde{c}^{T}Qp_{k}^{ref} + (\tilde{A} - \tilde{b}K)^{T}\theta_{k+1} \\ &= -2\{\tilde{c}^{T}Qp_{k}^{ref} + (\tilde{A} - \tilde{b}K)^{T}\tilde{c}^{T}Qp_{k+1}^{ref} + \dots + (\tilde{A} - \tilde{b}K)^{TN-2}\tilde{c}^{T}Qp_{k+N-1}^{ref} \\ &+ (\tilde{A} - \tilde{b}K)^{TN-1}\tilde{c}^{T}Qp_{k+N}^{ref} + (\tilde{A} - \tilde{b}K)^{TN}\tilde{c}^{T}Qp_{k+N+1}^{ref} + (\tilde{A} - \tilde{b}K)^{T(N+1)}\tilde{c}^{T}Qp_{k+N+2}^{ref} + \dots \} \\ &= -2\{\tilde{c}^{T}Qp_{k}^{ref} + (\tilde{A} - \tilde{b}K)^{T}\tilde{c}^{T}Qp_{k+1}^{ref} + \dots + (\tilde{A} - \tilde{b}K)^{TN-2}\tilde{c}^{T}Qp_{k+N-1}^{ref} \\ &+ (\tilde{A} - \tilde{b}K)^{TN-1}\tilde{c}^{T}Qp_{k+N}^{ref} + (\tilde{A} - \tilde{b}K)^{TN}\tilde{c}^{T}Qp_{k+N}^{ref} + (\tilde{A} - \tilde{b}K)^{T(N+1)}\tilde{c}^{T}Qp_{k+N}^{ref} + \dots \} \end{aligned}$$

$$&= -2\sum_{j=1}^{N-1}\{(\tilde{A} - \tilde{b}K)^{Tj-1}\tilde{c}^{T}Qp_{k+j}^{ref}\} - 2\sum_{j=N}^{\infty}\{(\tilde{A} - \tilde{b}K)^{Tj-1}\tilde{c}^{T}Qp_{k+N}^{ref}\}$$
(69)

Here, if we express Equation 68 using K, we get

$$P = \tilde{c}^T Q \tilde{c} + (\tilde{A} - \tilde{b}K)^T P \tilde{A} \tag{70}$$

By adding  $P\tilde{A}$  to both sides and rearranging,

$$(I - (\tilde{A} - \tilde{b}K)^T)P\tilde{A} = P(\tilde{A} - I) + \tilde{c}^T Q\tilde{c}$$
(71)

where  $\tilde{A} = \begin{bmatrix} 1 & cA \\ 0 & A \end{bmatrix}$ ,  $\tilde{c} = \begin{bmatrix} 1 & 0 & 0 & 0 \end{bmatrix}$ , from the equation in the first column of Equation 71 ,

$$(I - (\tilde{A} - \tilde{b}K)^T)P\tilde{c}^T = \tilde{c}^TQ \tag{72}$$

Substituting this Equation 72 into Equation 69 gives

$$\theta_k = -2\sum_{j=1}^{N-1} \{ (\tilde{A} - \tilde{b}K)^{Tj-1} \tilde{c}^T Q p_{k+j}^{ref} \} - 2(\tilde{A} - \tilde{b}K)^{TN-1} P \tilde{c}^T p_{k+N}^{ref}$$
(73)

the optimal control input  $\Delta u_k$  that minimizes Equation 59 is obtained.


$$\Delta u_{k} = -Kx_{k}^{*} + \sum_{j=1}^{N} \tilde{f}_{j} p_{k+j}^{ref}$$

$$\tilde{f}_{j} = \begin{cases} (\tilde{b}^{T} P \tilde{b} + R)^{-1} \tilde{b}^{T} (\tilde{A} - \tilde{b} K)^{Tj-1} \tilde{c}^{T} Q & (j < N) \\ (\tilde{b}^{T} P \tilde{b} + R)^{-1} \tilde{b}^{T} (\tilde{A} - \tilde{b} K)^{TN-1} P \tilde{c}^{T} & (j = N) \end{cases}$$

$$(74)$$

Given initial state  $x_1^*$  and target ZMP trajectory  $p_1^{ref}$ ,  $p_2^{ref}$ ,  $\cdots$ , the system of Equation 74 and Equation 58 system,  $\Delta u_1$ ,  $x_2^*$ ,  $\Delta u_2$ ,  $x_3^*$ ,  $\cdots$  are obtained sequentially. This makes it possible to generate a center-of-gravity trajectory whose ZMP matches the position of the foot on the ground as much as possible.

#### 18.7.2 Example of Walking Motion Generation



**図** 25: Example of walk pattern generation

The robot-model class defines a function :calc-walk-pattern-from-footstep-list that generates offline walking motion and returns the walking trajectory. Given a list of foot placement positions for each step, this function generates a walking motion that makes the ZMP as close to this position as possible. The program shown below uses :calc-walk-pattern-from-footstep-list to generate walking motion (Fig.25).

```
(load "irteus/demo/sample-robot-model.1")
(setq *robot* (instance sample-robot :init))
(send *robot* :reset-pose)
(send *robot* :fix-leg-to-coords (make-coords))
(objects (list *robot*))
(let ((footstep-list
       (list (make-coords :coords (send *robot* :rleg :end-coords :copy-worldcoords) :name :rleg)
             (make-coords :coords (send (send *robot* :lleg :end-coords :copy-worldcoords)
                                         :translate #f(100 0 0)) :name :lleg)
             (make-coords :coords (send (send *robot* :rleg :end-coords :copy-worldcoords)
                                         :translate #f(200 0 0)) :name :rleg)
             (make-coords :coords (send (send *robot* :lleg :end-coords :copy-worldcoords)
                                         :translate \#f(300\ 0\ 0) :name :lleg)
             (make-coords :coords (send (send *robot* :rleg :end-coords :copy-worldcoords)
                                         :translate \#f(400\ 0\ 0)) :name :rleg)
             (make-coords :coords (send (send *robot* :lleg :end-coords :copy-worldcoords)
                                         :translate \#f(400\ \tilde{0}\ 0)) :name :lleg))))
  (objects (append (list *robot*) footstep-list))
  (send *robot* :calc-walk-pattern-from-footstep-list
       footstep-list
        :default-step-height 50
        :default-step-time 1.0
        :dt 0.1
        :debug-view t)
 )
```

The variable footstep-list is set to the list of footstep positions and given to :calc-walk-pattern-from-footstep-list. Each element of footstep-list must specify which foot it is in :name. The first element of footstep-list is used for initialization, and the robot actually steps to positions after the next element. :default-step-height 50 specifies 50[mm] as the height for cycloidal interpolation of the swing leg. :default-step-time 1.0 specifies 1.0[s] as the time per step. :dt 0.1 specifies 0.1[s] as the sampling time of preview control and the interval between generated trajectories. Note that :default-step-height, :default-step-time and :dt are the default values, so there is no need to actually set these values.

The following program generates walking motions by automatically generating footstep-list when a desired destination is given.

Give the return value of (send \*robot\* :go-pos-params->footstep-list 500 150 45) as footstep-list. The walk-pattern-from-footstep-list—function generates walking motions.

The :go-pos-params->footstep-list function provides a footstep- This is a function that generates a 3 and generates a footstep-list that moves 500[mm] forward, 150[mm] left, and rotates 45[deg] to the left. there is

joint [Class]

:super propertied-object

:slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

:calc-inertia-matrix &rest args [method]

rotational-joint [Class]

:super joint

:slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

 $\begin{array}{l} \textbf{:calc-inertia-matrix} \ \textit{mat} \ \textit{row} \ \textit{column} \ \textit{paxis} \ \textit{m-til} \ \textit{c-til} \ \textit{i-til} \ \textit{axis-for-angular} \ \textit{world-default-coords} \ \textit{translation-axis} \ \textit{tmp-v0} \\ \end{array} \\ \begin{array}{l} \textbf{[method]} \\ \end{array}$ 

linear-joint [Class]

:super joint

:slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

 $\begin{array}{l} \textbf{:calc-inertia-matrix} \ \textit{mat row column paxis m-til c-til i-til axis-for-angular world-default-coords translation-axis rotation-axis} \\ \textit{tmp-v0 tmp-v1 tmp-v2 tmp-v2 tmp-vb tmp-vc tmp-vd tmp-m} \end{array} \quad \begin{array}{l} \textbf{[method]} \\ \end{array}$ 

omniwheel-joint [Class]

:super joint

slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

 $\begin{array}{l} \textbf{:calc-inertia-matrix} \ \textit{mat row column pax} \textit{is m-til c-til i-til axis-for-angular world-default-coords translation-axis rotation-axis} \\ \textit{tmp-v0 tmp-v1 tmp-v2 tmp-va tmp-vb tmp-vc tmp-vd tmp-m} \end{array} \quad \begin{bmatrix} \textbf{method} \end{bmatrix}$ 

sphere-joint [Class]

:super **join** 

slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

 $\begin{array}{l} \textbf{:calc-inertia-matrix} \ \textit{mat row column pax} \textit{is m-til c-til i-til axis-for-angular world-default-coords translation-axis rotation-axis} \\ \textit{tmp-v0 tmp-v1 tmp-v2 tmp-va tmp-vb tmp-vc tmp-vd tmp-m} \end{array} \quad \begin{array}{l} \textbf{[method]} \\ \textbf{[method]} \end{array}$ 

6dof-joint [Class]

:super joint

slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

 $\begin{array}{l} \textbf{:calc-inertia-matrix} \ \textit{mat row column pax} \textit{is m-til c-til i-til axis-for-angular world-default-coords translation-axis rotation-axis} \\ \textit{tmp-v0 tmp-v1 tmp-v2 tmp-va tmp-vb tmp-vc tmp-vd tmp-m} \end{array} \quad \begin{array}{l} \textbf{[method]} \\ \textbf{[method]} \end{array}$ 

bodyset-link [Class]

:super bodyset

:slots rot pos parent descendants worldcoords manager changed geometry::bodies joint pare

:calc-inertia-matrix-column column & rest args & key (rotation-axis nil) (translation-axis t) ((:inertia-matrix im)) (axis-for-angular (float-vector 0 0 0)) (tmp-v0 (instantiate float-vector 0)) (tmp-v1 (instantiate float-vector 1)) (tmp-v2 (instantiate float-vector 2)) (tmp-va (instantiate float-vector 3)) (tmp-vb (instantiate float-vector 3)) (tmp-vb (instantiate float-vector 3)) (tmp-va (instantiate float-vector 3)) (tmp-va (instantiate float-vector 3)) (tmp-vb (instantiate float-vector 3))

:propagate-mass-properties &key (debug-view nil) (tmp-va (instantiate float-vector 3)) (tmp-vb (instantiate float-vector 3)) (tmp-ma (make-matrix 3 3)) (tmp-mb (make-matrix 3 3)) (tmp-mc (make-matrix 3 3)) [method]

:append-mass-properties additional-links &key (update t) (tmp-va (float-vector 0 0 0)) (tmp-vb (float-vector 0 0 0)) (tmp-ma (make-matrix 3 3)) (tmp-mb (make-matrix 3 3)) (tmp-mc (make-matrix 3 3)) (tmp-md (make-matrix 3 3)) (additional-weights (send-all additional-links :weight)) (additional-centroids (send-all additional-links :centroid)) (additional-inertias (mapcar #'(lambda (x) (m\*(m\*(send x :worldrot) (send x :inertia-tensor) tmp-ma) (transpose (send x :worldrot) tmp-mb))) additional-links)) (self-centroid (send self :centroid))

:append-centroid-no-update additional-weights additional-centroids self-centroid new-weight & key (tmp-va (float-vector 0 0)) (tmp-vb (float-vector 0 0 0)) (len (length additional-weights))
[method]

:append-weight-no-update additional-weights &key (len (length additional-weights))

[method]

## cascaded-link

[Class]

:super cascaded-coords

 $\begin{array}{ll} \textbf{:cog-convergence-check} \ centroid\text{-}thre \ target\text{-}centroid\text{-}pos \ \&key \ (centroid\text{-}offset\text{-}func) \ (translation\text{-}axis :z) \ (update\text{-}mass\text{-}properties \ t) \\ \hline \\ \textbf{[method]} \end{array}$ 

:difference-cog-position target-centroid-pos &key (centroid-offset-func) (translation-axis :z) (add-draw-on-param) (update-mass-properties t) [method]

:calc-vel-for-cog cog-gain translation-axis target-centroid-pos &key (centroid-offset-func) (update-mass-properties t) [method]

:cog-jacobian-balance-nspace link-list &rest args &key (cog-gain 1.0) (translation-axis :z) (target-centroid-pos) (centroid-offset-func) (update-mass-properties t) &allow-other-keys [method]

 $\begin{array}{l} \textbf{:calc-cog-jacobian-from-link-list} \ \ \mathcal{E}rest \ args \ \mathcal{E}key \ (link-list \ (send-all \ joint-list \ :child-link)) \ (rotation-axis \ nil) \ (translation-axis \ t) \ (axis-dim \ (send \ self \ :calc-target-axis-dimension \ rotation-axis \ translation-axis)) \ (inertia-matrix \ (make-matrix \ axis-dim \ (send \ self \ :calc-target-joint-dimension \ link-list))) \ (update-mass-properties \ t) \ \mathcal{E}allow-other-keys \\ \hline \end{array} \ \ \ \ \begin{array}{l} \text{[method]} \end{array}$ 

:calc-inertia-matrix-from-link-list &rest args &key (link-list (send-all joint-list :child-link)) (rotation-axis nil) (translation-axis t) (axis-dim (send self :calc-target-axis-dimension rotation-axis translation-axis)) (inertia-matrix (make-matrix axis-dim (send self :calc-target-joint-dimension link-list))) (update-mass-properties t) (axis-for-angular) (tmp-v0 (instantiate float-vector 0)) (tmp-v1 (instantiate float-vector 1)) (tmp-v2 (instantiate float-vector 2)) (tmp-va (instantiate float-vector 3)) (tmp-vb (instantiate float-vector 3)) (tmp-vc (instantiate float-vector 3)) (tmp-ma (make-matrix 3 3)) (tmp-mb (make-matrix 3 3)) (tmp-mc (make-matrix 3 3)) & & [method]

 $\begin{array}{l} \textbf{:update-mass-properties} \ \& \textit{key} \ (\textit{tmp-va} \ (\textit{instantiate} \ \textit{float-vector} \ \textit{3})) \ (\textit{tmp-vb} \ (\textit{instantiate} \ \textit{float-vector} \ \textit{3})) \ (\textit{tmp-mb} \ (\textit{make-matrix} \ \textit{3} \ \textit{3})) \ (\textit{tmp-mb} \ (\textit{make-matrix} \ \textit{3} \ \textit{3})) \ (\textit{tmp-mb} \ (\textit{make-matrix} \ \textit{3} \ \textit{3})) \end{array} \\ \boxed{\text{[method]}}$ 

joint [Class]

:super propertied-object

:slots parent-link child-link joint-angle min-angle max-angle default-coords joint-velocity joi

:moment

[method]

:calc-angular-acceleration-jacobian $\mathscr{C}rest\ args$			[method]	
:calc-spacial-acceleration-jacobian $\mathscr{C}rest\ args$			[method]	
:calc-angular-veloci	ty-jacobian	Erest args	[method]	
:calc-spacial-velocit	y-jacobian	Grest args	[method]	
rotational-jo	oint		[Class]	
	:super	joint	[]	
	:slots	parent-link child-link joint-angle min-angle max-angle default-coord	ls joint-velocity joi	
:calc-angular-accele	ration-jaco	bian avj tmp-va	[method]	
:calc-spacial-acceler	ation-jacob	oian svj avj tmp-va tmp-vb	[method]	
:calc-angular-veloci	ty-jacobian	$ax\ tmp ext{-}va$	[method]	
:calc-spacial-velocity-jacobian ax tmp-va tmp-vb		[method]		
linear-joint			[Class]	
	:super	joint		
	:slots	parent-link child-link joint-angle min-angle max-angle default-coord	ls joint-velocity joi	
:calc-angular-accele	ration-jaco	bian avj tmp-va	$[\mathrm{method}]$	
:calc-spacial-acceler	ation-jacob	oian svj avj tmp-va tmp-vb	[method]	
:calc-angular-veloci	ty-jacobian	ax tmp-va	[method]	
:calc-spacial-velocit	y-jacobian	ax tmp-va tmp-vb	[method]	
bodyset-link	ζ.		[Class]	
	:super	bodyset		
	:slots	rot pos parent descendants worldcoords manager changed geometry	::bodies joint pare	
:inverse-dynamics &key (debug-view nil) (tmp-va (float-vector 0 0 0)) (tmp-vb (float-vector 0 0 0)) (tmp-vc (float-vector 0 0 0)) (tmp-ma (make-matrix 3 3)) (tmp-mb (make-matrix 3 3)) (tmp-mc (make-matrix 3 3)) (tmp-md (make-matrix 3 3)) [method]				
:forward-all-kinematics &key (debug-view nil) (tmp-va (float-vector 0 0 0))			[method]	
:ext-moment & option	$nal \ m$		[method]	
:ext-force Coptional	f		[method]	

:force
[method]

:spacial-acceleration & optional sa
[method]

:spacial-velocity & optional aa
[method]

:angular-acceleration & optional aa
[method]

:angular-velocity & optional aa
[method]

:reset-dynamics
[method]

cascaded-link
[Class]

:super cascaded-coords

## :inertia-tensor &optional (update-mass-properties t)

[method]

Calculate total robot inertia tensor [g  $mm^2$ ] around total robot centroid in euslisp world coordinates. If update-mass-properties argument is t, propagate total mass prop calculation for all links and returns total robot inertia tensor.

Otherwise, do not calculate total mass prop, just returns pre-computed total robot inertia tensor.

### :centroid &optional (update-mass-properties t)

[method]

Calculate total robot centroid (Center Of Gravity, COG) [mm] in euslisp world coordinates.

If update-mass-properties argument is t, propagate total mass prop calculation for all links and returns total robot centroid.

Otherwise, do not calculate total mass prop, just returns pre-computed total robot centroid.

#### :weight &optional (update-mass-properties t)

[method]

Calculate total robot weight [g].

If update-mass-properties argument is t, propagate total mass prop calculation for all links and returns total robot weight.

Otherwise, do not calculate total weight, just returns pre-computed total robot weight.

:calc-zmp [method]

```
Eoptional (av (send self :angle-vector)) (root-coords (send (car (send self :links)) :copy-worldcoords)) (dt 0.005)
(update t)
(debug-view)
```

Calculate Zero Moment Point based on Inverse Dynamics.

(calc-torque-buffer-args (send self :calc-torque-buffer-args))

The output is expressed by the world coordinates,

and depends on historical robot states of the past 3 steps. Step is incremented when this method is called.

After solving Inverse Dynamics, ZMP is calculated from total root-link force and moment. necessary arguments ->av and root-coords.

If update is t, call inverse dynamics, otherwise, just return zmp from total root-link force and moment. dt [s] is time step used only when update is t.

pZMPz is ZMP height [mm].

After this method, (send robot :get :zmp) is ZMP and (send robot :get :zmp-moment) is moment around ZMP.

:draw-torque vwer &key flush (width 2) (size 100) (color (float-vector 1 0.3 0)) (warning-color (float-vector 1 0 0)) (torque-threshold nil) (torque-vector (send self :torque-vector)) ((:joint-list jlist) (send self :joint-list)) [method]

 $: wrench-list-> wrench-vector \ \mathit{wrench-list}$ 

[method]

:wrench-vector->wrench-list wrench-vector

[method]

 $\textbf{:calc-cop-from-force-} moment \ \textit{force moment sensor-coords } \ \textit{\&key (fz-thre 1) (return-all-values)}$ 

[method]

:calc-torque-from-ext-wrenches &key (force-list) (moment-list) (target-coords) ((:jacobi tmp-jacobi))

[method]

:calc-av-vel-acc-from-pos dt av

[method]

 $: \textbf{calc-root-coords-vel-acc-from-pos} \ \textit{dt root-coords}$ 

[method]

:calc-torque-without-ext-wrench &key (debug-view nil) (calc-statics-p t) (dt 0.005) (av (send self :angle-vector)) (root-coords (send (car (send self :links)) :copy-worldcoords)) (calc-torque-buffer-args (send self :calc-torque-buffer-args)) [method]

:calc-torque &key (debug-view nil) (calc-statics-p t) (dt 0.005) (av (send self :angle-vector)) (root-coords (send (car (send self :links)) :copy-worldcoords)) (force-list) (moment-list) (target-coords) (calc-torque-buffer-args (send self :calc-torque-buffer-args))

[method]

:calc-torque-buffer-args

[method]

 $\textbf{:torque-ratio-vector} \ \textit{\&rest args} \ \textit{\&key} \ (torque \ (send*self : torque-vector \ args))$ 

[method]

:max-torque-vector

[method]

# riccati-equation

[Class]

:super **propertied-object** 

:slots a b c p q r k a-bkt r+btpb-1

:init  $aa\ bb\ cc\ qq\ rr$ 

[method]

:solve

[method]

[method]

:init aa bb cc qq rr

## preview-controller

[Class]

:super riccati-equation

:slots xk uk delay f1-n y1-n queue-index initialize-queue-p additional-data-queue finishedp i

:init [method]

```
dt &key (q)
(r)
((:delay d))
((:a _a))
((:b _b))
((:c _c))
(state-dim (array-dimension _a 0))
((:output-dim odim) (array-dimension _c 0))
((:input-dim idim) (array-dimension _b 1))
(init-xk (instantiate float-vector (array-dimension _a 0)))
(init-uk (make-matrix (array-dimension _b 1) 1))
((:initialize-queue-p iqp))
```

Initialize preview-controller.

Q is weighting of output error and R is weighting of input.

dt is sampling time [s].

delay is preview time [s].

init-xk is initial state value.

A, B, C are state eq matrices.

If initialize-queue-p is t, fill all queue by the first input at the begenning, otherwise, do not fill queue at the first.

## :update-xk p &optional (add-data)

[method]

Update xk by inputting reference output.

Return value: nil (initializing) =>return values (middle) =>nil (finished)

If p is nil, automatically the last value in queue is used as input and preview controller starts finishing.

#### :finishedp

Finished or not.

#### :last-reference-output-vector

[method]

Last value of reference output queue vector (y\_k+N\_ref).

Last value is latest future value.

#### :current-reference-output-vector

[method]

First value of reference output queue vector (y\_k\_ref).

First value is oldest future value and it can be used as current reference value.

#### :current-state-vector [method]

Current state value (xk).

## [method] :current-output-vector Current output value (yk). :current-additional-data [method] Current additional data value. First value of additional-data-queue. :pass-preview-controller reference-output-vector-list[method] Get preview controller results from reference-output-vector-list and returns list. :calc-f [method] :calc-u [method] [method] :calc-xk $: {\bf pass-preview-controller}\ \it reference-output-vector-list$ [method] Get preview controller results from reference-output-vector-list and returns list. :current-additional-data [method] Current additional data value. First value of additional-data-queue. [method] :current-output-vector Current output value (yk). :current-state-vector [method] Current state value (xk). :current-reference-output-vector [method] First value of reference output queue vector (y\_k\_ref). First value is oldest future value and it can be used as current reference value. :last-reference-output-vector [method] Last value of reference output queue vector (y\_k+N\_ref). Last value is latest future value. :finishedp [method] Finished or not. :update-xk p &optional (add-data) [method] Update xk by inputting reference output. Return value: nil (initializing) =>return values (middle) =>nil (finished) If p is nil, automatically the last value in queue is used as input and preview controller starts finishing. :init [method] $dt \ \mathcal{E}key \ (q)$ (r) ((:delay d)) $((:a _a))$ $((:b _b))$ $((:c \_c))$

(state-dim (array-dimension \_a 0))

```
((:output-dim odim) (array-dimension _c 0))
        ((:input-dim idim) (array-dimension _b 1))
        (init-xk (instantiate float-vector (array-dimension _a 0)))
        (init-uk (make-matrix (array-dimension _b 1) 1))
        ((:initialize-queue-p iqp))
     Initialize preview-controller.
      Q is weighting of output error and R is weighting of input.
     dt is sampling time [s].
     delay is preview time [s].
     init-xk is initial state value.
     A, B, C are state eq matrices.
     If initialize-queue-p is t, fill all queue by the first input at the begenning, otherwise, do not fill queue
     at the first.
:calc-xk
                                                                                                      [method]
:calc-u
                                                                                                      [method]
:calc-f
                                                                                                      [method]
extended-preview-controller
                                                                                                       [Class]
                                preview-controller
                     :super
                     :slots
                               orga orgb orgc xk*
:init
                                                                                                     [method]
        dt &key (q)
        (r)
        ((:delay d))
        ((:a _orga))
        ((:b _orgb))
        ((:c _orgc))
        (init-xk (instantiate float-vector (array-dimension Lorga 0)))
        (init-uk (make-matrix (array-dimension _orgb 1) 1))
        (state-dim (array-dimension Lorga 0))
        ((:initialize-queue-p iqp))
     Initialize preview-controller in extended system (error system).
      Q is weighting of output error and R is weighting of input.
     dt is sampling time [s].
     delay is preview time [s].
     init-xk is initial state value.
     A, B, C are state eq matrices for original system and slot variables A,B,C are used for error system
```

If initialize-queue-p is t, fill all queue by the first input at the begenning, otherwise, do not fill queue

:current-output-vector

at the first.

matrices.

[method]

(r 1.000000e-06)((:delay d) 1.6)

Current additional data value.

First value of additional-data-queue.

```
:calc-f
                                                                                                    [method]
:calc-u
                                                                                                    [method]
:calc-xk
                                                                                                    [method]
:current-output-vector
                                                                                                   [method]
     Current additional data value.
     First value of additional-data-queue.
:init
                                                                                                   [method]
        dt &key (q)
        (r)
        ((:delay d))
        ((:a _orga))
        ((:b _orgb))
        ((:c _orgc))
        (init-xk (instantiate float-vector (array-dimension _orga 0)))
        (init-uk (make-matrix (array-dimension _orgb 1) 1))
        (state-dim (array-dimension _orga 0))
        ((:initialize-queue-p iqp))
        (q-mat)
     Initialize preview-controller in extended system (error system).
     Q is weighting of output error and R is weighting of input.
     dt is sampling time [s].
     delay is preview time [s].
     init-xk is initial state value.
     A, B, C are state eq matrices for original system and slot variables A,B,C are used for error system
     matrices.
     If initialize-queue-p is t, fill all queue by the first input at the begenning, otherwise, do not fill queue
     at the first.
:calc-xk
                                                                                                    [method]
:calc-u
                                                                                                    [method]
:calc-f
                                                                                                    [method]
preview-control-cart-table-cog-trajectory-generator
                                                                                                     [Class]
                               propertied-object
                    :super
                    :slots
                               pcs cog-z zmp-z
:init
                                                                                                   [method]
        dt ₋zc &key (q 1)
```

Finished or not.

```
(init-xk (float-vector 0 0 0))
        ((:a _a) (make-matrix 3 3 (list (list 1 dt (*0.5 dt dt)) (list 0 1 dt) (list 0 0 1))))
        ((:b _b) (make-matrix 3 1 (list (list (*(/ 1.0 6.0) dt dt dt)) (list (*0.5 dt dt)) (list dt))))
        ((:c _c) (make-matrix 1 3 (list (list 1.0 0.0 (- (/ _zc (elt *g-vec*2)))))))
        ((:initialize-queue-p iqp))
        (preview-controller-class extended-preview-controller)
     COG (xy) trajectory generator using preview-control convert reference ZMP from reference COG.
     dt ->sampling time[s], \_zc is height of COG [mm].
     preview-controller-class is preview controller class (extended-preview-controller by default).
     For other arguments, please see preview-controller and extended-preview-controller :init documenta-
     tion.
:refcog
                                                                                                   [method]
     Reference COG [mm].
:cart-zmp
                                                                                                   [method]
     Cart-table system ZMP[mm] as an output variable.
:last-refzmp
                                                                                                   [method]
     Reference zmp at the last of queue.
                                                                                                   [method]
:current-refzmp
     Current reference zmp at the first of queue.
                                                                                                   [method]
:update-xk p &optional (add-data)
     Update xk and returns zmp and cog values.
     For arguments, please see preview-controller and extended-preview-controller :update-xk.
:finishedp
                                                                                                   [method]
     Finished or not.
:current-additional-data
                                                                                                   [method]
     Current additional data value.
                                                                                                   [method]
:pass-preview-controller reference-output-vector-list
     Get preview controller results from reference-output-vector-list and returns list.
                                                                                                   [method]
:cog-z
     COG Z [mm].
:update-cog-z zc
                                                                                                    [method]
                                                                                                   [method]
:cog-z
     COG Z [mm].
: {\bf pass-preview-controller}\ \it reference-output-vector-list
                                                                                                   [method]
     Get preview controller results from reference-output-vector-list and returns list.
:current-additional-data
                                                                                                   [method]
     Current additional data value.
                                                                                                   [method]
:finishedp
```

 $: {\bf get\text{-}swing\text{-}limbs} \ limbs$ 

[method]

```
:update-xk p &optional (add-data)
                                                                                                           [method]
      Update xk and returns zmp and cog values.
      For arguments, please see preview-controller and extended-preview-controller :update-xk.
                                                                                                           [method]
:current-refzmp
      Current reference zmp at the first of queue.
:last-refzmp
                                                                                                           [method]
      Reference zmp at the last of queue.
                                                                                                           [method]
      Cart-table system ZMP[mm] as an output variable.
:refcog
                                                                                                           [method]
      Reference COG [mm].
:init
                                                                                                           [method]
        dt \ zc \ \mathcal{E}key \ (q \ 1)
        (r 1.000000e-06)
        ((:delay d) 1.6)
        (init-xk (float-vector 0 0 0))
        ((:a _a) (make-matrix 3 3 (list (list 1 dt (*0.5 dt dt)) (list 0 1 dt) (list 0 0 1))))
        ((:b_b) (make-matrix 3 1 (list (list (*(/ 1.0 6.0) dt dt dt)) (list (*0.5 dt dt)) (list dt))))
        ((:c _c) (make-matrix 1 3 (list (list 1.0 0.0 (- (/ _zc (elt *g-vec*2)))))))
        ((:initialize-queue-p iqp))
        (preview-controller-class extended-preview-controller)
      COG (xy) trajectory generator using preview-control convert reference ZMP from reference COG.
      dt ->sampling time[s], _zc is height of COG [mm].
      preview-controller-class is preview controller class (extended-preview-controller by default).
      For other arguments, please see preview-controller and extended-preview-controller :init documenta-
      tion.
:update-cog-z zc
                                                                                                            [method]
gait-generator
                                                                                                             [Class]
                                 propertied-object
                      :slots
                                 robot dt footstep-node-list support-leg-list support-leg-coords-list swing-leg-dst-coords
:init rb \_dt
                                                                                                            [method]
: {\bf get\text{-}footstep\text{-}limbs}\ \mathit{fs}
                                                                                                            [method]
: get-counter-footstep-limbs \mathit{fs}
                                                                                                            [method]
: {\bf get\text{-}limbs\text{-}zmp\text{-}list}\ limb\text{-}coords\ limb\text{-}names
                                                                                                            [method]
:get-limbs-zmp limb-coords limb-names
                                                                                                            [method]
```

:initialize-gait-parameter fsl time cog &key ((:default-step-height dsh) 50) ((:default-double-support-ratio ddsr) 1.6) ((:all-limbs al) '(:rleg :lleg)) ((:default-zmp-offsets dzo) (mapcan #'(lambda (x) (list x (float-vector 0 0 0))) (r 1.000000e-06) (thre 1) (rthre (deg2rad 1)) (start-with-double-support t) ((:end-with-double-support ewds) t)	, ,
:finalize-gait-parameter	[method]
:make-gait-parameter	[method]
:calc-hoffarbib-pos-vel-acc tmp-remain-time tmp-goal old-acc old-vel old-pos	[method]
:calc-current-swing-leg-coords ratio src dst &key (type :shuffling) (step-height default-step-height)	[method]
: calc-ratio-from-double-support-ratio	[method]
:calc-current-refzmp prev cur next	[method]
$: {\bf calc-one-tick-gait-parameter}\ type$	[method]
$\textbf{:proc-one-tick} \ \& key \ (type \ : shuffling) \ (solve-angle-vector \ : solve-av-by-move-centroid-on-foot) \ (solve-angle-vector-angle)$	$rgs) (debug \\ [method]$
:update-current-gait-parameter	[method]
$\textbf{:} \textbf{solve-angle-vector} \ support-leg \ support-leg-coords \ swing-leg-coords \ cog \ \&key \ (solve-angle-vector \ :solve-av-by-movon-foot) \ (solve-angle-vector-args)$	ve-centroid- [method]
:solve-av-by-move-centroid-on-foot support-leg support-leg-coords swing-leg-coords cog robot &rest args &key (co (stop 100) (additional-nspace-list) &allow-other-keys	og-gain 3.5) [method]
:cycloid-midpoint ratio start goal height &key (top-ratio 0.5)	[method]
:cycloid-midcoords ratio start goal height &key (top-ratio 0.5) (rot-ratio ratio)	[method]
:cycloid-midcoords ratio start goal height &key (top-ratio 0.5) (rot-ratio ratio)	[method]
:cycloid-midpoint ratio start goal height &key (top-ratio 0.5)	[method]
eycloid-inidpoint raiso start you neight they (top-raiso 0.0)	[method]
:solve-av-by-move-centroid-on-foot support-leg support-leg-coords swing-leg-coords cog robot &rest args &key (co (stop 100) (additional-nspace-list) &allow-other-keys	g- $gain 3.5)$ [method]
	ve-centroid- [method]
:update-current-gait-parameter	[method]
$\textbf{:proc-one-tick} \ \textit{\&key} \ (type \ : shuffling) \ (solve-angle-vector \ : solve-av-by-move-centroid-on-foot) \ (solve-angle-vector-angle)$	rgs) (debug [method]
$: {\bf calc\text{-}one\text{-}tick\text{-}gait\text{-}parameter}\ type$	[method]
:calc-current-refzmp prev cur next	[method]
: calc-ratio-from-double-support-ratio	[method]

```
:calc-current-swing-leg-coords ratio src dst &key (type :shuffling) (step-height default-step-height)
                                                                                                                                                                                                                                                                                                                                                                                 [method]
:calc-hoffarbib-pos-vel-acc tmp-remain-time tmp-qoal old-acc old-vel old-pos
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:make-gait-parameter
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:finalize-gait-parameter
                                                                                                                                                                                                                                                                                                                                                                                  [method]
\textbf{:initialize-gait-parameter} \ \textit{fsl time cog } \& \textit{key ((:default-step-height \ dsh) \ 50) ((:default-double-support-ratio \ ddsr) \ 0.2) \ (\textit{delay } b) \\ \textbf{(delay } b) \\ \textbf{(default-double-support-ratio \ ddsr) \ 0.2) \ (\textit{delay } b) \\ \textbf{(delay } b)
1.6) ((:all-limbs al) '(:rleg:lleg)) ((:default-zmp-offsets dzo) (mapcan #'(lambda (x) (list x (float-vector 0 0 0))) al)) (q 1.0)
(r\ 1.000000e-06)\ (thre\ 1)\ (rthre\ (deg2rad\ 1))\ (start-with-double-support\ t)\ ((:end-with-double-support\ ewds)\ t)
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:get-swing-limbs limbs
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:get-limbs-zmp limb-coords limb-names
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:get-limbs-zmp-list limb-coords limb-names
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:get-counter-footstep-limbs fs
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:get-footstep-limbs fs
                                                                                                                                                                                                                                                                                                                                                                                  [method]
:init rb _dt
                                                                                                                                                                                                                                                                                                                                                                                  [method]
{\bf calc\text{-}inertia\text{-}matrix\text{-}rotational}\ mat\ row\ column\ paxis\ m\text{-}til\ c\text{-}til\ axis\text{-}for\text{-}angular\ child\text{-}link\ world\text{-}default\text{-}coords\ translation\text{-}}
axis rotation-axis tmp-v0 tmp-v1 tmp-v2 tmp-va tmp-vb tmp-vc tmp-vd tmp-m
                                                                                                                                                                                                                                                                                                                                                                                [function]
calc-inertia-matrix-linear mat row column paxis m-til c-til i-til axis-for-angular child-link world-default-coords translation-
axis\ rotation-axis\ tmp-v0\ tmp-v1\ tmp-v2\ tmp-va\ tmp-vb\ tmp-vc\ tmp-vd\ tmp-m
                                                                                                                                                                                                                                                                                                                                                                                [function]
```

## 19 Robot Viewer

```
Create a default Irtviewer(Fig.26).

(make-irtviewer)

Create an irtviewer to draw a grid in the xy plane(Fig.27).

(make-irtviewer)
(send *irtviewer* :draw-floor 100)
(send *irtviewer* :draw-objects)


Create an irtviewer with a white background and a black grid in the xy plane(Fig.28).

(make-irtviewer)
(send *irtviewer* :change-background (float-vector 1 1 1))
(send *irtviewer* :draw-floor 100)
(send *irtviewer* :floor-color #f(0 0 0))
(send *irtviewer* :draw-objects)
```


viewer

:super propertied-object

:slots geometry::eye geometry::port geometry::surface



☑ 26: Default irtviewer



☑ 27: Irtviewer with floor grid

:draw-objects &rest args [method]
:draw-circle x::c &key (x::radius 50) (x:flush nil) (x::arrow nil) (x::arrow-scale #f(1.0 1.0)) [method]

x::irtviewer [Class]

 $: super \qquad \textbf{x:panel}$ 

:slots x::viewer x::objects x::draw-things x::previous-cursor-pos x::left-right-angle x::up-down




図 28: Irtviewer with white background and floor grid

```
:draw-origin &optional (x::tmp-draw-origin :null)
                                                                                                   [method]
     get/set draw-origin
:draw-floor &optional (x::tmp-draw-floor :null)
                                                                                                   [method]
     get/set draw-floor
:floor-color &optional (x::tmp-floor-color :null)
                                                                                                   [method]
     get/set floor-color
:logging &optional (x::flag :on)
                                                                                                   [method]
     start/stop logging
     :clear Clear log
     :start Start logging
     :restart Stop and restart logging
     :stop Stop logging
:save-mpeg
                                                                                                   [method]
                &key (fname anim.mpg)
                (x::delay 5)
                (delete t)
     ':save-mpeg' saves logged images as mpeg.
```

:save-animgif [method]

:save-anmigif' did not stop nor clear the image sequence, so you have to run them manualy

To start image log, run ':logging :start' and to stop log, run ':logging :stop'. Note that ':logging :stop' did not clear the logged sequence, so you need to run

':logging :clear'.

```
&key (fname anim.gif)
(x::delay 5)
(x::transparent t)
(loop t)
(delete t)
```

':save-anmigif' saves logged images as animation gif.

To start image log, run ':logging :start' and to stop log, run ':logging :stop'.

Note that ':logging :stop' did not clear the logged sequence, so you need to run

':logging :clear'.

:save-anmigif' did not stop nor clear the image sequence, so you have to run them manualy

#### :save-image x::filename

[method]

save curent view to image, supported formats are jpg/png/pnm

:create & rest args & key (x::title IRT viewer) (x::view-name (gensym title)) (x::hither 200.0) (x::yon 50000.0) (x::width 500) (x::height 500) ((:draw-origin do) 150) ((:draw-floor x::df) nil) ((:floor-color x::fc) #f(1.0 1.0 1.0)) (x::call-super t) & allow other-keys [method]

:viewer &rest args [method] :redraw [method] [method] :expose x:event  $: {\bf resize} \ x :: new width \ x :: new height$ [method]  $: {\bf configure notify}\ x: event$ [method] :viewtarget &optional x::p [method]  $\textbf{:viewpoint} \ \mathscr{C}optional \ x{::}p \\$ [method] :look1 &optional (x::vt x::viewtarget) (x::lra x::left-right-angle) (x::uda x::up-down-angle) [method] :look-all  $\&optional \ x :: bbox$ [method] :move-viewing-around-viewtarget  $x:event \ x::x \ x::y \ x::dx \ x::dy \ x::vwr$ [method] :set-cursor-pos-event x:event[method] [method] :move-coords-event x:event :draw-event x:event[method]  $\textbf{:draw-objects} \ \mathscr{C}rest \ args$ [method] [method] :objects &rest args :select-drawmode x::mode[method] :flush [method]

:change-background x::col	[method]
:clear-log	[method]
:push-image	[method]
:clear-image-sequence	[method]
:image-sequence :floor-color &optional (x::tmp-floor-color :null) get/set floor-color	$[method] \\ [method]$
:draw-floor & optional (x::tmp-draw-floor :null) get/set draw-floor	[method]
:draw-origin &optional (x::tmp-draw-origin :null) get/set draw-origin	$[\mathrm{method}]$
$: {\bf change-background} \ x :: col$	[method]
:flush	[method]
:select-drawmode x::mode	[method]
:objects &rest args	[method]
:draw-objects &rest args	[method]
:draw-event x:event	[method]
:move-coords-event x:event	[method]
:set-cursor-pos-event x:event	[method]
:move-viewing-around-viewtarget $x:event \ x::x \ x::y \ x::dx \ x::dy \ x::vwr$	[method]
:look-all &optional x::bbox	[method]
$: \textbf{look1} \ \ \textit{Coptional} \ (x::vt \ x::viewtarget) \ (x::lra \ x::left-right-angle) \ (x::uda \ x::up-down-angle)$	[method]
:viewpoint &optional x::p	[method]
:viewtarget &optional x::p	[method]
:configurenotify x:event	[method]
:resize x::newwidth x::newheight	[method]
:expose x:event	[method]
:redraw	[method]

:viewer &rest args [method]

:create & rest args & key (x::title IRT viewer) (x::view-name (gensym title)) (x::hither 200.0) (x::yon 50000.0) (x::width 500) (x::height 500) ((:draw-origin do) 150) ((:draw-floor x::df) nil) ((:floor-color x::fc)  $\#f(1.0\ 1.0\ 1.0)$ ) (x::call-super t) & allow-other-keys [method]

```
:save-image x::filename
```

[method]

save curent view to image, supported formats are jpg/png/pnm

:save-animgif [method]

```
&key (fname anim.gif)
(x::delay 5)
(x::transparent t)
(loop t)
(delete t)
```

':save-anmigif' saves logged images as animation gif.

To start image log, run ':logging :start' and to stop log, run ':logging :stop'.

Note that ':logging :stop' did not clear the logged sequence, so you need to run

':logging :clear'.

:save-anmigif' did not stop nor clear the image sequence, so you have to run them manualy

:save-animgif [method]

```
&key (fname anim.gif)
(x::delay 5)
(x::transparent t)
(loop t)
(delete t)
```

':save-anmigif' saves logged images as animation gif.

To start image log, run ':logging :start' and to stop log, run ':logging :stop'.

Note that ':logging :stop' did not clear the logged sequence, so you need to run

':logging :clear'.

:save-anmigif' did not stop nor clear the image sequence, so you have to run them manually

:save-mpeg [method]

```
&key (fname anim.mpg)
(x::delay 5)
(delete t)
```

':save-mpeg' saves logged images as mpeg.

To start image log, run ':logging :start' and to stop log, run ':logging :stop'.

Note that ':logging :stop' did not clear the logged sequence, so you need to run

':logging :clear'.

:save-anmigif' did not stop nor clear the image sequence, so you have to run them manually

:logging &optional (x::flag :on)

[method]

```
start/stop logging
:clear Clear log
:start Start logging
:restart Stop and restart logging
:stop Stop logging
```

:resize newwidth newheight

[method]

:image-sequence [method] :clear-image-sequence [method] :push-image [method] :clear-log [method] viewing [Class] cascaded-coords :super :slots rot pos parent descendants worldcoords manager changed geometry::viewcoords :look geometry::from &optional (geometry::to (float-vector 0 0 0)) (geometry::view-up (float-vector 0 0 1)) [method] viewer-dummy [Class] :super propertied-object :slots nil :nomethod &rest args [method]  $: \mathbf{nomethod} \ \mathscr{C}\mathit{rest} \ \mathit{args}$ [method] irtviewer-dummy [Class] :super propertied-object objects draw-things :slots :objects &rest args [method] :nomethod &rest args [method] :nomethod &rest args [method] :objects &rest args [method] irtviewer-no-window [Class] :super propertied-object :slots irtviewer [method] :create &rest args [method]  $: {\bf resize} \ new width \ new height$ [method]  $: \mathbf{nomethod} \ \mathscr{C}rest \ args$ [method] :nomethod &rest args [method]

```
:create &rest args
                                                                                                             [method]
:init &rest args
                                                                                                             [method]
make-irtviewer &rest args
                                                                                                           [function]
      Create irtviewer
      :view-name title
      :hither near cropping plane
      :yon far cropping plane
      :width width of the window
      :height height of the window
      :draw-origin size of origin arrow, use nil to disable it
      :draw-floor use t to view floor
      :floor-color floor color. default is \#f(1\ 1\ 1), i.e. white.
x::make-lr-ud-coords x::lra x::uda
                                                                                                             [function]
x::make-mpeg-from-images x::mpgfile x::images &key (delete t) (x::delay 1)
                                                                                                             [function]
x::make-animgif-from-images x::giffile x::images &key (delete t) x::transparent (loop t) (x::delay 10) (x::background 000000)
[function]
x::draw-things x::objs
                                                                                                             [function]
objects &optional (objs t) vw
                                                                                                             [function]
make-irtviewer-dummy &rest args
                                                                                                             [function]
                                                                                                             [function]
geometry::default-pixmapsurface & rest args
make-irtviewer-no-window &rest args
                                                                                                             [function]
```

#### 20 Interference Calculation

### 20.1 Interference Calculation Overview

Interference calculation is the process of judging whether two sets of geometric models intersect and finding the distance between them. It mainly provides the following two functions:

- Collision detection to determine if two models intersect (collision-check function)
- A distance calculator that calculates the shortest distance between two models (collision-distance function)

In irreus, interference calculations are performed by calling external libraries through other language interfaces. As an external library, calls to PQP and Bullet are implemented, and PQP is used by default. The library to be used can be switched by the select-collision-algorithm function as follows:

```
(select-collision-algorithm *collision-algorithm-pqp*) ;; use PQP
(select-collision-algorithm *collision-algorithm-bullet*) ;; use Bullet
```

The features of each external library are described in detail below. See http://gamma.cs.unc.edu/research/collision/for other interference calculation software packages. (Note that the information may be outdated. For example, Bullet is not listed.)

cascaded-coords [Class]

:super coordinates

:slots rot pos parent descendants worldcoords manager changed

```
:make-collisionmodel &rest args &key &allow-other-keys
```

[method]

Make collision model and save pointer.

collision-distance model1 model2 Grest args &key &allow-other-keys

[function]

Calculate collision distance between model1 and model2.

Return value is (list [distance] [nearest point on model1] [nearest point on model2]).

## ${\bf collision\text{-}check}\ model1\ model2\ {\it \&rest\ args}$

[function]

Check collision between model1 and model2.

If return value is 0, no collision.

Otherwise (return value is 1), collision.

#### collision-check-objects obj1 obj2 &rest args &key &allow-other-keys

[function]

Check collision between obj1 and obj2.

obj1 and obj2 should be list of models.

If return value is nil, no collision.

Otherwise (return value is t), collision.

#### select-collision-algorithm alg

[function]


Select collision algorithm.

:pqp and :bullet are supported.

### 20.1.1 Interference Calculation Example Between Object Shape Models

Below is an example of using collision-check and collision-distance to detect the collision between two cubes, calculate the distance, and draw a line connecting the nearest points. The specifications of the closest point obtained by the collision-distance function when interference occurs are different between PQP and Bullet. For details, see the description of Bullet below:

```
;; Make models
(setq *b0* (make-cube 100 100 100))
(setq *b1* (make-cube 100 100 100))
;; Case 1 : no collision
(send *b0* :newcoords (make-coords :pos #f(100 100 -100)
                                     :rpy (list (deg2rad 10) (deg2rad -20) (deg2rad 30))))
(objects (list *b0* *b1*))
(print (collision-check *b0* *b1*)) ;; Check collision
(let ((ret (collision-distance *b0* *b1*))) ;; Check distance and nearest points
  (print (car ret)) ;; distance
  (send (cadr ret) :draw-on :flush nil :size 20 :color #f(1 0 0)) ;; nearest point on *b0* (send (caddr ret) :draw-on :flush nil :size 20 :color #f(1 0 0)) ;; nearest point on *b1*
  (send *irtviewer* :viewer :draw-line (cadr ret) (caddr ret))
  (send *irtviewer* :viewer :viewsurface :flush))
;; Case 2 : collision
(send *b0* :newcoords (make-coords :pos #f(50 50 -50)
                                     :rpy (list (deg2rad 10) (deg2rad -20) (deg2rad 30))))
(objects (list *b0* *b1*))
(print (collision-check *b0* *b1*)) ;; Check collision
(let ((ret (collision-distance *b0* *b1*)));; Check distance and nearest points
  (print (car ret)) ;; distance
  ;; In case of collision, nearest points are insignificant values.
  (send (cadr ret) :draw-on :flush nil :size 20 :color #f(1 0 0)) ;; nearest point on *b0*
  (send (caddr ret) :draw-on :flush nil :size 20 :color #f(1 0 0));; nearest point on *b1*
  (send *irtviewer* :viewer :draw-line (cadr ret) (caddr ret))
  (send *irtviewer* :viewer :viewsurface :flush))
```



**図** 29: Collision detection

#### 20.1.2 Robot Motion and Interference Calculation

When performing a static simulation of the action of grabbing an object with the hand, it is possible to investigate the interference between the links of the hand (fingers) and the target object, and stop the action of grabbing the object when this occurs.

```
(load "irteus/demo/sample-arm-model.1")
(setq *sarm* (instance sarmclass :init))
(send *sarm* :reset-pose)
(setq a 42)
(send *sarm* :move-fingers a)
(setq *target* (make-cube 30 30 30))
(send *target* :translate #f(350 200 400))
(objects (list *sarm* *target*))
(send *sarm* :inverse-kinematics *target* :move-target (send *sarm* :end-coords) :debug-view t)
(while (> a 0)
 (if (collision-check-objects
       (list (send *sarm* :joint-fr :child-link)
             (send *sarm* :joint-fl :child-link))
       (list *target*))
      (return))
  (decf a 0.1)
  (send *irtviewer* :draw-objects)
 (send *sarm* :move-fingers a))
(send *sarm* :end-coords :assoc *target*)
(dotimes (i 100)
  (send *sarm* :joint0 :joint-angle 1 :relative t)
  (send *irtviewer* :draw-objects))
(send *sarm* :end-coords :dissoc *target*)
(dotimes (i 100)
  (send *sarm* :joint0 :joint-angle -1 :relative t)
  (send *irtviewer* :draw-objects))
```

Similar functionality is provided by the methods :open-hand and :close-hand in the "irreus/demo/sample-arm-model.1" file.

## 20.2 Interference Calculation by PQP

PQP is an interference calculation library developed by Lin et al.'s group at the University of North Carolina. The usage of the PQP software package is described in irteus/PQP/README.txt, and can be understood by reading irteus/PQP/src/PQP.h.

The files for using PQP with irreus consist of CPQP.C, euspqp.c, and pqp.l. To determine if two geometric models will collide,

should be called. r1,r1,r2,t1 are the translation vector and rotation matrix of each object, and (get model1 :pqpmodel) refers to the pointer to the PQP geometric model. This pointer is computed in the :make-pqpmodel method as follows.

```
(defmethod cascaded-coords
  (:make-pqpmodel
   (&key (fat 0))
   (let ((m (pqpmakemodel))
         vs v1 v2 v3 (id 0))
     (setf (get self :pqpmodel) m)
     (pqpbeginmodel m)
     (dolist (f (send self :faces))
       (dolist (poly (face-to-triangle-aux f))
         (setq vs (send poly :vertices)
    v1 (send self :inverse-transform-vector (first vs))
                v2 (send self :inverse-transform-vector (second vs))
                v3 (send self :inverse-transform-vector (third vs)))
         (when (not (= fat 0))
            (setq v1 (v+ v1 (scale fat (normalize-vector v1)))
                  v2 (v+ v2 (scale fat (normalize-vector v2)))
                  v3 (v+ v3 (scale fat (normalize-vector v3)))))
          (pqpaddtri m v1 v2 v3 id)
          (incf id)))
     (pqpendmodel m)
  Here, (pqpmakemodel) is called first. In pqpmakemodel, defined in euqpqp.c,
pointer PQPMAKEMODEL(register context *ctx, int n, register pointer *argv)
    int addr = PQP_MakeModel();
    return makeint(addr);
  is invoked, which is the same as in CPQP.C
PQP\_Model *PQP_MakeModel()
    return new PQP_Model();
```

PQP\_Model() is defined in PQP.h. After the functions in euslisp are passed to the actual PQP library functions in this way, an instance of the PQP geometric model is created with (pqpbeginmodel m) and the surface information is registered as (pqpaddtri m v1 v2 v3 id) to register the surface information.

cascaded-coords [Class]

:super coordinates

:slots rot pos parent descendants worldcoords manager changed

:make-pqpmodel &key (geometry::fat 0) ((:faces geometry::fs) (send self :faces))

[method]

pqp-collision-check

[function]

geometry::model1 geometry::model2 &optional (geometry::flag geometry::pqp\_first\_contact) & (geometry::fat2 nil)

Check collision between model1 and model2 using PQP.

If return value is 0, no collision.

Otherwise (return value is 1), collision.

#### pqp-collision-distance

[function]

geometry::model1 geometry::model2 &key (geometry::fat 0)
(geometry::fat2 nil)
(geometry::qsize 2)

Calculate collision distance between model1 and model2 using PQP.

Return value is (list [distance] [nearest point on model1] [nearest point on model2]).

If collision occurs, [distance] is 0 and nearest points are insignificant values.

 $\textbf{pqp-collision-check-objects} \ \textit{geometry::obj1} \ \textit{geometry::obj2} \ \textit{\&key} \ (\textit{geometry::fat} \ \textit{0.2})$ 

[function]

return nil or t

## 20.3 Interference Calculation with Bullet

Bullet is a physics engine, and as part of it, an interference calculation function is provided. The files for using Bullet with irreus consist of CBULLET.cpp, eusbullet.c, and bullet.l. The calling order inside the function is the same as PQP.

The differences between PQP and Bullet are as follows.

- If you call collision-distance when there is interference, PQP will return 0 as the distance and a meaningless point as the closest point. Bullet, on the other hand, returns the shortest distance (called penetration depth) that should be moved to eliminate interference as the distance. Also, as the closest point, the points at both ends of the shortest distance to eliminate interference are returned.
- PQP can handle non-convex mesh models as is, but Bullet internally computes and handles the convex hull of non-convex models.

## cascaded-coords

[Class]

:super coordinates

:slots rot pos parent descendants worldcoords manager changed

:make-btmodel

[method]

&key (geometry::fat 0) ((:faces geometry::fs))

Make bullet model and save pointer of the bullet model.

#### geometry::bt-make-model-from-body

[function]

geometry::b &key (csg (send geometry::b :csg)) (geometry::margin 0)

Make bullet model from body.

#### bt-collision-distance

[function]

geometry::model1 geometry::model2 &key (geometry::fat 0) (geometry::fat2 nil) (geometry::qsize)

Calculate collision distance between model1 and model2 using Bullet.

Return value is (list [distance] [nearest point on model1] [nearest point on model2]). qsize argument is not used, just for compatibility with pqp-collision-distance.

bt-collision-check

[function]

[method]

[Class]

geometry::model1 geometry::model2 &key (geometry::fat 0) (geometry::fat2 nil)

Check collision between model1 and model2 using Bullet.

If return value is 0, no collision.

Otherwise (return value is 1), collision.

## 21 BVH Data

bvh-link [Class]

 $: super \qquad \textbf{bodyset-link}$ 

:slots type offset channels neutral

:init name typ offst chs parent children

create link for bvh model

:type [method]

 $: offset \\ [method]$ 

:channels [method]

:init name typ offst chs parent children [method]

create link for byh model

:channels [method]

:offset [method]

:type [method]

bvh-sphere-joint

:super sphere-joint

:slots axis-order byh-offset-rotation

```
:init
                                                                                                                                                                                                                                                                                                                                                                                          [method]
                                &rest args &key (order (list :z :x :y))
                               ((:bvh-offset-rotation bvh-rotation) (unit-matrix 3))
                               &allow-other-keys
                      create joint for byh model
:joint-angle-bvh \operatorname{\mathscr{C}\!\mathit{optional}} v
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-byh-offset \mathscr{C}optional\ v
                                                                                                                                                                                                                                                                                                                                                                                              [method]
:joint-angle-bvh-impl v bvh-offset
                                                                                                                                                                                                                                                                                                                                                                                              [method]
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:axis-order
:bvh-offset-rotation
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:init
                                                                                                                                                                                                                                                                                                                                                                                          [method]
                                &rest args &key (order (list :z :x :y))
                               ((:bvh-offset-rotation bvh-rotation) (unit-matrix 3))
                               &allow-other-keys
                      create joint for byh model
:bvh-offset-rotation
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:axis-order
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-bvh-implv\ bvh\text{-}of\!f\!set
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-byh-offset \ensuremath{\mathscr{C}optional}\ v
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-bvh &optional v
                                                                                                                                                                                                                                                                                                                                                                                              [method]
bvh-6dof-joint
                                                                                                                                                                                                                                                                                                                                                                                                  [Class]
                                                                              :super
                                                                                                                       6dof-joint
                                                                              :slots
                                                                                                                       scale axis-order byh-offset-rotation
 \textbf{:init} \ \textit{\&rest} \ \textit{args} \ \textit{\&key} \ (\textit{order} \ (\textit{list} \ :x \ :y \ :z \ :z \ :x \ :y)) \ ((:\textit{scale} \ \textit{scl})) \ ((:\textit{bvh-offset-rotation} \ \textit{bvh-rotation}) \ (\textit{unit-matrix} \ 3)) \ \textit{\&allow-rotation} \ (\textit{unit-matrix} \ 3) \ \textit{\&allow-rotation} \ (\textit{unit-matrix} \ 3)) \ \textit{\&allow-rotation} \ (\textit{unit-matrix} \ 3) \ \textit{\&allow-rotation} \
other\hbox{-}keys
                                                                                                                                                                                                                                                                                                                                                                                               [method]
:joint-angle-bvh \operatorname{\mathscr{C}optional} v
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-byh-offset \mathscr{C}optional\ v
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:joint-angle-bvh-implv\ bvh\text{-}of\!f\!set
                                                                                                                                                                                                                                                                                                                                                                                             [method]
:axis-order
                                                                                                                                                                                                                                                                                                                                                                                              [method]
```

```
: bvh\text{-}offset\text{-}rotation
                                                                                                                                [method]
:bvh-offset-rotation
                                                                                                                                [method]
:axis-order
                                                                                                                                [method]
:joint-angle-bvh-implv bvh-offset
                                                                                                                                [method]
:joint-angle-byh-offset \ensuremath{\mathscr{C}optional}\ v
                                                                                                                                [method]
:joint-angle-bvh &optional v
                                                                                                                                [method]
:init &rest args &key (order (list :x :y :z :z :x :y)) ((:scale scl)) ((:buh-offset-rotation buh-rotation) (unit-matrix 3)) &allow-
other-keys
                                                                                                                                [method]
bvh-robot-model
                                                                                                                                  [Class]
                          :super
                                       robot-model
                          :slots
                                       nil
:init
                                                                                                                              [method]
          Erest args Ekey tree
          coords
          ((:scale scl))
       create robot model for byh model
\textbf{:make-bvh-link} \ tree \ \mathscr{C}key \ parent \ ((:scale \ scl))
                                                                                                                                [method]
:angle-vector & optional vec (angle-vector (instantiate float-vector (calc-target-joint-dimension joint-list)))
                                                                                                                                [method]
\textbf{:dump-joints} \ \textit{links} \ \textit{\&key} \ (\textit{depth} \ \textit{0}) \ (\textit{strm} * \textit{standard-output*})
                                                                                                                                [method]
:dump-hierarchy &optional (strm *standard-output*)
                                                                                                                                [method]
\textbf{:dump-motion} \ \mathscr{C}optional \ (strm \ *standard-output*)
                                                                                                                                [method]
: {\bf copy\text{-}state\text{-}to}\ robot
                                                                                                                                [method]
:fix-joint-angle i limb joint-name joint-order a
                                                                                                                                [method]
:fix-joint-order jo limb
                                                                                                                                [method]
:bvh-offset-rotate name
                                                                                                                                [method]
:init-end-coords
                                                                                                                                [method]
:init-root-link
                                                                                                                                [method]
                                                                                                                              [method]
:init
          &rest args &key tree
          coords
          ((:scale scl))
```

create robot model for byh model

:bvh-offset-rotate name		
:fix-joint-order jo limb		
:fix-joint-angle i limb joint-name joint-order a		
:copy-state-to robot		
:dump-motion & optional (strm *standard-output*)		
:dump-hierarchy & optional (strm *standard-output*)		
:dump-joints links &key (depth 0) (strm *standard-output*)		
$\textbf{:angle-vector} \ \mathscr{C}optional \ vec \ (angle-vector \ (instantiate \ float-vector \ (calc-target-joint-dimension \ joint-list \ properties)) and the properties of the pro$	t))) [method]	
:make-bvh-link tree &key parent ((:scale scl))	[method]	
motion-capture-data	[Class]	
:super propertied-object		
slots frame model animation		
:init fname &key (coords (make-coords)) ((:scale scl))	[method]	
:model &rest args	[method]	
:animation & rest args	[method]	
:frame $\operatorname{\mathscr{C}optional} f$	[method]	
:frame-length	[method]	
:animate & erest args & key (start 0) (step 1) (end (send self:frame-length)) (interval 20) & allow-other-keys :animate & erest args & key (start 0) (step 1) (end (send self:frame-length)) (interval 20) & allow-other-keys		
:frame-length		
:frame $\operatorname{\mathscr{C}\!\mathit{optional}} f$	$[\mathrm{method}]$	
:animation & rest args	$[\mathrm{method}]$	
:model &rest args	[method]	
:init fname &key (coords (make-coords)) ((:scale scl)) :init-root-link		
:init-end-coords	$[\mathrm{method}]$	
rikiya-bvh-robot-model		

# $: \! \mathbf{super} \qquad \mathbf{bvh\text{-}robot\text{-}model}$

:slots nil

:init &rest args	[method]
:larm-collar &rest args	[method]
:larm-shoulder &rest args	[method]
:larm-elbow &rest args	[method]
:larm-wrist &rest args	[method]
:rarm-collar &rest args	[method]
:rarm-shoulder &rest args	[method]
:rarm-elbow &rest args	[method]
:rarm-wrist &rest args	[method]
:lleg-crotch & rest args	[method]
:lleg-knee &rest args	[method]
:lleg-ankle &rest args	[method]
:rleg-crotch &rest args	[method]
:rleg-knee &rest args	[method]
:rleg-ankle &rest args	[method]
:torso-chest &rest args	[method]
:head-neck & rest args	[method]
:copy-joint-to robot limb joint &optional (sign 1)	[method]
:copy-state-to robot	[method]
:copy-state-to robot	[method]
:copy-joint-to robot limb joint & optional (sign 1)	[method]
:head-neck & rest args	[method]
:torso-chest &rest args	[method]
:rleg-ankle &rest args	[method]

:rleg-knee &rest args	[method]
:rleg-crotch &rest args	[method]
:lleg-ankle &rest args	[method]
:lleg-knee &rest args	[method]
:lleg-crotch &rest args	[method]
:rarm-wrist &rest args	[method]
:rarm-elbow &rest args	[method]
:rarm-shoulder & rest args	[method]
:rarm-collar &rest args	[method]
:larm-wrist &rest args	[method]
:larm-elbow &rest args	[method]
:larm-shoulder &rest args	[method]
:larm-collar &rest args	[method]
:init &rest args	[method]
tum-bvh-robot-model	[Class]
:super bvh-robot-model	
:slots nil	
:init &rest args :init &rest args	[method]
cmu-bvh-robot-model	[Class]
:super <b>bvh-robot-model</b> :slots nil	
.Siots iiii	
:init &rest args :init &rest args	[method]
read-bvh fname &key scale read bvh file	[function]
bvh2eus  **fname & rest args & key ((:objects obj) nil)* & allow-other-keys	[function]

read byh file and anmiate robot model in the viewer

for Supported byh data, such as - CMU motion capture database (https://sites.google.com/a/cgspeed.com/cgspeed/motion-capture/cmu-bvh-conversion) - The TUM Kitchen Data Set (http://ias.cs.tum.edu/download/kitchen-activity-data) Use (tum-bvh2eus "Take 005.bvh");; tum (rikiya-bvh2eus "A01.bvh") ;; rikiya (cmu-bvh2eus "01\_01.bvh") ;; cmu Other Sites are: (http://www.mocapdata.com/page.cgi?p=free\_motions) (http://www.motekentertainment.com/) (http://www.mocapclub.com/Pages/Library.htm)(bvh2eus "poses.bvh") load-mcd [function] fname &key (scale) (coords) (bvh-robot-model-class bvh-robot-model) &allow-other-keys load motion capture data [function] rikiya-bvh2eus fname &rest args read rikiya bvh file and anmiate robot model in the viewer (rikiya-bvh2eus "A01.bvh") cmu-bvh2eus fname &rest args [function] read cmu byh file and anmiate robot model in the viewer CMU motion capture database (https://sites.google.com/a/cgspeed.com/cgspeed/motion-capture/cmu-bvh-conversion) (cmu-bvh2eus "01\_01.bvh" :scale 100.0)

#### tum-bvh2eus fname &rest args

[function]

read tum file and anmiate robot model in the viewer

The TUM Kitchen Data Set (http://ias.cs.tum.edu/download/kitchen-activity-data)

(tum-bvh2eus "Take 005.bvh" :scale 10.0)

parse-bvh-sexp src &key ((:scale scl)) [function]
make-bvh-robot-model bvh-data &rest args [function]
rikiya-file &key (num 1) (cls 'a) [function]
tum-kitchen-file &key (num 1) (cls 0) [function]
cmu-mocap-file &key (num 1) (cls 1) [function]

## 22 Collada Data

collada::eusmodel-description collada::model
convert a 'model' to eusmodel-description

collada::eusmodel-link-specs collada::links
convert 'links' to <link-specs>

collada::eusmodel-joint-specs collada::joints
convert 'joints' to <joint-specs>

collada::eusmodel-description->collada name collada::description &key (scale 0.001)
convert eusmodel-description to collada sxml

collada::matrix->collada-rotate-vector collada::mat

[function]

collada::matrix->collada-rotate-vector collada::mat [function convert a rotation matrix to axis-angle.

collada::symbol->string collada::sym [function] collada::->string collada::val [function] collada::string-append &rest args [function] collada::make-attr collada::l collada::ac[function]  ${f collada::make-xml}\ collada::x\ collada::bef\ collada::aft$ [function] collada::sxml->xml collada::sxml [function]  $collada::xml-output-to-string-stream\ collada::ss\ collada::l$ [function]  ${\bf collada::cat\text{-}normal}\ collada::l\ collada::s$ [function] collada::cat-clark collada::l collada::s collada::i [function] collada::verificate-unique-strings names [function]  ${\bf collada::eusmodel\text{-}link\text{-}spec}\ \mathit{collada::link}$ [function]  ${\bf collada::eusmodel\text{-}mesh\text{-}spec}\ \ collada::link\ \ collada::rt\text{-}cds$ [function]  ${\bf collada::eusmodel\text{-}joint\text{-}spec}\ \mathit{collada::}\text{-}\mathit{joint}$ [function] collada::eusmodel-limit-spec collada::\_joint [function]  ${\bf collada::eusmodel-endcoords-specs}\ collada::model$ [function]  ${\bf collada:: eusmodel\text{-}link\text{-}description}\ \ collada:: description$ [function]  ${\bf collada:: eus model-joint-description}\ \ collada:: description$ [function]

${\bf collada:: eus model-end coords-description} \ \ collada:: description$	[function]
${\bf collada::setup\text{-}collada-filesystem}\ \ collada::obj-name\ \ collada::base\text{-}dir$	[function]
collada::range2 collada::n	[function]
$\textbf{eus2collada} \ collada::obj \ collada::full-root-dir \ \&key \ (scale \ 0.001) \ (collada::file-suffix \ .dae)$	[function]
${\bf collada::collada-node-id} \ \ collada::link-descrption$	[function]
${\bf collada::collada-node-name}\ \ collada::link-descrption$	[function]
${\bf collada:: links-description-> collada-library-materials} \ \ collada:: links-desc$	[function]
${\bf collada:: link-description-> collada-materials} \ \ collada:: link-desc$	[function]
${\bf collada::mesh-description-}{\bf collada::mat}\ collada::mat\ collada::effect$	[function]
${\bf collada:: links-description-> collada-library-effects} \ \ collada:: links-desc$	[function]
${\bf collada::link-description->collada-effects} \ \ collada::link-desc$	[function]
collada::mesh-description->collada-effect collada::mesh id	[function]
collada::matrix->collada-string collada::mat	[function]
${\bf collada::} {\bf find-parent-liks-from-link-description} \ \ collada:: target-link \ \ \ collada:: target-link \ \ \ \ collada:: target-link \ \ \ \ collada:: target-link \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	[function]
collada::eusmodel-description->collada-node-transformations collada::target-link collada::desc	[function]
collada::eusmodel-description->collada-node collada::target-link collada::desc	[function]
collada::eusmodel-description->collada-library-visual-scenes name collada::desc	[function]
collada::mesh-description->instance-material collada::s	[function]
collada::link-description->collada-bind-material collada::link	[function]
collada::eusmodel-description->collada-library-kinematics-scenes name collada::desc	[function]
collada::eusmodel-description->collada-library-kinematics-models name collada::desc	[function]
collada::eusmodel-description->collada-kinematics-model name collada::desc	[function]
collada::eusmodel-description->collada-library-physics-scenes name collada::desc	[function]
collada::eusmodel-description->collada-library-physics-models name collada::desc	[function]
collada::find-root-link-from-joints-description collada::joints-description	[function]
collada::find-link-from-links-description name collada::links-description	[function]
collada::eusmodel-description->collada-links collada::description	[function]
collada::find-joint-from-link-description collada::target collada::joints	[function]
collada::find-child-link-descriptions collada::parent collada::finds collada::joints	[function]
collada::eusmodel-description->collada-library-articulated-systems collada::desc name	[function]
collada::eusmodel-endcoords-description->openrave-manipulator collada::end-coords collada::description	[function]
collada::eusmodel-description->collada-links-tree collada::target collada::links collada::joints	[function]
collada::joints-description->collada-instance-joints collada::joints-desc	[function]
collada::joint-description->collada-instance-joint collada::joint-desc collada::eusmodel-description->collada-library-joints collada::description	[function]
collada::joints-description->collada:-joints collada::joints-description	
collada::collada-joint-id collada::joint-description	[function]
• •	. ,
collada::joint-description->collada-joint collada::joint-description	[function]
collada::linear-joint-description->collada-joint collada::joint-description	[function]
collada::rotational-joint-description->collada-joint collada::joint-description	[function]
collada::eusmodel-description->collada:scene collada::description	[function]
collada::eusmodel-description->collada-library-geometries collada::description	[function]
collada::collada-geometry-id-base collada::link-descrption	[function]
collada::collada-geometry-name-base collada::link-descrption	[function]
collada::links-description->collada-geometries collada::links-description	[function]
collada::mesh-object->collada-mesh collada::mesh id	[function]
collada::link-description->collada-geometry collada::link-description	[function]
collada::mesh->collada-indices collada::mesh	[function]
collada::mesh-vertices->collada-string collada::mesh	[function]
collada::mesh-normals->collada-string collada::mesh	[function]
${\tt collada::float-vector->collada::} v$	[function]
collada::enum-integer-list collada::n	[function]

:centroid

retrun centroid of this point cloud

[method]

 collada::search-minimum-rotation-matrix
 collada::mat
 [function]

 collada::estimate-class-name
 collada::model-file
 [function]

 collada::remove-directory-name
 fname
 [function]

## 23 Point Cloud Data

pointcloud [Class] cascaded-coords :super parray carray narray curvature poolor psize awidth asize box height width view-coord :slots :init [method] &rest args &key ((:points mat)) ((:colors cary)) ((:normals nary)) ((:curvatures curv)) ((:height ht)) ((:width wd)) (point-color (float-vector 0 1 0)) (point-size 2.0) (fill) (arrow-width 2.0)(arrow-size 0.0) Create point cloud object :size-change &optional wd ht [method] change width and height, this method does not change points data :points &optional pts wd ht [method] replace points, pts should be list of points or ntimes matrix :colors &optional cls [method] replace colors, cls should be list of points or ntimes matrix :normals &optional nmls [method] replace normals by, nmls should be list of points or ntimes3 matrix :point-list &optional (remove-nan) [method] return list of points :color-list [method] return list of colors :normal-list [method] return list of normals

```
:append point-list &key (create t)
```

[method]

append point cloud list to this point cloud.

if :create is true, return appended point cloud and original point cloud does not change.

:filter [method]

&rest args &key create &allow-other-keys

this method can take the same keywords with :filter-with-indices method.

if :create is true, return filtered point cloud and original point cloud does not change.

:filter-with-indices [method]

idx-lst &key (create) (negative)

filter point cloud with list of index (points which are indicated by indices will remain).

if :create is true, return filtered point cloud and original point cloud does not change.

if :negative is true, points which are indicated by indices will be removed.

:filtered-indices [method]

&key key

ckey

nkey

pckey

pnkey

pcnkey

negative

&allow-other-keys

create list of index where filter function retrun true.

key, ckey, nkey are filter function for points, colors, normals. They are expected to take one argument and return t or nil.

pckey, pnkey are filter function for points and colors, points and normals. They are expected to take two arguments and return t or nil.

penkey is filter function for points, colors and normals. It is expected to take three arguments and return t or nil.

:step [method]

step &key (fixsize)

(create)

downsample points with step

:copy-from pc [method]

update object by pc

# $\textbf{:transform-points} \ \textit{coords} \ \textit{\&key} \ (\textit{create})$

[method]

transform points and normals with coords.

if :create is true, return transformed point cloud and original point cloud does not change.

# :convert-to-world &key (create)

[method]

transform points and normals with self coords. converted points data should be at the same position as displayed

# :move-origin-to neworigin &key (create)

[method]

origin of point cloud is moved to neworigin. moved points data should be at the same position as displayed

:reset-box [method]

:box [method]

:vertices [method]

 $[method] \label{eq:method}$ 

 $: width \\ [method]$ 

 $: \mathbf{height} \\ [method]$ 

:curvatures & optional curv [method]

:curvature-list [method]

:set-color col & optional (\_transparent) [method]

:point-color & optional pc [method]

 $: \textbf{point-size} \ \mathscr{C}optional \ ps \\ [method]$ 

:axis-length &optional al [method]

:axis-width &optional aw [method]

:clear-color [method]

:clear-normal [method]

:nfilter &rest args [method]

:viewangle-inlier &key (min-z 0.0) (hangle 44.0) (vangle 35.0) [method]

 $\textbf{:image-position-inlier} \ \&key \ (ipkey) \ (height \ 144) \ (width \ 176) \ (cy \ (/ \ (float \ (- \ height \ 1)) \ 2)) \ (cx \ (/ \ (float \ (- \ width \ 1)) \ 2)) \ (co) \ (/ \ (- \ width \ 1)) \ (/ \ (- \ width \$ 

```
[method]
negative
:image-circle-filter dist &key (height 144) (width 176) (cy (/ (float (- height 1)) 2)) (cx (/ (float (- width 1)) 2)) create
negative
                                                                                                        [method]
:step-inlier step offx offy
:generate-color-histogram-hs &key (h-step 9) (s-step 7) (hlimits (cons 360.0 0.0)) (vlimits (cons 1.0 0.15)) (slimits (cons
1.0 0.25)) (rotate-hue) (color-scale 255.0) (sizelimits 1)
:set-offset cds &key (create)
                                                                                                        [method]
:drawnormalmode \ @optional \ mode
                                                                                                        [method]
:transparent &optional trs
                                                                                                        [method]
                                                                                                        [method]
:draw vwer
:move-origin-to neworigin &key (create)
                                                                                                       [method]
     origin of point cloud is moved to neworigin. moved points data should be at the same position as
     displayed
:convert-to-world &key (create)
                                                                                                       [method]
     transform points and normals with self coords. converted points data should be at the same position
     as displayed
:transform-points coords &key (create)
                                                                                                       [method]
      transform points and normals with coords.
     if :create is true, return transformed point cloud and original point cloud does not change.
:copy-from pc
                                                                                                       [method]
     update object by pc
                                                                                                       [method]
:step
         step &key (fixsize)
         (create)
     downsample points with step
:filtered-indices
                                                                                                       [method]
                      &key key
                      ckey
                      nkey
                      pckey
                      pnkey
                      pcnkey
                      negative
                      &allow-other-keys
     create list of index where filter function retrun true.
```

key, ckey, nkey are filter function for points, colors, normals. They are expected to take one argument

and return t or nil.

pckey, pnkey are filter function for points and colors, points and normals. They are expected to take two arguments and return t or nil.

penkey is filter function for points, colors and normals. It is expected to take three arguments and return t or nil.

:filter-with-indices [method]

idx-lst &key (create)

(negative)

filter point cloud with list of index (points which are indicated by indices will remain).

if :create is true, return filtered point cloud and original point cloud does not change.

if :negative is true, points which are indicated by indices will be removed.

:filter [method]

&rest args &key create

&allow-other-keys

this method can take the same keywords with :filter-with-indices method.

if :create is true, return filtered point cloud and original point cloud does not change.

**:append** point-list &key (create t)

[method]

[method]

append point cloud list to this point cloud.

if :create is true, return appended point cloud and original point cloud does not change.

retrun centroid of this point cloud

:normal-list [method]

return list of normals

:centroid

:color-list [method]

return list of colors

:point-list &optional (remove-nan) [method]

return list of points

:normals & optional nmls [method]

replace normals by, nmls should be list of points or ntimes3 matrix

:colors & optional cls [method]

replace colors, cls should be list of points or ntimes matrix

:points & optional pts wd ht [method]

replace points, pts should be list of points or ntimes matrix

```
:size-change &optional wd ht
                                                                                                                      [method]
      change width and height, this method does not change points data
:init
                                                                                                                      [method]
         &rest args &key ((:points mat))
         ((:colors cary))
         ((:normals nary))
         ((:curvatures curv))
         ((:height ht))
         ((:width wd))
         (point-color (float-vector 0 1 0))
         (point-size 2.0)
         (fill)
         (arrow-width 2.0)
         (arrow-size 0.0)
       Create point cloud object
                                                                                                                        [method]
:draw \ vwer
:transparent &optional trs
                                                                                                                        [method]
: \mathbf{drawnormalmode} \ \mathscr{C}optional \ mode
                                                                                                                        [method]
:set-offset cds &key (create)
                                                                                                                        [method]
:generate-color-histogram-hs &key (h-step 9) (s-step 7) (hlimits (cons 360.0 0.0)) (vlimits (cons 1.0 0.15)) (slimits (cons
1.0 0.25)) (rotate-hue) (color-scale 255.0) (sizelimits 1)
                                                                                                                        [method]
:step-inlier step offx offy
                                                                                                                        [method]
:image-circle-filter dist &key (height 144) (width 176) (cy (/ (float (- height 1)) 2)) (cx (/ (float (- width 1)) 2)) create
negative
:image-position-inlier &key (ipkey) (height 144) (width 176) (cy (/ (float (- height 1)) 2)) (cx (/ (float (- width 1)) 2))
                                                                                                                        [method]
:viewangle-inlier &key (min-z 0.0) (hangle 44.0) (vangle 35.0)
                                                                                                                        [method]
:nfilter &rest args
                                                                                                                        [method]
:clear-normal
                                                                                                                        [method]
:clear-color
                                                                                                                        [method]
\textbf{:axis-width} \ \mathcal{E}optional \ aw
                                                                                                                        [method]
:axis-length \operatorname{\mathscr{C}optional} al
                                                                                                                        [method]
                                                                                                                        [method]
\textbf{:point-size} \ \mathscr{C}optional \ ps
\textbf{:point-color} \ \mathscr{C}optional \ pc
                                                                                                                        [method]
```

:set-color col &optional (_transparent)	[method]
:curvature-list	[method]
:curvatures & optional curv	[method]
:view-coords &optional vc	[method]
:height	[method]
:width	[method]
:size	[method]
:vertices	[method]
:box	[method]
:reset-box make-random-pointcloud &key (num 1000) (with-color) (with-normal) (scale 100.0)	[method] [function]

# 24 Graph Representation

node	:super	propertied-object arc-list image	[Class]
:init n &optional ime	age		[method]
:arc-list			[method]
:successors			[method]
:add-arc $a$			[method]
:remove-arc $a$			[method]
:remove-all-arcs			[method]
:unlink $n$			[method]
:image Coptional im			[method]
:add-neighbor $n\ {\it \&o}$	$optional\ a$		[method]
:neighbors Coptional			$[\mathrm{method}]$ $[\mathrm{method}]$

:unlink $n$			[method]
:remove-all-arcs			[method]
:remove-arc $a$			[method]
:add-arc $a$			[method]
:successors			[method]
:arc-list			[method]
:init n Coptional ime	ige		[method]
arc	:super :slots	propertied-object from to	[Class]
:init from_ to_			[method]
:from			[method]
:to			[method]
:prin1 &optional (str	*		$[{\rm method}] \\ [{\rm method}]$
:to			[method]
:from			[method]
:init from_ to_			[method]
directed-gra	aph :super :slots	propertied-object nodes	[Class]
write graph s Args: strm: stream	structure to class for c list of solve	ional (strm *standard-output*) result-path (title output) o stream as dot(graphviz) style output er-node, it's result of (send solver :solve graph)	[method]
:write-to-dot fna	me Coptio	nal result-path (title output)	[method]

fname: filename for output

title: title of graph

write graph structure to dot(graphviz) file Args: fname: filename for output result-path: list of solver-node, it's result of (send solver :solve graph) title: title of graph :write-to-file basename &optional result-path title (type pdf) [method] write graph structure to various type of file Args: basename: basename for output (output filename is 'basename.type') result-path: list of solver-node, it's result of (send solver :solve graph) title: title of graph type: type of output :write-to-pdf fname & optional result-path (title (string-right-trim .pdf fname)) [method] write graph structure to pdf Args: fname: filename for output result-path: list of solver-node, it's result of (send solver :solve graph) title: title of graph :original-draw-mode [method] change draw-mode to original mode :current-draw-mode [method] change draw-mode to latest mode :draw-both-arc &optional (bothq:both) [method] change draw-mode, if true is set, draw bidirectional arc as two arcs :draw-arc-label &optional (writeq :write) [method] change draw-mode, if true is set, draw label(name) of arcs :draw-merged-result &optional (mergeq :merge) [method] change draw-mode, if true is set, draw result arc as red. if not, draw red arc independently :write-to-png fname &optional result-path (title (string-right-trim .png fname)) [method] write graph structure to png Args:

:init [method]

result-path: list of solver-node, it's result of (send solver :solve graph)

:successors node &rest args [method]

:node name		$[\mathrm{method}]$
:nodes &optional arg		$[\mathrm{method}]$
:add-node $n$		$[\mathrm{method}]$
:remove-node $n$		$[\mathrm{method}]$
:clear-nodes		$[\mathrm{method}]$
: add-arc-from-to $from\ to$		$[\mathrm{method}]$
:remove-arc arc		$[\mathrm{method}]$
:adjacency-matrix		[method]
:adjacency-list :adjacency-list		$[method] \\ [method]$
:adjacency-matrix		$[\mathrm{method}]$
:remove-arc arc		$[\mathrm{method}]$
: add-arc-from-to $from\ to$		$[\mathrm{method}]$
:clear-nodes		[method]
:remove-node $n$		[method]
:add-node $n$		$[\mathrm{method}]$
:nodes &optional arg		[method]
:node name		$[\mathrm{method}]$
:successors node &rest args		$[\mathrm{method}]$
:init		[method]
costed-arc		[Class]
:super :slots	arc cost	
:init from to c		$[\mathrm{method}]$
:cost		$[\mathrm{method}]$
:cost		$[\mathrm{method}]$
:init from to c		$[\mathrm{method}]$

:draw-both-arc &optional (bothq:both)

[method]

costed-graph [Class] directed-graph :super :slots [method]  $: \mathbf{add\text{-}arc\text{-}from\text{-}to}\ \mathit{from}\ \mathit{to}\ \mathit{cost}\ \mathit{\&key}\ (\mathit{both}\ \mathit{nil})$ [method]  $\textbf{:path-cost}\ \textit{from}\ \textit{arc}\ \textit{to}$ [method] :path-cost from arc to [method] :add-arc-from-to from to cost &key (both nil) [method] :add-arc from to cost &key (both nil) [method] graph [Class] costed-graph :super :slots start-state goal-state :goal-test gs[method] [method]  $: \!\! \mathbf{path\text{-}cost} \ \mathit{from} \ \mathit{arc} \ \mathit{to}$ :start-state &optional arq [method] :goal-state &optional arg [method] :add-arc from to Ekey (both nil) [method] :add-arc-from-to from to Ekey (both nil) [method] :add-arc-from-to from to Ekey (both nil) [method] :add-arc from to &key (both nil) [method] :goal-state &optional arg [method] :start-state &optional arg [method]  $\textbf{:path-cost}\ \textit{from}\ \textit{arc}\ \textit{to}$ [method] [method] :goal-test gs:draw-merged-result &optional (mergeq :merge) [method] change draw-mode, if true is set, draw result arc as red. if not, draw red arc independently :draw-arc-label &optional (writeq :write) [method] change draw-mode, if true is set, draw label(name) of arcs

change draw-mode, if true is set, draw bidirectional arc as two arcs

:current-draw-mode

[method]

change draw-mode to latest mode

:original-draw-mode

[method]

change draw-mode to original mode

:write-to-png fname &optional result-path (title (string-right-trim .png fname))

[method]

write graph structure to png

Args:

fname: filename for output

result-path: list of solver-node, it's result of (send solver :solve graph)

title: title of graph

 $\textbf{:write-to-pdf} \ \textit{fname} \ \mathcal{E}\textit{optional} \ \textit{result-path} \ (\textit{title} \ (\textit{string-right-trim} \ .\textit{pdf} \ \textit{fname}))$ 

[method]

write graph structure to pdf

Args:

fname: filename for output

result-path: list of solver-node, it's result of (send solver :solve graph)

title: title of graph

:write-to-file basename &optional result-path title (type pdf)

[method]

write graph structure to various type of file

Args:

basename: basename for output (output filename is 'basename.type') result-path: list of solver-node, it's result of (send solver :solve graph)

title: title of graph type: type of output

:write-to-dot fname &optional result-path (title output)

[method]

write graph structure to dot(graphviz) file

Args:

fname: filename for output

result-path: list of solver-node, it's result of (send solver :solve graph)

title: title of graph

 $\textbf{:write-to-dot-stream} \ \mathscr{C}optional \ (strm *standard-output*) \ result-path \ (title \ output)$ 

[method]

write graph structure to stream as dot(graphviz) style

Args:

strm: stream class for output

result-path: list of solver-node, it's result of (send solver :solve graph)

title: title of graph

 $: {\bf neighbors} \ \mathscr{C}optional \ args$ 

[method]

:add-neighbor n &optional a

[method]

arced-node			[Class]
	:super :slots	node nil	
:init &key name			[method]
:find-action $n$			[method]
:neighbor-action-alist			[method]
:find-action $n$			[method]
:init &key name			[method]
solver-node			[Class]
	:super :slots	propertied-object state cost parent action memorized-path	
		•	
:init st &key ((:cost c)	0) ((:paren	t p) nil) ((:action a) nil)	[method]
:path &optional (prev	nil)		[method]
:expand prblm &rest a	urgs		[method]
:state Coptional arg			[method]
:cost &optional arg			[method]
:parent Coptional arg			[method]
:action Coptional arg			[method]
:action Coptional arg			[method]
:parent Coptional arg			[method]
:cost Coptional arg			[method]
:state Coptional arg			[method]
:expand prblm &rest a	urgs		[method]
:path &optional (prev	nil)		[method]
:init st &key ((:cost c)	0) ((:paren	t p) nil) ((:action a) nil)	[method]
solver			[Class]

 $: \mathbf{super} \qquad \mathbf{propertied\text{-}object}$ 

:slots nil

:init	[method]
:solve prblm	[method]
:solve-by-name prblm s g &key (verbose nil) :solve-by-name prblm s g &key (verbose nil)	$[{\rm method}] \\ [{\rm method}]$
:solve prblm	[method]
:init	[method]
graph-search-solver	[Class]
:super solver	. 1
:slots open-list close-list	
:solve-init $prblm$	[method]
:find-node-in-close-list $n$	[method]
:solve prblm &key (verbose nil)	[method]
Solve prount Grey (versose nu)	[method]
:add-to-open-list obj/list	[method]
:null-open-list?	[method]
:clear-open-list	[method]
:add-list-to-open-list $lst$	[method]
	[memou]
$: {\bf add-object-to-open-list} \ \mathit{lst}$	[method]
:pop-from-open-list $\&key\ (debug)$	[method]
that Working I are	[4] ]]
:open-list Goptional arg	[method]
:close-list &optional arg	[method]
:close-list &optional arg	[method]
:open-list &optional arg	[method]
	F * *7
:pop-from-open-list $\&$ key $(debug)$	[method]
:add-object-to-open-list $lst$	[method]
rada object to open-met see	[method]
:add-list-to-open-list $lst$	[method]

:clear-open-list	[method]
:null-open-list?	[method]
$: {\bf add\text{-}to\text{-}open\text{-}list} \ obj/list$	[method]
:solve prblm &key (verbose nil)	[method]
:find-node-in-close-list $n$	[method]
:solve-init prblm	[method]
breadth-first-graph-search-solver :super graph-search-solver :slots nil	[Class]
:init	[method]
:clear-open-list	[method]
: add-list-to-open-list $\mathit{lst}$	[method]
: add-object-to-open-list $\mathit{obj}$	[method]
:pop-from-open-list &key (debug) :pop-from-open-list &key (debug)	[method]
: add-object-to-open-list $\mathit{obj}$	[method]
:add-list-to-open-list $lst$	[method]
:clear-open-list	[method]
:init	[method]
depth-first-graph-search-solver :super graph-search-solver :slots nil	[Class]
:init	[method]
:clear-open-list	[method]
: add-list-to-open-list $\mathit{lst}$	[method]
: add-object-to-open-list $\mathit{obj}$	[method]

:pop-from-open-list &key (debugger):pop-from-open-list &key (debugger)		[method]
: add-object-to-open-list $\mathit{obj}$		[method]
: add-list-to-open-list $\mathit{lst}$		[method]
:clear-open-list		[method]
:init		[method]
best-first-graph-se	arch-solver	[Class]
:super	graph-search-solver	
:slots	aproblem	
:init p		[method]
:clear-open-list		[method]
: add-list-to-open-list $lst$		[method]
$: {\bf add\text{-}object\text{-}to\text{-}open\text{-}list} \ \textit{obj}$		[method]
:pop-from-open-list &key (debu	g  nil)	[method]
<b>:fn</b> <i>n p</i>		[method]
<b>:fn</b> n p		[method]
:pop-from-open-list &key (debu	g  nil)	[method]
: add-object-to-open-list $\mathit{obj}$		[method]
: add-list-to-open-list $\mathit{lst}$		[method]
:clear-open-list		[method]
:init p		[method]
a*-graph-search-so	olver	[Class]
:super	best-first-graph-search-solver	
:slots	nil	
:init p		[method]
:fn n p &key (debug nil)		[method]
:gn $n$ $p$		[method]

:hn $n$ $p$	[method]
:hn $n$ $p$	[method]
:gn $n$ $p$	[method]
:fn n p &key (debug nil)	[method]
:init $p$	[method]

# 25 irteus Extension

# 25.1 GL/X Display

polygon [Class]

:super plane

:slots normal distance convexp edges vertices model-normal model-distance

line [Class]

:super propertied-object

:slots pvert nvert

faceset [Class]

:super cascaded-coords

:slots rot pos parent descendants worldcoords manager changed box faces edges vertices mo

:set-color gl::color &optional (gl::transparent)

[method]

Set color of given color name, color sample and color name are referenced from http://en.wikipedia.org/wiki/X11\_

:paste-texture-to-face gl::aface &key gl::file gl::image (gl::tex-coords (list (float-vector 0 0) (float-vector 0 1) (float-vector 1 1) (float-vector 1 0))) [method]

coordinates

:super **propertied-object** 

:slots rot pos

:draw-on &key ((:viewer gl::vwer) \*viewer\*) gl::flush (gl::width (get self :width)) (gl::color (get self :color)) (size (get self :size)) [method]

:vertices [method] float-vector [Class] :super vector :slots nil :draw-on &key ((:viewer gl::vwer) \*viewer\*) gl::flush (gl::width 1) (gl::color #f(1.0 1.0 1.0)) (size 50) [method] :vertices [method] gl::glvertices [Class] cascaded-coords :super gl::mesh-list gl::filename gl::bbox :slots :set-color gl::color &optional (gl::transparent) [method] set color as float vector of 3 elements, and transparent as float, all values are betwenn 0 to 1 :actual-vertices [method] return list of vertices (float-vector), it returns all vertices of this object :calc-bounding-box [method] calculate and set bounding box of this object :vertices [method] return list of vertices (float-vector), it returns vertices of bounding box of this object :reset-offset-from-parent [method] move vertices in this object using self transformation, this method change values of vertices. coordinates's method such as :transform just change view of this object :expand-vertices [method] expand vertices number as same number of indices, it enable to set individual normal to every vertices :use-flat-shader [method] use flat shader mode, use opengl function of glShadeModel(GL\_FLAT) [method] :use-smooth-shader use smooth shader mode, use opengl function of glShadeModel(GL\_SMOOTH) default :calc-normals &optional (gl::force nil) (gl::expand t) (gl::flat t) [method] normal calculation if force option is true, clear current normalset. if exapnd option is ture, do :expand-vertices. if flat option is true, use-flat-shader

creating mirror vertices respect to :axis

:convert-to-faces [method]

& Erest args & key (gl::wrt :local)

&allow-other-keys

create list of faces using vertices of this object

:convert-to-faceset &rest args

[method]

create faceset using vertices of this object

:set-offset gl::cds &key (gl::create)

[method]

move vertices in this object using given coordinates, this method change values of vertices. coordinates's method such as :transform just change view of this object

:convert-to-world &key (gl::create)

[method]

move vertices in this object using self's coordinates. vertices data should be moved as the same as displayed

:glvertices &optional (name) (gl::test #'string=)

[method]

create individual glyertices objects from mesh-list. if name is given, search mesh has the same name

:append-glvertices gl::glv-lst

[method]

append list of glvertices to this object

:init gl::mlst &rest args &key ((:filename gl::fn)) &allow-other-keys

[method]

:filename  $\mathscr{C}optional\ gl::nm$ 

[method]

:get-meshinfo  $gl::key \ @optional \ (pos \ -1)$ 

[method]

 $:\mathbf{set\text{-}meshinfo}\ \mathit{gl::key}\ \mathit{gl::info}\ \mathit{\mathfrak{Coptional}}\ (\mathit{pos}\ \text{-}1)$ 

[method]

 $\textbf{:get-material} \ \textit{\&optional} \ (pos \ \textit{-1})$ 

[method]

 $\textbf{:set-material}\ gl{::mat}\ \mathcal{C}optional\ (pos\ \text{-}1)$ 

[method]

:expand-vertices-info gl::minfo

[method]

:draw-on &key ((:viewer gl::vwer) \*viewer\*)

[method]

:draw gl::vwr &rest args

[method]

:collision-check-objects &rest args

[method]

:box

:faces

[method]

:make-pqpmodel &key (gl::fat 0)

 $[\mathrm{method}]$ 

:append-glvertices gl::glv-lst

[method]

append list of glvertices to this object

## :glvertices & optional (name) (gl::test #'string=)

[method]

create individual glyertices objects from mesh-list. if name is given, search mesh has the same name

#### :convert-to-world &key (gl::create)

method

move vertices in this object using self's coordinates. vertices data should be moved as the same as displayed

#### :set-offset gl::cds &key (gl::create)

[method]

move vertices in this object using given coordinates, this method change values of vertices. coordinates's method such as :transform just change view of this object

# $\textbf{:convert-to-faceset} \ \mathscr{E}\mathit{rest} \ \mathit{args}$

[method]

create faceset using vertices of this object

#### :convert-to-faces

[method]

&rest args &key (gl::wrt :local)

&allow-other-keys

create list of faces using vertices of this object

#### :mirror-axis

[method]

&key (gl::create t) (gl::invert-faces t) (gl::axis :y)

creating mirror vertices respect to :axis

#### :calc-normals &optional (gl::force nil) (gl::expand t) (gl::flat t)

[method]

normal calculation

if force option is true, clear current normalset.

if exapnd option is ture, do :expand-vertices.

if flat option is true, use-flat-shader

#### :use-smooth-shader

[method]

use smooth shader mode, use opengl function of glShadeModel(GL\_SMOOTH) default

# :use-flat-shader

[method]

use flat shader mode, use opengl function of glShadeModel(GL\_FLAT)

## :expand-vertices

[method]

expand vertices number as same number of indices, it enable to set individual normal to every vertices

# $: {\bf reset\text{-}offset\text{-}from\text{-}parent}$

[method]

move vertices in this object using self transformation, this method change values of vertices. coordinates's method such as :transform just change view of this object

#### :vertices

[method]

return list of vertices (float-vector), it returns vertices of bounding box of this object

#### :calc-bounding-box

[method]

calculate and set bounding box of this object

# :actual-vertices

[method]

return list of vertices (float-vector), it returns all vertices of this object

:set-color gl::color &	- , -	l::transparent) 3 elements, and transparent as float, all values are betwenn 0 to	$[{ m method}]$
:make-pqpmodel &key			[method]
:box			$[\mathrm{method}]$
:collision-check-object	ts Erest args		[method]
:draw gl::vwr &rest args	s		[method]
:draw-on &key ((:viewe	er gl::vwer) *v	iewer*)	[method]
:faces			[method]
:expand-vertices-info	$gl{::}minfo$		[method]
:set-material $gl$ :: $mat$ $\mathscr E$	Soptional (pos	-1)	[method]
:get-material Coptiona	ul (pos -1)		[method]
:set-meshinfo gl::key gl	l::info &option	nal (pos -1)	[method]
:get-meshinfo gl::key &	${\it Soptional\ (pos}$	-1)	[method]
:filename &optional gl::	:nm		[method]
:init gl::mlst &rest args	Ekey ((:filend	me gl::fn)) & allow-other-keys	[method]
gl::glbody			[Class]
	-	ody :::aglvertices	
:glvertices &rest args			[method]
:draw gl::vwr			$[\mathrm{method}]$
:set-color &rest args :set-color &rest args			[method]
:draw gl::vwr			[method]
:glvertices &rest args			[method]
gl::find-color gl::col returns color ve		color name, the name is defined in https://github.com/euslisp/jsk $\ensuremath{^{\circ}}$	[function] eus/blob/master/ir
gl::transparent gl::			[function]
gl::make-glvertices	s-from-face	set gl::fs &key (gl::material)	[function]

returns glvertices instance fs is geomatry::faceset

# gl::make-glvertices-from-faces gl::flst &key (gl::material)

[function]

returns glvertices instance flst is list of geomatry::face

# $\textbf{gl::write-wrl-from-glvertices} \ \textit{fname} \ \textit{gl::glv} \ \textit{\&rest} \ \textit{args}$

[function]

write .wrl file from instance of glvertices

gl::set-stereo-gl-attribute [function] gl::reset-gl-attribute [function]  ${\bf gl::delete\text{-}displaylist\text{-}id} \ \textit{gl::dllst}$ [function] gl::transpose-image-rows gl::img &optional gl::ret [function] gl::draw-globjects gl::wwr gl::draw-things &key (gl::clear t) (gl::flush t) (gl::draw-origin 150) (gl::draw-floor nil) (gl::floorcolor #f(1.0 1.0 1.0)) [function] gl::draw-glbody gl::vwr gl::abody [function] gl::-dump-wrl-shape gl::strm gl::mesh &key ((:scale gl::scl) 1.0) (gl::use\_ambient nil) (gl::use\_normal nil) (gl::use\_texture nil) & allow-other-keys [function]

x:xwindow [Class]

:super x:xdrawable

:slots x::display x::drawable x::gcon x::bg-color x::width x::height x::parent x::subwindows x

:buttonpress x:event [method]

:motionnotify x:event [method]

:buttonrelease x:event [method]

:set-event-proc type x::method x::receiver [method]

:clientmessage x:event [method]

:quit &rest x::a [method]

:event-notify type x:event [method]

:create &rest args

**x:panel** [Class]

:super x:xwindow

:slots x::display x::drawable x::gcon x::bg-color x::width x::height x::parent x::subwindows x

:quit &rest args

x:xscroll-bar [Class]

:super x:xwindow

:slots x::display x::drawable x::gcon x::bg-color x::width x::height x::parent x::subwindows x

:slots

buf

:redraw		[method]
x::tabbed-panel		[Class]
:super	x:panel	
:slots	x::tabbed-buttons $x$ ::tabbed-panels $x$ ::selected-tabbed-panel	
:create &rest args		[method]
:add-tabbed-panel name		[method]
$: {\bf change-tabbed-panel}\ x{::}obj$		[method]
:tabbed-button name &rest args	S	[method]
:tabbed-panel name &rest args		[method]
:resize		$[\mathrm{method}] \\ [\mathrm{method}]$
:tabbed-panel name &rest args		[method]
:tabbed-button name &rest args	S	[method]
:change-tabbed-panel $x::obj$		[method]
:add-tabbed-panel name		[method]
:create &rest args		[method]
x::panel-tab-butto	n-item	[Class]
:super	x:button-item	
:slots	nil	
:draw-label & optional (x::state :		[method]
:draw-label & optional (x::state :		[method]
x::window-main-one & optional x::event-far x::e	ja	[function] [function]
x::event-near x::e		[function]
25.2 Utility Function	n	
		[ C ]
mtimer	1.	[Class]
:super	object	

[method]

[method]

:init [method] Initialize timer object. [method] :start Start timer. :stop [method] Stop timer and returns elapsed time in seconds. [method] :stop Stop timer and returns elapsed time in seconds. :start [method] Start timer. :init [method] Initialize timer object. interpolator [Class] :super propertied-object :slots (position-list :type cons) (time-list :type cons) (position :type float-vector) (time :type :init [method] Abstract class of interpolator [method] :reset & rest args & key ((:position-list pl) (send self :position-list)) ((:time-list tl) (send self :time-list)) &allow-other-keys Initialize interpolator position-list: list of control point time-list: list of time from start for each control point, time in first contrall point is zero, so length of this list is length of control point minus 1 :position-list [method] returns position list :position [method] returns current position : time-list[method] returns time list :time [method] returns current time

returns index of segment which is currently processing

returns time[sec] with in each segment

:segment-time

:segment

position-list: list of control point

:segment-num returns number of total segment	[method]
:interpolatingp returns if it is currently processing	[method]
:start-interpolation start interpolation	[method]
:stop-interpolation stop interpolation	[method]
:pass-time $dt$ process interpolation for dt[sec] :pass-time $dt$ process interpolation for dt[sec]	[method]
:stop-interpolation stop interpolation	[method]
:start-interpolation start interpolation	[method]
:interpolatingp returns if it is currently processing	[method]
:segment-num returns number of total segment	[method]
:segment returns index of segment which is currently processing	[method]
:segment-time returns time[sec] with in each segment	[method]
:time returns current time	[method]
:time-list returns time list	[method]
:position returns current position	[method]
:position-list returns position list	[method]
:reset  & & & & & & & & & & & & & & & & & & &	[method]
Initialize interpolator	

time-list: list of time from start for each control point, time in first contrall point is zero, so length of this list is length of control point minus 1

:init [method]

Abstract class of interpolator

# linear-interpolator

[Class]

 $: \mathbf{super} \qquad \mathbf{interpolator}$ 

:slots nil

:interpolation [method]

Linear interpolator

:interpolation [method]

Linear interpolator

# minjerk-interpolator

[Class]

:super interpolator

:slots velocity acceleration velocity-list acceleration-list

:velocity [method]

returns current velocity

:velocity-list [method]

returns velocity list

:acceleration [method]

returns current acceleration

:acceleration-list [method]

returns acceleration list

:reset [method]

& rest args & key ((:velocity-list vl) (send self :velocity-list)) ((:acceleration-list al) (send self :acceleration-list))

&allow-other-keys

minjerk interopolator

position-list: list of control point

velocity-list: list of velocity in each control point

acceleration-list: list of acceleration in each control point

:interpolation [method]

Minjerk interpolator, a.k.a Hoff & Arbib

Example code is:

(setq l (instance minjerk-interpolator:init))

(send 1 :reset :position-list (list  $\#f(1\ 2\ 3)\ \#f(3\ 4\ 5)\ \#f(1\ 2\ 3)$ ) :time-list (list 0.1\ 0.18))

(send 1:start-interpolation)

(while (send l :interpolatingp) (send l :pass-time 0.02) (print (send l :position)))

```
:interpolation
                                                                                                      [method]
     Minjerk interpolator, a.k.a Hoff & Arbib
     Example code is:
      (setq l (instance minjerk-interpolator :init))
      (send l :reset :position-list (list \#f(1\ 2\ 3)\ \#f(3\ 4\ 5)\ \#f(1\ 2\ 3)) :time-list (list 0.1 0.18))
      (send 1 :start-interpolation)
      (while (send 1:interpolatingp) (send 1:pass-time 0.02) (print (send 1:position)))
                                                                                                      [method]
:reset
          &rest args &key ((:velocity-list vl) (send self :velocity-list))
          ((:acceleration-list al) (send self :acceleration-list))
          &allow-other-keys
     minjerk interopolator
     position-list: list of control point
      velocity-list: list of velocity in each control point
      acceleration-list: list of acceleration in each control point
:acceleration-list
                                                                                                      [method]
     returns acceleration list
:acceleration
                                                                                                      [method]
     returns current acceleration
:velocity-list
                                                                                                      [method]
     returns velocity list
                                                                                                     [method]
:velocity
     returns current velocity
                                                                                                     [function]
forward-message-to to args
      forward _args_ message to _to_ object
forward-message-to-all to args
                                                                                                     [function]
     forward _args_ message to all _to_ object
                                                                                                     [function]
permutation lst n
     Returns permutation of given list
combination lst n
                                                                                                     [function]
     Returns combination of given list
find-extreams
                                                                                                     [function]
                   datum &key (key #'identity)
                   (identity \#'=)
                   (bigger #'>)
     Returns the elements of datum which maximizes key function
eus-server & optional (port 6666) & key (host (unix:gethostname))
                                                                                                     [function]
```

Create euslisp interpreter server, data sent to socket is evaluated as lisp expression

set-termios-c\_ispeed lisp::s lisp::val

 ${\bf termios\text{-}c\text{\_}ospeed}\ \mathit{lisp::s}$ 

[function]

[function]

#### connect-server-until-success [function] host port &key (max-port (+ port 20)) (return-with-port nil) Connect euslisp interpreter server until success format-array arr Eoptional (header ) (in 7) (fl 3) (strm \*error-output\*) (use-line-break t) [function] print formatted array his2rgb h & optional (i 1.0) (s 1.0) ret [function] convert his to rgb $(0 \le h \le 360, 0.0 \le i \le 1.0, 0.0 \le s \le 1.0)$ hvs2rgb h &optional (i 1.0) (s 1.0) ret [function] convert hvs to rgb (0 $\leq$ h $\leq$ 360, 0.0 $\leq$ i $\leq$ 1.0, 0.0 $\leq$ s $\leq$ 1.0) rgb2his r &optional g b ret [function] convert rgb to his $(0 \le r,g,b \le 255)$ rgb2hvs r &optional g b ret [function] convert rt to hvs $(0 \le r,g,b \le 255)$ [function] color-category 10 iChoose good color from 10 colors color-category 20 i[function] Choose good color from 20 colors kbhit [function] Checks the console for a keystroke. returns keycode value if a key has been pressed, otherwise it returns nil. Note that this does not work well on Emacs Shell mode, run EusLisp program from terminal shell. piped-fork-returns-list cmd &optional args [function] piped fork returning result as list make-robot-model-from-name name &rest args [function] make a robot model from string: (make-robot-model "pr2") [function] $\mathbf{mapjoin}\ expr\ seq1\ seq2$ need-thread n & optional (lsize (\*512 1024)) (csize lsize) [function] $termios-c\_iflag \ lisp::s$ [function] $\textbf{set-termios-} \textbf{c\_iflag} \ \textit{lisp::s} \ \textit{lisp::val}$ [function] termios-c\_oflag lisp::s [function] $set-termios-c\_oflag\ lisp::s\ lisp::val$ [function] [function] $\mathbf{termios\text{-}c\_cflag}\ \mathit{lisp::s}$ set-termios-c\_cflag lisp::s lisp::val [function] termios-c\_lflag lisp::s [function] $\textbf{set-termios-c\_lflag} \ \textit{lisp::s} \ \textit{lisp::val}$ [function] termios-c\_line lisp::s[function] set-termios-c\_line lisp::s lisp::val [function] termios-c\_cc lisp::s &optional lisp::i [function] set-termios-c\_cc lisp::s lisp::i &rest lisp::val [function] ${\bf termios\text{-}c\_ispeed}\ \mathit{lisp::s}$ [function]

Robot Modelling Function 344 set-termios-c\_ospeed lisp::s lisp::val [function] gnuplot [Class] propertied-object :super :slots strm data data-length last-command debug :init [method] host &key (clear t) ((:debug \_debug)) Initialize gnuplot interface object with given host name :clear [method] Clear graph :draw &rest vs [method] Draw graph with given float vectors, :range, :xrange, :yrange, : range of each axis :title : title of graph :line-width : line width :direction : direction of the graph (:right, :left) :xscale, :xoffset : scale and offset for data :y2tics: list variable to specify when y2 range is used :y2range : set y2 tics and specify range :type: specify type of the graph (:lines, :2dmap) :save f &key (type postscript eps color "Times-Roman" 24) [method] save graph as eps file :replot [method] [method] :reset [method] :command msg :quit [method]  $\textbf{:proc-length}\ \mathcal{E}optional\ n$ [method] :proc-clear [method] :proc-one vs &rest args [method]

[method]

[method]

:draw &rest vs

:save f &key (type postscript eps color "Times-Roman" 24)

Draw graph with given float vectors,

save graph as eps file

:range, :xrange, :yrange, : range of each axis

:title : title of graph

```
:line-width : line width
      :direction: direction of the graph (:right, :left)
      :xscale, :xoffset : scale and offset for data
      :y2tics: list variable to specify when y2 range is used
      :y2range : set y2 tics and specify range
      :type: specify type of the graph (:lines, :2dmap)
:clear
                                                                                                         [method]
      Clear graph
:init
                                                                                                         [method]
        host &key (clear t)
        ((:debug _debug))
     Initialize gnuplot interface object with given host name
:proc-one vs \ \&rest \ args
                                                                                                          [method]
:proc-clear
                                                                                                          [method]
\textbf{:proc-length} \ \mathcal{C}optional \ n
                                                                                                          [method]
:quit
                                                                                                          [method]
                                                                                                          [method]
:command msg
                                                                                                          [method]
:reset
:replot
                                                                                                          [method]
gnuplot &key (host (unix:gethostname))
                                                                                                        [function]
      Returns gnuplot interface instance
      ex)
      (setq *g*(gnuplot))
      (send *g*:draw #f(0 1 2 3 4 5) #f(5 4 3 2 1 0) :xrange '(0 10) :yrange '(0 10) :title '("data1" "data2"))
     see irteus/gnuplotlib.l for more info
graph-view
                                                                                                        [function]
                 ordinate-list & optional (abscissa-list (let ((idx -1)) (mapcar #'(lambda (x) (incf idx)) (make-list (len
                 (xlabel X)
                 (ylabel Y)
                 (zlabel Z)
                 (dump-graph nil)
                 (graph-fname (format nil A.eps (substitute 95 (elt 0) title)))
                 (mode lines)
                 keylist
                 xrange
```

```
yrange
          zrange
           x11
           additional-func
           no-dump
           ((:graph-instance gp) (if (boundp '*gp*) *gp*(setq *gp*(gnuplot))))
           (fname (format nil data A (system:address gp)))
plot function for 2d or 3d plot
ordinate-list: list of data for ordinate axis
2D = (list (list y00 y01 \dots y0n), \dots (list ym0 ym1 \dots ymn))
3D = (list (list z00 z01 \dots z0n), \dots (list zm0 zm1 \dots zmn))
abscissa-list : list of data for abscissa axes
2D = (list x0 x1 ... xn)
3D = (list xylist0 ... xylistn) ;; xylist = (list x y)
:title: title of graph
:xlabel, :ylabel, zlabel : label for each axis
:keylist : legend of each data
:xrange, :yrange, :zrange : range of each axis
:mode: "lines" or "points"
```

#### 25.3 Math Function

matrix(a) v = a \*v

```
inverse-matrix mat
                                                                                                 [function]
     returns inverse matrix of mat
inverse-matrix-complex cmat
                                                                                                 [function]
     returns inverse matrix of complex square matrix
m*-complex cmat1 cmat2
                                                                                                 [function]
     returns complex matrix 1 *complex matrix 2
diagonal v
                                                                                                 [function]
     make diagonal matrix from given vector, diagonal \#f(1\ 2) \rightarrow \#2f((1\ 0)(0\ 2))
minor-matrix m ic jc
                                                                                                 [function]
     return a matrix removing ic row and jc col elements from m
                                                                                                 [function]
atan2 y x
     returns at an 2 of y and x (at an (/yx))
outer-product-matrix v & optional (ret (unit-matrix 3))
                                                                                                 [function]
     returns outer product matrix of given v
```

0 -w2 w1 w2 0 -w0

-w1 w0 0

# ${\bf matrix 2 quaternion}\ m$

[function]

returns quaternion (w x y z) of given matrix

### quaternion2matrix q

[function]

returns matrix of given quaternion (w x y z)

#### matrix-log m

[function]

returns matrix log of given m, it returns [-pi, pi]

### matrix-exponent omega Goptional (p 1.0)

[function]

returns exponent of given omega

#### midrot p r1 r2

[function]

returns mid (or p) rotation matrix of given two matrix r1 and r2

### pseudo-inverse mat &optional weight-vector ret wmat mat-tmp

[function]

returns pseudo inverse of given mat

sr-inverse mat & optional (k 1.0) weight-vector ret wmat tmat umat umat 2 mat-tmp mat-tmp-rc mat-tmp-rr mat-tmp-rr2 [function]

returns sr-inverse of given mat

#### manipulability jacobi &optional tmp-mrr tmp-mcr

[function]

return manipulability of given matrix

#### random-gauss & optional (m 0) (s 1)

[function]

 $make\ random\ gauss,\ m\hbox{:}mean\ s\hbox{:}standard\hbox{-}deviation$ 

# gaussian-random dim &optional (m 0) (s 1)

[function]

make random gauss vector, replacement for quasi-random defined in matlib.c

# eigen-decompose-complex m

[function]

returns eigen decomposition from real square matrix

#### solve-non-zero-vector-from-det0-matrix m

[function]

solves non-zero-vector v from real square determinant-zero-matrix mat, when mat\*v=O and det(mat)=0

# ${\bf concatenate\text{-}matrix\text{-}column}\ \ \mathscr{C}rest\ args$

[function]

Concatenate matrix in column direction.

# ${\bf concatenate\text{-}matrix\text{-}row}\ \mathscr{C}rest\ args$

[function]

Concatenate matrix in row direction.

#### concatenate-matrix-diagonal & rest args

[function]

Concatenate matrix in diagonal.

# ${f vector-variance}\ vector-list$

[function]

returns vector, each element represents variance of elements in the same index of vector within vector-list

#### covariance-matrix vector-list

[function]

make covariance matrix of given input vector-list

 $normalize\text{-vector}\ v\ \mathcal{E}optional\ r\ (eps\ 1.000000e\text{-}20)$ 

[function]

calculate normalize-vector  $\#f(0\ 0\ 0)->\#f(0\ 0\ 0)$ .

pseudo-inverse-org m &optional ret winv mat-tmp-cr

[function]

sr-inverse-org  $mat\ @optional\ (k\ 1)$   $me\ mat\text{-}tmp\text{-}cr\ mat\text{-}tmp\text{-}rr$  eigen-decompose m

[function]

lms point-list

[function]

lms-estimate res point-

[function]

 ${\bf lms\text{-}error}\ \mathit{result\ point\text{-}list}$ 

[function]

 $\begin{array}{l} \textbf{Imeds} \ point-list \ \&key \ (num \ 5) \ (err-rate \ 0.3) \ (iteration) \ (ransac-threshold) \ (lms-func \ \#'lms) \ (lmeds-error-func \ \#'lms-estimate) \\ (lms-estimate-func \ \#'lms-estimate) \end{array} \ [\textbf{function}]$ 

 ${\bf lmeds\text{-}error}\ \mathit{result\ point\text{-}list\ } \& key\ (\mathit{lms\text{-}estimate\text{-}func\ \#'lms\text{-}estimate})$ 

[function]

 ${\bf lmeds\text{-}error\text{-}mat}\ \textit{result}\ \textit{mat}\ \textit{\&key}\ (\textit{lms\text{-}estimate\text{-}func}\ \#'\textit{lms\text{-}estimate})$ 

[function]

# 25.4 Image Function

# read-image-file fname

[function]

read image of given fname. It returns instance of grayscale-image or color-image24.

# write-image-file fname image::img

[function]

write img to given fname

read-png-file fname

[function]

write-png-file fname image::img

[function]