

CPET-561 Embedded Systems Design I

Signoffs and Grade:

Name:

Component	Signoff	Date	Time
Hex Display Counts Up			
-Stops at 9			
Hex Display Counts down			
-Stops at 0			
Bonus Points: Counter			
Wraps Around in both			
directions (+5pts)			

Component	Received	Possible
Prelab		10
Signoffs		90
Penalties • 1st week after session lab is due: -10 • 2nd week after session lab is due: -25 No signoffs will be given more than 2 weeks after due date	-	
Total		100



CPET-561 Embedded Systems Design I

Education Objective

The educational objective of this laboratory is to investigate the use of the NIOS II assembly language to interface the NIOS II processor with I/O devices on the DE1-SoC development board.

Technical Objective

The technical objective of this laboratory is to design an embedded system for the Nios II processor and DE1-SoC that will execute an assembly language programs that increments and decrements a single digit counter displayed on the seven-segment display when the pushbutton KEY1 is pressed.

Prelab

Complete prelab parts 1 and 2. When the prelab is complete, you should have a system that sets HEXO to a zero when the assembly program is run.

Prelab Part 1 - Hardware

- 1. Open Quartus II and create a new project
- 2. Open tools > Platform Designer
- 3. Create a system with the following components
 - a. Nios II/e processor
 - b. On-chip memory for program code and data
 - c. 8-bit input PIO for switches
 - d. 4-bit input PIO for pushbuttons
 - e. 7-bit output PIO for hex0
 - f. JTAG Uart
 - g. Sysid

You can use lab 1 as a guide, but it is important to be able to create the nios_system on your own, so that building the system does not become a stumbling block on future labs and demos.

- 4. Save your system as nios system.qsys
- 5. Generate the VHDL
- 6. Return to the Quartus project and add nios_system.qip to the project
- 8. Use Assignments > Import Assignments... to import the pin assignments in the DE1_SoC.qsf file
- 9. Compile the design
- 10. Program the DE1_SoC board.

Part 2 - Software

- 1. Write a NIOS II assembly language program that does the following:
 - a. Displays 0 on hex0
- 2. Obtain a prelab signoff



CPET-561 Embedded Systems Design I

Procedure

Part1 - Software

- 1. Write a NIOS II assembly language program that does the following:
 - a. Displays 0 on hex0
 - b. Checks to see if key1 is pushed (active low)
 - i. If SWO is high, increments the value on hexO
 - ii. If SW0 is low, decrements the value on hex0
 - c. Do not increment or decrement the value on hex0 until key1 is released
 - d. Do not go higher than 9, or lower than 0.
- 2. Below are some suggestions for writing the code
 - a. Use bit masking (learned in microcontrollers) to isolate bits
 - b. Use a subroutine for displaying the current count and for waiting for the key to be released
 - c. Use an array (example in the lecture notes) for storing the seven-segment display constants
- 3. BONUS: Once you have all of your signoffs, you may expand on the original assembly design and create a wraparound counter that allows the user to increment from 9 -> 0, and decrement from 0 -> 9.
- 4. Obtain signoffs from the professor or TA