

TECHNO TURING GROOVEBOX

R16 STABLE - USER MANUAL

Exsiderurgica

TTG is a performance-oriented generative techno instrument for Android. R16 combines four Turing-style sequencing lanes, synthesis voices, polyrhythm, modulation, a live mixer, a modular BREAK processor, MIDI I/O and WAV recording.

Platform: Android 8+ **Release baseline:** R16 stable #157

QUICK START

1. Open SOUND and set BPM, shuffle and the voice parameters. 2. Open TURING to generate and mutate the four musical lanes. 3. Use MIXER for performance levels and temporary FX. 4. Open BREAK BUS when you want to process and slice the performance. 5. Use MIDI for external clock or outgoing notes/CC. 6. Use REC to capture the master output.


MIXER / PERFORMANCE

KICK, TOM, HATS, BASS, SYNTH and CHORDS have independent performance levels and mute controls. The **FX / TEMP PERFORMANCE** section provides delay, reverb, beat repeat and temporary/drop effects. **START** controls transport. The mixer is designed as the main live-performance surface.



TURING / POLYRHYTHM / MODULATION

Four Turing-style lanes drive **T1 Kick + Tom**, **T2 Bass**, **T3 Synth** and **T4 Chords**. DENS controls activity/density; VAR changes variation; the rhythmic division and STEP controls define each lane's behavior. FREEZE holds a lane and NEW regenerates it. Pitch LFO and Decay LFO add modulation. The bottom length selectors (4/8/16/32/FREE) and GEN control shape global evolution. **HARD RESET** restarts the application core when a full reset is required.




SOUND / PERFORMANCE

Set the master **BPM** with minus/plus or TAP and adjust SHUFFLE. Kick + Tom includes drive, groove and pitch-envelope controls. Hat/Perc provides 909/16th-hat behavior, decay and drive. Bass and Synth expose pitch, decay, color, drive and filter controls. Chords/Drone provides performance drive, color, drive amount and chord reverb.




BREAK / MODULAR CHAIN

BREAK is a dedicated performance processor. BREAK ACTIVE enables the processor; MUTE removes it from the active path. NEW and FREEZE control break generation. DENS, VAR and LEN shape the break pattern. **PITCH**, **ROLL**, **REV** and **CHOP** are macro performance functions with amount and division controls. The modular signal chain runs through Source Insert, Level In, Bipolar A, LP/HP Filter, Resonance, Bipolar B, Drive and Level Out, followed by BPM-locked delay.



MIDI

The MIDI panel exposes independent **CLOCK IN**, **CLOCK OUT**, **NOTES OUT** and **CC OUT**. Clock In follows an external BPM. Clock Out sends the internal clock at **24 PPQN**. Notes and CC output can be enabled independently. Use RESCAN / CLOSE after connecting or changing a MIDI device.



RECORDING, RESET AND FEEDBACK

REC records the master output as WAV. For recovery from an abnormal state, use HARD RESET to restart the application core. The public project site provides the current stable APK, documentation, optional PayPal support and a GitHub Issues entry point for feedback and bug reports.

When reporting a problem, include the TTG version, Android version, phone/tablet model, what you were doing when the problem occurred, and whether the problem is reproducible.