



XIQ API – Permission Requirements and User Roles

18 July 2025 Version 25r4



Revisions History

Rev	Revision Summary	By Whom	Publish Date
25r2	25r2 updates	Tim	March 21, 2025
25r3	25r3 Updates	Tim	May 13, 2025
25r4	25r4 Updates	Tim	July 18, 2025



Table of Contents

18
19
19
19
19
19
20
20
20
20
20
21
21
21
21
21
22
22
22
22
23
23
23
23
24
24
24
24
24
25
25
25
25
25
25
25
26
26
26
26
26
26
27
27
27



HIQ.		27
	GET /hiq/context	27
	PUT /hig/context	27
	GET /hig/context/creating	28
	PUT /hig/context/creating	28
	GET /hig/context/reading	28
	PUT /hig/context/reading	28
	GET /hiq/organizations	
	POST /hig/organizations	
	DELETE /hiq/organizations/{id}	
	POST /hig/organizations/{id}/:rename	
	GET /hiq/status	30
Loca	ation	30
	POST /locations	
	POST /locations/:init	
	PUT /locations/{id}	
	DELETE /locations/{id}	
	GET /locations/building	
	POST /locations/building	
	GET /locations/building/{id}	
	PUT /locations/building/{id}	
	DELETE /locations/building/{id}	
	GET /locations/floor	
	POST /locations/floor	
	GET /locations/floor/{id}	
	PUT /locations/floor/{id}	
	DELETE /locations/floor/{id}	
	POST /locations/floorplan	
	POST /locations/import/ekahau	
	GET /locations/site	
	POST /locations/site	
	GET /locations/site/{id}	
	PUT /locations/site/{id}	
	DELETE /locations/site/{id}	
	GET /locations/tree	
	GET /locations/tree/devices	
	GET /locations/tree/maps	
Dav		
Dev		
	GET /devices	
	POST /devices/:advanced-onboard	
	POST /devices/:check-ownership	
	POST /devices/:cli	
	POST /devices/:delete	
	POST /devices/:manage	
	POST /devices/:onboard	
	POST /devices/:reboot	
	POST /devices/:unmanage	
	GET /devices/{id}	
	DELETE /devices/{id}	38



POST /devices/{id}/:cli	38
POST /devices/{id}/:manage	38
POST /devices/{id}/:reboot	39
POST /devices/{id}/:reset	39
POST /devices/{id}/:unmanage	39
GET /devices/{id}/alarms	39
POST /devices/{id}/bounce-port	39
GET /devices/{id}/client-monitor	40
PUT /devices/{id}/client-monitor	40
DELETE /devices/{id}/client-monitor	40
PUT /devices/{id}/description	40
GET /devices/{id}/ftm-settings	
POST /devices/{id}/config/ftm-settings	40
DELETE /devices/{id}/config/ftm-settings	41
GET /devices/{id}/gallery-image	
GET /devices/{id}/geolocation	
GET /devices/{id}/history/cpu-mem	41
PUT /devices/{id}/hostname	
GET /devices/{id}/ibeacon	
GET /devices/{id}/installation-report	
GET /devices/{id}/interfaces/wifi	42
GET /devices/{id}/iot	
POST /devices/{id}/iot/:disable	
POST /devices/{id}/iot/:enable	
GET /devices/{id}/location	
PUT /devices/{id}/location	
DELETE /devices/{id}/location	
POST /devices/{id}/monitor/:refresh	
GET /devices/{id}/monitor/refresh/status	
GET /devices/{id}/network-policy	
PUT /devices/{id}/network-policy	
DELETE /devices/{id}/network-policy	
GET /devices/{id}/radio-operating-mode	
PUT /devices/{id}/radio-operating-mode	
POST /devices/{id}/ssid/:override	
GET /devices/{id}/ssid/status	
POST /devices/{id}/ssid/status/:change	
POST /devices/{id}/thread/commissioner/:start	
POST /devices/{id}/thread/commissioner/:stop	
PUT /devices/{id}/thread/visible	
"Installer"	
POST /devices/client-monitor/:assign	
POST /devices/ client-monitor/:revoke	
POST /devices/client-monitor/:query	
POST /devices/country-code/:assign	
GET /devices/{id}/digital-twin	
PUT /devices/ibeacon	
POST /devices/location/:assign	
POST /devices/location/:query	
POST /devices/location/:revoke	
POST /devices/network-policy/:assign	48



	POST /devices/network-policy/:query	
	POST /devices/network-policy/:revoke	49
	GET /devices/network-policy/{policyId}	49
	POST /devices/os/:change	49
	GET /devices/radio-information	49
	PUT /devices/radius-proxy/:assign	49
	DELETE /devices/radius-proxy/:revoke	50
	POST /devices/rm-devices-connection-status	50
	POST /devices/rm-devices-metadata	50
	POST /devices/rm-devices-page	50
	POST /devices/rm-devices-page/export	51
	GET /devices/rm-devices-stack/{id}	51
	GET /devices/stats	51
Nο	etwork Policy	E2
ive	•	
	GET /network-policies	
	GET /network-policies/fid}	
	PUT /network-policies/{id}	
	DELETE /network-policies/{id}	
	GET /network-policies/{id}/ssids	
	POST /network-policies/{id}/ssids/:add	
	POST /network-policies/{id}/ssids/:remove	
	POST / Hetwork-policies/{lu}/ssius/.Terriove	
Cli	ient	53
	GET /clients/{id}	53
	GET /clients/active	53
	PUT /clients/alias	54
	GET /clients/active/count	54
	GET /clients/byMac/{client_mac}	54
	DELETE /clients/byMac/{client_mac}	54
	GET /clients/summary	54
	GET /clients/usage	55
Cli	ient - Details	55
CIII	GET /client-details/overview/chart-data/{id}	
	GET /client-details/overview/trialt-data/{id}	
	GET/Client-details/overview/info/{id}	
D3	360	56
	POST /d360/client/graph	56
	POST /d360/client/grid	56
	POST /d360/client/grid/metadata	56
	POST /d360/client/stats	57
	POST /d360/device/interfaces	57
	POST /d360/device/issues	57
	POST /d360/device/metadata	57
	POST /d360/device/stats	57
	POST /d360/overview/devices-summary	57
	POST /d360/ssid-metadata	57
	POST /d360/wireless/interfaces-graph	58
	POST /d360/wireless/interfaces-stats	58
	POST /d360/wireless/surrounding-aps	58



Dashboard	58
POST /dashboard/alerts	58
POST /dashboard/assets	58
POST /dashboard/clients	58
GET /dashboard/device-types	59
POST /dashboard/devices	59
POST /dashboard/export	59
POST /dashboard/sites-with-issues	59
POST /dashboard/usage-capacity	59
GET /dashboard/wireless/dashboard/critera	60
POST /dashboard/wireless/dashboard/critera	60
Dashboard Wireless Usage and Capacity	61
POST /dashboard/wireless/usage-capacity/excessive-packet-loss	65
POST /dashboard/wireless/usage-capacity/excessive-retries	65
POST /dashboard/wireless/usage-capacity/excessive-utilization	65
POST /dashboard/wireless/usage-capacity/export	66
POST /dashboard/wireless/usage-capacity/grid	66
Dashboard Wireless Client Health	66
POST /dashboard/wireless/client-health/connectivity-issues	66
POST /dashboard/wireless/client-health/export	
POST /dashboard/wireless/client-health/filter-metadata	67
POST /dashboard/wireless/client-health/frequency-distribution	67
POST /dashboard/wireless/client-health/grid	67
POST /dashboard/wireless/client-health/issue/association	67
POST /dashboard/wireless/client-health/issue/authentication	
POST /dashboard/wireless/client-health/issue/ipaddress	68
POST /dashboard/wireless/client-health/issue/roaming	68
POST /dashboard/wireless/client-health/roaming-issues	68
Dashboard Wireless Device Health	69
POST /dashboard/wireless/device-health/export	69
POST /dashboard/wireless/device-health/grid	
POST /dashboard/wireless/device-health/cpu-usage-issues	
POST /dashboard/wireless/device-health/memory-usage-issues	
POST /dashboard/wireless/device-health/poe-usage-issues	
GET /dashboard/wireless/device-health/reboot/summary	
POST /dashboard/wireless/device-health/summary	70
Geo View	70
GET /geo-view	
Application	71
GET /applications	
GET /applications/{id}/clients/top{n}	
GET /applications/top{n}	
Alert	72
GET /alert-policies	
POST /alert-policies	
GET /alert-policies/{id}	



	PUT /alert-policies/{id}	
	DELETE /alert-policies/{id}	
	GET /alert-policies/{id}/rules/{alert_rule_id}	73
	PUT /alert-policies/{id}}/rules/{alert_rule_id}	73
	POST /alert-policies/{id}}/rules/{alert_rule_id}/:disable	73
	PUT /alert-policies/{id}}/rules/{alert_rule_id}/:enable	73
	GET /alert-policies/available-sites	
	GET /alert-subscriptions/emails	74
	POST /alert-subscriptions/emails	74
	POST /alert-subscriptions/emails/:delete	74
	GET /alert-subscriptions/emails/{id}	
	PUT /alert-subscriptions/emails/{id}	
	DELETE /alert-subscriptions/emails/{id}	
	POST /alert-subscriptions/emails/{id}/:verify	
	GET /alert-subscriptions/servicenow	
	POST /alert-subscriptions/servicenow	
	POST /alert-subscriptions/servicenow/:delete	
	GET /alert-subscriptions/servicenow/{id}	
	PUT /alert-subscriptions/servicenow/{id}	
	PATCH /alert-subscriptions/servicenow/{id}	
	GET /alert-subscriptions/webhooks	
	POST /alert-subscriptions/webhooks	
	POST /alert-subscriptions/webhooks/:delete	
	GET /alert-subscriptions/webhooks /{id}	
	PUT /alert-subscriptions/webhooks /{id}	
	DELETE /alert-subscriptions/webhooks /{id}	
	GET /alerts	
	POST /alerts/:acknowledge	
	GET /alerts/count-by-{group}	
	POST /alerts/report	
	GET /alerts/reports/{id}	
Log		78
	GET /logs/accounting	78
	GET /logs/audit	79
	GET /logs/audit/full-descriptions/{id}	79
	POST /logs/audit/reports	79
	GET /logs/audit/reports/{id}	79
	GET /logs/auth	79
	GET /logs/credential	80
	GET /logs/email	80
	GET /logs/sms	80
Not	ification	80
	GET /subscriptions/webhook	81
	POST /subscriptions/webhook	81
	DELETE /subscriptions/webhook/:delete	
	PUT /subscriptions/webhook/{id}	81
	GET /subscriptions/webhook/export	81
Adn	ninistration	
	GET /acct-ani-token	97



	POST /acct-api-token	82
	DELETE /acct-api-token/:delete	82
	DELETE /acct-api-token/{id}	82
	PATCH /acct-api-token/{id}	82
	GET /acct-api-token/export	82
	GET /credential-distribution-groups	82
	POST /credential-distribution-groups	82
	DELETE /credential-distribution-groups	83
	PUT /credential-distribution-groups/{id}	83
	GET /third-party-api-connection	83
	PUT /third-party-api-connection	83
	DELETE /third-party-api-connection	83
NOS	5	83
Conf	figuration - Deployment	
	GET /deployments	
	POST /deployments	
	GET /deployments/{id}	
	PUT /deployments/{id}	
	DELETE /deployments/{id}	
	GET /deployments/{id}/status	
	POST /deployments/firmware-metadatas	
	GET /deployments/overview	
	GET /deployments/status	85
Conf	figuration - Basic	
	GET /vlan-profiles	
	POST /vlan-profiles	
	POST /vlan-profiles/:delete	
	GET /vlan-profiles/{id}	
	DELETE /vlan-profiles/{id}	
	PATCH /vlan-profiles/{id}	86
Conf	figuration - User Management	
	GET /email-templates	
	GET /endusers	
	POST /endusers	
	PUT /endusers/{id}	87
	DELETE /endusers/{id}	
	POST /endusers/{id}/:regenerate-password	
	GET /pcgs/key-based	
	POST /pcgs/key-based	
	DELETE /pcgs/key-based/network-policy-{policyId}	
	POST /pcgs/key-based/network-policy-{policyId}/:onboard	
	POST /pcgs/key-based/network-policy-{policyId}/keys/:email	
	POST /pcgs/key-based/network-policy-{policyId}/keys/:generate	
	GET /pcgs/key-based/network-policy-{policyId}/port-assignments	
	POST /pcgs/key-based/network-policy-{policyId}/port-assignments	
	GET /pcgs/key-based/network-policy-{policyId}/users	
	PUT /pcgs/key-based/network-policy-{policyId}/users	
	POST /pcgs/key-based/network-policy-{policyId}/users	90



DELETE /pcgs/key-based/network-policy-{policyId}/users	
GET /sms-templates	
GET /usergroups	90
POST /usergroups	
GET /usergroups/:unique	
PUT /usergroups/{id}	91
DELETE /usergroups/{id}	91
nfiguration - Policy	91
GET /ccgs	91
POST /ccgs	91
GET /ccgs/{id}	92
PUT /ccgs/{id}	92
DELETE /ccgs/{id}	92
GET /classification-rules	92
POST /classification-rules	92
GET /classification-rules/{id}	92
PUT /classification-rules/{id}	93
DELETE /classification-rules/{id}	93
GET /client-monitor-profiles	
POST /client-monitor-profile	
GET /client-monitor-profile/{id}	
PUT /client-monitor-profile/{id}	
DELETE /client-monitor-profile/{id}	
GET /hotspot-profiles	
POST /hotspot-profiles	
GET /hotspot-profiles/{id}	
PUT /hotspot-profiles/{id}	
DELETE /hotspot-profiles/{id}	
GET /hotspot-service-provider-profiles	
POST /hotspot-service-provider-profiles	
GET /hotspot-service-provider-profiles/{id}	
PUT /hotspot-service-provider-profiles/{id}	
DELETE /hotspot-service-provider-profiles/{id}	
GET /iot-profiles	
POST /iot-profiles	
GET /iot-profiles/{id}	
PUT /iot-profiles/{id}	
DELETE /iot-profiles/{id}	
GET /ip-firewall-policies	
POST /ip-firewall-policies	
GET /ip-firewall-policies/{id}	
PUT /ip-firewall-policies/{id}	
DELETE /ip-firewall-policies/{id}	
POST /ip-firewall-policies/{{id}}/:attach	
POST /ip-firewall-policies/{{id}}/:detach	
GET /I3-address-profiles	
POST /l3-address-profiles	
GET /I3-address-profiles/{id}	
PUT /l3-address-profiles/{id}	
DELETE /I3-address-profiles/{id}	



GET/mac-firewall-policies	
POST /mac-firewall-policies	
GET /mac-firewall-policies/{id}	99
PUT /mac-firewall-policies/{id}	99
DELETE /mac-firewall-policies/{id}	
POST /mac-firewall-policies/{{id}}/:attach	99
POST /mac-firewall-policies/{{id}}/:detach	100
GET /mac-object-profiles	100
POST /mac-object-profiles	100
GET /mac-object-profiles/{id}	100
PUT /mac-object-profiles/{id}	100
DELETE /mac-object-profiles/{id}	100
GET /radio-operating-modes/{id}	100
GET /radio-profiles	101
POST /radio-profiles	
GET /radio-profiles/{id}	
PUT /radio-profiles/{id}	
DELETE /radio-profiles/{id}	
GET /radio-profiles/channel-selection/{channel-selection-id}	
PUT /radio-profiles/channel-selection/{channel-selection-id}	
GET /radio-profiles/mac-ouis	
POST /radio-profiles/mac-ouis	
GET /radio-profiles/mac-ouis/{mac-oui-id}	
PUT /radio-profiles/mac-ouis/{mac-oui-id}	
DELETE /radio-profiles/mac-ouis/{mac-oui-id}	
GET /radio-profiles/miscellaneous/{radio-misc-id}	
PUT /radio-profiles/miscellaneous/{radio-misc-id}	
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
GET /radio-profiles/sensor-scan/{sensor-scan-id}	
PUT /radio-profiles/sensor-scan/{sensor-scan-id}	
GET /radio-profiles/wmm-qos/{radio-qos-id}	
PUT /radio-profiles/wmm-qos/{radio-qos-id}PUT /radio-profiles/wmm-qos/{radio-qos-id}	
GET /ssidsGET	
POST /ssids/{id}/:rename	
POST /ssids/{id}/client-monitor-profile/:attach	
POST /ssids/{id}/cwp/:attach	
POST /ssids/{id}/cwp/:disable	
POST /ssids/{id}/cwp/:disablePOST /ssids/{id}/cwp/:enable	
PUT /ssids/{id}/mode/dot1x	
PUT /ssids/{id}/mode/open	
PUT /ssids/{id}/mode/ppsk	
PUT /ssids/{id}/mode/psk	
PUT /ssids/{id}/mode/wep	
PUT /ssids/{id}/psk/password	
POST /ssids/{id}/radius-client-profile	
POST /ssids/{id}/radius-server-group/:attach	
POST /ssids/{id}/user-profile-assignment	
POST /ssids/{id}/user-profile/:attach	107



	GET /ssids/advanced-settings/{id}	107
	PUT /ssids/advanced-settings/{id}	108
	GET /user-profile-assignments	108
	POST /user-profile-assignments	108
	GET /user-profile-assignments/{id}	108
	DELETE /user-profile-assignments/{id}	108
	GET /user-profiles	108
	POST /user-profiles	109
	GET /user-profiles/{id}	109
	PUT /user-profiles/{id}	109
	DELETE /user-profiles/{id}	109
	POST /user-profiles/{id}/ip-firewall-policies/:attach	109
	POST /user-profiles/{id}/ip-firewall-policies/:detach	
	POST /user-profiles/{id}/mac-firewall-policies/:attach	
	POST /user-profiles/{id}/,ac-firewall-policies/:detach	110
r	onfiguration - Network	110
C	GET /network-services	
	POST /network-services	
	•	
	DELETE /network-services/{id}GET /tunnel-concentrators	
	POST /tunnel-concentrators	
	GET /tunnel-concentrators/{id}	
	PUT /tunnel-concentrators/{id}	
	DELETE /tunnel-concentrators/{id}	
Ca	onfiguration - Authentication	111
	GET /ad-servers	112
	GET /cwps	112
	GET /ldap-servers	112
	POST /ldap-servers	112
	GET /ldap-servers/{id}	112
	PUT /ldap-servers/{id}	113
	DELETE /ldap-servers/{id}	113
	GET /radius-client-objects	113
	POST /radius-client-objects	113
	GET /radius-client-objects/{id}	113
	PUT /radius-client-objects/{id}	114
	DELETE /radius-client-objects/{id}	114
	GET /radius-proxies	114
	POST /radius-proxies	114
	GET /radius-proxies/{id}	114
	PUT /radius-proxies/{id}	114
	DELETE /radius-proxies/{id}	115
	GET /radius-proxies/devices	115
	GET /radius-servers/external	
	POST /radius-servers/external	115
	GET /radius-servers/external/{id}	115
	PUT /radius-servers/external/{id}	116
	DELETE /radius-servers/external/{id}	116
	GET /radius-servers/internal	



POST /radius-servers/internal	
DELETE /radius-servers/internal	116
GET /radius-servers/internal/{id}	116
PUT /radius-servers/internal/{id}	117
DELETE /radius-servers/internal/{id}	117
GET /radius-servers/internal/devices	117
Configuration - Certificate	118
GET /certificates	
Copilot – Connectivity Experience	119
GET /copilot/connectivity/client-type	119
GET /copilot/connectivity/locations	119
GET /copilot/connectivity/wired/events	
GET /copilot/connectivity/wired/experience	
GET /copilot/connectivity/wired/hardware	120
GET /copilot/connectivity/wired/locations/hardware	
GET /copilot/connectivity/wired/quality-index	
GET /copilot/connectivity/wireless/apps	121
GET /copilot/connectivity/wireless/events	121
GET /copilot/connectivity/wireless/experience	121
GET /copilot/connectivity/wireless/locations/events	121
GET /copilot/connectivity/wireless/locations/performance	122
GET /copilot/connectivity/wireless/locations/quality-index	122
GET /copilot/connectivity/wireless/locations/time-to-connect	
GET /copilot/connectivity/wireless/performance	
GET /copilot/connectivity/wireless/quality-index	
GET /copilot/connectivity/wireless/time-to-connect	
GET /copilot/connectivity/wireless/views	123
Copilot – Anomalies	123
GET /copilot/anomalies/adverse-traffic/device-stats	123
GET / copilot/anomalies/adverse-traffic/packet-counts	123
GET /copilot/anomalies/anomalies-by-category	124
GET /copilot/anomalies/device-by-location	124
GET /copilot/anomalies/device-with-locations	124
PUT /copilot/anomalies/devices/feedback	124
PUT /copilot/anomalies/devices/update-action	124
GET /copilot/anomalies/dfs-recurrence/channel-stats	125
GET /copilot/anomalies/dfs-recurrence/count-stats	125
GET /copilot/anomalies/exclude-vlans	125
GET /copilot/anomalies/exclude-vlans-csv	125
GET /copilot/anomalies/exclude-vlans-list	125
GET /copilot/anomalies/hardware-health/client-list	125
GET /copilot/anomalies/hardware-health/cpu-mem-stats	126
GET /copilot/anomalies/hardware-health/stats	126
GET /copilot/anomalies/locations	126
GET /copilot/anomalies/missing-vlan/count	
GET /copilot/anomalies/notifications	
GET /copilot/anomalies/poeflapping/lldp-cdp-info	
GET /copilot/anomalies/poeflapping/stats	
GET /copilot/anomalies/poeflapping/trends	



	GET /copilot/anomalies/port-efficiency/speed-duplex-stats	127
	GET /copilot/anomalies/port-efficiency/stats	128
	GET /copilot/anomalies/wifi-capacity/client-list	128
	GET /copilot/anomalies/wifi-capacity/stats	128
	GET /copilot/anomalies/report	128
	PUT /copilot/anomalies/update-action	128
	PUT / copilot/anomalies/update-device-action	129
	GET /copilot/anomalies/wifi-efficiency/client-list	
	GET /copilot/anomalies/wifi-efficiency/stats	
	GET /copilot/assurance-scans/overview	
Pac	cket Capture	
	GET /packetcaptures	129
	POST /packetcaptures	130
	GET /packetcaptures/{id}	130
	Delete /packetcaptures/{id}	130
	POST /packetcaptures/{id}/:stop	
	POST /packetcaptures/{id}/:upload	131
	GET /packetcaptures/files	131
Net	twork Scorecard	131
	GET /network-scorecard/clientHealth/{id}	131
	GET /network-scorecard/deviceHealth/{id}	131
	GET /network-scorecard/networkHealth/{id}	132
	GET /network-scorecard/serviceHealth/{id}	132
	GET /network-scorecard/wifiHealth/{id}	132
Ess	entials - ExtremeLocation	
	GET /essentials/eloc/clients/{client-mac}/last-known-location	132
Mis	sc - Metadata – Country	132
	GET /countries	
	GET /countries/{countryAlpha2Code}/states	
	GET /countries/{id}/:validate	
Th.,	read	
ını	GET /thread/networks	
	GET /thread/routers	
	GET /thread/topology	
11	iversal Compute Platform	
Uni	GET /upc/{id}/engines/installed	
AF	C-endpoint	
	GET /afcserver	
	GET /afcserver/{id}	
	GET /afcserver/statistics/{id}	
	GET /afcserver/diagnostics/{sn}	
	GET /ap/afc/interface/details/{sn}	
	DOST / /	
	POST /ap/spectrum	
	GET /aps/afc/query	
		135 136



PUT /site/arc/schedule	136
POST /site/afc/schedule	
POST /site/spectrum	
RTTS-endpoint	
•	
·	
APPENDIX – A	
API call list based on Roles	137
•	
	143
	143
•	
··	
•	
APPENDIX – B	
3	
·	
	159
· · · · · ·	
·	
•	
<u> </u>	
·	
·	
·	
device:deploy	



device:manage	164
device:unmanage	164
device:reboot	164
device:reset	164
device:thread-commissioner	165
client	165
client:r	165
locations	165
locations:r	
network-policy	
policy:ssid	
network-policy:r	
network-scorecard	
network-scorecard:r	
ssid	
ssid:r	
pcg:key	
pcg:key:r	
subscriptions-webhook	
subscriptions-webhook:r	
CCg	
ccg:r	
log	
log:r	
CWp	
cwp:r	
sms-tmpl	
sms-tmpl:r	
class-rule	
class-rule:r	
user-profile	
user-profile:ruser-profile:r	
tunnel-concentrator	
tunnel-concentrator:	
radius-proxy	
radius-proxy:r	
radius-server	
radius-server:r	
usergroup	
usergroup:r	
deployment	
deployment:r	
ad-server	
ad-server:r	
alert	
alert:r	
alert-policies	
alert-policies:r	
alert-subscriptions	
alert-subscriptions:r	
app	174



application:r	
l3-address-profile	
l3-address-profile:r	174
vlan-profile	175
vlan-profile:r	175
enduser	175
enduser:r	175
radius-client-object	175
radius-client-object:r	175
ldap-serverldap-server	175
ldap-server:r	176
email-template	176
email-template:r	176
certificate	176
certificate:r	176
radio-profile	176
radio-profile:r	177
iot-profile	177
iot-profile:r	177
client-monitor-profile	177
client-monitor-profile:r	178
copilot-connectivity-wired:r	178
copilot-connectivity-wireless:r	178
copilot-anomalies:r	
licenses	179
licenses:r	179
copilot-assurance-scans:r	179
packet-capture	179
packet-capture:rpacket-capture:r	179
country	179
country:r	180
cas	180
cas:r	180
cas-policies	180
cas-policies:r	180
cas-metadata:r	180
cns-subscriptions	180
cns-subscriptions:r	
hotspot-profile	
hotspot-profile:r	
hotspot-service-provider-profile	
hotspot-service-provider-profile·r	181



Introduction

This document will list each category of XIQ APIs and all the API calls under those categories. Laid out as it is laid out on the api.extremecloudiq.com Swagger page. Under each category, the document will list the category permissions that can be used for the API calls in that category. Most categories have two permissions for the category. The first permission will match or be similar to the category's name. Example - **device** for the devices category. This permission will give access to all the GET, POST, PUT, PATCH, and DELETE API calls in that category. The second permission will be named the same as the first but followed with a :r. Example - **device**:r for the devices category. This permission will give access to only the GET API calls in that category.

This document will also list any additional permissions available for a particular API call. This would allow for a token to be created only to be able to perform a specific API call without having permission to do all API calls within the category. Example – **device:list** under the GET /devices API call. This would allow the token only to be able to view the list of devices using that API call but not be able to perform any of the other GET API calls in the devices category. This document also notes which Roles have access to each of the API call. In addition, there is Appendix - A that lists the different roles with a list of the API calls available to those roles by default as well as Appendix - B that lists the different permissions with a list of the API calls available with that permission.



Authentication

No default permissions for this category

POST /login

No permissions needed – This call uses basic auth to generate a token. This token will have access to APIs based on the user's role.

```
POST /logout
Permissions:
"logout" – revokes currently used token
Roles:
"Operator",
"Help Desk",
"Monitor",
"Administrator",
"Installer",
"Observer",
"Guest Management"
```

Authorization

Permissions:

"auth" – Permission for all API calls in the Authorization Section

"auth:r" - Permission for all GET API calls in the Authorization Section

POST /auth/apitoken

Permissions:

"token:new" – Permission to generate a new token.

NOTE: new tokens can only be granted permissions that the currently used token has.

Also included with "auth" Roles:
"Operator",
"Administrator",
"Monitor",

POST /auth/apitoken/:validate

Permissions:

"Installer"

No Specific permission - included with "auth"

Roles:

"Operator",

"Administrator"



GET /auth/apitoken/info Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" **GET /auth/permissions** Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" POST /auth/permissions/:check Permissions: "perm:check" - Allows token to check permissions needed for any API call Also included with "auth" Roles "Operator", "Administrator" Operation Permissions: "Iro" – Permission for all API calls in the Operation Section "lor:r" – Permission for all GET API calls in the Operation Section GET /operations/{operationId} Permissions: No Specific permission - included with "lro" and "lro:r" Roles: "Operator", "Administrator" DELETE /operations/{operationId} Permissions: No Specific permission - included with "lro" Roles:

"Operator",
"Administrator"



POST /operations/{operationId}/:cancel Permissions: No Specific permission - included with "lro" Roles: "Operator", "Administrator" Account "account" - Permission for all API calls in the Account Section "account:r" – Permission for all GET API calls in the Account Section POST /account/:switch Permissions: "account:switch" - Allows user to switch to external account Also included with "account" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" GET /account/external Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" GET /account/home Permissions: No Specific permission - included with "account" and "account:r" Roles:

"Operator",



```
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
GET /account/third-party-applications
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
GET /account/vhm/setting
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
PUT /account/vhm/setting/{id}
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/vhm/setting/status
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
```



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
GET /account/viq
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/:backup
Permissions:
"viq:backup" – Permission to backup the viq.
Also included with "account"
Roles:
"Operator",
"Administrator"
POST /account/viq/:reset
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/vig/default-device-password
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
```



```
"Observer",
"Application Operator",
"Guest Management"
PUT /account/viq/default-device-password
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/vig/download
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/export
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/viq/export-import-status
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/import
Permissions:
```



No Specific permission - included with "account" Roles: "Operator", "Administrator" POST /backup/history/:restore Permissions: NOT SET! Roles: NOT SET! POST /backup/history/delete Permissions: NOT SET! Roles: NOT SET! GET /backup/history/grid Permissions: NOT SET! Roles: NOT SET! PUT /backup/history/grid Permissions: NOT SET! Roles: NOT SET! **Users** Permissions: "user" - Permission for all API calls in the User Section "user:r" - Permission for all GET API calls in the User Section **GET /users** Permissions: No Specific permission - included with "user" and "user:r" Roles: "Operator", "Administrator", "Monitor" **POST /users**

Permissions:

No Specific permission - included with "user"



```
Roles:
"Administrator"
GET /users/{id}
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
"Monitor"
DELETE /users/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
PATCH /users/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
GET /users/external
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
"Monitor"
POST /users/external
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
GET /users/external/{id}
Permissions:
No Specific permission - included with "user" and "user:r"
Roles:
"Operator",
"Administrator",
```

"Monitor"



```
DELETE /users/external/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
PATCH /users/external/{id}
Permissions:
No Specific permission - included with "user"
Roles:
"Administrator"
GET /users/me
Permissions:
"user-me:r" – Permission to view details on yourself
Roles:
"Operator",
"Administrator",
"Monitor"
HIQ
Permissions:
"hiq" – Permission for all API calls in the HIQ Section
"hig:r" – Permission for all GET API calls in the HIQ Section
GET /hiq/context
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hig.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
```



```
"Operator",
"Administrator",
"Installer"
GET /hiq/context/creating
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hig/context/creating
Permissions:
"hig.ctx" – Permission for full control HIQ Context (HIQ account only).
"hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/context/reading
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hig" and "hig:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context/reading
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hig"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
Also included with "hig" and "hig:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:new" – Permission to create HIQ organization (HIQ account only).
Also included with "hig"
Roles:
"Operator",
"Administrator"
DELETE /hiq/organizations/{id}
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:del" – Permission to delete HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
POST /hiq/organizations/{id}/:rename
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:rename" – Permission to rename HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
```



GET /hiq/status Permissions: No Specific permission - included with "hiq" and "hiq:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" Location Permissions: "locations" – Permission for all API calls in the Location Section "locations:r" - Permission for all GET API calls in the Location Section **POST /locations** Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" POST /locations/:init Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" PUT /locations/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" **DELETE /locations/{id}**

Permissions:

No Specific permission - included with "locations"

Roles:



```
"Operator",
"Administrator"
"Installer"
GET /locations/building
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/building
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/building/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
```

Page 31 of 179



```
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/floor
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/floor
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/floor/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /locations/floor/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/floor/{id}
Permissions:
```

No Specific permission - included with "locations"

Page 32 of 179



```
Roles:
"Operator",
"Administrator"
"Installer"
POST /locations/floorplan
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
POST /locations/import/ekahau
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/site
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/site
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/site/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
```



```
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /locations/site/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/site/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/tree
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/devices
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/maps
```

Permissions:



```
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/wall/type
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/wall/type
Permissions:
No Specific permission - included with "locations
Roles:
"Operator",
"Administrator",
"Installer"
PUT /locations/wall/type/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /locations/wall/type/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator",
"Installer"
GET /locations/wall/type/references/{id}
Permissions:
```



```
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
Device
Permissions:
"device" – Permission for all API calls in the Device Section
"device:r" – Permission for all GET API calls in the Device Section
GET /devices
Permissions:
"device:list" – Permission to get the list of devices
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/:advanced-onboard
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:check-ownership
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:cli
Permissions:
"device:cli" – Permission to send cli commands to device(s)
Also included with "device"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:delete
Permissions:
"device:del" – Permission to delete device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:manage
Permissions:
"device:mange" – Permission to change management on device(s) to MANAGED
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:onboard
Permissions:
"device:new" – Permission to onboard device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:reboot
Permissions:
"device:reboot" – Permission to reboot device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:reset
Permissions:
No Specific permission - included with "device"
```

Roles:



```
"Operator",
"Administrator",
"Installer"
POST /devices/:unmanage
Permissions:
"device:mange" – Permission to change management on device(s) to UNMANAGED
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
DELETE /devices/{id}
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:cli
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:manage
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
```



"Installer" POST /devices/{id}/:reboot Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/:reset Permissions: "device:reset" - Permission to reset a device to factory default Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/:unmanage Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/alarms Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/bounce-port Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator",

"Installer"



GET /devices/{id}/client-monitor Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer PUT /devices/{id}/client-monitor Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" DELETE /devices/{id}/client-monitor Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" PUT /devices/{id}/description Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/ftm-settings Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/config/ftm-settings

Permissions:



```
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/config/ftm-settings
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/gallery-image
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/geolocation
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/history/cpu-mem
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/hostname
Permissions:
```



```
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/ibeacon
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/installation-report
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/interfaces/wifi
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/iot
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



POST /devices/{id}/iot/:disable Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/iot/:enable Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/location Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /devices/{id}/location Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" DELETE /devices/{id}/location Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" PUT /devices/{id}/mobileapp/gps Permissions: No Specific permission - included with "device"

Page 43 of 179



```
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/monitor/:refresh
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/monitor/refresh/status
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/network-policy
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/network-policy
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/network-policy
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
```



```
"Administrator",
"Installer"
GET /devices/{id}/radio-operating-mode
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/radio-operating-mode
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/ssid/:override
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/ssid/status
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/{id}/ssid/status/:change
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



POST /devices/{id}/thread/commissioner/:start Permissions: "device:thread-commissioner" – Permission to change thread commissioner to device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/thread/commissioner/:stop Permissions: "device:thread-commissioner" – Permission to change thread commissioner to device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer" PUT /devices/{id}/thread/visible Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/actions-support-metadata Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/anchor/assign Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/anchor/revoke Permissions: No Specific permission - included with "device"

Roles:



```
"Operator",
"Administrator",
"Installer"
POST /devices/client-monitor/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/ client-monitor/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/client-monitor/:query
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/country-code/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/digital-twin
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
PUT /devices/ibeacon
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:query
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/location/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:query
Permissions:
No Specific permission - included with "device"
```

Page 48 of 179



```
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/network-policy/{policyId}
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/os/:change
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/radio-information
Permissions:
"device:list" – Permission to get the list of devices
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/radius-proxy/:assign
Permissions:
No Specific permission - included with "device"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/radius-proxy/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/reports/{id}
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/rm-devices-connection-status
Permissions:
"'device:relaxed_read'" - Permission to read using the POST call
Also included with "device"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/rm-devices-metadata
Permissions:
"'device:relaxed_read'" - Permission to read using the POST call
Also included with "device"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
POST /devices/rm-devices-page
Permissions:
"'device:relaxed_read'" - Permission to read using the POST call
Also included with "device"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/rm-devices-page/export
Permissions:
"'device:relaxed_read'" - Permission to read using the POST call
Also included with "device"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/rm-devices-stack/{id}
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/stats
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
Network Policy
Permissions:
"network-policy" – Permission for all API calls in the Network Policy Section
"network-policy:r" – Permission for all GET API calls in the Network Policy Section
GET /network-policies
Permissions:
No Specific permission - included with "network-policy" and "network-policy:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /network-policies
Permissions:
No Specific permission - included with "network-policy"
Roles:
"Operator",
"Administrator"
GET /network-policies/{id}
Permissions:
No Specific permission - included with "network-policy" and "network-policy:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /network-policies/{id}
Permissions:
No Specific permission - included with "network-policy"
Roles:
"Operator",
"Administrator"
DELETE /network-policies/{id}
Permissions:
No Specific permission - included with "network-policy"
```

Roles:
"Operator",
"Administrator"



GET /network-policies/{id}/ssids Permissions: No Specific permission - included with "network-policy" and "network-policy:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /network-policies/{id}/ssids/:add Permissions: "policy:ssid" – SSID management on network-policy Also included with "network-policy" Roles: "Operator", "Administrator" POST /network-policies/{id}/ssids/:remove Permissions: "policy:ssid" – SSID management on network-policy Also included with "network-policy" Roles: "Operator", "Administrator" Client Permissions: "client" – Permission for all API calls in the Client Section "client:r" – Permission for all GET API calls in the Client Section GET /clients/{id} Permissions: No Specific permission - included with "client" and "client:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" **GET /clients/active** Permissions:

No Specific permission - included with "client" and "client:r"

Page 53 of 179



```
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /clients/alias
Permissions:
No Specific permission - included with "client"
Roles:
"Operator",
"Administrator"
GET /clients/active/count
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/byMac/{client_mac}
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
DELETE /clients/byMac/{client_mac}
Permissions:
No Specific permission - included with "client"
Roles:
"Operator",
"Administrator"
GET /clients/summary
```

Permissions:



```
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/usage
Permissions:
No Specific permission - included with "client" and "client:r"
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Client - Details
No default permissions for this category
GET /client-details/client-trail/connectivity-experience/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
GET /client-details/client-trail/roaming-trail/count/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
GET /client-details/client-trail/roaming-trail/grid/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
GET /client-details/overview/chart-data/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
```



GET /client-details/overview/info/{id}

Permissions: NOT SET! Roles: NOT SET!

Switch Inspector Panel

No default permissions for this category

POST /switch-inspector/diagnostics

Permissions: NOT SET! Roles: NOT SET!

D360

Permissions:

"d360:relaxed_read" – Permission for all API calls in the D360 Section

POST /d360/client/graph

Permissions:

No Specific permission - included with "d360:relaxed_read"

Roles:

"Operator",

"Administrator",

"Monitor",

"Installer",

"Observer"

POST /d360/client/grid

Permissions:

No Specific permission - included with "d360:relaxed read"

Roles:

"Operator",

"Administrator",

"Monitor",

"Installer",

"Observer"

POST /d360/client/grid/metadata

Permissions:

NOT SET!

Roles:



NOT SET!

POST /d360/client/stats

Permissions: NOT SET! Roles: NOT SET!

POST /d360/device/interfaces

Permissions: NOT SET! Roles: NOT SET!

POST /d360/device/issues

Permissions: NOT SET! Roles: NOT SET!

POST /d360/device/metadata

Permissions: NOT SET! Roles: NOT SET!

POST /d360/device/stats

Permissions: NOT SET! Roles: NOT SET!

POST /d360/overview/devices-summary

Permissions: NOT SET! Roles: NOT SET!

POST /d360/ssid-metadata

Permissions: NOT SET! Roles: NOT SET!



```
POST /d360/wireless/interfaces-graph
Permissions:
NOT SET!
Roles:
NOT SET!
POST /d360/wireless/interfaces-stats
Permissions:
NOT SET!
Roles:
NOT SET!
POST /d360/wireless/surrounding-aps
Permissions:
No Specific permission - included with "d360:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Dashboard
Permissions:
"dashboard:relaxed_read" - Permission for all API calls in the Dashboard Section
POST /dashboard/alerts
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/assets
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



POST /dashboard/clients Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" GET /dashboard/device-types Permissions: NOT SET! Roles: NOT SET! POST /dashboard/devices Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer". "Observer" POST /dashboard/export Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" GET /dashboard/reports/{id} Permissions: NOT SET! Roles: NOT SET!

POST /dashboard/sites-with-issues

Permissions:

No Specific permission - included with "dashboard:relaxed read" Roles:



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/usage-capacity
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /dashboard/wireless/dashboard/critera
Permissions:
NOT SET!
Roles:
NOT SET!
POST /dashboard/wireless/dashboard/critera
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Dashboard Wired Usage and Capacity
No default permissions for this category
POST /dashboard/wired/usage-capacity/grid
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
```

"Installer",
"Observer"



```
POST /dashboard/wired/usage-capacity/usage-utilization
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/usage-capacity/wired-congestion
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/usage-capacity/wired-throughput
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Dashboard Wired Client Health
No default permissions for this category
POST /dashboard/wired/client-health/grid
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

POST /dashboard/wired/client-health/ip-connectivity-issues

Permissions:

Page 61 of 179



```
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/client-health/port-congestion
Permissions:
No Specific permission - included with "dashboard:relaxed read"
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/client-health/port-errors
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/client-health/traffic-anomalies
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

Dashboard Wired Device Health

No default permissions for this category

POST /dashboard/wired/device-health/cpu-usage-issues

Permissions:

No Specific permission - included with "dashboard:relaxed_read" Roles:



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/fan-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/fan-status
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/grid
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/memory-usage-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
POST /dashboard/wired/device-health/poe-usage-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/poe-usage-status
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/psu-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/psu-status
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/summary
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/temperature-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wired/device-health/temperature-status
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Dashboard Wireless Usage and Capacity
No default permissions for this category
POST /dashboard/wireless/usage-capacity/excessive-packet-loss
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/usage-capacity/excessive-retries
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
```



"Observer"

```
POST /dashboard/wireless/usage-capacity/excessive-utilization
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/usage-capacity/export
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/usage-capacity/grid
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /dashboard/wireless/usage-capacity/reports/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
```

Dashboard Wireless Client Health

No default permissions for this category

POST /dashboard/wireless/client-health/connectivity-issues

Permissions:

No Specific permission - included with "dashboard:relaxed_read" Roles:



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/export
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/filter-metadata
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/frequency-distribution
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/grid
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
POST /dashboard/wireless/client-health/issue/association
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/issue/authentication
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/issue/ipaddress
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/client-health/issue/roaming
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /dashboard/wireless/client-health/reports/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
```



POST /dashboard/wireless/client-health/roaming-issues Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" **Dashboard Wireless Device Health** No default permissions for this category POST /dashboard/wireless/device-health/export Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /dashboard/wireless/device-health/grid Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /dashboard/wireless/device-health/cpu-usage-issues Permissions: No Specific permission - included with "dashboard:relaxed read" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer"

POST /dashboard/wireless/device-health/memory-usage-issues Permissions:



```
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /dashboard/wireless/device-health/poe-usage-issues
Permissions:
No Specific permission - included with "dashboard:relaxed read"
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /dashboard/wireless/device-health/reboot/summary
Permissions:
NOT SET!
Roles:
NOT SET!
GET /dashboard/wireless/device-health/reports/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
POST /dashboard/wireless/device-health/summary
Permissions:
No Specific permission - included with "dashboard:relaxed read"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Monitoring
No default permissions for this category
GET /monitoring/topology/client-trail/{{client_mac}}
Permissions:
```



NOT SET! Roles: NOT SET!

Geo View

No default permissions for this category

GET /geo-view Permissions:

NOT SET!

Roles:

NOT SET!

Application

```
Permissions:
```

"app" – Permission for all API calls in the Application Section

"application:r" – Permission for all GET API calls in the Application Section

GET /applications

Permissions:

No Specific permission - included with "app" and "application:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Observer"

GET /applications/{id}/clients/top{n}

Permissions:

No Specific permission - included with "app" and "application:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Observer"

GET /applications/top{n}

Permissions:

No Specific permission - included with "app" and "application:r"

Roles:

"Operator",

"Administrator",



```
"Monitor",
"Observer"
```

Alert

No default permissions for this category

```
GET /alert-policies
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" - Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /alert-policies
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
```



```
DELETE /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/{id}/rules/{alert_rule_id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}}/rules/{alert_rule_id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
POST /alert-policies/{id}}/rules/{alert_rule_id}/:disable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
PUT /alert-policies/{id}}/rules/{alert rule id}/:enable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/available-sites
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
```



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"Operator",
"Administrator"
POST /alert-subscriptions/emails/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
PUT /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
```



```
"Operator",
"Administrator"
DELETE /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/emails/{id}/:verify
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/servicenow
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/servicenow
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/servicenow/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/servicenow/{id}
Permissions:
```

"alert-subscriptions" – Permission for full control of alert subscriptions.

Page 75 of 179



```
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
PUT /alert-subscriptions/servicenow/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"Operator",
"Administrator"
PATCH /alert-subscriptions/servicenow/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/webhooks
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/webhooks
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/webhooks/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
```



GET /alert-subscriptions/webhooks /{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. "alert-subscriptions:r" – Permission to read alert subscriptions. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer PUT /alert-subscriptions/webhooks /{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" DELETE /alert-subscriptions/webhooks /{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" **GET /alerts** Permissions: "alert" – Permission for full control of alerts. "alert:r" – Permission to read alerts. Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" POST /alerts/:acknowledge Permissions: "alert" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator"



```
GET /alerts/count-by-{group}
Permissions:
"alert" – Permission for full control of alerts.
"alert:r" – Permission to read alerts.
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /alerts/report
Permissions:
"alert" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alerts/reports/{id}
Permissions:
"alert" – Permission for full control of alerts.
"alert:r" – Permission to read alerts.
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
Log
Permissions:
"log" – Permission for all API calls in the Log Section
"log:r" – Permission for all GET API calls in the Log Section
GET /logs/accounting
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
```



```
"Observer",
"Application Operator"
GET /logs/audit
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/audit/full-descriptions/{id}
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
POST /logs/audit/reports
Permissions:
No Specific permission - included with "log"
Roles:
"Operator",
"Administrator
GET /logs/audit/reports/{id}
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/auth
Permissions:
No Specific permission - included with "log" and "log:r"
```

Page 79 of 179



```
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/credential
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/email
Permissions:
No Specific permission - included with "log" and "log:r"
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/sms
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
```

Notification

[&]quot;subscriptions-webhook" – Permission for all API calls in the Notification Section



"subscriptions-webhook:r" - Permission for all GET API calls in the Notification Section

GET /subscriptions/webhook

Permissions:

No Specific permission - included with "subscriptions-webhook" and "subscriptionswebhook:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Observer"

POST /subscriptions/webhook

Permissions:

No Specific permission - included with "subscriptions-webhook"

Roles:

"Operator",

"Administrator"

DELETE /subscriptions/webhook/:delete

Permissions:

No Specific permission - included with "subscriptions-webhook"

Roles:

"Operator",

"Administrator"

PUT /subscriptions/webhook/{id}

Permissions:

No Specific permission - included with "subscriptions-webhook"

Roles:

"Operator",

"Administrator"

GET /subscriptions/webhook/export

Permissions:

No Specific permission - included with "subscriptions-webhook" and "subscriptionswebhook:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Observer"

Administration

No default permissions for this category



GET /acct-api-token

Permissions:

NOT SET!

Roles:

NOT SET!

POST /acct-api-token

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /acct-api-token/:delete

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /acct-api-token/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

PATCH /acct-api-token/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

GET /acct-api-token/export

Permissions:

NOT SET!

Roles:

NOT SET!

GET /credential-distribution-groups

Permissions:

NOT SET!

Roles:

NOT SET!

POST /credential-distribution-groups

Permissions:

NOT SET!



Roles: NOT SET!

DELETE /credential-distribution-groups

Permissions: NOT SET! Roles: NOT SET!

PUT /credential-distribution-groups/{id}

Permissions: NOT SET! Roles: NOT SET!

GET /third-party-api-connection

Permissions: NOT SET! Roles: NOT SET!

PUT /third-party-api-connection

Permissions: NOT SET! Roles: NOT SET!

DELETE /third-party-api-connection

Permissions: NOT SET! Roles: NOT SET!

NOS

No default permissions for this category

Configuration - Deployment

Permissions:

- "deployment" Permission for all API calls in the Configuration Deployment Section
- "deployment:r" Permission for all GET API calls in the Configuration Deployment Section

GET /deployments



```
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
POST /deployments
Permissions:
No Specific permission - included with "deployment"
Roles:
"Operator",
"Administrator"
GET /deployments/{id}
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
PUT /deployments/{id}
Permissions:
No Specific permission - included with "deployment"
Roles:
"Operator",
"Administrator
DELETE /deployments/{id}
Permissions:
No Specific permission - included with "deployment"
Roles:
"Operator",
"Administrator
GET /deployments/{id}/status
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
```

Page 84 of 179



```
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
POST /deployments/firmware-metadatas
Permissions:
No Specific permission - included with "deployment"
Roles:
"Operator",
"Administrator"
GET /deployments/overview
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
GET /deployments/status
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
```

Configuration - Basic

Permissions:

"vlan-profile" – Permission for all API calls in the Configuration - Basic Section



"vlan-profile:r" - Permission for all GET API calls in the Configuration - Basic Section

GET /vlan-profiles Permissions: No Specific permission - included with "vlan-profile" and "vlan-profile:r" Roles: "Operator", "Administrator", "Monitor", "Observer" POST /vlan-profiles Permissions: No Specific permission - included with "vlan-profile" Roles: "Operator", "Administrator" POST /vlan-profiles/:delete Permissions: No Specific permission - included with "vlan-profile" Roles: "Operator", "Administrator" GET /vlan-profiles/{id} Permissions: No Specific permission - included with "vlan-profile" and "vlan-profile:r" Roles: "Operator", "Administrator", "Monitor", "Observer" DELETE /vlan-profiles/{id} Permissions: No Specific permission - included with "vlan-profile" Roles: "Operator", "Administrator" PATCH /vlan-profiles/{id} Permissions: No Specific permission - included with "vlan-profile" Roles:

"Operator",



"Administrator"

Configuration - User Management

No default permissions for this category

```
GET /email-templates
Permissions:
"email-template" – Permission for full of email template.
"email-template:r" – Permission to read email templates
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /endusers
Permissions:
"enduser" – Permission for full control of end users.
"enduser:r" – Permission to read end users
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Observer",
"Guest Management"
POST /endusers
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator",
"Guest Management"
PUT /endusers/{id}
Permissions:
"enduser" – Permission for full control of end users.
Roles:
"Operator",
"Administrator",
"Guest Management"
```



DELETE /endusers/{id} Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" POST /endusers/{id}/:regenerate-password Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" GET /pcgs/key-based Permissions: "pcg:key" – Permission for full control of PCG key based. "pcg:key:r" – Permission to read PCG key based Roles: "Operator", "Administrator", "Monitor", "Observer" POST /pcgs/key-based Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" DELETE /pcgs/key-based/network-policy-{policyId} Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" POST /pcgs/key-based/network-policy-{policyId}/:onboard Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator",



"Administrator" POST /pcgs/key-based/network-policy-{policyId}/keys/:email Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" POST /pcgs/key-based/network-policy-{policyId}/keys/:generate Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" GET /pcgs/key-based/network-policy-{policyId}/port-assignments Permissions: "pcg:key" – Permission for full control of PCG key based. "pcg:key:r" – Permission to read PCG key based Roles: "Operator", "Administrator", "Monitor". "Observer" POST /pcgs/key-based/network-policy-{policyId}/port-assignments Permissions: "pcg:key" – Permission for full control of PCG key based. Roles: "Operator", "Administrator" GET /pcgs/key-based/network-policy-{policyId}/users Permissions: "pcg:key" – Permission for full control of PCG key based. "pcg:key:r" – Permission to read PCG key based Roles: "Operator", "Administrator",

PUT /pcgs/key-based/network-policy-{policyId}/users

Permissions:

"Monitor", "Observer"



```
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
DELETE /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
GET /sms-templates
Permissions:
"sms-tmpl" – Permission for full control of SMS template.
"sms-tmpl:r" – Permission to read SMS template
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /usergroups
Permissions:
"usergroup" – Permission for full control of user groups.
"usergroup:r" – Permission to read user groups
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Guest Management"
POST /usergroups
Permissions:
"usergroup" – Permission for full control of user groups.
Roles:
"Operator",
```



"Administrator" GET /usergroups/:unique Permissions: "usergroup" – Permission for full control of user groups. "usergroup:r" – Permission to read user groups Roles: "Operator", "Administrator", "Monitor", "Observer", "Guest Management" PUT /usergroups/{id} Permissions: "usergroup" – Permission for full control of user groups. Roles: "Operator", "Administrator" DELETE /usergroups/{id} Permissions: "usergroup" – Permission for full control of user groups. "Operator", "Administrator" **Configuration - Policy** No default permissions for this category **GET /ccgs** Permissions: "ccg" – Permission for full control of CCG. "ccg:r" – Permission to read CCG Roles: "Operator", "Administrator", "Monitor", "Observer" POST /ccgs Permissions: "ccg" – Permission for full control of CCG.

Roles:



```
"Operator",
"Administrator"
GET /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
"ccg:r" - Permission to read CCG
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
DELETE /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
GET /classification-rules
Permissions:
"class-rule" – Permission for full control of classification rule.
"class-rule:r" – Permission to read classification rule
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /classification-rules
Permissions:
"class-rule" – Permission for full control of classification rule.
Roles:
"Operator",
"Administrator"
GET /classification-rules/{id}
Permissions:
```



```
"class-rule" – Permission for full control of classification rule.
"class-rule:r" - Permission to read classification rule
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /classification-rules/{id}
Permissions:
"class-rule" – Permission for full control of classification rule.
Roles:
"Operator",
"Administrator"
DELETE /classification-rules/{id}
Permissions:
"class-rule" – Permission for full control of classification rule.
Roles:
"Operator",
"Administrator"
GET / client-monitor-profiles
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
"client-monitor-profile:r" – Permission to read client monitor profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Installer"
POST /client-monitor-profile
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
Roles:
"Operator",
"Administrator"
GET /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
"client-monitor-profile:r" – Permission to read client monitor profiles
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Installer"
PUT /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
Roles:
"Operator",
"Administrator"
DELETE /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
"Operator",
"Administrator"
GET /hotspot-profiles
Permissions:
"hotspot-profile" – Permission for full control of hotspot-profiles.
"hotspot-profile:r" – Permission to read hotspot-profiles.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /hotspot-profiles
Permissions:
"hotspot-profile" – Permission for full control of hotspot-profiles.
Roles:
"Operator",
"Administrator"
GET /hotspot-profiles/{id}
Permissions:
"hotspot-profile" – Permission for full control of hotspot-profiles.
"hotspot-profile:r" – Permission to read hotspot-profiles.
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
PUT /hotspot-profiles/{id}
Permissions:
"hotspot-profile" – Permission for full control of hotspot-profiles.
Roles:
"Operator",
"Administrator"
DELETE /hotspot-profiles/{id}
Permissions:
"hotspot-profile" – Permission for full control of hotspot-profiles.
Roles:
"Operator",
"Administrator"
GET /hotspot-service-provider-profiles
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
"hotspot-service-provider-profile:r" – Permission to read hotspot-service-provider-profiles.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /hotspot-service-provider-profiles
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
Roles:
"Operator",
"Administrator"
GET /hotspot-service-provider-profiles/{id}
Permissions:
"hotspot-service-provider-profile" - Permission for full control of hotspot-service-provider-
profiles.
"hotspot-service-provider-profile:r" – Permission to read hotspot-service-provider-profiles.
Roles:
"Operator",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hotspot-service-provider-profiles/{id}
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
Roles:
"Operator",
"Administrator"
DELETE /hotspot-service-provider-profiles/{id}
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
Roles:
"Operator",
"Administrator"
GET /iot-profiles
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
"iot-profile:r" – Permission to read iot-profiles.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /iot-profiles
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
Roles:
"Operator",
"Administrator"
GET /iot-profiles/{id}
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
"iot-profile:r" – Permission to read iot-profiles.
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
PUT /iot-profiles/{id}
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
Roles:
"Operator",
"Administrator"
DELETE /iot-profiles/{id}
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
Roles:
"Operator",
"Administrator"
GET /ip-firewall-policies
Permissions:
NOT SET!
Roles:
NOT SET!
POST /ip-firewall-policies
Permissions:
NOT SET!
Roles:
NOT SET!
GET /ip-firewall-policies/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
PUT /ip-firewall-policies/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
DELETE /ip-firewall-policies/{id}
```



```
NOT SET!
Roles:
NOT SET!
POST /ip-firewall-policies/{{id}}/:attach
Permissions:
NOT SET!
Roles:
NOT SET!
POST /ip-firewall-policies/{{id}}/:detach
Permissions:
NOT SET!
Roles:
NOT SET!
GET /I3-address-profiles
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
"13-address-profile:r" – Permission to read L3 address profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /I3-address-profiles
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
Roles:
"Operator",
"Administrator"
GET /I3-address-profiles/{id}
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
"13-address-profile:r" – Permission to read L3 address profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /I3-address-profiles/{id}
Permissions:
```



"I3-address-profile" – Permission for full control of L3 address profile. Roles: "Operator", "Administrator" DELETE /I3-address-profiles/{id} Permissions: "I3-address-profile" – Permission for full control of L3 address profile. Roles: "Operator", "Administrator" GET /mac-firewall-policies Permissions: NOT SET! Roles: NOT SET! POST /mac-firewall-policies Permissions: NOT SET! Roles: NOT SET! GET /mac-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! PUT /mac-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! DELETE /mac-firewall-policies/{id}

Permissions: NOT SET! Roles:

NOT SET!

POST /mac-firewall-policies/{{id}}/:attach

Permissions: NOT SET!



Roles: NOT SET! POST /mac-firewall-policies/{{id}}/:detach Permissions: NOT SET! Roles: NOT SET! GET /mac-object-profiles Permissions: NOT SET! Roles: NOT SET! POST /mac-object-profiles Permissions: NOT SET! Roles: NOT SET! GET /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! PUT /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! DELETE /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! GET /radio-operating-modes/{id}

Permissions: NOT SET! Roles: NOT SET!



GET /radio-profiles Permissions: "radio-profile" – Permission for full control of radio profiles "radio-porfile:r" – Permission to read radio profiles Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /radio-profiles Permissions: "radio-profile" – Permission for full control of radio profiles Roles: "Operator", "Administrator" GET /radio-profiles/{id} Permissions: "radio-profile" – Permission for full control of radio profiles "radio-porfile:r" – Permission to read radio profiles Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /radio-profiles/{id} Permissions: "radio-profile" – Permission for full control of radio profiles Roles: "Operator", "Administrator", DELETE /radio-profiles/{id} Permissions: "radio-profile" – Permission for full control of radio profiles Roles: "Operator", "Administrator" GET /radio-profiles/channel-selection/{channel-selection-id}



```
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/channel-selection/{channel-selection-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radio-profiles/mac-ouis
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
PUT /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
DELETE /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
```



```
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" - Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /ssids
Permissions:
"ssid" – Permission for full control of SSID
"ssid:r" - Permission to read SSID
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /ssids/{id}/:rename
Permissions:
"ssid" - Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/client-monitor-profile/:attach
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:attach
Permissions:
"ssid" – Permission for full control of SSID
Roles:
```



```
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:disable
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:enable
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/dot1x
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/open
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/ppsk
Permissions:
"ssid" - Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/psk
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
```

"Administrator"



PUT /ssids/{id}/mode/wep Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" PUT /ssids/{id}/psk/password Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/radius-client-profile Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/radius-server-group/:attach Attach radius server group to an SSID Permissions: "ssid" - Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/user-profile-assignment Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/user-profile/:attach Permissions: "ssid" – Permission for full control of SSID Roles: "Operator",

GET /ssids/advanced-settings/{id}

Permissions:

"Administrator"



```
"ssid" – Permission for full control of SSID
"ssid:r" - Permission to read SSID
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /ssids/advanced-settings/{id}
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
GET /user-profile-assignments
Permissions:
NOT SET!
Roles:
NOT SET!
POST /user-profile-assignments
Permissions:
NOT SET!
Roles:
NOT SET!
GET /user-profile-assignments/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
DELETE /user-profile-assignments/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
GET /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
```



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
GET /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
DELETE /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
POST /user-profiles/{id}/ip-firewall-policies/:attach
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
```



POST /user-profiles/{id}/ip-firewall-policies/:detach

Permissions:

"user-profile" – Permission for full control of user profile

Roles:

"Operator",

"Administrator"

POST /user-profiles/{id}/mac-firewall-policies/:attach

Permissions:

"user-profile" – Permission for full control of user profile

Roles:

"Operator",

"Administrator"

POST /user-profiles/{id}/,ac-firewall-policies/:detach

Permissions:

"user-profile" – Permission for full control of user profile

Roles:

"Operator",

"Administrator"

Configuration - Network

No default permissions for this category

GET / network-services

Permissions:

NOT SET!

Roles:

NOT SET!

POST /network-services

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /network-services/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

GET /tunnel-concentrators

Permissions:



```
"tunnel-concentrator" - Permission for full control of tunnel concentrator
"tunnel-concentrator:r" - Permission to read tunnel concentrator
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /tunnel-concentrators
Permissions:
"tunnel-concentrator" - Permission for full control of tunnel concentrator
Roles:
"Operator",
"Administrator"
GET /tunnel-concentrators/{id}
Permissions:
"tunnel-concentrator" - Permission for full control of tunnel concentrator
"tunnel-concentrator:r" - Permission to read tunnel concentrator
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /tunnel-concentrators/{id}
Permissions:
"tunnel-concentrator" - Permission for full control of tunnel concentrator
Roles:
"Operator",
"Administrator"
DELETE /tunnel-concentrators/{id}
Permissions:
"tunnel-concentrator" – Permission for full control of tunnel concentrator
Roles:
"Operator",
"Administrator"
```

Configuration - Authentication

No default permissions for this category



```
GET /ad-servers
Permissions:
"ad-server" – Permission for full control of AD server
"ad-server:r" – Permission to read AD server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /cwps
Permissions:
"cwp" – Permission for full control of captive web portals
"cwp:r" – Permission to read captive web portals
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /Idap-servers
Permissions:
"Idap-server" – Permission for full control of LDAP server
"Idap-server:r" – Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /Idap-servers
Permissions:
"Idap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /ldap-servers/{id}
Permissions:
"ldap-server" – Permission for full control of LDAP server
"Idap-server:r" – Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Observer"
PUT /ldap-servers/{id}
Permissions:
"Idap-server" - Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
DELETE /ldap-servers/{id}
Permissions:
"Idap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /radius-client-objects
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-client-objects
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



```
PUT /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
DELETE /radius-client-objects/{id}
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-proxies
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /radius-proxies
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
GET /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" - Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
```

Roles:



```
"Operator",
"Administrator"
DELETE /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
GET /radius-proxies/devices
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /radius-servers/external
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" – Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-servers/external
Permissions:
"radius-server" - Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
PUT /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
DELETE /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
DELETE /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
```

Page 116 of 179



```
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor".
"Installer",
"Observer"
PUT /radius-servers/internal/{id}
Permissions:
"radius-server" - Permission for full control of RADIUS server
"Operator",
"Administrator"
DELETE /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal/devices
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /radsec-proxies
Permissions:
NOT SET!
Roles:
NOT SET!
POST /radsec-proxies
Permissions:
NOT SET!
Roles:
NOT SET!
```



GET /radsec-proxies/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

PUT /radsec-proxies/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /radsec-proxies/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

Configuration - Certificate

Permissions:

- "certificate" Permission for all API calls in the Configuration Certificate Section
- "certificate:r" Permission for all GET API calls in the Configuration Certificate Section

GET /certificate-bundle

Permissions:

NOT SET!

Roles:

NOT SET!

POST /certificate-bundle

Permissions:

NOT SET!

Roles:

NOT SET!

GET /certificate-bundle/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

PUT /certificate-bundle/{id}

Permissions:

NOT SET!

Roles:



NOT SET!

DELETE /certificate-bundle/{id} Permissions: NOT SET! Roles: NOT SET! **GET /certificates** Permissions: No Specific permission - included with "certificate" and "certificate:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" DELETE /certificates/{id} Permissions: No Specific permission - included with "certificate" Roles: "Operator", "Administrator POST /certificates/import Permissions:

No Specific permission - included with "certificate"

Roles:

"Operator",

"Administrator

Copilot – Connectivity Experience

No default permissions for this category

GET /copilot/connectivity/client-type

Permissions:

NOT SET!

Roles:

NOT SET!

GET /copilot/connectivity/locations

Permissions:

NOT SET!

Roles:



NOT SET!

```
GET /copilot/connectivity/wired/events
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/experience
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/hardware
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/locations/hardware
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/quality-index
Permissions:
"copilot-connectivity-wired:r" - Permission to read copilot wired connectivity
Roles:
```



```
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/apps
Permissions:
"copilot-connectivity-wireless:r" - Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/experience
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
```



GET /copilot/connectivity/wireless/locations/performance Permissions: "copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wireless/locations/quality-index Permissions: "copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wireless/locations/time-to-connect Permissions: "copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wireless/performance Permissions: "copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wireless/quality-index Permissions: "copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity Roles: "Operator", "Monitor",



```
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/time-to-connect
Permissions:
"copilot-connectivity-wireless:r" - Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/views
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
Copilot – Anomalies
Permissions:
"copilot-anomalies:r" - Permission for all GET API calls in the Copilot Anomalies Section
GET /copilot/anomalies/adverse-traffic/device-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET / copilot/anomalies/adverse-traffic/packet-counts
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
```



```
"Observer",
"Guest Management"
GET /copilot/anomalies/anomalies-by-category
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/device-by-location
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/device-with-locations
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
PUT /copilot/anomalies/devices/feedback
Permissions:
NOT SET!
Roles:
NOT SET!
PUT /copilot/anomalies/devices/update-action
Permissions:
NOT SET!
Roles:
NOT SET!
```



```
GET /copilot/anomalies/dfs-recurrence/channel-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/dfs-recurrence/count-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/exclude-vlans
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/exclude-vlans-csv
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/exclude-vlans-list
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/hardware-health/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
```



"Guest Management"

Roles:

```
GET /copilot/anomalies/hardware-health/cpu-mem-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/hardware-health/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/locations
Permissions:
"copilot-anomalies:r" – Permission to read copilot anomalies
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/missing-vlan/count
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/notifications
Permissions:
No Specific permission - included with "copilot-anomalies:r"
```

Page 126 of 179



```
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/lldp-cdp-info
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/trends
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/port-efficiency/speed-duplex-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
```



GET /copilot/anomalies/port-efficiency/stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/wifi-capacity/client-list Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/wifi-capacity/stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/report Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" PUT /copilot/anomalies/update-action Permissions: NOT SET! Roles: NOT SET!



```
PUT / copilot/anomalies/update-device-action
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/wifi-efficiency/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-efficiency/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/assurance-scans/overview
Permissions:
"copilot-assurance-scans:r" – Permission to read access to Copilot Assurance scan
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
Packet Capture
Permissions:
"packet-capture" – Permission for all API calls in the Packet Capture Section
"packet-capture:r" – Permission for all GET API calls in the Packet Capture Section
```

Permissions:
No Specific permission - includ

GET /packetcaptures

No Specific permission - included with "packet-capture" and "packet-capture:r" Roles:



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
POST /packetcaptures
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
DELETE /packetcaptures
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
Delete /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:stop
Permissions:
No Specific permission - included with "packet-capture"
Roles:
```



```
"Operator",
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:upload
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/files
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
Network Scorecard
Permissions:
"network-scorecard" – Permission for all API calls in the Network Scorecard Section
"network-scorecard:r" – Permission for all GET API calls in the Network Scorecard Section
GET /network-scorecard/clientHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/deviceHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
GET /network-scorecard/networkHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/serviceHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/wifiHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Essentials - ExtremeLocation
```

No default permissions for this category

GET /essentials/eloc/clients/{client-mac}/last-known-location

Permissions:

NOT SET!

Roles:

NOT SET!

Misc - Metadata – Country

Permissions:

"country" – Permission for all API calls in the Metadata-Country Section



"country:r" - Permission for all GET API calls in the Metadata-Country Section

```
GET /countries
Permissions:
No Specific permission - included with "country" and "country:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
GET /countries/{countryAlpha2Code}/states
Permissions:
No Specific permission - included with "country" and "country:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
GET /countries/{id}/:validate
Permissions:
No Specific permission - included with "country" and "country:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
Thread
No default permissions for this category
GET /thread/networks
Permissions:
NOT SET!
Roles:
```

NOT SET!



GET /thread/routers

Permissions:

NOT SET!

Roles:

NOT SET!

GET /thread/topology

Permissions:

NOT SET!

Roles:

NOT SET!

Universal Compute Platform

No default permissions for this category

GET /upc/{id}/engines/installed

Permissions:

NOT SET!

Roles:

NOT SET!

AFC-endpoint

No default permissions for this category

POST /afc/aps/reportFtm

Permissions:

NOT SET!

Roles:

NOT SET!

GET /afc/mobileapp/apcandidates

Permissions:

NOT SET!

Roles:

NOT SET!

GET /afc/recalculateSite/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

GET /afcserver

Permissions:



NOT SET! Roles:

NOT SET!

GET /afcserver/{id}

Permissions: NOT SET!

Roles:

NOT SET!

GET /afcserver/statistics/{id}

Permissions: NOT SET!

Roles:

NOT SET!

GET /afcserver/diagnostics/{sn}

Permissions: NOT SET!

Roles:

NOT SET!

GET /ap/afc/floorReport/{deviceId}

Permissions:

NOT SET!

Roles:

NOT SET!

GET /ap/afc/interface/details/{sn}

Permissions:

NOT SET!

Roles:

NOT SET!

POST /ap/spectrum

Permissions:

NOT SET!

Roles:

NOT SET!

GET /aps/afc/query

Permissions:

NOT SET!

Roles:

NOT SET!



POST /aps/afc/update

Permissions:

NOT SET!

Roles:

NOT SET!

GET /floor/afc/details

Permissions:

NOT SET!

Roles:

NOT SET!

PUT /floor/afc/details

Permissions:

NOT SET!

Roles:

NOT SET!

POST /floor/afc/details

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /floor/afc/details/{id}

Permissions:

NOT SET!

Roles:

NOT SET!

GET /site/afc/schedule

Permissions:

NOT SET!

Roles:

NOT SET!

PUT /site/afc/schedule

Permissions:

NOT SET!

Roles:

NOT SET!

POST /site/afc/schedule

Permissions:

NOT SET!



Roles: NOT SET!

POST /site/spectrum

Permissions: NOT SET! Roles:

NOT SET!

RTTS-endpoint

No default permissions for this category

POST /rtts-endpoint

Permissions:

NOT SET!

Roles:

NOT SET!

POST /rtts-endpoint

Permissions:

NOT SET!

Delete:

NOT SET!

APPENDIX - A

API call list based on Roles

Administrator

All available API calls

Operator

All available API calls except for the following:

POST /users

DELETE /users/{id}

PATCH /users/{id}

POST /users/external

DELETE /users/external/{id}

PATCH /users/external/{id}

Monitor

POST /logout

POST /auth/apitoken

GET /auth/apitoken/info

GET /auth/permissions



- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting
- GET /account/vhm/status
- GET /account/viq
- GET /account/viq/default-device-password
- GET /account/viq/download
- GET /account/viq/export-import-status
- GET /users
- GET /users/{id}
- GET /users/external
- GET /users/external/{id}
- GET /users/me
- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /hiq/organizations
- GET /hiq/status
- GET /locations/building
- GET /locations/building/{id}
- GET /locations/floor
- GET /locations/floor/{id}
- GET /locations/site
- GET /locations/site/{id}
- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps
- GET /locations/wall/type
- GET /locations/wall/type/references/{id}
- GET /devices
- GET /devices/{id}
- GET /devices/{id}/alarms
- GET /devices/{id}/client-monitor
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/gallery-image
- GET /devices/{id}/geolocation
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/ibeacon
- GET /devices/{id}/installation-report
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/iot



GET /devices/{id}/location

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/network-policy

GET /devices/{id}/radio-operating-mode

GET /devices/{id}/ssid/status

GET /devices/digital-twin

GET /devices/network-policy/{policyId}

GET /devices/radio-information

GET /devices/reports/{id}

POST /devices/rm-devices-connection-status

POST /devices/rm-devices-metadata

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

GET /devices/rm-devices-stack/{stackId}

GET /devices/stats

GET /network-policies

GET /network-policies/{id}

GET /network-policies/{id}/ssids

GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

POST /d360/client/graph

POST /d360/client/grid

POST /d360/wireless/surrounding-aps

POST /dashboard/alerts

POST /dashboard/assets

POST /dashboard/clients

POST /dashboard/devices

POST /dashboard/export

POST /dashboard/sites-with-issues

POST /dashboard/usage-capacity

POST /dashboard/wired/usage-capacity/grid

POST /dashboard/wired/usage-capacity/usage-utilization

POST /dashboard/wired/usage-capacity/wired-congestion

POST /dashboard/wired/usage-capacity/wired-throughput

POST /dashboard/wired/client-health/grid

POST /dashboard/wired/client-health/ip-connectivity-issues

POST /dashboard/wired/client-health/port-congestion

POST /dashboard/wired/client-health/port-errors

POST /dashboard/wired/client-health/traffic-anomalies

POST /dashboard/wired/device-health/cpu-usage-issues

POST /dashboard/wired/device-health/fan-issues



POST /dashboard/wired/device-health/fan-status

POST /dashboard/wired/device-health/grid

POST /dashboard/wired/device-health/memory-usage-issues

POST /dashboard/wired/device-health/poe-usage-issues

POST /dashboard/wired/device-health/poe-usage-status

POST /dashboard/wired/device-health/psu-issues

POST /dashboard/wired/device-health/psu-status

POST /dashboard/wired/device-health/summary

POST /dashboard/wired/device-health/temperature-issues

POST /dashboard/wired/device-health/temperature-status

POST /dashboard/wireless/usage-capacity/excessive-packet-loss

POST /dashboard/wireless/usage-capacity/excessive-retries

POST /dashboard/wireless/usage-capacity/excessive-utilization

POST /dashboard/wireless/usage-capacity/export

POST /dashboard/wireless/usage-capacity/grid

POST /dashboard/wireless/client-health/connectivity-issues

POST /dashboard/wireless/client-health/export

POST /dashboard/wireless/client-health/filter-metadata

POST /dashboard/wireless/client-health/frequency-distribution

POST /dashboard/wireless/client-health/grid

POST /dashboard/wireless/client-health/issue/association

POST /dashboard/wireless/client-health/issue/authentication

POST /dashboard/wireless/client-health/issue/ipaddress

POST /dashboard/wireless/client-health/issue/roaming

POST /dashboard/wireless/client-health/roaming-issues

POST /dashboard/wireless/device-health/export

POST /dashboard/wireless/device-health/grid

POST /dashboard/wireless/device-health/issues/cpu-usage-issues

POST /dashboard/wireless/device-health/issues/memory-usage-issues

POST /dashboard/wireless/device-health/issues/poe-usage-issues

POST /dashboard/wireless/device-health/summary

GET /applications

GET /applications/{id}/clients/top{n}

GET /applications/top {n}

GET /alert-policies

GET /alert-policies/{id}

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/available-sites

GET /alert-subscriptions/emails

GET /alert-subscriptions/emails/{id}

GET /alert-subscriptions/servicenow

GET /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/webhooks

GET /alert-subscriptions/webhooks/{id}

GET /alerts



- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/full-descriptions/{id}
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /subscriptions/webhook
- GET /subscriptions/webhook/export
- GET /deployments
- GET /deployments/{deploymentId}
- GET /deployments/{deploymentId}/status
- GET /deployments/overview
- GET /deployments/status
- GET /vlan-profiles
- GET /vlan-profiles/{id}
- GET /email-templates
- GET /endusers
- GET /pcgs/key-based
- GET /pcgs/key-based/network-policy-{policyId}/port-assignments
- GET /pcgs/key-based/network-policy-{policyId}/users
- GET /sms-templates
- GET /usergroups
- GET /usergroups/:unique
- GET /ccgs
- GET /ccgs/{id}
- GET /classification-rules
- GET /classification-rules/{id}
- GET /client-monitor-profiles
- GET /client-monitor-profiles/{id}
- GET /hotspot-profiles
- GET /hotspot-profiles/{id}
- GET /hotspot-service-provider-profiles
- GET /hotspot-service-provider-profiles/{id}
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /13-address-profiles
- GET /13-address-profiles/{id}
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis



- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}
- GET /user-profiles
- GET /user-profiles/{id}
- GET /tunnel-concentrators
- GET /tunnel-concentrators/{id}
- GET /ad-servers
- GET /cwps
- GET /ldap-servers
- GET /ldap-servers/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-proxies
- GET /radius-proxies/{id}
- GET /radius-proxies/devices
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts



- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/excluded-vlans-list
- GET /copilot/anomalies/hardware-health/client-list
- GET /copilot/anomalies/hardware-health/cpu-mem-stats
- GET /copilot/anomalies/hardware-health/stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/missing-vlan/count
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/lldp-cdp-info
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/poeflapping/trends
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats
- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /network-scorecard/clientHealth/{locationId}
- GET /network-scorecard/deviceHealth/{locationId}
- GET /network-scorecard/networkHealth/{locationId}
- GET /network-scorecard/servicesHealth/{locationId}
- GET /network-scorecard/wifiHealth/{locationId}
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

Installer

- POST /logout
- POST /auth/apitoken
- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting



GET /account/vhm/status

GET /account/viq

GET /account/viq/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /users/me

GET /hiq/context

PUT /hiq/context

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

POST /locations

POST /locations/:init

PUT /locations/{id}

DELETE /locations/{id}

GET /locations/building

POST /locations/building

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

GET /locations/floor

POST /locations/floor

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

POST /locations/floorplan

POST /locations/import/ekahau

GET /locations/site

POST /locations/site

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/tree

GET /locations/tree/devices

GET /locations/tree/maps

GET /locations/wall/type

POST /locations/wall/type

PUT /locations/wall/type/{id}

DELETE /locations/wall/type/{id}

GET /locations/wall/type/references/{id}

GET /devices

POST /devices/:advanced-onboard



POST /devices/:check-ownership

POST /devices/:cli

POST /devices/:delete

POST /devices/:manage

POST /devices/:onboard

POST /devices/:reboot

POST /devices/:reset

POST /devices/:unmanage

GET /devices/{id}

DELETE /devices/{id}

POST /devices/{id}/:cli

POST /devices/{id}/:manage

POST /devices/{id}/:reboot

POST /devices/{id}/:reset

POST /devices/{id}/:unmanage

GET /devices/{id}/alarms

POST /devices/{id}/bounce-port

GET /devices/{id}/client-monitor

PUT /devices/{id}/client-monitor

DELETE /devices/{id}/client-monitor

PUT /devices/{id}/description

GET /devices/{id}/ftm-settings

PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings

GET /devices/{id}/gallery-image

GET /devices/{id}/geolocation

GET /devices/{id}/history/cpu-mem

PUT /devices/{id}/hostname

GET /devices/{id}/ibeacon

GET /devices/{id}/installation-report

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/iot

POST /devices/{id}/iot/:disable

POST /devices/{id}/iot/:enable

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

PUT /devices/{id}/mobileapp/gps

POST /devices/{id}/monitor/:refresh

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

GET /devices/{id}/radio-operating-mode

PUT /devices/{id}/radio-operating-mode



POST /devices/{id}/ssid/:override

GET /devices/{id}/ssid/status

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/thread/commissioner/:stop

PUT /devices/{id}/visible

POST /devices/actions-support-metadata

POST /devices/anchor/assign

POST /devices/anchor/revoke

POST /devices/client-monitor/:assign

POST /devices/client-monitor/:revoke

POST /devices/client-monitor/:query

POST /devices/country-code/:assign

GET /devices/digital-twin

PUT /devices/ibeacon

POST /devices/location/:assign

POST /devices/location/:query

POST /devices/location/:revoke

POST /devices/network-policy/:assign

POST /devices/network-policy/:query

POST /devices/network-policy/:revoke

GET /devices/network-policy/{policyId}

POST /devices/os/:change

GET /devices/radio-information

PUT /devices/radius-proxy/:assign

DELETE /devices/radius-proxy/:revoke

GET /devices/reports/{id}

POST /devices/rm-devices-connection-status

POST /devices/rm-devices-metadata

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

GET /devices/rm-devices-stack/{stackId}

GET /devices/stats

GET /network-policies

GET /network-policies/{id}

GET /network-policies/{id}/ssids

GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

POST /d360/client/graph

POST /d360/client/grid

POST /d360/wireless/surrounding-aps



POST /dashboard/alerts

POST /dashboard/assets

POST /dashboard/clients

POST /dashboard/devices

POST /dashboard/export

POST /dashboard/sites-with-issues

POST /dashboard/usage-capacity

POST /dashboard/wired/usage-capacity/grid

POST /dashboard/wired/usage-capacity/usage-utilization

POST /dashboard/wired/usage-capacity/wired-congestion

POST /dashboard/wired/usage-capacity/wired-throughput

POST /dashboard/wired/client-health/grid

POST /dashboard/wired/client-health/ip-connectivity-issues

POST /dashboard/wired/client-health/port-congestion

POST /dashboard/wired/client-health/port-errors

POST /dashboard/wired/client-health/traffic-anomalies

POST /dashboard/wired/device-health/cpu-usage-issues

POST /dashboard/wired/device-health/fan-issues

POST /dashboard/wired/device-health/fan-status

POST /dashboard/wired/device-health/grid

POST /dashboard/wired/device-health/memory-usage-issues

POST /dashboard/wired/device-health/poe-usage-issues

POST /dashboard/wired/device-health/poe-usage-status

POST /dashboard/wired/device-health/psu-issues

POST /dashboard/wired/device-health/psu-status

POST /dashboard/wired/device-health/summary

POST /dashboard/wired/device-health/temperature-issues

POST /dashboard/wired/device-health/temperature-status

POST /dashboard/wireless/usage-capacity/excessive-packet-loss

POST /dashboard/wireless/usage-capacity/excessive-retries

POST /dashboard/wireless/usage-capacity/excessive-utilization

POST /dashboard/wireless/usage-capacity/export

POST /dashboard/wireless/usage-capacity/grid

POST /dashboard/wireless/client-health/connectivity-issues

POST /dashboard/wireless/client-health/export

POST /dashboard/wireless/client-health/filter-metadata

POST /dashboard/wireless/client-health/frequency-distribution

POST /dashboard/wireless/client-health/grid

POST /dashboard/wireless/client-health/issue/association

POST /dashboard/wireless/client-health/issue/authentication

POST /dashboard/wireless/client-health/issue/ipaddress

POST /dashboard/wireless/client-health/issue/roaming

POST /dashboard/wireless/client-health/roaming-issues

POST /dashboard/wireless/device-health/export

POST /dashboard/wireless/device-health/grid



POST /dashboard/wireless/device-health/issues/cpu-usage-issues

POST /dashboard/wireless/device-health/issues/memory-usage-issues

POST /dashboard/wireless/device-health/issues/poe-usage-issues

POST /dashboard/wireless/device-health/summary

GET /alert-policies

GET /alert-policies/{id}

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/available-sites

GET /alert-subscriptions/emails

GET /alert-subscriptions/emails/{id}

GET /alert-subscriptions/servicenow

GET /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/webhooks

GET /alert-subscriptions/webhooks/{id}

GET /alerts

GET /alerts/count-by-{group}

GET /alerts/reports/{id}

GET /logs/accounting

GET /logs/audit

GET /logs/audit/full-descriptions/{id}

GET /logs/audit/reports/{id}

GET /logs/auth

GET /logs/credential

GET /logs/email

GET /logs/sms

GET /deployments

GET /deployments/{deploymentId}

GET /deployments/{deploymentId}/status

GET /deployments/overview

GET /deployments/status

GET /client-monitor-profiles

GET /client-monitor-profiles/{id}

GET /hotspot-profiles

GET /hotspot-profiles/{id}

GET /hotspot-service-provider-profiles

GET /hotspot-service-provider-profiles/{id}

GET /iot-profiles

GET /iot-profiles/{id}

GET /radio-profiles

GET /radio-profiles/{id}

GET /radio-profiles/channel-selection/{id}

GET /radio-profiles/mac-ouis

GET /radio-profiles/mac-ouis/{id}

GET /radio-profiles/miscellaneous/{id}

GET /radio-profiles/neighborhood-analysis/{id}



- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}
- GET /user-profiles
- GET /user-profiles/{id}
- GET /tunnel-concentrators
- GET /tunnel-concentrators/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /network-scorecard/clientHealth/{locationId}
- GET /network-scorecard/deviceHealth/{locationId}
- GET /network-scorecard/networkHealth/{locationId}
- GET /network-scorecard/servicesHealth/{locationId}
- GET /network-scorecard/wifiHealth/{locationId}
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

Observer

- POST /logout
- GET /auth/apitoken/info
- GET /auth/permissions
- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting
- GET /account/vhm/status
- GET /account/viq
- GET /account/viq/default-device-password
- GET /account/vig/download
- GET /account/viq/export-import-status



- GET /users/me
- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /hiq/organizations
- GET /hiq/status
- GET /locations/building
- GET /locations/building/{id}
- GET /locations/floor
- GET /locations/floor/{id}
- GET /locations/site
- GET /locations/site/{id}
- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps
- GET /locations/wall/type
- GET /locations/wall/type/references/{id}
- GET /devices
- GET /devices/{id}
- GET /devices/{id}/alarms
- GET /devices/{id}/client-monitor
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/gallery-image
- GET /devices/{id}/geolocation
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/ibeacon
- GET /devices/{id}/installation-report
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/iot
- GET /devices/{id}/location
- GET /devices/{id}/monitor/refresh/status
- GET /devices/{id}/network-policy
- GET /devices/{id}/radio-operating-mode
- GET /devices/{id}/ssid/status
- GET /devices/digital-twin
- GET /devices/network-policy/{policyId}
- GET /devices/radio-information
- GET /devices/reports/{id}
- POST /devices/rm-devices-connection-status
- POST /devices/rm-devices-metadata
- POST /devices/rm-devices-page
- POST /devices/rm-devices-page/export
- GET /devices/rm-devices-stack/{stackId}
- GET /devices/stats
- GET /network-policies



GET /network-policies/{id}

GET /network-policies/{id}/ssids

GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

POST /d360/client/graph

POST /d360/client/grid

POST /d360/wireless/surrounding-aps

POST /dashboard/alerts

POST /dashboard/assets

POST /dashboard/clients

POST /dashboard/devices

POST /dashboard/export

POST /dashboard/sites-with-issues

POST /dashboard/usage-capacity

POST /dashboard/wired/usage-capacity/grid

POST /dashboard/wired/usage-capacity/usage-utilization

POST /dashboard/wired/usage-capacity/wired-congestion

POST /dashboard/wired/usage-capacity/wired-throughput

POST /dashboard/wired/client-health/grid

POST /dashboard/wired/client-health/ip-connectivity-issues

POST /dashboard/wired/client-health/port-congestion

POST /dashboard/wired/client-health/port-errors

POST /dashboard/wired/client-health/traffic-anomalies

POST /dashboard/wired/device-health/cpu-usage-issues

POST /dashboard/wired/device-health/fan-issues

POST /dashboard/wired/device-health/fan-status

POST /dashboard/wired/device-health/grid

POST /dashboard/wired/device-health/memory-usage-issues

POST /dashboard/wired/device-health/poe-usage-issues

POST /dashboard/wired/device-health/poe-usage-status

POST /dashboard/wired/device-health/psu-issues

POST /dashboard/wired/device-health/psu-status

POST /dashboard/wired/device-health/summary

POST /dashboard/wired/device-health/temperature-issues

POST /dashboard/wired/device-health/temperature-status

POST /dashboard/wireless/usage-capacity/excessive-packet-loss

POST /dashboard/wireless/usage-capacity/excessive-retries

POST /dashboard/wireless/usage-capacity/excessive-utilization

POST /dashboard/wireless/usage-capacity/export

POST /dashboard/wireless/usage-capacity/grid

POST /dashboard/wireless/client-health/connectivity-issues



- POST /dashboard/wireless/client-health/export
- POST /dashboard/wireless/client-health/filter-metadata
- POST /dashboard/wireless/client-health/frequency-distribution
- POST /dashboard/wireless/client-health/grid
- POST /dashboard/wireless/client-health/issue/association
- POST /dashboard/wireless/client-health/issue/authentication
- POST /dashboard/wireless/client-health/issue/ipaddress
- POST /dashboard/wireless/client-health/issue/roaming
- POST /dashboard/wireless/client-health/roaming-issues
- POST /dashboard/wireless/device-health/export
- POST /dashboard/wireless/device-health/grid
- POST /dashboard/wireless/device-health/issues/cpu-usage-issues
- POST /dashboard/wireless/device-health/issues/memory-usage-issues
- POST /dashboard/wireless/device-health/issues/poe-usage-issues
- POST /dashboard/wireless/device-health/summary
- **GET** /applications
- GET /applications/{id}/clients/top{n}
- GET /applications/top{n}
- GET /alert-policies
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-policies/available-sites
- GET /alert-subscriptions/emails
- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/servicenow
- GET /alert-subscriptions/servicenow/{id}
- GET /alert-subscriptions/webhooks
- GET /alert-subscriptions/webhooks/{id}
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/full-descriptions/{id}
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /subscriptions/webhook
- GET /subscriptions/webhook/export
- GET /deployments
- GET /deployments/{deploymentId}
- GET /deployments/{deploymentId}/status
- GET /deployments/overview



GET /deployments/status GET /vlan-profiles GET /vlan-profiles/{id} GET /email-templates GET /endusers GET /pcgs/key-based GET /pcgs/key-based/network-policy-{policyId}/port-assignments GET /pcgs/key-based/network-policy-{policyId}/users GET /sms-templates GET /usergroups GET /usergroups/:unique GET /ccgs GET /ccgs/{id} GET /classification-rules GET /classification-rules/{id} GET /client-monitor-profiles GET /client-monitor-profiles/{id} GET /hotspot-profiles GET /hotspot-profiles/{id} GET /hotspot-service-provider-profiles GET /hotspot-service-provider-profiles/{id} GET /iot-profiles GET /iot-profiles/{id} GET /13-address-profiles GET /l3-address-profiles/{id} GET /radio-profiles GET /radio-profiles/{id} GET /radio-profiles/channel-selection/{id} GET /radio-profiles/mac-ouis GET /radio-profiles/mac-ouis/{id} GET /radio-profiles/miscellaneous/{id} GET /radio-profiles/neighborhood-analysis/{id} GET /radio-profiles/radio-usage-opt/{id} GET /radio-profiles/sensor-scan/{id} GET /radio-profiles/wmm-qos/{id} GET /ssids GET /ssids/advanced-settings/{id} GET /user-profiles GET /user-profiles/{id} GET /tunnel-concentrators GET /tunnel-concentrators/{id} GET /ad-servers GET /cwps

GET /ldap-servers GET /ldap-servers/{id}



- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-proxies
- GET /radius-proxies/{id}
- GET /radius-proxies/devices
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/excluded-vlans-list
- GET /copilot/anomalies/hardware-health/client-list
- GET /copilot/anomalies/hardware-health/cpu-mem-stats
- GET /copilot/anomalies/hardware-health/stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/missing-vlan/count
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/lldp-cdp-info
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/poeflapping/trends
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats



- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /network-scorecard/clientHealth/{locationId}
- GET /network-scorecard/deviceHealth/{locationId}
- GET /network-scorecard/networkHealth/{locationId}
- GET /network-scorecard/servicesHealth/{locationId}
- GET /network-scorecard/wifiHealth/{locationId}
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

Help Desk

- POST /logout
- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting
- GET /account/vhm/status
- GET /account/viq
- GET /account/viq/default-device-password
- GET /account/viq/download
- GET /account/viq/export-import-status
- GET /users/me
- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /hiq/organizations
- GET /hiq/status
- GET /locations/building
- GET /locations/building/{id}
- GET /locations/floor
- GET /locations/floor/{id}
- GET /locations/site
- GET /locations/site/{id}



- GET /locations/tree
- GET /locations/tree/devices
- GET /locations/tree/maps
- GET /locations/wall/type
- GET /locations/wall/type/references/{id}
- GET /clients/{id}
- GET /clients/active
- GET /clients/active/count
- GET /clients/byMac/{clientMac}
- GET /clients/summary
- GET /clients/usage
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /deployments
- GET /deployments/{deploymentId}
- GET /deployments/{deploymentId}/status
- GET /deployments/overview
- GET /deployments/status
- GET /endusers
- GET /packetcaptures
- POST /packetcaptures
- DELETE /packetcaptures
- GET /packetcaptures/{id}
- DELETE /packetcaptures/{id}
- POST /packetcaptures/{id}/:stop
- POST /packetcaptures/{id}/:upload
- GET /packetcaptures/files
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

Application Operator

- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting
- GET /account/vhm/status
- GET /account/viq
- GET /account/viq/default-device-password
- GET /account/viq/download
- GET /account/viq/export-import-status
- GET /logs/accounting
- GET /logs/audit



GET /logs/audit/full-descriptions/{id}

GET /logs/audit/reports/{id}

GET /logs/auth

GET /logs/credential

GET /logs/email

GET /logs/sms

Guest Management

POST /logout

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/third-party-applications

GET /account/vhm/setting

GET /account/vhm/status

GET /account/viq

GET /account/viq/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /deployments

GET /deployments/{deploymentId}

GET /deployments/{deploymentId}/status

GET /deployments/overview

GET /deployments/status

GET /endusers

POST /endusers

PUT /endusers/{id}

DELETE /endusers/{id}

POST /endusers/{id}/:regenerate-password

GET /usergroups

GET /usergroups/:unique

GET /copilot/connectivity/wired/events

GET /copilot/connectivity/wired/experience

GET /copilot/connectivity/wired/hardware

GET /copilot/connectivity/wired/locations/hardware

GET /copilot/connectivity/wired/quality-index

GET /copilot/connectivity/wireless/apps

GET /copilot/connectivity/wireless/events

GET /copilot/connectivity/wireless/experience

GET /copilot/connectivity/wireless/locations/events

GET /copilot/connectivity/wireless/locations/performance

GET /copilot/connectivity/wireless/locations/quality-index

GET /copilot/connectivity/wireless/locations/time-to-connect



- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/excluded-vlans-list
- GET /copilot/anomalies/hardware-health/client-list
- GET /copilot/anomalies/hardware-health/cpu-mem-stats
- GET /copilot/anomalies/hardware-health/stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/missing-vlan/count
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/lldp-cdp-info
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/poeflapping/trends
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats
- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview

APPENDIX - B

API call list based on Permission

logout

POST /logout

auth

POST /auth/permissions/:check

POST /auth/apitoken

POST /auth/apitoken/:validate

GET /auth/permissions

GET /auth/apitoken/info



auth:r

GET /auth/permissions GET /auth/apitoken/info

token:new

POST /auth/apitoken

perm:check

POST /auth/permissions/:check

Iro

POST /operations/{operationId}/:cancel GET /operations/{operationId} DELETE /operations/{operationId}

lro:r

GET /operations/{operationId}

account

GET /account/viq/default-device-password

PUT /account/viq/default-device-password

PUT /account/vhm/setting/{id}

POST /account/viq/import

POST /account/viq/export

POST /account/viq/:reset

POST /account/viq/:backup

POST /account/:switch

GET /account/viq

GET /account/viq/export-import-status

GET /account/viq/download

GET /account/vhm/status

GET /account/vhm/setting

GET /account/third-party-applications

GET /account/home

GET /account/external

account:switch

POST /account/:switch

account:r

GET /account/viq/default-device-password

GET /account/viq

GET /account/viq/export-import-status

GET /account/viq/download

GET /account/vhm/status



GET /account/vhm/setting

GET /account/third-party-applications

GET /account/home

GET /account/external

viq:backup

POST /account/viq/:backup

user-me:r

GET /users/me

user:r

GET /users

GET /users/external

GET /users/{id}

GET /users/external/{id}

GET /users/me

hiq

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

GET /hiq/status

DELETE /hiq/organizations/{id}

hiq:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

GET /hiq/organizations

GET /hiq/status

org

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

DELETE /hiq/organizations/{id}



org:new

POST /hiq/organizations

org:del

DELETE /hiq/organizations/{id}

org:rename

POST /hiq/organizations/{id}/:rename

hiq.ctx

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

hiq.ctx:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

hiq.ctx:w

PUT /hiq/context

PUT /hiq/context/reading

PUT /hiq/context/creating

device

PUT /devices/{id}/visible

GET /devices/{id}/radio-operating-mode

PUT /devices/{id}/radio-operating-mode

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

PUT /devices/{id}/mobileapp/gps

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

PUT /devices/{id}/hostname

GET /devices/{id}/ftm-settings

PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings

PUT /devices/{id}/description

GET /devices/{id}/client-monitor

PUT /devices/{id}/client-monitor



DELETE /devices/{id}/client-monitor

PUT /devices/radius-proxy/:assign

PUT /devices/ibeacon

POST /devices/{id}/thread/commissioner/:stop

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/ssid/:override

POST /devices/{id}/monitor/:refresh

POST /devices/{id}/iot/:enable

POST /devices/{id}/iot/:disable

POST /devices/{id}/bounce-port

POST /devices/{id}/:unmanage

POST /devices/{id}/:reset

POST /devices/{id}/:reboot

POST /devices/{id}/:manage

POST /devices/{id}/:cli

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

POST /devices/rm-devices-metadata

POST /devices/rm-devices-connection-status

POST /devices/os/:change

POST /devices/network-policy/:revoke

POST /devices/network-policy/:query

POST /devices/network-policy/:assign

POST /devices/location/:revoke

POST /devices/location/:query

POST /devices/location/:assign

POST /devices/country-code/:assign

POST /devices/client-monitor/:revoke

POST /devices/client-monitor/:query

POST /devices/client-monitor/:assign

POST /devices/anchor/revoke

POST /devices/anchor/assign

POST /devices/actions-support-metadata

POST /devices/:unmanage

POST /devices/:reset

POST /devices/:reboot

POST /devices/:onboard

POST /devices/:manage

POST /devices/:delete

POST /devices/:cli

POST /devices/:check-ownership

POST /devices/:advanced-onboard

GET /devices

GET /devices/{id}



- DELETE /devices/{id}
- GET /devices/{id}/ssid/status
- GET /devices/{id}/monitor/refresh/status
- GET /devices/{id}/iot
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/installation-report
- GET /devices/{id}/ibeacon
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/geolocation
- GET /devices/{id}/gallery-image
- GET /devices/{id}/alarms
- GET /devices/stats
- GET /devices/rm-devices-stack/{stackId}
- GET /devices/reports/{id}
- GET /devices/radio-information
- GET /devices/network-policy/{policyId}
- GET /devices/digital-twin
- DELETE /devices/radius-proxy/:revoke

device:r

- GET /devices/{id}/radio-operating-mode
- GET /devices/{id}/network-policy
- GET /devices/{id}/location
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/client-monitor
- GET /devices
- GET /devices/{id}
- GET /devices/{id}/ssid/status
- GET /devices/{id}/monitor/refresh/status
- GET /devices/{id}/iot
- GET /devices/{id}/interfaces/wifi
- GET /devices/{id}/installation-report
- GET /devices/{id}/ibeacon
- GET /devices/{id}/history/cpu-mem
- GET /devices/{id}/geolocation
- GET /devices/{id}/gallery-image
- GET /devices/{id}/alarms
- GET /devices/stats
- GET /devices/rm-devices-stack/{stackId}
- GET /devices/reports/{id}
- GET /devices/radio-information
- GET /devices/network-policy/{policyId}
- GET /devices/digital-twin



device:list

GET /devices

device:view

GET /devices/{id}

GET /devices/stats

GET /devices/radio-information

GET /devices/digital-twin

device:relaxed_read

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

POST /devices/rm-devices-metadata

POST /devices/rm-devices-connection-status

device:new

POST /devices/:onboard

device:del

POST /devices/:delete

device:cli

POST /devices/:cli

device:deploy

Permission not used

device:manage

POST /devices/:manage

device:unmanage

POST /devices/:unmanage

device:reboot

POST /devices/:reboot

device:reset

POST /devices/{id}/:reset

device:thread-commissioner

POST /devices/{id}/thread/commissioner/:stop POST /devices/{id}/thread/commissioner/:start

d360:relaxed_read

POST /d360/wireless/surrounding-aps

POST /d360/client/grid



POST /d360/client/graph

dashboard:relaxed read

POST /dashboard/wireless/usage-capacity/grid

POST /dashboard/wireless/usage-capacity/export

POST /dashboard/wireless/usage-capacity/excessive-utilization

POST /dashboard/wireless/usage-capacity/excessive-retries

POST /dashboard/wireless/usage-capacity/excessive-packet-loss

POST /dashboard/wireless/device-health/summary

POST /dashboard/wireless/device-health/issues/poe-usage-issues

POST /dashboard/wireless/device-health/issues/memory-usage-issues

POST /dashboard/wireless/device-health/issues/cpu-usage-issues

POST /dashboard/wireless/device-health/grid

POST /dashboard/wireless/device-health/export

POST /dashboard/wireless/client-health/roaming-issues

POST /dashboard/wireless/client-health/issue/roaming

POST /dashboard/wireless/client-health/issue/ipaddress

POST /dashboard/wireless/client-health/issue/authentication

POST /dashboard/wireless/client-health/issue/association

POST /dashboard/wireless/client-health/grid

POST /dashboard/wireless/client-health/frequency-distribution

POST /dashboard/wireless/client-health/filter-metadata

POST /dashboard/wireless/client-health/export

POST /dashboard/wireless/client-health/connectivity-issues

POST /dashboard/wired/usage-capacity/wired-throughput

POST /dashboard/wired/usage-capacity/wired-congestion

POST /dashboard/wired/usage-capacity/usage-utilization

POST /dashboard/wired/usage-capacity/grid

POST /dashboard/wired/device-health/temperature-status

POST /dashboard/wired/device-health/temperature-issues

POST /dashboard/wired/device-health/summary

POST /dashboard/wired/device-health/psu-status

POST /dashboard/wired/device-health/psu-issues

POST /dashboard/wired/device-health/poe-usage-status

POST /dashboard/wired/device-health/poe-usage-issues

POST /dashboard/wired/device-health/memory-usage-issues

POST /dashboard/wired/device-health/grid

POST /dashboard/wired/device-health/fan-status

POST /dashboard/wired/device-health/fan-issues

POST /dashboard/wired/device-health/cpu-usage-issues

POST /dashboard/wired/client-health/traffic-anomalies

POST /dashboard/wired/client-health/port-errors

POST /dashboard/wired/client-health/port-congestion

POST /dashboard/wired/client-health/ip-connectivity-issues

POST /dashboard/wired/client-health/grid



POST /dashboard/usage-capacity

POST /dashboard/sites-with-issues

POST /dashboard/export

POST /dashboard/devices

POST /dashboard/clients

POST /dashboard/assets

POST /dashboard/alerts

client

PUT /clients/alias

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

DELETE /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

client:r

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

locations

PUT /locations/{id}

DELETE /locations/{id}

PUT /locations/wall/type/{id}

DELETE /locations/wall/type/{id}

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

POST /locations

GET /locations/wall/type

POST /locations/wall/type

GET /locations/site

POST /locations/site



POST /locations/import/ekahau

POST /locations/floorplan

GET /locations/floor

POST /locations/floor

GET /locations/building

POST /locations/building

POST /locations/:init

GET /locations/wall/type/references/{id}

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

locations:r

GET /locations/site/{id}

GET /locations/floor/{id}

GET /locations/building/{id}

GET /locations/wall/type

GET /locations/site

GET /locations/floor

GET /locations/building

GET /locations/wall/type/references/{id}

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

network-policy

GET /network-policies/{id}

PUT /network-policies/{id}

DELETE /network-policies/{id}

GET /network-policies

POST /network-policies

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

GET /network-policies/{id}/ssids

policy:ssid

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

network-policy:r

GET /network-policies/{id}

GET /network-policies

GET /network-policies/{id}/ssids



network-scorecard

GET /network-scorecard/wifiHealth/{locationId}

GET /network-scorecard/servicesHealth/{locationId}

GET /network-scorecard/networkHealth/{locationId}

GET /network-scorecard/deviceHealth/{locationId}

GET /network-scorecard/clientHealth/{locationId}

network-scorecard:r

GET /network-scorecard/wifiHealth/{locationId}

GET /network-scorecard/servicesHealth/{locationId}

GET /network-scorecard/networkHealth/{locationId}

GET /network-scorecard/deviceHealth/{locationId}

GET /network-scorecard/clientHealth/{locationId}

ssid

PUT /ssids/{id}/psk/password

PUT /ssids/{id}/mode/wep

PUT /ssids/{id}/mode/psk

PUT /ssids/{id}/mode/ppsk

PUT /ssids/{id}/mode/open

PUT /ssids/{id}/mode/dot1x

GET /ssids/advanced-settings/{id}

PUT /ssids/advanced-settings/{id}

POST /ssids/{id}/user-profile/:attach

POST /ssids/{id}/user-profile-assignment/:attach

POST /ssids/{id}/radius-server-group/:attach

POST /ssids/{id}/radius-client-profile/:attach

POST /ssids/{id}/cwp/:enable

POST /ssids/{id}/cwp/:disable

POST /ssids/{id}/cwp/:attach

POST /ssids/{id}/client-monitor-profile/:attach

POST /ssids/{id}/:rename

GET /ssids

ssid:r

GET /ssids/advanced-settings/{id}

GET /ssids

pcg:key

GET /pcgs/key-based/network-policy-{policyId}/users

PUT /pcgs/key-based/network-policy-{policyId}/users

POST /pcgs/key-based/network-policy-{policyId}/users

DELETE /pcgs/key-based/network-policy-{policyId}/users

GET /pcgs/key-based

POST /pcgs/key-based



GET /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/port-assignments POST /pcgs/key-based/network-policy-{policyId}/keys/:generate POST /pcgs/key-based/network-policy-{policyId}/keys/:email POST /pcgs/key-based/network-policy-{policyId}/:onboard DELETE /pcgs/key-based/network-policy-{policyId}

pcg:key:r

GET /pcgs/key-based/network-policy-{policyId}/users

GET /pcgs/key-based

GET /pcgs/key-based/network-policy-{policyId}/port-assignments

subscriptions-webhook

PUT /subscriptions/webhook/{id}

GET /subscriptions/webhook

POST /subscriptions/webhook

GET /subscriptions/webhook/export

DELETE /subscriptions/webhook/:delete

subscriptions-webhook:r

GET /subscriptions/webhook

GET /subscriptions/webhook/export

ccg

GET /ccgs/{id}

PUT /ccgs/{id}

DELETE /ccgs/{id}

GET /ccgs

POST /ccgs

ccg:r

GET /ccgs/{id}

GET /ccgs

log

POST /logs/audit/reports

GET /logs/sms

GET /logs/email

GET /logs/credential

GET /logs/auth

GET /logs/audit

GET /logs/audit/reports/{id}

GET /logs/audit/full-descriptions/{id}

GET /logs/accounting



log:r

GET /logs/sms

GET /logs/email

GET /logs/credential

GET /logs/auth

GET /logs/audit

GET /logs/audit/reports/{id}

GET /logs/audit/full-descriptions/{id}

GET /logs/accounting

cwp

GET /cwps

cwp:r

GET /cwps

sms-tmpl

GET /sms-templates

sms-tmpl:r

GET /sms-templates

class-rule

GET /classification-rules/{id}

PUT /classification-rules/{id}

DELETE /classification-rules/{id}

GET /classification-rules

POST /classification-rules

class-rule:r

GET /classification-rules/{id}

GET /classification-rules

user-profile

GET /user-profiles/{id}

PUT /user-profiles/{id}

DELETE /user-profiles/{id}

GET /user-profiles

POST /user-profiles

POST /user-profiles/{id}/mac-firewall-policies/:detach

POST /user-profiles/{id}/mac-firewall-policies/:attach

POST /user-profiles/{id}/ip-firewall-policies/:detach

POST /user-profiles/{id}/ip-firewall-policies/:attach



user-profile:r

GET /user-profiles/{id}

GET /user-profiles

tunnel-concentrator

GET /tunnel-concentrators/{id}

PUT /tunnel-concentrators/{id}

DELETE /tunnel-concentrators/{id}

GET /tunnel-concentrators

POST /tunnel-concentrators

tunnel-concentrator:r

GET /tunnel-concentrators/{id}

GET /tunnel-concentrators

radius-proxy

GET /radius-proxies/{id}

PUT /radius-proxies/{id}

DELETE /radius-proxies/{id}

GET /radius-proxies

POST /radius-proxies

GET /radius-proxies/devices

radius-proxy:r

GET /radius-proxies/{id}

GET /radius-proxies

GET /radius-proxies/devices

radius-server

GET /radius-servers/internal/{id}

PUT /radius-servers/internal/{id}

DELETE /radius-servers/internal/{id}

GET /radius-servers/external/{id}

PUT /radius-servers/external/{id}

DELETE /radius-servers/external/{id}

GET /radius-servers/internal

POST /radius-servers/internal

DELETE /radius-servers/internal

GET /radius-servers/external

POST /radius-servers/external

GET /radius-servers/internal/devices

radius-server:r

GET /radius-servers/internal/{id}

GET /radius-servers/external/{id}



GET /radius-servers/internal

GET /radius-servers/external

GET /radius-servers/internal/devices

usergroup

PUT /usergroups/{id}

DELETE /usergroups/{id}

GET /usergroups

POST /usergroups

GET /usergroups/:unique

usergroup:r

GET /usergroups

GET /usergroups/:unique

deployment

GET /deployments/{deploymentId}

PUT /deployments/{deploymentId}

DELETE /deployments/{deploymentId}

GET /deployments

POST /deployments

POST /deployments/firmware-metadatas

GET /deployments/{deploymentId}/status

GET /deployments/status

GET /deployments/overview

deployment:r

GET /deployments/{deploymentId}

GET /deployments

GET /deployments/{deploymentId}/status

GET /deployments/status

GET /deployments/overview

ad-server

GET /ad-servers

ad-server:r

GET /ad-servers

alert

POST /alerts/reports

POST /alerts/:acknowledge

GET /alerts

GET /alerts/reports/{id}

GET /alerts/count-by-{group}



alert:r

GET /alerts

GET /alerts/reports/{id}

GET /alerts/count-by-{group}

alert-policies

GET /alert-policies/{policyId}/rules/{ruleId}

PUT /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

PUT /alert-policies/{id}

DELETE /alert-policies/{id}

GET /alert-policies

POST /alert-policies

POST /alert-policies/{policyId}/rules/{ruleId}/:enable

POST /alert-policies/{policyId}/rules/{ruleId}/:disable

GET /alert-policies/available-sites

alert-policies:r

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

GET /alert-policies

GET /alert-policies/available-sites

alert-subscriptions

GET /alert-subscriptions/webhooks/{id}

PUT /alert-subscriptions/webhooks/{id}

DELETE /alert-subscriptions/webhooks/{id}

GET /alert-subscriptions/servicenow/{id}

PUT /alert-subscriptions/servicenow/{id}

PATCH /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/emails/{id}

PUT /alert-subscriptions/emails/{id}

DELETE /alert-subscriptions/emails/{id}

GET /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks/:delete

GET /alert-subscriptions/servicenow

POST /alert-subscriptions/servicenow

POST /alert-subscriptions/servicenow/:delete

GET /alert-subscriptions/emails

POST /alert-subscriptions/emails

POST /alert-subscriptions/emails/{id}/:verify

POST /alert-subscriptions/emails/:delete



alert-subscriptions:r

GET /alert-subscriptions/webhooks/{id}

GET /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/emails/{id}

GET /alert-subscriptions/webhooks

GET /alert-subscriptions/servicenow

GET /alert-subscriptions/emails

app

GET /applications

GET /applications/{id}/clients/top{n}

GET /applications/top {n}

application:r

GET /applications

GET /applications/{id}/clients/top{n}

GET /applications/top {n}

13-address-profile

GET /l3-address-profiles/{id}

PUT /13-address-profiles/{id}

DELETE /13-address-profiles/{id}

GET /13-address-profiles

POST /13-address-profiles

13-address-profile:r

GET /13-address-profiles/{id}

GET /l3-address-profiles

vlan-profile

GET /vlan-profiles

POST /vlan-profiles

POST /vlan-profiles/:delete

GET /vlan-profiles/{id}

DELETE /vlan-profiles/{id}

PATCH /vlan-profiles/{id}

vlan-profile:r

GET /vlan-profiles

GET /vlan-profiles/{id}

enduser

PUT /endusers/{id}

DELETE /endusers/{id}

GET /endusers



POST /endusers POST /endusers/{id}/:regenerate-password

enduser:r

GET /endusers

radius-client-object

GET /radius-client-objects/{id} PUT /radius-client-objects/{id} DELETE /radius-client-objects/{id} GET /radius-client-objects POST /radius-client-objects

radius-client-object:r

GET /radius-client-objects/{id} GET /radius-client-objects

Idap-server

GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id} GET /ldap-servers POST /ldap-servers

Idap-server:r

GET /ldap-servers/{id} GET /ldap-servers

email-template

GET /email-templates

email-template:r

GET /email-templates

certificate

POST /certificates/import GET /certificates DELETE /certificates/{id}

certificate:r

GET /certificates

radio-profile

GET /radio-profiles/{id} PUT /radio-profiles/{id} DELETE /radio-profiles/{id}



GET /radio-profiles/wmm-qos/{id} PUT /radio-profiles/wmm-qos/{id} GET /radio-profiles/sensor-scan/{id} PUT /radio-profiles/sensor-scan/{id} GET /radio-profiles/radio-usage-opt/{id} PUT /radio-profiles/radio-usage-opt/{id} GET /radio-profiles/neighborhood-analysis/{id} PUT /radio-profiles/neighborhood-analysis/{id} GET /radio-profiles/miscellaneous/{id} PUT /radio-profiles/miscellaneous/{id} GET /radio-profiles/mac-ouis/{id} PUT /radio-profiles/mac-ouis/{id} DELETE /radio-profiles/mac-ouis/{id} GET /radio-profiles/channel-selection/{id} PUT /radio-profiles/channel-selection/{id} GET /radio-profiles POST /radio-profiles GET /radio-profiles/mac-ouis POST /radio-profiles/mac-ouis radio-profile:r GET /radio-profiles/{id} GET /radio-profiles/wmm-qos/{id} GET /radio-profiles/sensor-scan/{id} GET /radio-profiles/radio-usage-opt/{id} GET /radio-profiles/neighborhood-analysis/{id} GET /radio-profiles/miscellaneous/{id} GET /radio-profiles/mac-ouis/{id} GET /radio-profiles/channel-selection/{id} GET /radio-profiles GET /radio-profiles/mac-ouis iot-profile GET /iot-profiles/{id} PUT /iot-profiles/{id} DELETE /iot-profiles/{id} GET /iot-profiles POST /iot-profiles iot-profile:r GET /iot-profiles/{id} GET /iot-profiles client-monitor-profile

GET /client-monitor-profiles/{id}



PUT /client-monitor-profiles/{id} DELETE /client-monitor-profiles/{id} GET /client-monitor-profiles POST /client-monitor-profiles

client-monitor-profile:r

GET /client-monitor-profiles/{id} GET /client-monitor-profiles

copilot-connectivity-wired:r

GET /copilot/connectivity/wired/quality-index

GET /copilot/connectivity/wired/locations/hardware

GET /copilot/connectivity/wired/hardware

GET /copilot/connectivity/wired/experience

GET /copilot/connectivity/wired/events

copilot-connectivity-wireless:r

GET /copilot/connectivity/wireless/views

GET /copilot/connectivity/wireless/time-to-connect

GET /copilot/connectivity/wireless/quality-index

GET /copilot/connectivity/wireless/performance

GET /copilot/connectivity/wireless/locations/time-to-connect

GET /copilot/connectivity/wireless/locations/quality-index

GET /copilot/connectivity/wireless/locations/performance

GET /copilot/connectivity/wireless/locations/events

GET /copilot/connectivity/wireless/experience

GET /copilot/connectivity/wireless/events

GET /copilot/connectivity/wireless/apps

copilot-anomalies:r

GET /copilot/anomalies/wifi-efficiency/stats

GET /copilot/anomalies/wifi-efficiency/client-list

GET /copilot/anomalies/wifi-capacity/stats

GET /copilot/anomalies/wifi-capacity/client-list

GET /copilot/anomalies/report

GET /copilot/anomalies/port-efficiency/stats

GET /copilot/anomalies/port-efficiency/speed-duplex-stats

GET /copilot/anomalies/poeflapping/trends

GET /copilot/anomalies/poeflapping/stats

GET /copilot/anomalies/poeflapping/lldp-cdp-info

GET /copilot/anomalies/notifications

GET /copilot/anomalies/missing-vlan/count

GET /copilot/anomalies/locations

GET /copilot/anomalies/hardware-health/stats

GET /copilot/anomalies/hardware-health/cpu-mem-stats



GET /copilot/anomalies/hardware-health/client-list

GET /copilot/anomalies/excluded-vlans-list

GET /copilot/anomalies/dfs-recurrence/count-stats

GET /copilot/anomalies/dfs-recurrence/channel-stats

GET /copilot/anomalies/devices-with-locations

GET /copilot/anomalies/devices-by-location

GET /copilot/anomalies/anomalies-by-category

GET /copilot/anomalies/adverse-traffic/packet-counts

GET /copilot/anomalies/adverse-traffic/device-stats

licenses

Permission not used

licenses:r

Permission not used

copilot-assurance-scans:r

GET /copilot/assurance-scans/overview

packet-capture

GET /packetcaptures

POST /packetcaptures

DELETE /packetcaptures

POST /packetcaptures/{id}/:upload

POST /packetcaptures/{id}/:stop

GET /packetcaptures/{id}

DELETE /packetcaptures/{id}

GET /packetcaptures/files

packet-capture:r

GET /packetcaptures

GET /packetcaptures/{id}

GET /packetcaptures/files

country

GET /countries

GET /countries/{countryCode}/:validate

GET /countries/{countryAlpha2Code}/states

country:r

GET /countries

GET /countries/{countryCode}/:validate

GET /countries/{countryAlpha2Code}/states



cas

Permission not used

cas:r

Permission not used

cas-policies

Permission not used

cas-policies:r

Permission not used

cas-metadata:r

Permission not used

cns-subscriptions

Permission not used

cns-subscriptions:r

Permission not used

hotspot-profile

GET /hotspot-profiles/{id} PUT /hotspot-profiles/{id} DELETE /hotspot-profiles/{id} GET /hotspot-profiles POST /hotspot-profiles

hotspot-profile:r

GET /hotspot-profiles/{id} GET /hotspot-profiles

hotspot-service-provider-profile

GET /hotspot-service-provider-profiles/{id} PUT /hotspot-service-provider-profiles/{id} DELETE /hotspot-service-provider-profiles/{id} GET /hotspot-service-provider-profiles POST /hotspot-service-provider-profiles

hotspot-service-provider-profile:r

GET /hotspot-service-provider-profiles/{id} GET /hotspot-service-provider-profiles