



XIQ API – Permission Requirements and User Roles



# **Revisions History**

Rev	Revision Summary	By Whom	<b>Publish Date</b>
24r4	24r4 updates	Tim	June 3,2024
24r5	24r5 updates	Tim	July 3, 2024
24r6	24r6 updates	Tim	Oct 10, 2024
25r1	25r1 updates	Tim	Jan 7, 2025
25r2	25r2 updates	Tim	March 21, 2025



# **Table of Contents**

Introduction	19
Authentication	20
POST /login	20
POST /logout	20
Authorization	20
POST /auth/apitoken	
POST /auth/apitoken/:validate	
GET /auth/apitoken/info	
GET /auth/permissions	
POST /auth/permissions/:check	
GET /operations/{operationId}	
DELETE /operations/{operationId}	
POST /operations/{operationId}/:cancel	
Account	
POST /account/:switch	
GET /account/external	
GET /account/home	
GET /account/third-party-applications	
GET /account/vhm/setting	
PUT /account/vhm/setting/{id}	
GET /account/vhm/setting/status	
GET /account/vig	
POST /account/vig/:backup	
POST /account/vig/:reset	
GET /account/vig/default-device-password	
PUT /account/vig/default-device-password	
GET /account/vig/download	
POST /account/vig/export	
GET /account/vig/export-import-status	
POST /account/vig/import	
POST /backup/history/:restore	
POST /backup/history/delete	
GET /backup/history/grid	
PUT /backup/history/grid	27
Users	27
GET /users	
POST /users	
GET /users/{id}	
DELETE /users/{id}	
PATCH /users/{id}	
GET /users/external	
POST /users/external	
GET /users/external/{id}	
DELETE /users/external/{id}	



PATCH /users/external/{id}	
GET /users/me	29
HIQ	29
GET /hig/context	
PUT /hiq/context	
GET /hiq/context/creating	
PUT /hig/context/creating	
GET /hiq/context/reading	
PUT /hig/context/reading	
GET /hig/organizations	
POST /hig/organizations	
DELETE /hiq/organizations/{id}	
POST /hiq/organizations/{id}/:rename	
GET /hig/status	
Location	33
POST /locations	
POST /locations/:init	
PUT /locations/{id}	
DELETE /locations/{id}	
GET /locations/building	
POST /locations/building	
GET /locations/building/{id}	
PUT /locations/building/{id}	
DELETE /locations/building/{id}	
GET /locations/floor	
POST /locations/floor	
GET /locations/floor/{id}	
PUT /locations/floor/{id}	
DELETE /locations/floor/{id}	
POST /locations/floorplan	
POST /locations/import/ekahau	
GET /locations/site	
POST /locations/site	
GET /locations/site/{id}	
PUT /locations/site/{id}	
DELETE /locations/site/{id}	38
GET /locations/tree	
GET /locations/tree/devices	
GET /locations/tree/maps	
, , , ,	
Device	
GET /devices	
POST /devices/:advanced-onboard	
POST /devices/:check-ownership	
POST /devices/:cli	
POST /devices/:delete	
POST /devices/:manage	
POST /devices/:onboard	
POST /devices/:reboot	41



POST /devices/:unmanage	
GET /devices/{id}	
DELETE /devices/{id}	
POST /devices/{id}/:cli	
POST /devices/{id}/:manage	
POST /devices/{id}/:reboot	
POST /devices/{id}/:reset	
POST /devices/{id}/:unmanage	
GET /devices/{id}/alarms	
POST /devices/{id}/bounce-port	
GET /devices/{id}/client-monitor	
PUT /devices/{id}/client-monitor	
DELETE /devices/{id}/client-monitor	
PUT /devices/{id}/description	
GET /devices/{id}/ftm-settings	44
POST /devices/{id}/config/ftm-settings	44
DELETE /devices/{id}/config/ftm-settings	
GET /devices/{id}/gallery-image	
GET /devices/{id}/geolocation	45
GET /devices/{id}/history/cpu-mem	45
PUT /devices/{id}/hostname	45
GET /devices/{id}/ibeacon	46
GET /devices/{id}/installation-report	46
GET /devices/{id}/interfaces/wifi	
GET /devices/{id}/iot	46
POST /devices/{id}/iot/:disable	47
POST /devices/{id}/iot/:enable	47
GET /devices/{id}/location	47
PUT /devices/{id}/location	47
DELETE /devices/{id}/location	48
POST /devices/{id}/monitor/:refresh	48
GET /devices/{id}/monitor/refresh/status	48
GET /devices/{id}/network-policy	48
PUT /devices/{id}/network-policy	48
DELETE /devices/{id}/network-policy	49
GET /devices/{id}/radio-operating-mode	49
PUT /devices/{id}/radio-operating-mode	49
POST /devices/{id}/ssid/:override	49
GET /devices/{id}/ssid/status	50
POST /devices/{id}/ssid/status/:change	50
POST /devices/{id}/thread/commissioner/:start	50
POST /devices/{id}/thread/commissioner/:stop	50
PUT /devices/{id}/thread/visible	51
"Installer"	51
POST /devices/client-monitor/:assign	
POST /devices/ client-monitor/:revoke	
POST /devices/client-monitor/:query	51
POST /devices/country-code/:assign	
GET /devices/{id}/digital-twin	52
PUT /devices/ibeacon	52



	POST /devices/location/:assign	52
	POST /devices/location/:query	52
	POST /devices/location/:revoke	53
	POST /devices/network-policy/:assign	53
	POST /devices/network-policy/:query	53
	POST /devices/network-policy/:revoke	53
	GET /devices/network-policy/{policyId}	53
	POST /devices/os/:change	54
	GET /devices/radio-information	54
	PUT /devices/radius-proxy/:assign	54
	DELETE /devices/radius-proxy/:revoke	54
	POST /devices/rm-devices-connection-status	55
	POST /devices/rm-devices-metadata	55
	POST /devices/rm-devices-page	55
	POST /devices/rm-devices-page/export	55
	GET /devices/rm-devices-stack/{id}	55
	GET /devices/stats	56
Ne	etwork Policy	5 <i>6</i>
	GET /network-policies	
	POST /network-policies	
	GET /network-policies/{id}	
	PUT /network-policies/{id}	
	DELETE /network-policies/{id}	
	GET /network-policies/{id}/ssids	
	POST /network-policies/{id}/ssids/:add	
	POST /network-policies/{id}/ssids/:remove	
Cli	ient	58
	GET /clients/{id}	
	GET /clients/active	
	PUT /clients/alias	
	GET /clients/active/count	
	GET /clients/byMac/{client_mac}	
	DELETE /clients/byMac/{client_mac}	
	GET /clients/summary	
	GET /clients/usage	
Cli	ient - Details	60
CII	GET /client-details/overview/chart-data/{id}	
	GET /client-details/overview/info/{id}	
D3	360	
	POST /d360/client/graph	
	POST /d360/client/grid	
	POST /d360/client/grid/metadata	
	POST /d360/client/stats	
	POST /d360/device/interfaces	
	POST /d360/device/issues	
	POST /d360/device/metadata	
	POST /d360/device/stats	62



	POST /d360/overview/devices-summary	62
	POST /d360/ssid-metadata	62
	POST /d360/wireless/interfaces-graph	62
	POST /d360/wireless/interfaces-stats	62
	POST /d360/wireless/surrounding-aps	62
Da:	ashboard	63
	POST /dashboard/alerts	63
	POST /dashboard/assets	63
	POST /dashboard/clients	63
	GET /dashboard/device-types	63
	POST /dashboard/devices	63
	POST /dashboard/export	63
	POST /dashboard/sites-with-issues	64
	POST /dashboard/usage-capacity	64
	GET /dashboard/wireless/dashboard/critera	64
	POST /dashboard/wireless/dashboard/critera	64
Da:	ashboard Wireless Usage and Capacity	64
	POST /dashboard/wireless/usage-capacity/excessive-packet-loss	
	POST /dashboard/wireless/usage-capacity/excessive-retries	65
	POST /dashboard/wireless/usage-capacity/excessive-utilization	65
	POST /dashboard/wireless/usage-capacity/export	65
	POST /dashboard/wireless/usage-capacity/grid	65
Da:	ashboard Wireless Client Health	65
	POST /dashboard/wireless/client-health/connectivity-issues	65
	POST /dashboard/wireless/client-health/export	65
	POST /dashboard/wireless/client-health/filter-metadata	66
	POST /dashboard/wireless/client-health/frequency-distribution	66
	POST /dashboard/wireless/client-health/grid	66
	POST /dashboard/wireless/client-health/issue/association	66
	POST /dashboard/wireless/client-health/issue/authentication	66
	POST /dashboard/wireless/client-health/issue/ipaddress	66
	POST /dashboard/wireless/client-health/issue/roaming	67
	POST /dashboard/wireless/client-health/roaming-issues	67
Da.	ashboard Wireless Device Health	
	POST /dashboard/wireless/device-health/export	67
	POST /dashboard/wireless/device-health/grid	67
	POST /dashboard/wireless/device-health/cpu-usage-issues	67
	POST /dashboard/wireless/device-health/memory-usage-issues	67
	POST /dashboard/wireless/device-health/poe-usage-issues	68
	GET /dashboard/wireless/device-health/reboot/summary	68
	POST /dashboard/wireless/device-health/summary	68
Ge	eo View	68
	GET /geo-view	68
Ap	pplication	68
•	GET /applications	69
	GET /applications/{id}/clients/top{n}	



	GET /applications/top{n}	69
4le	rt	69
	GET /alert-policies	
	POST /alert-policies	
	GET /alert-policies/{id}	
	PUT /alert-policies/{id}	
	DELETE /alert-policies/{id}	
	GET /alert-policies/{id}/rules/{alert_rule_id}	
	PUT /alert-policies/{id}}/rules/{alert_rule_id}	
	POST /alert-policies/{id}}/rules/{alert_rule_id}/:disable	
	PUT /alert-policies/{id}}/rules/{alert_rule_id}/:enable	
	GET /alert-policies/available-sites	
	GET /alert-subscriptions/emails	
	POST /alert-subscriptions/emails	
	POST /alert-subscriptions/emails/:delete	
	GET /alert-subscriptions/emails/{id}	
	PUT /alert-subscriptions/emails/{id}	
	DELETE /alert-subscriptions/emails/{id}	
	POST /alert-subscriptions/emails/{id}/:verify	
	GET /alert-subscriptions/servicenow	
	POST /alert-subscriptions/servicenow	
	POST /alert-subscriptions/servicenow/:delete	
	GET /alert-subscriptions/servicenow/{id}	
	PUT /alert-subscriptions/servicenow/{id}	
	PATCH /alert-subscriptions/servicenow/{id}	
	GET /alert-subscriptions/webhooks	74
	POST /alert-subscriptions/webhooks	
	POST /alert-subscriptions/webhooks/:delete	75
	GET /alert-subscriptions/webhooks /{id}	
	PUT /alert-subscriptions/webhooks /{id}	
	DELETE /alert-subscriptions/webhooks /{id}	76
	GET /alerts	76
	POST /alerts/:acknowledge	76
	GET /alerts/count-by-{group}	76
	POST /alerts/report	77
	GET /alerts/reports/{id}	77
	]	77
LUG	GET /logs/accounting	
	GET /logs/accounting	
	GET /logs/audit/full-descriptions/{id}	
	POST /logs/audit/reports	
	GET /logs/audit/reports/{id}	
	GET /logs/auth	
	GET /logs/credential	
	GET /logs/email GET /logs/sms	
Vol	tification	
	GET /subscriptions/webhook	80



	POST /subscriptions/webnook	
	DELETE /subscriptions/webhook/:delete	80
	PUT /subscriptions/webhook/{id}	80
	GET /subscriptions/webhook/export	81
Adı	lministration	81
	GET /acct-api-token	81
	POST /acct-api-token	81
	DELETE /acct-api-token/:delete	81
	DELETE /acct-api-token/{id}	81
	PATCH /acct-api-token/{id}	82
	GET /acct-api-token/export	82
	GET /credential-distribution-groups	82
	POST /credential-distribution-groups	82
	DELETE /credential-distribution-groups	82
	PUT /credential-distribution-groups/{id}	82
	GET /third-party-api-connection	
	PUT /third-party-api-connection	83
	DELETE /third-party-api-connection	83
NO	os	<i>8</i> 3
Cor	nfiguration - Deployment	83
	GET /deployments	83
	POST /deployments	84
	GET /deployments/{id}	
	PUT /deployments/{id}	
	DELETE /deployments/{id}	
	GET /deployments/{id}/status	
	POST /deployments/firmware-metadatas	85
	GET /deployments/overview	
	GET /deployments/status	
Cor	nfiguration - Basic	86
	GET /vlan-profiles	86
	POST /vlan-profiles	86
	POST /vlan-profiles/:delete	86
	GET /vlan-profiles/{id}	86
	DELETE /vlan-profiles/{id}	86
	PATCH /vlan-profiles/{id}	87
Cor	nfiguration - User Management	
	GET /email-templates	
	GET /endusers	
	POST /endusers	
	PUT /endusers/{id}	
	DELETE /endusers/{id}	
	POST /endusers/{id}/:regenerate-password	
	GET /pcgs/key-based	
	POST /pcgs/key-based	
	DELETE /pcgs/key-based/network-policy-{policyId}	89



	POST /pcgs/key-based/network-policy-{policyid}/:onboard	
	POST /pcgs/key-based/network-policy-{policyId}/keys/:email	
	POST /pcgs/key-based/network-policy-{policyId}/keys/:generate	
	GET /pcgs/key-based/network-policy-{policyId}/port-assignments	
	POST /pcgs/key-based/network-policy-{policyId}/port-assignments	90
	GET /pcgs/key-based/network-policy-{policyId}/users	
	PUT /pcgs/key-based/network-policy-{policyId}/users	90
	POST /pcgs/key-based/network-policy-{policyId}/users	90
	DELETE /pcgs/key-based/network-policy-{policyId}/users	91
	GET /sms-templates	
	GET /usergroups	91
	POST /usergroups	91
	GET /usergroups/:unique	92
	PUT /usergroups/{id}	92
	DELETE /usergroups/{id}	92
c	Configuration - Policy	02
_	GET /ccgs	
	POST /ccgs	
	GET /ccgs/{id}	
	PUT /ccgs/{id}	
	DELETE /ccgs/{id}	
	GET /classification-rules	
	POST /classification-rules	
	GET /classification-rules/{id}	
	PUT /classification-rules/{id}	
	DELETE /classification-rules/{id}	
	GET /client-monitor-profiles	
	POST /client-monitor-profile	
	GET /client-monitor-profile/{id}	
	PUT /client-monitor-profile/{id}	
	DELETE /client-monitor-profile/{id}	
	GET /hotspot-profiles	
	POST /hotspot-profiles	
	GET /hotspot-profiles/{id}	
	PUT /hotspot-profiles/{id}	
	DELETE /hotspot-profiles/{id}	
	GET /hotspot-service-provider-profiles	
	POST /hotspot-service-provider-profiles	
	GET /hotspot-service-provider-profiles/{id}	
	PUT /hotspot-service-provider-profiles/{id}	
	DELETE /hotspot-service-provider-profiles/{id}	
	GET /iot-profiles	
	POST /iot-profiles	
	GET /iot-profiles/{id}	
	PUT /iot-profiles/{id}	
	DELETE /iot-profiles/{id}	
	GET /ip-firewall-policies	
	POST /ip-firewall-policies	
	GET /ip-firewall-policies/{id}	99



PUT /ip-tirewall-policies/{id}	100
DELETE /ip-firewall-policies/{id}	
POST /ip-firewall-policies/{{id}}/:attach	
POST /ip-firewall-policies/{{id}}/:detach	100
GET /I3-address-profiles	100
POST /I3-address-profiles	100
GET /I3-address-profiles/{id}	101
PUT /I3-address-profiles/{id}	101
DELETE /I3-address-profiles/{id}	
GET /mac-firewall-policies	101
POST /mac-firewall-policies	101
GET /mac-firewall-policies/{id}	102
PUT /mac-firewall-policies/{id}	102
DELETE /mac-firewall-policies/{id}	102
POST /mac-firewall-policies/{{id}}/:attach	102
POST /mac-firewall-policies/{{id}}/:detach	
GET /mac-object-profiles	102
POST /mac-object-profiles	
GET /mac-object-profiles/{id}	103
PUT /mac-object-profiles/{id}	
DELETE /mac-object-profiles/{id}	103
GET /radio-operating-modes/{id}	103
GET /radio-profiles	
POST /radio-profiles	104
GET /radio-profiles/{id}	
PUT /radio-profiles/{id}	104
DELETE /radio-profiles/{id}	104
GET /radio-profiles/channel-selection/{channel-selection-id}	
PUT /radio-profiles/channel-selection/{channel-selection-id}	105
GET /radio-profiles/mac-ouis	105
POST /radio-profiles/mac-ouis	
GET /radio-profiles/mac-ouis/{mac-oui-id}	
PUT /radio-profiles/mac-ouis/{mac-oui-id}	
DELETE /radio-profiles/mac-ouis/{mac-oui-id}	
GET /radio-profiles/miscellaneous/{radio-misc-id}	
PUT /radio-profiles/miscellaneous/{radio-misc-id}	
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}	
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}	
GET /radio-profiles/sensor-scan/{sensor-scan-id}	
PUT /radio-profiles/sensor-scan/{sensor-scan-id}	
GET /radio-profiles/wmm-qos/{radio-qos-id}	
PUT /radio-profiles/wmm-qos/{radio-qos-id}	
GET /ssids	
POST /ssids/{id}/:rename	
POST /ssids/{id}/client-monitor-profile/:attach	
POST /ssids/{id}/cwp/:attach	
POST /ssids/{id}/cwp/:disable	
POST /ssids/{id}/cwp/:enable	109



	PUT /ssids/{id}/mode/dot1x	110
	PUT /ssids/{id}/mode/open	110
	PUT /ssids/{id}/mode/ppsk	110
	PUT /ssids/{id}/mode/psk	110
	PUT /ssids/{id}/mode/wep	110
	PUT /ssids/{id}/psk/password	111
	POST /ssids/{id}/radius-client-profile	111
	POST /ssids/{id}/radius-server-group/:attach	111
	POST /ssids/{id}/user-profile-assignment	111
	POST /ssids/{id}/user-profile/:attach	111
	GET /ssids/advanced-settings/{id}	111
	PUT /ssids/advanced-settings/{id}	112
	GET /user-profile-assignments	112
	POST /user-profile-assignments	112
	GET /user-profile-assignments/{id}	112
	DELETE /user-profile-assignments/{id}	112
	GET /user-profiles	
	POST /user-profiles	
	GET /user-profiles/{id}	
	PUT /user-profiles/{id}	113
	DELETE /user-profiles/{id}	
	POST /user-profiles/{id}/ip-firewall-policies/:attach	
	POST /user-profiles/{id}/ip-firewall-policies/:detach	
	POST /user-profiles/{id}/mac-firewall-policies/:attach	
	POST /user-profiles/{id}/,ac-firewall-policies/:detach	114
_		
Co	onfiguration - Network	
	GET /network-services	
	POST /network-services	
	DELETE /network-services/{id}	
	GET /tunnel-concentrators	
	POST /tunnel-concentrators	
	GET /tunnel-concentrators/{id}	
	PUT /tunnel-concentrators/{id}	
	DELETE /tunnel-concentrators/{id}	116
Co	onfiguration - Authentication	116
	onfiguration - Authentication	
	GET /ad-servers	116
	GET /ad-servers	116 117
	GET /ad-servers GET /cwps GET /ldap-servers	116 117 117
	GET /ad-servers	116 117 117
	GET /ad-servers GET /cwps GET /ldap-servers POST /ldap-servers GET /ldap-servers/{id}	116117117117
	GET /ad-servers  GET /cwps  GET /ldap-servers  POST /ldap-servers  GET /ldap-servers/{id}  PUT /ldap-servers/{id}	116117117117117
	GET /ad-servers GET /cwps GET /ldap-servers POST /ldap-servers GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id}	
	GET /ad-servers GET /cwps GET /ldap-servers POST /ldap-servers GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id} GET /radius-client-objects	
	GET /ad-servers  GET /cwps  GET /ldap-servers  POST /ldap-servers  GET /ldap-servers/{id}  PUT /ldap-servers/{id}  DELETE /ldap-servers/{id}  GET /radius-client-objects  POST /radius-client-objects	
	GET /ad-servers  GET /cwps  GET /ldap-servers  POST /ldap-servers  GET /ldap-servers/{id}  PUT /ldap-servers/{id}  DELETE /ldap-servers/{id}  GET /radius-client-objects  POST /radius-client-objects  GET /radius-client-objects/{id}	
	GET /ad-servers GET /cwps GET /ldap-servers POST /ldap-servers GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id} GET /radius-client-objects POST /radius-client-objects GET /radius-client-objects/{id} PUT /radius-client-objects/{id}	
	GET /ad-servers  GET /cwps  GET /ldap-servers  POST /ldap-servers  GET /ldap-servers/{id}  PUT /ldap-servers/{id}  DELETE /ldap-servers/{id}  GET /radius-client-objects  POST /radius-client-objects  GET /radius-client-objects/{id}	



	POST /radius-proxies	119
	GET /radius-proxies/{id}	119
	PUT /radius-proxies/{id}	120
	DELETE /radius-proxies/{id}	120
	GET /radius-proxies/devices	120
	GET /radius-servers/external	120
	POST /radius-servers/external	121
	GET /radius-servers/external/{id}	121
	PUT /radius-servers/external/{id}	121
	DELETE /radius-servers/external/{id}	121
	GET /radius-servers/internal	121
	POST /radius-servers/internal	122
	DELETE /radius-servers/internal	122
	GET /radius-servers/internal/{id}	122
	PUT /radius-servers/internal/{id}	122
	DELETE /radius-servers/internal/{id}	123
	GET /radius-servers/internal/devices	123
Co	onfiguration - Certificate	123
-	GET /certificates	
_	·	
Co	ppilot – Connectivity Experience	
	GET /copilot/connectivity/client-type	
	GET /copilot/connectivity/locations	
	GET /copilot/connectivity/wired/events	
	GET /copilot/connectivity/wired/experience	
	GET /copilot/connectivity/wired/hardware	
	GET /copilot/connectivity/wired/locations/hardware	
	GET /copilot/connectivity/wired/quality-index	
	GET /copilot/connectivity/wireless/apps	
	GET /copilot/connectivity/wireless/events	
	GET /copilot/connectivity/wireless/experience	
	GET /copilot/connectivity/wireless/locations/events	
	GET /copilot/connectivity/wireless/locations/performance	
	GET /copilot/connectivity/wireless/locations/quality-index	
	GET /copilot/connectivity/wireless/locations/time-to-connect	
	GET /copilot/connectivity/wireless/performance	
	GET /copilot/connectivity/wireless/quality-index	
	GET /copilot/connectivity/wireless/time-to-connect	
	GET /copilot/connectivity/wireless/views	128
Со	pilot – Anomalies	128
	GET /copilot/anomalies/adverse-traffic/device-stats	128
	GET / copilot/anomalies/adverse-traffic/packet-counts	128
	GET /copilot/anomalies/anomalies-by-category	
	GET /copilot/anomalies/device-by-location	
	GET /copilot/anomalies/device-with-locations	
	PUT /copilot/anomalies/devices/feedback	
	PUT /copilot/anomalies/devices/update-action	
	GET /copilot/anomalies/dfs-recurrence/channel-stats	
	GET /copilot/anomalies/dfs-recurrence/count-stats	



(	GET /copilot/anomalies/exclude-vlans	130
G	GET /copilot/anomalies/exclude-vlans-csv	130
G	GET /copilot/anomalies/exclude-vlans-list	131
G	GET /copilot/anomalies/hardware-health/client-list	131
G	GET /copilot/anomalies/hardware-health/cpu-mem-stats	131
G	GET /copilot/anomalies/hardware-health/stats	131
G	GET /copilot/anomalies/locations	131
(	GET /copilot/anomalies/missing-vlan/count	132
(	GET /copilot/anomalies/notifications	132
G	GET /copilot/anomalies/poeflapping/lldp-cdp-info	132
G	GET /copilot/anomalies/poeflapping/stats	132
G	GET /copilot/anomalies/poeflapping/trends	133
G	GET /copilot/anomalies/port-efficiency/speed-duplex-stats	133
G	GET /copilot/anomalies/port-efficiency/stats	133
G	GET /copilot/anomalies/wifi-capacity/client-list	133
G	GET /copilot/anomalies/wifi-capacity/stats	134
G	GET /copilot/anomalies/report	134
	PUT /copilot/anomalies/update-action	
	PUT / copilot/anomalies/update-device-action	
	GET /copilot/anomalies/wifi-efficiency/client-list	
	GET /copilot/anomalies/wifi-efficiency/stats	
(	GET /copilot/assurance-scans/overview	135
Packe	et Capture	
(	GET /packetcaptures	135
P	POST /packetcaptures	136
(	GET /packetcaptures/{id}	136
	Delete /packetcaptures/{id}	136
P	POST /packetcaptures/{id}/:stop	136
P	POST /packetcaptures/{id}/:upload	137
(	GET /packetcaptures/files	137
Netw	ork Scorecard	
G	GET /network-scorecard/clientHealth/{id}	137
	GET /network-scorecard/deviceHealth/{id}	
G	GET /network-scorecard/networkHealth/{id}	138
(	GET /network-scorecard/serviceHealth/{id}	138
(	GET /network-scorecard/wifiHealth/{id}	138
Fssen	tials - ExtremeLocation	138
	GET /essentials/eloc/clients/{client-mac}/last-known-location	
	- Metadata – Country	
	GET /countries	
	GET /countries/{countryAlpha2Code}/states	
	GET /countries/{id}/:validate	
Threa		
(	GET /thread/networks	140
	GET /thread/routers	
(	GET /thread/topology	140



Universal Compute Platform	140
GET /upc/{id}/engines/installed	140
AFC-endpoint	141
GET /afcserver	
GET /afcserver/{id}	
GET /afcserver/statistics/{id}	
GET /afcserver/diagnostics/{sn}	
GET /ap/afc/interface/details/{sn}	
POST /ap/spectrum	
GET /aps/afc/query	
POST /aps/afc/update	
GET /site/afc/schedule	
PUT /site/afc/schedule	
POST /site/afc/schedule	
POST /site/spectrum	
RTTS-endpoint	143
POST /rtts-endpoint	
POST /rtts-endpoint	
APPENDIX – A	143
API call list based on Roles	
Administrator	143
Operator	143
Monitor	143
Installer	145
Observer	
Help Desk	
Application Operator	155
Guest Management	
APPENDIX – B	
API call list based on Permission	158
logout	
auth	
auth:r	
token:new	
perm:check	
Iro	
lro:r	
account	
account:switch	
account:r	
vig:backup	
user-me:r	
user:r	
hig	
hig:r	
org	
<del>-</del>	



org:new	
org:del	
org:rename	161
hiq.ctx	161
hiq.ctx:r	161
hig.ctx:w	161
device	
device:r	163
device:list	
device:view	
device:new	
device:del	
device:cli	
device:deploy	
device:manage	
device:unmanage	
device:reboot	
device:reset	
device:thread-commissioner	
client	
client:r	
locations	
locations:	
network-policy	
policy:ssid	
network-policy:r	
network-scorecard	
network-scorecard:r	
ssid	
ssid:r	
pcg:key	
pcg:key:r	
subscriptions-webhook	
subscriptions-webhook:r	
ccg	
ccg:r	
log	169
log:r	169
cwp	169
cwp:r	169
sms-tmpl	169
sms-tmpl:r	169
class-rule	170
class-rule:r	170
user-profile	
user-profile:r	
tunnel-concentrator	
tunnel-concentrator:r	
radius-proxy	
radius-proxy:r	
	<u> </u>



radius-server	171
radius-server:r	
usergroup	171
usergroup:r	
deployment	172
deployment:r	172
ad-server	172
ad-server:r	172
alert	172
alert:r	173
alert-policies	173
alert-policies:r	
alert-subscriptions	
alert-subscriptions:r	
app	
application:r	
l3-address-profile	
l3-address-profile:r	
vlan-profile	
vlan-profile:r	
enduser	
enduser:r	
radius-client-object	
radius-client-object:r	
ldap-server	
ldap-server:r	
email-template	
email-template:r	
certificate	
certificate:r	
radio-profile	
radio-profile:r	
iot-profile	
iot-profile:r	
client-monitor-profile	
client-monitor-profile:r	
copilot-connectivity-wired:r	
copilot-connectivity-wired:	
copilot-anomalies:r	
licenses	
licenses:r	
copilot-assurance-scans:r	
packet-capture	
packet-capture:r	
country	
country:r	
Cas	
cas:r	
cas-policies	
cas-policies:r	180



cas-metadata:r	
cns-subscriptions	
cns-subscriptions:r	
hotspot-profile	
hotspot-profile:r	
hotspot-service-provider-profile	
hotspot-service-provider-profile·r	181



### Introduction

This document will list each category of XIQ APIs and all the API calls under those categories. Laid out as it is laid out on the api.extremecloudiq.com Swagger page. Under each category, the document will list the category permissions that can be used for the API calls in that category. Most categories have two permissions for the category. The first permission will match or be similar to the category's name. Example - **device** for the devices category. This permission will give access to all the GET, POST, PUT, PATCH, and DELETE API calls in that category. The second permission will be named the same as the first but followed with a :r. Example - **device**:r for the devices category. This permission will give access to only the GET API calls in that category.

This document will also list any additional permissions available for a particular API call. This would allow for a token to be created only to be able to perform a specific API call without having permission to do all API calls within the category. Example – **device:list** under the <u>GET</u> <u>/devices</u> API call. This would allow the token only to be able to view the list of devices using that API call but not be able to perform any of the other GET API calls in the devices category.

This document also notes which Roles have access to each of the API call.

In addition, there is  $\underline{\text{Appendix - A}}$  that lists the different roles with a list of the API calls available to those roles by default as well as  $\underline{\text{Appendix - B}}$  that lists the different permissions with a list of the API calls available with that permission.



### **Authentication**

No default permissions for this category

### POST /login

No permissions needed – This call uses basic auth to generate a token. This token will have access to APIs based on the user's role.

# POST /logout Permissions:

"logout" – revokes currently used token

#### Roles:

```
"Operator",
"Help Desk",
"Monitor",
"Administrator"
```

### **Authorization**

#### Permissions:

"auth" – Permission for all API calls in the Authorization Section

### POST /auth/apitoken

### Permissions:

"token:new" – Permission to generate a new token.

NOTE: new tokens can only be granted permissions that the currently used token has.

Also included with "auth"

#### Roles:

```
"Operator",
"Administrator",
```

### POST /auth/apitoken/:validate

Permissions:

<sup>&</sup>quot;Administrator", "Installer",

<sup>&</sup>quot;Observer",

<sup>&</sup>quot;Guest Management"

<sup>&</sup>quot;auth:r" – Permission for all GET API calls in the Authorization Section

<sup>&</sup>quot;Monitor",

<sup>&</sup>quot;Installer"



No Specific permission - included with "auth" Roles: "Operator", "Administrator" GET /auth/apitoken/info Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /auth/permissions Permissions: No Specific permission - included with "auth" and "auth:r" Roles: "Operator", "Administrator", "Monitor", "Observer" POST /auth/permissions/:check Permissions: "perm:check" – Allows token to check permissions needed for any API call Also included with "auth" Roles "Operator", "Administrator" Operation Permissions: "Iro" – Permission for all API calls in the Operation Section "lor:r" – Permission for all GET API calls in the Operation Section GET /operations/{operationId} Permissions:



No Specific permission - included with "lro" and "lro:r" Roles: "Operator", "Administrator" DELETE /operations/{operationId} Permissions: No Specific permission - included with "lro" Roles: "Operator", "Administrator" POST /operations/{operationId}/:cancel Permissions: No Specific permission - included with "lro" "Operator", "Administrator" Account "account" - Permission for all API calls in the Account Section "account:r" - Permission for all GET API calls in the Account Section POST /account/:switch Permissions: "account:switch" - Allows user to switch to external account Also included with "account" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator",

"Guest Management"



### GET /account/external Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" GET /account/home Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" GET /account/third-party-applications Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer",

"Application Operator",
"Guest Management"



### GET /account/vhm/setting Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" PUT /account/vhm/setting/{id} Permissions: No Specific permission - included with "account" Roles: "Operator", "Administrator" GET /account/vhm/setting/status Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Application Operator", "Guest Management" GET /account/viq Permissions: No Specific permission - included with "account" and "account:r" Roles: "Operator", "Help Desk", "Administrator",



```
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/:backup
Permissions:
"viq:backup" – Permission to backup the viq.
Also included with "account"
Roles:
"Operator",
"Administrator"
POST /account/viq/:reset
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/viq/default-device-password
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
PUT /account/viq/default-device-password
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
```



#### "Administrator"

```
GET /account/viq/download
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/export
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
"Administrator"
GET /account/viq/export-import-status
Permissions:
No Specific permission - included with "account" and "account:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Application Operator",
"Guest Management"
POST /account/viq/import
Permissions:
No Specific permission - included with "account"
Roles:
"Operator",
```



### "Administrator"

POST /backup/history/:restore

Permissions: NOT SET!

Roles: NOT SET!

POST /backup/history/delete

Permissions: NOT SET!

Roles: NOT SET!

GET /backup/history/grid

Permissions: NOT SET!

Roles: NOT SET!

PUT /backup/history/grid

Permissions: NOT SET!

Roles: NOT SET!

### Users

Permissions:

"user" – Permission for all API calls in the User Section

"user:r" – Permission for all GET API calls in the User Section

### **GET /users**

Permissions:

No Specific permission - included with "user" and "user:r"

Roles:

"Operator",

"Administrator",



# "Monitor" **POST /users** Permissions: No Specific permission - included with "user" Roles: "Administrator" GET /users/{id} Permissions: No Specific permission - included with "user" and "user:r" Roles: "Operator", "Administrator", "Monitor" DELETE /users/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" PATCH /users/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" **GET /users/external** Permissions: No Specific permission - included with "user" and "user:r" Roles: "Operator", "Administrator", "Monitor"



# POST /users/external Permissions: No Specific permission - included with "user" Roles: "Administrator" GET /users/external/{id} Permissions: No Specific permission - included with "user" and "user:r" Roles: "Operator", "Administrator", "Monitor" DELETE /users/external/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" PATCH /users/external/{id} Permissions: No Specific permission - included with "user" Roles: "Administrator" GET /users/me Permissions: "user-me:r" – Permission to view details on yourself Roles: "Operator", "Administrator", "Monitor" HIQ

Permissions:

"hig" – Permission for all API calls in the HIQ Section



"hig:r" - Permission for all GET API calls in the HIQ Section GET /hiq/context Permissions: "hig.ctx" – Permission for control HIQ Context (HIQ account only). "hiq.ctx:r" – Permission to read HIQ Context (HIQ account only). Also included with "hiq" and "hiq:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" PUT /hiq/context Permissions: "hiq.ctx" – Permission for control HIQ Context (HIQ account only). "hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only). Also included with "hiq" Roles: "Operator", "Administrator", "Installer" GET /hiq/context/creating Permissions: "hiq.ctx" – Permission for control HIQ Context (HIQ account only). "hiq.ctx:r" – Permission to read HIQ Context (HIQ account only). Also included with "hiq" and "hiq:r" Roles: "Operator", "Help Desk", "Administrator",

"Monitor",
"Installer",
"Observer"



```
PUT /hiq/context/creating
Permissions:
"hiq.ctx" – Permission for full control HIQ Context (HIQ account only).
"hig.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/context/reading
Permissions:
"hiq.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:r" – Permission to read HIQ Context (HIQ account only).
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hiq/context/reading
Permissions:
"hig.ctx" – Permission for control HIQ Context (HIQ account only).
"hiq.ctx:w" – Permission to switch HIQ Context (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator",
"Installer"
GET /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
```



```
Also included with "hiq" and "hiq:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /hiq/organizations
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:new" – Permission to create HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
DELETE /hiq/organizations/{id}
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:del" – Permission to delete HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
POST /hiq/organizations/{id}/:rename
Permissions:
"org" – Permission for full control HIQ organizations (HIQ account only).
"org:rename" – Permission to rename HIQ organization (HIQ account only).
Also included with "hiq"
Roles:
"Operator",
"Administrator"
```



# **GET /hiq/status** Permissions: No Specific permission - included with "hiq" and "hiq:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" Location Permissions: "locations" – Permission for all API calls in the Location Section "locations:r" – Permission for all GET API calls in the Location Section **POST /locations** Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" POST /locations/:init Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" PUT /locations/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator",



```
"Administrator"
"Installer"
DELETE /locations/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/building
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/building
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/building/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
```



### "Observer"

```
PUT /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
DELETE /locations/building/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/floor
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/floor
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
```



## GET /locations/floor/{id} Permissions: No Specific permission - included with "locations" and "locations:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" PUT /locations/floor/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" DELETE /locations/floor/{id} Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" POST /locations/floorplan Permissions: No Specific permission - included with "locations" Roles: "Operator", "Administrator" "Installer" POST /locations/import/ekahau Permissions: No Specific permission - included with "locations"



```
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/site
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /locations/site
Permissions:
No Specific permission - included with "locations"
Roles:
"Operator",
"Administrator"
"Installer"
GET /locations/site/{id}
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /locations/site/{id}
Permissions:
No Specific permission - included with "locations"
Roles:
```



```
"Operator",
"Administrator"
"Installer"
DELETE /locations/site/{id}
Permissions:
No Specific permission - included with "locations"
"Operator",
"Administrator"
"Installer"
GET /locations/tree
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/devices
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /locations/tree/maps
Permissions:
No Specific permission - included with "locations" and "locations:r"
Roles:
"Operator",
"Help Desk",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
Device
Permissions:
"device" – Permission for all API calls in the Device Section
"device:r" – Permission for all GET API calls in the Device Section
GET /devices
Permissions:
"device:list" – Permission to get the list of devices
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/:advanced-onboard
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:check-ownership
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
```

"Installer"



# POST /devices/:cli Permissions: "device:cli" – Permission to send cli commands to device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/:delete Permissions: "device:del" – Permission to delete device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/:manage Permissions: "device:mange" – Permission to change management on device(s) to MANAGED Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/:onboard Permissions: "device:new" – Permission to onboard device(s) Also included with "device" Roles: "Operator", "Administrator",



```
"Installer"
POST /devices/:reboot
Permissions:
"device:reboot" – Permission to reboot device(s)
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/:unmanage
Permissions:
"device:mange" – Permission to change management on device(s) to UNMANAGED
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
DELETE /devices/{id}
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
```



```
"Administrator",
"Installer"
POST /devices/{id}/:cli
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:manage
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:reboot
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:reset
Permissions:
"device:reset" – Permission to reset a device to factory default
Also included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/:unmanage
Permissions:
```



No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/alarms Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/bounce-port Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/client-monitor Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", **"Observer** PUT /devices/{id}/client-monitor Permissions: No Specific permission - included with "device" Roles: "Operator",



```
"Administrator",
"Installer"
DELETE /devices/{id}/client-monitor
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
PUT /devices/{id}/description
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/ftm-settings
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/{id}/config/ftm-settings
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/config/ftm-settings
Permissions:
```



```
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/gallery-image
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/geolocation
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/history/cpu-mem
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/hostname
Permissions:
No Specific permission - included with "device"
```



```
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/ibeacon
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/installation-report
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/interfaces/wifi
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /devices/{id}/iot
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /devices/{id}/iot/:disable
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/iot/:enable
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/location
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/location
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



### DELETE /devices/{id}/location Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/monitor/:refresh Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" GET /devices/{id}/monitor/refresh/status Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" GET /devices/{id}/network-policy Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /devices/{id}/network-policy Permissions: No Specific permission - included with "device"



```
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/{id}/network-policy
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/{id}/radio-operating-mode
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/{id}/radio-operating-mode
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/{id}/ssid/:override
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



## GET /devices/{id}/ssid/status Permissions: No Specific permission - included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /devices/{id}/ssid/status/:change Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/thread/commissioner/:start Permissions: "device:thread-commissioner" – Permission to change thread commissioner to device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/{id}/thread/commissioner/:stop Permissions: "device:thread-commissioner" – Permission to change thread commissioner to device(s) Also included with "device" Roles: "Operator", "Administrator", "Installer"



## PUT /devices/{id}/thread/visible Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/client-monitor/:assign Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/ client-monitor/:revoke Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/client-monitor/:query Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/country-code/:assign Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator",



# "Installer" GET /devices/{id}/digital-twin Permissions: "device:view" – Permission to view details of a device Also included with "device" and "device:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /devices/ibeacon Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/location/:assign Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer" POST /devices/location/:query Permissions: No Specific permission - included with "device" Roles: "Operator", "Administrator", "Installer"



```
POST /devices/location/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:query
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/network-policy/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/network-policy/{policyId}
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
POST /devices/os/:change
Permissions:
No Specific permission - included with "device"
"Operator",
"Administrator",
"Installer"
GET /devices/radio-information
Permissions:
"device:list" – Permission to get the list of devices
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /devices/radius-proxy/:assign
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
DELETE /devices/radius-proxy/:revoke
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
```



```
POST /devices/rm-devices-connection-status
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/rm-devices-metadata
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/rm-devices-page
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
POST /devices/rm-devices-page/export
Permissions:
No Specific permission - included with "device"
Roles:
"Operator",
"Administrator",
"Installer"
GET /devices/rm-devices-stack/{id}
Permissions:
No Specific permission - included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
GET /devices/stats
Permissions:
"device:view" – Permission to view details of a device
Also included with "device" and "device:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Network Policy
Permissions:
"network-policy" – Permission for all API calls in the Network Policy Section
"network-policy:r" – Permission for all GET API calls in the Network Policy Section
GET /network-policies
Permissions:
No Specific permission - included with "network-policy" and "network-policy:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /network-policies
Permissions:
No Specific permission - included with "network-policy"
Roles:
"Operator",
"Administrator"
GET /network-policies/{id}
Permissions:
```



No Specific permission - included with "network-policy" and "network-policy:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /network-policies/{id} Permissions: No Specific permission - included with "network-policy" Roles: "Operator", "Administrator" DELETE /network-policies/{id} Permissions: No Specific permission - included with "network-policy" Roles: "Operator", "Administrator" GET /network-policies/{id}/ssids Permissions: No Specific permission - included with "network-policy" and "network-policy:r" Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /network-policies/{id}/ssids/:add Permissions: "policy:ssid" – SSID management on network-policy Also included with "network-policy"

Roles:



```
"Operator",
"Administrator"
POST /network-policies/{id}/ssids/:remove
Permissions:
"policy:ssid" – SSID management on network-policy
Also included with "network-policy"
Roles:
"Operator",
"Administrator"
Client
Permissions:
"client" - Permission for all API calls in the Client Section
"client:r" – Permission for all GET API calls in the Client Section
GET /clients/{id}
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/active
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer"
```



### PUT /clients/alias Permissions: No Specific permission - included with "client" Roles: "Operator", "Administrator" GET /clients/active/count Permissions: No Specific permission - included with "client" and "client:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" GET /clients/byMac/{client\_mac} Permissions: No Specific permission - included with "client" and "client:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" DELETE /clients/byMac/{client\_mac} Permissions: No Specific permission - included with "client" Roles: "Operator", "Administrator" **GET /clients/summary** Permissions: No Specific permission - included with "client" and "client:r"



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /clients/usage
Permissions:
No Specific permission - included with "client" and "client:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
Client - Details
No default permissions for this category
GET /client-details/overview/chart-data/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
GET /client-details/overview/info/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
D360
No default permissions for this category
POST /d360/client/graph
Permissions:
NOT SET!
```



POST /d360/client/grid Permissions: NOT SET! Roles: NOT SET! POST /d360/client/grid/metadata Permissions: NOT SET! Roles: NOT SET! POST /d360/client/stats Permissions: NOT SET! Roles: NOT SET! POST /d360/device/interfaces Permissions: NOT SET! Roles: NOT SET! POST /d360/device/issues Permissions: NOT SET! Roles: NOT SET! POST /d360/device/metadata Permissions: NOT SET!

Roles: NOT SET!



Roles: NOT SET!
POST /d360/device/stats Permissions: NOT SET!
Roles: NOT SET!
POST /d360/overview/devices-summary Permissions: NOT SET!
Roles: NOT SET!
POST /d360/ssid-metadata Permissions: NOT SET!
Roles: NOT SET!
POST /d360/wireless/interfaces-graph Permissions: NOT SET!
Roles: NOT SET!
POST /d360/wireless/interfaces-stats Permissions: NOT SET!
Roles: NOT SET!
POST /d360/wireless/surrounding-aps Permissions: NOT SET!
Roles:



#### NOT SET!

### **Dashboard**

No default permissions for this category

POST /dashboard/alerts

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/assets

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/clients

Permissions: NOT SET!

Roles:

NOT SET!

GET /dashboard/device-types

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/devices

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/export

Permissions:



NOT SET!
Roles: NOT SET!
POST /dashboard/sites-with-issues Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/usage-capacity Permissions: NOT SET!
Roles: NOT SET!
GET /dashboard/wireless/dashboard/critera Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/dashboard/critera Permissions: NOT SET!
Roles: NOT SET!
Dashboard Wireless Usage and Capacity No default permissions for this category
POST /dashboard/wireless/usage-capacity/excessive-packet-loss Permissions: NOT SET!
Roles: NOT SET!



POST /dashboard/wireless/usage-capacity/excessive-retries Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/usage-capacity/excessive-utilization Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/usage-capacity/export Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/usage-capacity/grid Permissions: NOT SET!
Roles: NOT SET!
Dashboard Wireless Client Health No default permissions for this category
POST /dashboard/wireless/client-health/connectivity-issues Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/export Permissions: NOT SET!



Roles: NOT SET!
POST /dashboard/wireless/client-health/filter-metadata Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/frequency-distribution Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/grid Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/issue/association Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/issue/authentication Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/client-health/issue/ipaddress Permissions: NOT SET!
Roles:



#### NOT SET!

POST /dashboard/wireless/client-health/issue/roaming Permissions:

NOT SET!

Roles:

NOT SET!

POST /dashboard/wireless/client-health/roaming-issues

Permissions: NOT SET!

Roles:

NOT SET!

### **Dashboard Wireless Device Health**

No default permissions for this category

POST /dashboard/wireless/device-health/export

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/wireless/device-health/grid

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/wireless/device-health/cpu-usage-issues

Permissions: NOT SET!

Roles:

NOT SET!

POST /dashboard/wireless/device-health/memory-usage-issues

Permissions:



NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/device-health/poe-usage-issues Permissions: NOT SET!
Roles: NOT SET!
GET /dashboard/wireless/device-health/reboot/summary Permissions: NOT SET!
Roles: NOT SET!
POST /dashboard/wireless/device-health/summary Permissions: NOT SET!
Roles: NOT SET!
Geo View
No default permissions for this category
GET /geo-view
Permissions:

# **Application**

Permissions:

NOT SET!

Roles: NOT SET!

<sup>&</sup>quot;app" – Permission for all API calls in the Application Section

<sup>&</sup>quot;application:r" – Permission for all GET API calls in the Application Section



# **GET /applications** Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /applications/{id}/clients/top{n} Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" GET /applications/top{n} Permissions: No Specific permission - included with "app" and "application:r" Roles: "Operator", "Administrator", "Monitor", "Observer" **Alert** No default permissions for this category **GET /alert-policies** Permissions: "alert-policies" – Permission for full control of alert polices. "alert-policies:r" – Permission to read alert polices. Roles: "Operator", "Administrator",



```
"Monitor",
"Installer",
"Observer"
POST /alert-policies
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
DELETE /alert-policies/{id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/{id}/rules/{alert_rule_id}
Permissions:
```



```
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /alert-policies/{id}}/rules/{alert_rule_id}
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
POST /alert-policies/{id}}/rules/{alert_rule_id}/:disable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
PUT /alert-policies/{id}}/rules/{alert_rule_id}/:enable
Permissions:
"alert-policies" – Permission for full control of alert polices.
Roles:
"Operator",
"Administrator"
GET /alert-policies/available-sites
Permissions:
"alert-policies" – Permission for full control of alert polices.
"alert-policies:r" – Permission to read alert polices.
Roles:
"Operator",
"Administrator",
```



```
"Monitor",
"Installer",
"Observer"
GET /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/emails
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/emails/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/emails/{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
```



## PUT /alert-subscriptions/emails/{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" DELETE /alert-subscriptions/emails/{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" POST /alert-subscriptions/emails/{id}/:verify Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" GET /alert-subscriptions/servicenow Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. "alert-subscriptions:r" – Permission to read alert subscriptions. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer POST /alert-subscriptions/servicenow Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator",



## "Administrator" POST /alert-subscriptions/servicenow/:delete Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" GET /alert-subscriptions/servicenow/{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. "alert-subscriptions:r" – Permission to read alert subscriptions. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer PUT /alert-subscriptions/servicenow/{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions.

Roles:

"Operator",

"Administrator"

PATCH /alert-subscriptions/servicenow/{id}

Permissions:

"alert-subscriptions" – Permission for full control of alert subscriptions.

Roles:

"Operator",

"Administrator"

GET /alert-subscriptions/webhooks

Permissions:

"alert-subscriptions" – Permission for full control of alert subscriptions.

"alert-subscriptions:r" – Permission to read alert subscriptions.



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
POST /alert-subscriptions/webhooks
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
POST /alert-subscriptions/webhooks/:delete
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
GET /alert-subscriptions/webhooks /{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
"alert-subscriptions:r" – Permission to read alert subscriptions.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer
PUT /alert-subscriptions/webhooks /{id}
Permissions:
"alert-subscriptions" – Permission for full control of alert subscriptions.
Roles:
"Operator",
"Administrator"
```



## DELETE /alert-subscriptions/webhooks /{id} Permissions: "alert-subscriptions" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" **GET /alerts** Permissions: "alert" – Permission for full control of alerts. "alert:r" – Permission to read alerts. Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" POST /alerts/:acknowledge Permissions: "alert" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" GET /alerts/count-by-{group} Permissions: "alert" – Permission for full control of alerts. "alert:r" – Permission to read alerts. Roles: "Operator", "Help Desk", "Administrator", "Monitor",

"Installer",
"Observer"



## POST /alerts/report Permissions: "alert" – Permission for full control of alert subscriptions. Roles: "Operator", "Administrator" GET /alerts/reports/{id} Permissions: "alert" – Permission for full control of alerts. "alert:r" – Permission to read alerts. Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer" Log Permissions: "log" – Permission for all API calls in the Log Section "log:r" – Permission for all GET API calls in the Log Section **GET /logs/accounting** Permissions: No Specific permission - included with "log" and "log:r" Roles: "Operator", "Administrator", "Monitor", 'Installer', "Observer", "Application Operator" **GET /logs/audit** Permissions:

No Specific permission - included with "log" and "log:r"



```
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/audit/full-descriptions/{id}
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
POST /logs/audit/reports
Permissions:
No Specific permission - included with "log"
Roles:
"Operator",
"Administrator
GET /logs/audit/reports/{id}
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/auth
Permissions:
No Specific permission - included with "log" and "log:r"
```

Page 78 of 181



```
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/credential
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/email
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
GET /logs/sms
Permissions:
No Specific permission - included with "log" and "log:r"
Roles:
"Operator",
"Administrator",
"Monitor",
'Installer',
"Observer",
"Application Operator"
```



### **Notification**

### Permissions:

- "subscriptions-webhook" Permission for all API calls in the Notification Section
- "subscriptions-webhook:r" Permission for all GET API calls in the Notification Section

### **GET /subscriptions/webhook**

Permissions:

No Specific permission - included with "subscriptions-webhook" and "subscriptions-webhook:r"

#### Roles:

- "Operator",
- "Administrator",
- "Monitor",
- "Observer"

### POST /subscriptions/webhook

Permissions:

No Specific permission - included with "subscriptions-webhook"

### Roles:

- "Operator",
- "Administrator"

### DELETE /subscriptions/webhook/:delete

Permissions:

No Specific permission - included with "subscriptions-webhook"

#### Roles:

- "Operator",
- "Administrator"

### PUT /subscriptions/webhook/{id}

Permissions:

No Specific permission - included with "subscriptions-webhook"

### Roles:

- "Operator",
- "Administrator"



### GET /subscriptions/webhook/export

Permissions:

No Specific permission - included with "subscriptions-webhook" and "subscriptions-webhook:r"

Roles:

"Operator",

"Administrator",

"Monitor",

"Observer"

## Administration

No default permissions for this category

GET /acct-api-token

Permissions:

NOT SET!

Roles:

NOT SET!

POST /acct-api-token

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /acct-api-token/:delete

Permissions:

NOT SET!

Roles:

NOT SET!

DELETE /acct-api-token/{id}

Permissions:

NOT SET!

Roles:

NOT SET!



# PATCH /acct-api-token/{id} Permissions: NOT SET! Roles: NOT SET! GET /acct-api-token/export Permissions: NOT SET! Roles: NOT SET! GET /credential-distribution-groups Permissions: NOT SET! Roles: NOT SET! POST /credential-distribution-groups Permissions: NOT SET! Roles: NOT SET! DELETE /credential-distribution-groups Permissions: NOT SET! Roles: NOT SET! PUT /credential-distribution-groups/{id} Permissions: NOT SET! Roles: NOT SET!



# GET /third-party-api-connection Permissions: NOT SET! Roles: NOT SET! PUT /third-party-api-connection Permissions: NOT SET! Roles: NOT SET! DELETE /third-party-api-connection Permissions: NOT SET! Roles: NOT SET! NOS No default permissions for this category Configuration - Deployment "deployment" – Permission for all API calls in the Configuration - Deployment Section "deployment:r" – Permission for all GET API calls in the Configuration – Deployment Section **GET /deployments** Permissions: No Specific permission - included with "deployment" and "deployment:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer",

"Observer",

"Guest Management"



## **POST /deployments** Permissions: No Specific permission - included with "deployment" Roles: "Operator", "Administrator" GET /deployments/{id} Permissions: No Specific permission - included with "deployment" and "deployment:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer", "Observer", "Guest Management" PUT /deployments/{id} Permissions: No Specific permission - included with "deployment" Roles: "Operator", "Administrator DELETE /deployments/{id} Permissions: No Specific permission - included with "deployment" Roles: "Operator", "Administrator GET /deployments/{id}/status Permissions: No Specific permission - included with "deployment" and "deployment:r" Roles:



```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
POST /deployments/firmware-metadatas
Permissions:
No Specific permission - included with "deployment"
Roles:
"Operator",
"Administrator"
GET /deployments/overview
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
GET /deployments/status
Permissions:
No Specific permission - included with "deployment" and "deployment:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer",
"Observer",
"Guest Management"
```



```
Configuration - Basic
Permissions:
"vlan-profile" – Permission for all API calls in the Configuration - Basic Section
"vlan-profile:r" - Permission for all GET API calls in the Configuration - Basic Section
GET /vlan-profiles
Permissions:
No Specific permission - included with "vlan-profile" and "vlan-profile:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /vlan-profiles
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
POST /vlan-profiles/:delete
Permissions:
No Specific permission - included with "vlan-profile"
Roles:
"Operator",
"Administrator"
GET /vlan-profiles/{id}
Permissions:
No Specific permission - included with "vlan-profile" and "vlan-profile:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
```

DELETE /vlan-profiles/{id}

Permissions:



No Specific permission - included with "vlan-profile"

```
Roles:
"Operator",
"Administrator"

PATCH /vlan-profiles/{id}
Permissions:
No Specific permission - included with "vlan-profile"

Roles:
"Operator",
"Administrator"
```

## Configuration - User Management

No default permissions for this category

```
GET /email-templates
```

```
Permissions:
```

"email-template" — Permission for full of email template.
"email-template:r" — Permission to read email templates

```
Roles:
```

```
"Operator",
"Administrator",
"Monitor",
"Observer"
```

### **GET /endusers**

#### Permissions:

"enduser" – Permission for full control of end users.

"enduser:r" – Permission to read end users

### Roles:

```
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Observer",
"Guest Management"
```



## **POST /endusers** Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" PUT /endusers/{id} Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" DELETE /endusers/{id} Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" POST /endusers/{id}/:regenerate-password Permissions: "enduser" – Permission for full control of end users. Roles: "Operator", "Administrator", "Guest Management" GET /pcgs/key-based Permissions: "pcg:key" – Permission for full control of PCG key based. "pcg:key:r" – Permission to read PCG key based Roles: "Operator",



```
"Administrator",
"Monitor",
"Observer"
POST /pcgs/key-based
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
DELETE /pcgs/key-based/network-policy-{policyId}
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/:onboard
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/keys/:email
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/keys/:generate
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
```



```
GET /pcgs/key-based/network-policy-{policyId}/port-assignments
Permissions:
"pcg:key" – Permission for full control of PCG key based.
"pcg:key:r" – Permission to read PCG key based
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /pcgs/key-based/network-policy-{policyId}/port-assignments
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
GET /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
"pcg:key:r" – Permission to read PCG key based
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
POST /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
```



```
Roles:
"Operator",
"Administrator"
DELETE /pcgs/key-based/network-policy-{policyId}/users
Permissions:
"pcg:key" – Permission for full control of PCG key based.
Roles:
"Operator",
"Administrator"
GET /sms-templates
Permissions:
"sms-tmpl" – Permission for full control of SMS template.
"sms-tmpl:r" - Permission to read SMS template
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /usergroups
Permissions:
"usergroup" – Permission for full control of user groups.
"usergroup:r" – Permission to read user groups
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Guest Management"
POST /usergroups
Permissions:
"usergroup" – Permission for full control of user groups.
Roles:
"Operator",
```

"Administrator"



## GET /usergroups/:unique Permissions: "usergroup" – Permission for full control of user groups. "usergroup:r" – Permission to read user groups Roles: "Operator", "Administrator", "Monitor", "Observer", "Guest Management" PUT /usergroups/{id} Permissions: "usergroup" – Permission for full control of user groups. Roles: "Operator", "Administrator" DELETE /usergroups/{id} Permissions: "usergroup" – Permission for full control of user groups. Roles: "Operator", "Administrator" **Configuration - Policy** No default permissions for this category **GET /ccgs** Permissions: "ccg" – Permission for full control of CCG. "ccg:r" - Permission to read CCG Roles: "Operator", "Administrator", "Monitor", "Observer"



```
POST /ccgs
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
GET /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
"ccg:r" - Permission to read CCG
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
DELETE /ccgs/{id}
Permissions:
"ccg" – Permission for full control of CCG.
Roles:
"Operator",
"Administrator"
GET /classification-rules
Permissions:
"class-rule" – Permission for full control of classification rule.
"class-rule:r" – Permission to read classification rule
Roles:
"Operator",
"Administrator",
"Monitor",
```



# "Observer" POST /classification-rules Permissions: "class-rule" – Permission for full control of classification rule. Roles: "Operator", "Administrator" GET /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. "class-rule:r" - Permission to read classification rule Roles: "Operator", "Administrator", "Monitor", "Observer" PUT /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. Roles: "Operator", "Administrator" DELETE /classification-rules/{id} Permissions: "class-rule" – Permission for full control of classification rule. Roles: "Operator", "Administrator" GET /client-monitor-profiles Permissions: "client-monitor-profile" – Permission for full control of client monitor profiles "client-monitor-profile:r" – Permission to read client monitor profiles



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Installer"
POST /client-monitor-profile
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
Roles:
"Operator",
"Administrator"
GET /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
"client-monitor-profile:r" – Permission to read client monitor profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer",
"Installer"
PUT /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
Roles:
"Operator",
"Administrator"
DELETE /client-monitor-profile/{id}
Permissions:
"client-monitor-profile" – Permission for full control of client monitor profiles
Roles:
"Operator",
```

"Administrator"



## **GET /hotspot-profiles** Permissions: "hotspot-profile" – Permission for full control of hotspot-profiles. "hotspot-profile:r" – Permission to read hotspot-profiles. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /hotspot-profiles Permissions: "hotspot-profile" – Permission for full control of hotspot-profiles. Roles: "Operator", "Administrator" GET /hotspot-profiles/{id} Permissions: "hotspot-profile" – Permission for full control of hotspot-profiles. "hotspot-profile:r" – Permission to read hotspot-profiles. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /hotspot-profiles/{id} Permissions: "hotspot-profile" – Permission for full control of hotspot-profiles. Roles: "Operator", "Administrator" DELETE /hotspot-profiles/{id} Permissions: "hotspot-profile" – Permission for full control of hotspot-profiles.



```
Roles:
"Operator",
"Administrator"
GET /hotspot-service-provider-profiles
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
"hotspot-service-provider-profile:r" – Permission to read hotspot-service-provider-profiles.
"Operator",
"Administrator",
"Monitor",
"Installer".
"Observer"
POST /hotspot-service-provider-profiles
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
Roles:
"Operator",
"Administrator"
GET /hotspot-service-provider-profiles/{id}
Permissions:
"hotspot-service-provider-profile" – Permission for full control of hotspot-service-provider-
profiles.
"hotspot-service-provider-profile:r" – Permission to read hotspot-service-provider-profiles.
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /hotspot-service-provider-profiles/{id}
```

Permissions:



"hotspot-service-provider-profile" – Permission for full control of hotspot-service-providerprofiles. Roles: "Operator", "Administrator" DELETE /hotspot-service-provider-profiles/{id} Permissions: "hotspot-service-provider-profile" – Permission for full control of hotspot-service-providerprofiles. Roles: "Operator", "Administrator" **GET /iot-profiles** Permissions: "iot-profile" – Permission for full control of iot-profiles. "iot-profile:r" – Permission to read iot-profiles. Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" POST /iot-profiles Permissions: "iot-profile" – Permission for full control of iot-profiles. Roles: "Operator", "Administrator" GET /iot-profiles/{id} Permissions: "iot-profile" – Permission for full control of iot-profiles. "iot-profile:r" – Permission to read iot-profiles.

Roles: "Operator",



```
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /iot-profiles/{id}
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
Roles:
"Operator",
"Administrator"
DELETE /iot-profiles/{id}
Permissions:
"iot-profile" – Permission for full control of iot-profiles.
Roles:
"Operator",
"Administrator"
GET /ip-firewall-policies
Permissions:
NOT SET!
Roles:
NOT SET!
POST /ip-firewall-policies
Permissions:
NOT SET!
Roles:
NOT SET!
GET /ip-firewall-policies/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
```



# PUT /ip-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! DELETE /ip-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! POST /ip-firewall-policies/{{id}}/:attach Permissions: NOT SET! Roles: NOT SET! POST /ip-firewall-policies/{{id}}/:detach Permissions: NOT SET! Roles: NOT SET! GET /I3-address-profiles Permissions: **"I3-address-profile"** – Permission for full control of L3 address profile. "I3-address-profile:r" – Permission to read L3 address profile Roles: "Operator", "Administrator", "Monitor", "Observer" POST /I3-address-profiles Permissions: "I3-address-profile" – Permission for full control of L3 address profile.



```
Roles:
"Operator",
"Administrator"
GET /I3-address-profiles/{id}
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
"I3-address-profile:r" – Permission to read L3 address profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /I3-address-profiles/{id}
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
Roles:
"Operator",
"Administrator"
DELETE /I3-address-profiles/{id}
Permissions:
"I3-address-profile" – Permission for full control of L3 address profile.
Roles:
"Operator",
"Administrator"
GET /mac-firewall-policies
Permissions:
NOT SET!
Roles:
NOT SET!
POST /mac-firewall-policies
Permissions:
NOT SET!
Roles:
```



# NOT SET! GET /mac-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! PUT /mac-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! DELETE /mac-firewall-policies/{id} Permissions: NOT SET! Roles: NOT SET! POST /mac-firewall-policies/{{id}}/:attach Permissions: NOT SET! Roles: NOT SET! POST /mac-firewall-policies/{{id}}/:detach Permissions: NOT SET! Roles: NOT SET! GET /mac-object-profiles Permissions: NOT SET! Roles: NOT SET!



# POST /mac-object-profiles Permissions: NOT SET! Roles: NOT SET! GET /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! PUT /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! DELETE /mac-object-profiles/{id} Permissions: NOT SET! Roles: NOT SET! GET /radio-operating-modes/{id} Permissions: NOT SET! Roles: NOT SET! **GET /radio-profiles** Permissions: "radio-profile" – Permission for full control of radio profiles "radio-porfile:r" – Permission to read radio profiles Roles: "Operator",



```
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radio-profiles
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator",
DELETE /radio-profiles/{id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/channel-selection/{channel-selection-id}
Permissions:
```

Page 104 of 181



```
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/channel-selection/{channel-selection-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radio-profiles/mac-ouis
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
DELETE /radio-profiles/mac-ouis/{mac-oui-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/miscellaneous/{radio-misc-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
```



```
GET /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/neighborhood-analysis/{neigh-analysis-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" – Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/radio-usage-opt/{radio-usage-opt-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
```



```
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" - Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/sensor-scan/{sensor-scan-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
"radio-porfile:r" - Permission to read radio profiles
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radio-profiles/wmm-qos/{radio-qos-id}
Permissions:
"radio-profile" – Permission for full control of radio profiles
Roles:
"Operator",
"Administrator"
GET /ssids
Permissions:
"ssid" – Permission for full control of SSID
"ssid:r" - Permission to read SSID
Roles:
```



```
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /ssids/{id}/:rename
Permissions:
"ssid" - Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/client-monitor-profile/:attach
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:attach
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:disable
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
POST /ssids/{id}/cwp/:enable
Permissions:
"ssid" - Permission for full control of SSID
Roles:
```



```
"Operator",
"Administrator"
PUT /ssids/{id}/mode/dot1x
Permissions:
"ssid" - Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/open
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/ppsk
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/psk
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
PUT /ssids/{id}/mode/wep
Permissions:
"ssid" – Permission for full control of SSID
Roles:
```

"Operator",
"Administrator"



# PUT /ssids/{id}/psk/password Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/radius-client-profile Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/radius-server-group/:attach Attach radius server group to an SSID Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/user-profile-assignment Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" POST /ssids/{id}/user-profile/:attach Permissions: "ssid" – Permission for full control of SSID Roles: "Operator", "Administrator" GET /ssids/advanced-settings/{id} Permissions:



```
"ssid" – Permission for full control of SSID
"ssid:r" - Permission to read SSID
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /ssids/advanced-settings/{id}
Permissions:
"ssid" – Permission for full control of SSID
Roles:
"Operator",
"Administrator"
GET /user-profile-assignments
Permissions:
NOT SET!
Roles:
NOT SET!
POST /user-profile-assignments
Permissions:
NOT SET!
Roles:
NOT SET!
GET /user-profile-assignments/{id}
Permissions:
NOT SET!
Roles:
NOT SET!
DELETE /user-profile-assignments/{id}
Permissions:
NOT SET!
```



```
Roles:
NOT SET!
GET /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /user-profiles
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
GET /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
"user-profile:r" – Permission to read user profile
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /user-profiles/{id}
Permissions:
"user-profile" – Permission for full control of user profile
Roles:
"Operator",
"Administrator"
```



# DELETE /user-profiles/{id} Permissions: "user-profile" – Permission for full control of user profile Roles: "Operator", "Administrator" POST /user-profiles/{id}/ip-firewall-policies/:attach Permissions: "user-profile" – Permission for full control of user profile Roles: "Operator", "Administrator" POST /user-profiles/{id}/ip-firewall-policies/:detach Permissions: "user-profile" – Permission for full control of user profile Roles: "Operator", "Administrator" POST /user-profiles/{id}/mac-firewall-policies/:attach Permissions: "user-profile" – Permission for full control of user profile Roles: "Operator", "Administrator" POST /user-profiles/{id}/,ac-firewall-policies/:detach Permissions: "user-profile" – Permission for full control of user profile Roles: "Operator", "Administrator"



# Configuration - Network

No default permissions for this category

GET /network-services Permissions: NOT SET!
Roles: NOT SET!
POST /network-services Permissions: NOT SET!
Roles: NOT SET!
DELETE /network-services/{id} Permissions: NOT SET!
Roles: NOT SET!
GET /tunnel-concentrators Permissions: "tunnel-concentrator" – Permission for full control of tunnel concentrator "tunnel-concentrator:r" – Permission to read tunnel concentrator
Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer"
POST /tunnel-concentrators Permissions: "tunnel-concentrator" – Permission for full control of tunnel concentrator
Roles: "Operator",



# "Administrator" GET /tunnel-concentrators/{id} Permissions: "tunnel-concentrator" - Permission for full control of tunnel concentrator "tunnel-concentrator:r" - Permission to read tunnel concentrator Roles: "Operator", "Administrator", "Monitor", "Installer", "Observer" PUT /tunnel-concentrators/{id} Permissions: "tunnel-concentrator" – Permission for full control of tunnel concentrator Roles: "Operator", "Administrator" DELETE /tunnel-concentrators/{id} Permissions: "tunnel-concentrator" – Permission for full control of tunnel concentrator Roles: "Operator", "Administrator" **Configuration - Authentication** No default permissions for this category **GET /ad-servers** Permissions: "ad-server" – Permission for full control of AD server "ad-server:r" – Permission to read AD server Roles: "Operator", "Administrator",

"Monitor",



```
"Observer"
GET /cwps
Permissions:
"cwp" – Permission for full control of captive web portals
"cwp:r" – Permission to read captive web portals
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /Idap-servers
Permissions:
"ldap-server" – Permission for full control of LDAP server
"Idap-server:r" – Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /Idap-servers
Permissions:
"ldap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /ldap-servers/{id}
Permissions:
"ldap-server" – Permission for full control of LDAP server
"Idap-server:r" - Permission to read LDAP server
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
```



```
PUT /ldap-servers/{id}
Permissions:
"Idap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
DELETE /Idap-servers/{id}
Permissions:
"ldap-server" – Permission for full control of LDAP server
Roles:
"Operator",
"Administrator"
GET /radius-client-objects
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-client-objects
Permissions:
"radius-client-object" - Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
"radius-client-object:r" - Permission to read RADIUS client object
Roles:
"Operator",
```



```
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
DELETE /radius-client-objects/{id}
Permissions:
"radius-client-object" – Permission for full control of RADIUS client object
Roles:
"Operator",
"Administrator"
GET /radius-proxies
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
POST /radius-proxies
Permissions:
"radius-proxy" - Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
GET /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
PUT /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
DELETE /radius-proxies/{id}
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
Roles:
"Operator",
"Administrator"
GET /radius-proxies/devices
Permissions:
"radius-proxy" – Permission for full control of RADIUS proxy
"radius-proxy:r" – Permission to read RADIUS proxy
Roles:
"Operator",
"Administrator",
"Monitor",
"Observer"
GET /radius-servers/external
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" – Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
```



```
"Installer",
"Observer"
POST /radius-servers/external
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
DELETE /radius-servers/external/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" - Permission to read RADIUS server
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
POST /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
DELETE /radius-servers/internal
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
GET /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
"radius-server:r" – Permission to read RADIUS server
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
PUT /radius-servers/internal/{id}
Permissions:
"radius-server" – Permission for full control of RADIUS server
Roles:
"Operator",
"Administrator"
```



# DELETE /radius-servers/internal/{id} Permissions: "radius-server" – Permission for full control of RADIUS server Roles: "Operator", "Administrator" GET /radius-servers/internal/devices Permissions: "radius-server" – Permission for full control of RADIUS server "radius-server:" – Permission to read RADIUS server Roles: "Operator", "Administrator", "Monitor", "Installer",

#### **Configuration - Certificate**

#### Permissions:

"Observer"

- "certificate" Permission for all API calls in the Configuration Certificate Section
- "certificate:r" Permission for all GET API calls in the Configuration Certificate Section

#### **GET /certificates**

#### Permissions:

No Specific permission - included with "certificate" and "certificate:r"

#### Roles:

- "Operator",
- "Administrator",
- "Monitor",
- "Installer",
- "Observer"

#### Copilot – Connectivity Experience

No default permissions for this category



## GET /copilot/connectivity/client-type Permissions: NOT SET! Roles: NOT SET! GET /copilot/connectivity/locations Permissions: NOT SET! Roles: NOT SET! GET /copilot/connectivity/wired/events Permissions: "copilot-connectivity-wired:r" - Permission to read copilot wired connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wired/experience Permissions: "copilot-connectivity-wired:r" – Permission to read copilot wired connectivity Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/connectivity/wired/hardware Permissions: "copilot-connectivity-wired:r" - Permission to read copilot wired connectivity Roles: "Operator", "Monitor",



```
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/locations/hardware
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wired/quality-index
Permissions:
"copilot-connectivity-wired:r" – Permission to read copilot wired connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/apps
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
```



```
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/experience
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/events
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/performance
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/quality-index
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
```

Roles:



```
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/locations/time-to-connect
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/performance
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/quality-index
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/time-to-connect
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
```



```
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/connectivity/wireless/views
Permissions:
"copilot-connectivity-wireless:r" – Permission to read copilot wireless connectivity
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
Copilot – Anomalies
Permissions:
"copilot-anomalies:r" – Permission for all GET API calls in the Copilot Anomalies Section
GET /copilot/anomalies/adverse-traffic/device-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET / copilot/anomalies/adverse-traffic/packet-counts
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
```



#### "Guest Management"

```
GET /copilot/anomalies/anomalies-by-category
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/device-by-location
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/device-with-locations
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
PUT /copilot/anomalies/devices/feedback
Permissions:
NOT SET!
Roles:
NOT SET!
```



PUT /copilot/anomalies/devices/update-action Permissions: NOT SET! Roles: NOT SET! GET /copilot/anomalies/dfs-recurrence/channel-stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/dfs-recurrence/count-stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/exclude-vlans Permissions: NOT SET! Roles: NOT SET! GET /copilot/anomalies/exclude-vlans-csv Permissions: NOT SET! Roles: NOT SET!



```
GET /copilot/anomalies/exclude-vlans-list
Permissions:
NOT SET!
Roles:
NOT SET!
GET /copilot/anomalies/hardware-health/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/hardware-health/cpu-mem-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/hardware-health/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/locations
Permissions:
"copilot-anomalies:r" – Permission to read copilot anomalies
```

Page 131 of 181



```
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/missing-vlan/count
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/notifications
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/lldp-cdp-info
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
```

Page 132 of 181



```
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/poeflapping/trends
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/port-efficiency/speed-duplex-stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/port-efficiency/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-capacity/client-list
Permissions:
No Specific permission - included with "copilot-anomalies:r"
```

Page 133 of 181



```
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/wifi-capacity/stats
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
GET /copilot/anomalies/report
Permissions:
No Specific permission - included with "copilot-anomalies:r"
Roles:
"Operator",
"Monitor",
"Administrator",
"Observer",
"Guest Management"
PUT /copilot/anomalies/update-action
Permissions:
NOT SET!
Roles:
NOT SET!
PUT / copilot/anomalies/update-device-action
Permissions:
NOT SET!
Roles:
NOT SET!
```



### GET /copilot/anomalies/wifi-efficiency/client-list Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/anomalies/wifi-efficiency/stats Permissions: No Specific permission - included with "copilot-anomalies:r" Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" GET /copilot/assurance-scans/overview Permissions: "copilot-assurance-scans:r" – Permission to read access to Copilot Assurance scan Roles: "Operator", "Monitor", "Administrator", "Observer", "Guest Management" **Packet Capture** Permissions: "packet-capture" – Permission for all API calls in the Packet Capture Section "packet-capture:r" – Permission for all GET API calls in the Packet Capture Section **GET /packetcaptures** Permissions:

No Specific permission - included with "packet-capture" and "packet-capture:r"



```
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
POST /packetcaptures
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
Delete /packetcaptures/{id}
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:stop
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
```



```
"Help Desk",
"Administrator"
POST /packetcaptures/{id}/:upload
Permissions:
No Specific permission - included with "packet-capture"
Roles:
"Operator",
"Help Desk",
"Administrator"
GET /packetcaptures/files
Permissions:
No Specific permission - included with "packet-capture" and "packet-capture:r"
Roles:
"Operator",
"Help Desk",
"Administrator",
"Monitor",
"Installer"
"Observer"
Network Scorecard
Permissions:
"network-scorecard " - Permission for all API calls in the Network Scorecard Section
"network-scorecard:r" - Permission for all GET API calls in the Network Scorecard Section
GET /network-scorecard/clientHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/deviceHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
```



```
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/networkHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/serviceHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
GET /network-scorecard/wifiHealth/{id}
Permissions:
No Specific permission - included with "network-scorecard" and "network-scorecard:r"
Roles:
"Operator",
"Administrator",
"Monitor",
"Installer",
"Observer"
```

#### **Essentials - ExtremeLocation**

No default permissions for this category



# GET /essentials/eloc/clients/{client-mac}/last-known-location Permissions: NOT SET! Roles: NOT SET! Misc - Metadata - Country Permissions: "country" – Permission for all API calls in the Metadata-Country Section "country:r" – Permission for all GET API calls in the Metadata-Country Section **GET /countries** Permissions: No Specific permission - included with "country" and "country:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer" "Observer" GET /countries/{countryAlpha2Code}/states Permissions: No Specific permission - included with "country" and "country:r" Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer" "Observer" GET /countries/{id}/:validate Permissions:

No Specific permission - included with "country" and "country:r"



# Roles: "Operator", "Help Desk", "Administrator", "Monitor", "Installer" "Observer"

#### **Thread**

No default permissions for this category

GET /thread/networks

Permissions: NOT SET!

Roles: NOT SET!

**GET /thread/routers** 

Permissions: NOT SET!

Roles: NOT SET!

GET /thread/topology

Permissions: NOT SET!

Roles: NOT SET!

# **Universal Compute Platform**

No default permissions for this category

GET /upc/{id}/engines/installed

Permissions: NOT SET!

Roles: NOT SET!



# **AFC-endpoint**

No default permissions for this category

The wereness permissions for this carego
GET /afcserver Permissions: NOT SET!
Roles: NOT SET!
GET /afcserver/{id} Permissions: NOT SET!
Roles: NOT SET!
GET /afcserver/statistics/{id} Permissions: NOT SET!
Roles: NOT SET!
GET /afcserver/diagnostics/{sn} Permissions: NOT SET!
Roles: NOT SET!
GET /ap/afc/interface/details/{sn} Permissions: NOT SET!
Roles: NOT SET!
POST /ap/spectrum Permissions:

NOT SET!



NOT SET!
GET /aps/afc/query Permissions: NOT SET!
Roles: NOT SET!
POST /aps/afc/update Permissions: NOT SET!
Roles: NOT SET!
GET /site/afc/schedule Permissions: NOT SET!
Roles: NOT SET!
PUT /site/afc/schedule Permissions: NOT SET!
Roles: NOT SET!
POST /site/afc/schedule Permissions: NOT SET!
Roles: NOT SET!
POST /site/spectrum Permissions: NOT SET!

Roles:



Roles: NOT SET!

# RTTS-endpoint

No default permissions for this category

POST /rtts-endpoint

Permissions: NOT SET!

Roles: NOT SET!

POST /rtts-endpoint

Permissions: NOT SET!

Delete: NOT SET!

#### APPENDIX - A

API call list based on Roles

#### Administrator

All available API calls

#### Operator

All available API calls except for the following:

POST /users

DELETE /users/{id}

PATCH /users/{id}

POST /users/external

DELETE /users/external/{id}

PATCH /users/external/{id}

#### **Monitor**

POST /logout

GET /account/viq/default-device-password

GET /users

GET /users/external



- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /locations/building/{id}
- GET /locations/floor/{id}
- GET /locations/site
- GET /locations/site/{id}
- GET /devices/{id}/client-monitor
- GET /devices/{id}/ftm-settings
- GET /devices/{id}/location
- GET /devices/{id}/network-policy
- GET /devices/{id}/radio-operating-mode
- GET /network-policies
- GET /network-policies/{id}
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/servicenow/{id}
- GET /alert-subscriptions/webhooks/{id}
- GET /subscriptions/webhook
- GET /deployments/{deploymentId}
- GET /vlan-profiles
- GET /pcgs/key-based
- GET /pcgs/key-based/network-policy-{policyId}/port-assignments
- GET /pcgs/key-based/network-policy-{policyId}/users
- GET /usergroups
- GET /ccgs/{id}
- GET /classification-rules/{id}
- GET /client-monitor-profiles/{id}
- GET /hotspot-profiles/{id}
- GET /hotspot-service-provider-profiles/{id}
- GET /iot-profiles/{id}
- GET /l3-address-profiles/{id}
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids/advanced-settings/{id}



GET /user-profiles

GET /user-profiles/{id}

GET /tunnel-concentrators

GET /tunnel-concentrators/{id}

GET /ldap-servers/{id}

GET /radius-client-objects

GET /radius-client-objects/{id}

GET /radius-proxies

GET /radius-proxies/{id}

GET /radius-servers/external

GET /radius-servers/external/{id}

GET /radius-servers/internal

GET /radius-servers/internal/{id}

GET /packetcaptures

#### Installer

POST /logout

POST /auth/apitoken

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/third-party-applications

GET /account/vhm/setting

GET /account/vhm/status

GET /account/viq

GET /account/viq/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /users/me

GET /hiq/context

PUT /hiq/context

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

POST /locations

POST /locations/:init

PUT /locations/{id}

DELETE /locations/{id}

GET /locations/building



POST /locations/building

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

GET /locations/floor

POST /locations/floor

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

POST /locations/floorplan

POST /locations/import/ekahau

GET /locations/site

POST /locations/site

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/tree

GET /locations/tree/devices

GET /locations/tree/maps

GET /devices

POST /devices/:advanced-onboard

POST /devices/:check-ownership

POST /devices/:cli

POST /devices/:delete

POST /devices/:manage

POST /devices/:onboard

POST /devices/:reboot

POST /devices/:unmanage

GET /devices/{id}

DELETE /devices/{id}

POST /devices/{id}/:cli

POST /devices/{id}/:manage

POST /devices/{id}/:reboot

POST /devices/{id}/:reset

POST /devices/{id}/:unmanage

GET /devices/{id}/alarms

POST /devices/{id}/bounce-port

GET /devices/{id}/client-monitor

PUT /devices/{id}/client-monitor

DELETE /devices/{id}/client-monitor

PUT /devices/{id}/description

GET /devices/{id}/ftm-settings

PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings



GET /devices/{id}/gallery-image

GET /devices/{id}/geolocation

GET /devices/{id}/history/cpu-mem

PUT /devices/{id}/hostname

GET /devices/{id}/ibeacon

GET /devices/{id}/installation-report

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/iot

POST /devices/{id}/iot/:disable

POST /devices/{id}/iot/:enable

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

POST /devices/{id}/monitor/:refresh

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

GET /devices/{id}/radio-operating-mode

PUT /devices/{id}/radio-operating-mode

POST /devices/{id}/ssid/:override

GET /devices/{id}/ssid/status

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/thread/commissioner/:stop

PUT /devices/{id}/visible

POST /devices/client-monitor/:assign

POST /devices/client-monitor/:revoke

POST /devices/client-monitor/:query

POST /devices/country-code/:assign

GET /devices/digital-twin

PUT /devices/ibeacon

POST /devices/location/:assign

POST /devices/location/:query

POST /devices/location/:revoke

POST /devices/network-policy/:assign

POST /devices/network-policy/:query

POST /devices/network-policy/:revoke

GET /devices/network-policy/{policyId}

POST /devices/os/:change

GET /devices/radio-information

PUT /devices/radius-proxy/:assign

DELETE /devices/radius-proxy/:revoke

POST /devices/rm-devices-connection-status



POST /devices/rm-devices-metadata

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

GET /devices/rm-devices-stack/{stackId}

GET /devices/stats

GET /network-policies

GET /network-policies/{id}

GET /network-policies/{id}/ssids

GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

GET /alert-policies

GET /alert-policies/{id}

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/available-sites

GET /alert-subscriptions/emails

GET /alert-subscriptions/emails/{id}

GET /alert-subscriptions/servicenow

GET /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/webhooks

GET /alert-subscriptions/webhooks/{id}

GET /alerts

GET /alerts/count-by-{group}

GET /alerts/reports/{id}

GET /logs/accounting

GET /logs/audit

GET /logs/audit/full-descriptions/{id}

GET /logs/audit/reports/{id}

GET /logs/auth

GET /logs/credential

GET /logs/email

GET /logs/sms

GET /deployments

GET /deployments/{deploymentId}

GET /deployments/{deploymentId}/status

GET /deployments/overview

GET /deployments/status

GET /client-monitor-profiles

GET /client-monitor-profiles/{id}

GET /hotspot-profiles

GET /hotspot-profiles/{id}



- GET /hotspot-service-provider-profiles
- GET /hotspot-service-provider-profiles/{id}
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}
- GET /user-profiles
- GET /user-profiles/{id}
- GET /tunnel-concentrators
- GET /tunnel-concentrators/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /network-scorecard/clientHealth/{locationId}
- GET /network-scorecard/deviceHealth/{locationId}
- GET /network-scorecard/networkHealth/{locationId}
- GET /network-scorecard/servicesHealth/{locationId}
- GET /network-scorecard/wifiHealth/{locationId}
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

#### Observer

POST /logout

GET /auth/apitoken/info

GET /auth/permissions



POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/third-party-applications

GET /account/vhm/setting

GET /account/vhm/status

GET /account/viq

GET /account/vig/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /users/me

GET /hiq/context

GET /hiq/context/creating

GET /hiq/context/reading

GET /hiq/organizations

GET /hiq/status

GET /locations/building

GET /locations/building/{id}

GET /locations/floor

GET /locations/floor/{id}

GET /locations/site

GET /locations/site/{id}

GET /locations/tree

GET /locations/tree/devices

GET /locations/tree/maps

GET /devices

GET /devices/{id}

GET /devices/{id}/alarms

GET /devices/{id}/client-monitor

GET /devices/{id}/ftm-settings

GET /devices/{id}/gallery-image

GET /devices/{id}/geolocation

GET /devices/{id}/history/cpu-mem

GET /devices/{id}/ibeacon

GET /devices/{id}/installation-report

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/iot

GET /devices/{id}/location

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/network-policy

GET /devices/{id}/radio-operating-mode

GET /devices/{id}/ssid/status



- GET /devices/digital-twin
- GET /devices/network-policy/{policyId}
- GET /devices/radio-information
- GET /devices/rm-devices-stack/{stackId}
- GET /devices/stats
- GET /network-policies
- GET /network-policies/{id}
- GET /network-policies/{id}/ssids
- GET /clients/{id}
- GET /clients/active
- GET /clients/active/count
- GET /clients/byMac/{clientMac}
- GET /clients/summary
- GET /clients/usage
- GET /applications
- GET /applications/{id}/clients/top{n}
- GET /applications/top{n}
- GET /alert-policies
- GET /alert-policies/{id}
- GET /alert-policies/{policyId}/rules/{ruleId}
- GET /alert-policies/available-sites
- GET /alert-subscriptions/emails
- GET /alert-subscriptions/emails/{id}
- GET /alert-subscriptions/servicenow
- GET /alert-subscriptions/servicenow/{id}
- GET /alert-subscriptions/webhooks
- GET /alert-subscriptions/webhooks/{id}
- GET /alerts
- GET /alerts/count-by-{group}
- GET /alerts/reports/{id}
- GET /logs/accounting
- GET /logs/audit
- GET /logs/audit/full-descriptions/{id}
- GET /logs/audit/reports/{id}
- GET /logs/auth
- GET /logs/credential
- GET /logs/email
- GET /logs/sms
- GET /subscriptions/webhook
- GET /subscriptions/webhook/export
- GET /deployments
- GET /deployments/{deploymentId}
- GET /deployments/{deploymentId}/status
- GET /deployments/overview



- GET /deployments/status
- GET /vlan-profiles
- GET /vlan-profiles/{id}
- GET /email-templates
- GET /endusers
- GET /pcgs/key-based
- GET /pcgs/key-based/network-policy-{policyId}/port-assignments
- GET /pcgs/key-based/network-policy-{policyId}/users
- GET /sms-templates
- GET /usergroups
- GET /usergroups/:unique
- GET /ccgs
- GET /ccgs/{id}
- GET /classification-rules
- GET /classification-rules/{id}
- GET /client-monitor-profiles
- GET /client-monitor-profiles/{id}
- GET /hotspot-profiles
- GET /hotspot-profiles/{id}
- GET /hotspot-service-provider-profiles
- GET /hotspot-service-provider-profiles/{id}
- GET /iot-profiles
- GET /iot-profiles/{id}
- GET /13-address-profiles
- GET /13-address-profiles/{id}
- GET /radio-profiles
- GET /radio-profiles/{id}
- GET /radio-profiles/channel-selection/{id}
- GET /radio-profiles/mac-ouis
- GET /radio-profiles/mac-ouis/{id}
- GET /radio-profiles/miscellaneous/{id}
- GET /radio-profiles/neighborhood-analysis/{id}
- GET /radio-profiles/radio-usage-opt/{id}
- GET /radio-profiles/sensor-scan/{id}
- GET /radio-profiles/wmm-qos/{id}
- GET /ssids
- GET /ssids/advanced-settings/{id}
- GET /user-profiles
- GET /user-profiles/{id}
- GET /tunnel-concentrators
- GET /tunnel-concentrators/{id}
- GET /ad-servers
- GET /cwps
- GET /ldap-servers



- GET /ldap-servers/{id}
- GET /radius-client-objects
- GET /radius-client-objects/{id}
- GET /radius-proxies
- GET /radius-proxies/{id}
- GET /radius-proxies/devices
- GET /radius-servers/external
- GET /radius-servers/external/{id}
- GET /radius-servers/internal
- GET /radius-servers/internal/{id}
- GET /radius-servers/internal/devices
- GET /certificates
- GET /copilot/connectivity/wired/events
- GET /copilot/connectivity/wired/experience
- GET /copilot/connectivity/wired/hardware
- GET /copilot/connectivity/wired/locations/hardware
- GET /copilot/connectivity/wired/quality-index
- GET /copilot/connectivity/wireless/apps
- GET /copilot/connectivity/wireless/events
- GET /copilot/connectivity/wireless/experience
- GET /copilot/connectivity/wireless/locations/events
- GET /copilot/connectivity/wireless/locations/performance
- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/excluded-vlans-list
- GET /copilot/anomalies/hardware-health/client-list
- GET /copilot/anomalies/hardware-health/cpu-mem-stats
- GET /copilot/anomalies/hardware-health/stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/missing-vlan/count
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/lldp-cdp-info
- GET /copilot/anomalies/poeflapping/stats



- GET /copilot/anomalies/poeflapping/trends
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats
- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview
- GET /packetcaptures
- GET /packetcaptures/{id}
- GET /packetcaptures/files
- GET /network-scorecard/clientHealth/{locationId}
- GET /network-scorecard/deviceHealth/{locationId}
- GET /network-scorecard/networkHealth/{locationId}
- GET /network-scorecard/servicesHealth/{locationId}
- GET /network-scorecard/wifiHealth/{locationId}
- GET /countries
- GET /countries/{countryAlpha2Code}/states
- GET /countries/{countryCode}/:validate

# Help Desk

- POST /logout
- POST /auth/permissions/:check
- GET /operations/{operationId}
- POST /account/:switch
- GET /account/external
- GET /account/home
- GET /account/third-party-applications
- GET /account/vhm/setting
- GET /account/vhm/status
- GET /account/viq
- GET /account/viq/default-device-password
- GET /account/viq/download
- GET /account/viq/export-import-status
- GET /users/me
- GET /hiq/context
- GET /hiq/context/creating
- GET /hiq/context/reading
- GET /hiq/organizations
- GET /hiq/status
- GET /locations/building
- GET /locations/building/{id}
- GET /locations/floor



GET /locations/floor/{id}

GET /locations/site

GET /locations/site/{id}

GET /locations/tree

GET /locations/tree/devices

GET /locations/tree/maps

GET /clients/{id}

GET /clients/active

GET /clients/active/count

GET /clients/byMac/{clientMac}

GET /clients/summary

GET /clients/usage

GET /alerts

GET /alerts/count-by-{group}

GET /alerts/reports/{id}

GET /deployments

GET /deployments/{deploymentId}

GET /deployments/{deploymentId}/status

GET /deployments/overview

GET /deployments/status

GET /endusers

GET /packetcaptures

POST /packetcaptures

GET /packetcaptures/{id}

DELETE /packetcaptures/{id}

POST /packetcaptures/{id}/:stop

POST /packetcaptures/{id}/:upload

GET /packetcaptures/files

GET /countries

GET /countries/{countryAlpha2Code}/states

GET /countries/{countryCode}/:validate

#### **Application Operator**

POST /account/:switch

GET /account/external

GET /account/home

GET /account/third-party-applications

GET /account/vhm/setting

GET /account/vhm/status

GET /account/viq

GET /account/viq/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /logs/accounting



GET /logs/audit

GET /logs/audit/full-descriptions/{id}

GET /logs/audit/reports/{id}

GET /logs/auth

GET /logs/credential

GET /logs/email

GET /logs/sms

# **Guest Management**

POST /logout

POST /auth/permissions/:check

GET /operations/{operationId}

POST /account/:switch

GET /account/external

GET /account/home

GET /account/third-party-applications

GET /account/vhm/setting

GET /account/vhm/status

GET /account/viq

GET /account/viq/default-device-password

GET /account/viq/download

GET /account/viq/export-import-status

GET /deployments

GET /deployments/{deploymentId}

GET /deployments/{deploymentId}/status

GET /deployments/overview

GET /deployments/status

GET /endusers

POST /endusers

PUT /endusers/{id}

DELETE /endusers/{id}

POST /endusers/{id}/:regenerate-password

GET /usergroups

GET /usergroups/:unique

GET /copilot/connectivity/wired/events

GET /copilot/connectivity/wired/experience

GET /copilot/connectivity/wired/hardware

GET /copilot/connectivity/wired/locations/hardware

GET /copilot/connectivity/wired/quality-index

GET /copilot/connectivity/wireless/apps

GET /copilot/connectivity/wireless/events

GET /copilot/connectivity/wireless/experience

GET /copilot/connectivity/wireless/locations/events

GET /copilot/connectivity/wireless/locations/performance



- GET /copilot/connectivity/wireless/locations/quality-index
- GET /copilot/connectivity/wireless/locations/time-to-connect
- GET /copilot/connectivity/wireless/performance
- GET /copilot/connectivity/wireless/quality-index
- GET /copilot/connectivity/wireless/time-to-connect
- GET /copilot/connectivity/wireless/views
- GET /copilot/anomalies/adverse-traffic/device-stats
- GET /copilot/anomalies/adverse-traffic/packet-counts
- GET /copilot/anomalies/anomalies-by-category
- GET /copilot/anomalies/devices-by-location
- GET /copilot/anomalies/devices-with-locations
- GET /copilot/anomalies/dfs-recurrence/channel-stats
- GET /copilot/anomalies/dfs-recurrence/count-stats
- GET /copilot/anomalies/excluded-vlans-list
- GET /copilot/anomalies/hardware-health/client-list
- GET /copilot/anomalies/hardware-health/cpu-mem-stats
- GET /copilot/anomalies/hardware-health/stats
- GET /copilot/anomalies/locations
- GET /copilot/anomalies/missing-vlan/count
- GET /copilot/anomalies/notifications
- GET /copilot/anomalies/poeflapping/lldp-cdp-info
- GET /copilot/anomalies/poeflapping/stats
- GET /copilot/anomalies/poeflapping/trends
- GET /copilot/anomalies/port-efficiency/speed-duplex-stats
- GET /copilot/anomalies/port-efficiency/stats
- GET /copilot/anomalies/report
- GET /copilot/anomalies/wifi-capacity/client-list
- GET /copilot/anomalies/wifi-capacity/stats
- GET /copilot/anomalies/wifi-efficiency/client-list
- GET /copilot/anomalies/wifi-efficiency/stats
- GET /copilot/assurance-scans/overview



# APPENDIX - B

API call list based on Permission

logout

POST /logout

auth

POST /auth/permissions/:check POST /auth/apitoken POST /auth/apitoken/:validate GET /auth/permissions GET /auth/apitoken/info

auth:r

GET /auth/permissions GET /auth/apitoken/info

token:new

POST /auth/apitoken

perm:check

POST /auth/permissions/:check

Iro

POST /operations/{operationId}/:cancel GET /operations/{operationId}
DELETE /operations/{operationId}

lro:r

GET /operations/{operationId}



#### account

GET /account/viq/default-device-password

PUT /account/viq/default-device-password

PUT /account/vhm/setting/{id}

POST /account/viq/import

POST /account/viq/export

POST /account/viq/:reset

POST /account/viq/:backup

POST /account/:switch

GET /account/viq

GET /account/viq/export-import-status

GET /account/viq/download

GET /account/vhm/status

GET /account/vhm/setting

GET /account/third-party-applications

GET /account/home

GET /account/external

#### account:switch

#### POST /account/:switch

#### account:r

GET /account/viq/default-device-password

GET /account/viq

GET /account/viq/export-import-status

GET /account/viq/download

GET /account/vhm/status

GET /account/vhm/setting

GET /account/third-party-applications

GET /account/home

GET /account/external

#### viq:backup

#### POST /account/viq/:backup

#### user-me:r

#### GET /users/me



#### user:r

GET /users

GET /users/external

GET /users/{id}

GET /users/external/{id}

GET /users/me

#### hiq

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

GET /hiq/status

DELETE /hiq/organizations/{id}

#### hiq:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

GET /hiq/organizations

GET /hiq/status

# org

GET /hiq/organizations

POST /hiq/organizations

POST /hiq/organizations/{id}/:rename

DELETE /hiq/organizations/{id}

#### org:new

POST /hiq/organizations



# org:del

DELETE /hiq/organizations/{id}

#### org:rename

POST /hiq/organizations/{id}/:rename

#### hiq.ctx

GET /hiq/context

PUT /hiq/context

GET /hiq/context/reading

PUT /hiq/context/reading

GET /hiq/context/creating

PUT /hiq/context/creating

#### hiq.ctx:r

GET /hiq/context

GET /hiq/context/reading

GET /hiq/context/creating

#### hiq.ctx:w

PUT /hiq/context

PUT /hiq/context/reading

PUT /hiq/context/creating

#### device

PUT /devices/{id}/visible

GET /devices/{id}/radio-operating-mode

PUT /devices/{id}/radio-operating-mode

GET /devices/{id}/network-policy

PUT /devices/{id}/network-policy

DELETE /devices/{id}/network-policy

GET /devices/{id}/location

PUT /devices/{id}/location

DELETE /devices/{id}/location

PUT /devices/{id}/hostname

GET /devices/{id}/ftm-settings



PUT /devices/{id}/ftm-settings

DELETE /devices/{id}/ftm-settings

PUT /devices/{id}/description

GET /devices/{id}/client-monitor

PUT /devices/{id}/client-monitor

DELETE /devices/{id}/client-monitor

PUT /devices/radius-proxy/:assign

PUT /devices/ibeacon

POST /devices/{id}/thread/commissioner/:stop

POST /devices/{id}/thread/commissioner/:start

POST /devices/{id}/ssid/status/:change

POST /devices/{id}/ssid/:override

POST /devices/{id}/monitor/:refresh

POST /devices/{id}/iot/:enable

POST /devices/{id}/iot/:disable

POST /devices/{id}/bounce-port

POST /devices/{id}/:unmanage

POST /devices/{id}/:reset

POST /devices/{id}/:reboot

POST /devices/{id}/:manage

POST /devices/{id}/:cli

POST /devices/rm-devices-page

POST /devices/rm-devices-page/export

POST /devices/rm-devices-metadata

POST /devices/rm-devices-connection-status

POST /devices/os/:change

POST /devices/network-policy/:revoke

POST /devices/network-policy/:query

POST /devices/network-policy/:assign

POST /devices/location/:revoke

POST /devices/location/:query

POST /devices/location/:assign

POST /devices/country-code/:assign

POST /devices/client-monitor/:revoke

POST /devices/client-monitor/:query

POST /devices/client-monitor/:assign

POST /devices/:unmanage

POST /devices/:reboot

POST /devices/:onboard

POST /devices/:manage

POST /devices/:delete

POST /devices/:cli

POST /devices/:check-ownership

POST /devices/:advanced-onboard



GET /devices

GET /devices/{id}

DELETE /devices/{id}

GET /devices/{id}/ssid/status

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/iot

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/installation-report

GET /devices/{id}/ibeacon

GET /devices/{id}/history/cpu-mem

GET /devices/{id}/geolocation

GET /devices/{id}/gallery-image

GET /devices/{id}/alarms

GET /devices/stats

GET /devices/rm-devices-stack/{stackId}

GET /devices/radio-information

GET /devices/network-policy/{policyId}

GET /devices/digital-twin

DELETE /devices/radius-proxy/:revoke

#### device:r

GET /devices/{id}/radio-operating-mode

GET /devices/{id}/network-policy

GET /devices/{id}/location

GET /devices/{id}/ftm-settings

GET /devices/{id}/client-monitor

GET /devices

GET /devices/{id}

GET /devices/{id}/ssid/status

GET /devices/{id}/monitor/refresh/status

GET /devices/{id}/iot

GET /devices/{id}/interfaces/wifi

GET /devices/{id}/installation-report

GET /devices/{id}/ibeacon

GET /devices/{id}/history/cpu-mem

GET /devices/{id}/geolocation

GET /devices/{id}/gallery-image

GET /devices/{id}/alarms

GET /devices/stats

GET /devices/rm-devices-stack/{stackId}

GET /devices/radio-information

GET /devices/network-policy/{policyId}

GET /devices/digital-twin



# device:list GET /devices device:view GET /devices/{id} GET /devices/stats GET /devices/radio-information GET /devices/digital-twin device:new POST /devices/:onboard device:del POST /devices/:delete device:cli POST /devices/:cli device:deploy Permission not used device:manage POST /devices/:manage device:unmanage POST /devices/:unmanage device:reboot POST /devices/:reboot device:reset



# POST /devices/{id}/:reset

#### device:thread-commissioner

POST /devices/{id}/thread/commissioner/:stop POST /devices/{id}/thread/commissioner/:start

#### client

PUT /clients/alias

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

DELETE /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

#### client:r

GET /clients/{id}

GET /clients/usage

GET /clients/summary

GET /clients/byMac/{clientMac}

GET /clients/active

GET /clients/active/count

# locations

PUT /locations/{id}

DELETE /locations/{id}

GET /locations/site/{id}

PUT /locations/site/{id}

DELETE /locations/site/{id}

GET /locations/floor/{id}

PUT /locations/floor/{id}

DELETE /locations/floor/{id}

GET /locations/building/{id}

PUT /locations/building/{id}

DELETE /locations/building/{id}

POST /locations

GET /locations/site

POST /locations/site



POST /locations/import/ekahau

POST /locations/floorplan

GET /locations/floor

POST /locations/floor

GET /locations/building

POST /locations/building

POST /locations/:init

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

#### locations:r

GET /locations/site/{id}

GET /locations/floor/{id}

GET /locations/building/{id}

GET /locations/site

GET /locations/floor

GET /locations/building

GET /locations/tree

GET /locations/tree/maps

GET /locations/tree/devices

#### network-policy

GET /network-policies/{id}

PUT /network-policies/{id}

DELETE /network-policies/{id}

GET /network-policies

POST /network-policies

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

GET /network-policies/{id}/ssids

#### policy:ssid

POST /network-policies/{id}/ssids/:remove

POST /network-policies/{id}/ssids/:add

#### network-policy:r

GET /network-policies/{id}

GET /network-policies



### GET /network-policies/{id}/ssids

#### network-scorecard

GET /network-scorecard/wifiHealth/{locationId}

GET /network-scorecard/servicesHealth/{locationId}

GET /network-scorecard/networkHealth/{locationId}

GET /network-scorecard/deviceHealth/{locationId}

GET /network-scorecard/clientHealth/{locationId}

#### network-scorecard:r

GET /network-scorecard/wifiHealth/{locationId}

GET /network-scorecard/servicesHealth/{locationId}

GET /network-scorecard/networkHealth/{locationId}

GET /network-scorecard/deviceHealth/{locationId}

GET /network-scorecard/clientHealth/{locationId}

#### ssid

PUT /ssids/{id}/psk/password

PUT /ssids/{id}/mode/wep

PUT /ssids/{id}/mode/psk

PUT /ssids/{id}/mode/ppsk

PUT /ssids/{id}/mode/open

PUT /ssids/{id}/mode/dot1x

GET /ssids/advanced-settings/{id}

PUT /ssids/advanced-settings/{id}

POST /ssids/{id}/user-profile/:attach

POST /ssids/{id}/user-profile-assignment/:attach

POST /ssids/{id}/radius-server-group/:attach

POST /ssids/{id}/radius-client-profile/:attach

POST /ssids/{id}/cwp/:enable

POST /ssids/{id}/cwp/:disable

POST /ssids/{id}/cwp/:attach

POST /ssids/{id}/client-monitor-profile/:attach

POST /ssids/{id}/:rename

GET /ssids

#### ssid:r

GET /ssids/advanced-settings/{id}

GET /ssids



#### pcg:key

GET /pcgs/key-based/network-policy-{policyId}/users
PUT /pcgs/key-based/network-policy-{policyId}/users
POST /pcgs/key-based/network-policy-{policyId}/users
DELETE /pcgs/key-based/network-policy-{policyId}/users
GET /pcgs/key-based
POST /pcgs/key-based
GET /pcgs/key-based/network-policy-{policyId}/port-assignments
POST /pcgs/key-based/network-policy-{policyId}/port-assignments
POST /pcgs/key-based/network-policy-{policyId}/keys/:generate
POST /pcgs/key-based/network-policy-{policyId}/keys/:email
POST /pcgs/key-based/network-policy-{policyId}/:onboard

#### pcg:key:r

GET /pcgs/key-based/network-policy-{policyId}/users GET /pcgs/key-based GET /pcgs/key-based/network-policy-{policyId}/port-assignments

DELETE /pcgs/key-based/network-policy-{policyId}

# subscriptions-webhook

PUT /subscriptions/webhook/{id}
GET /subscriptions/webhook
POST /subscriptions/webhook
GET /subscriptions/webhook/export
DELETE /subscriptions/webhook/:delete

#### subscriptions-webhook:r

GET /subscriptions/webhook GET /subscriptions/webhook/export

#### ccg

GET /ccgs/{id}
PUT /ccgs/{id}
DELETE /ccgs/{id}
GET /ccgs
POST /ccgs



# ccg:r GET /ccgs/{id} GET /ccgs log POST /logs/audit/reports GET /logs/sms GET /logs/email GET /logs/credential GET /logs/auth GET /logs/audit GET /logs/audit/reports/{id} GET /logs/audit/full-descriptions/{id} GET /logs/accounting log:r GET /logs/sms GET /logs/email GET /logs/credential GET /logs/auth GET /logs/audit GET /logs/audit/reports/{id} GET /logs/audit/full-descriptions/{id} GET /logs/accounting cwp GET /cwps cwp:r GET /cwps sms-tmpl $GET\ /sms\text{-templates}$ sms-tmpl:r GET /sms-templates



#### class-rule

GET /classification-rules/{id} PUT /classification-rules/{id} DELETE /classification-rules/{id} GET /classification-rules POST /classification-rules

#### class-rule:r

GET /classification-rules/{id}
GET /classification-rules

# user-profile

GET /user-profiles/{id} PUT /user-profiles/{id} DELETE /user-profiles/{id} GET /user-profiles POST /user-profiles

#### user-profile:r

GET /user-profiles/{id} GET /user-profiles

# tunnel-concentrator

GET /tunnel-concentrators/{id} PUT /tunnel-concentrators/{id} DELETE /tunnel-concentrators/{id} GET /tunnel-concentrators POST /tunnel-concentrators

#### tunnel-concentrator:r

GET /tunnel-concentrators/{id}
GET /tunnel-concentrators



# radius-proxy

GET /radius-proxies/{id} PUT /radius-proxies/{id} DELETE /radius-proxies/{id} GET /radius-proxies POST /radius-proxies GET /radius-proxies/devices

#### radius-proxy:r

GET /radius-proxies/{id}
GET /radius-proxies
GET /radius-proxies/devices

#### radius-server

GET /radius-servers/internal/{id}
PUT /radius-servers/internal/{id}
DELETE /radius-servers/internal/{id}
GET /radius-servers/external/{id}
PUT /radius-servers/external/{id}
PUT /radius-servers/external/{id}
DELETE /radius-servers/external/{id}
GET /radius-servers/internal
POST /radius-servers/internal
DELETE /radius-servers/internal
GET /radius-servers/external
POST /radius-servers/external
GET /radius-servers/external

#### radius-server:r

GET /radius-servers/internal/{id} GET /radius-servers/external/{id} GET /radius-servers/internal GET /radius-servers/external GET /radius-servers/internal/devices

#### usergroup

PUT /usergroups/{id}
DELETE /usergroups/{id}



GET /usergroups POST /usergroups GET /usergroups/:unique

#### usergroup:r

GET /usergroups/:unique

# deployment

GET /deployments/{deploymentId}
PUT /deployments/{deploymentId}
DELETE /deployments/{deploymentId}
GET /deployments
POST /deployments
POST /deployments/firmware-metadatas
GET /deployments/{deploymentId}/status
GET /deployments/status
GET /deployments/overview

# deployment:r

GET /deployments/{deploymentId} GET /deployments GET /deployments/{deploymentId}/status GET /deployments/status GET /deployments/overview

#### ad-server

GET /ad-servers

#### ad-server:r

GET /ad-servers

#### alert

POST /alerts/reports
POST /alerts/:acknowledge
GET /alerts
GET /alerts/reports/{id}



# GET /alerts/count-by-{group}

#### alert:r

GET /alerts

GET /alerts/reports/{id}

GET /alerts/count-by-{group}

# alert-policies

GET /alert-policies/{policyId}/rules/{ruleId}

PUT /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

PUT /alert-policies/{id}

DELETE /alert-policies/{id}

GET /alert-policies

POST /alert-policies

POST /alert-policies/{policyId}/rules/{ruleId}/:enable

POST /alert-policies/{policyId}/rules/{ruleId}/:disable

GET /alert-policies/available-sites

#### alert-policies:r

GET /alert-policies/{policyId}/rules/{ruleId}

GET /alert-policies/{id}

GET /alert-policies

GET /alert-policies/available-sites

#### alert-subscriptions

GET /alert-subscriptions/webhooks/{id}

PUT /alert-subscriptions/webhooks/{id}

DELETE /alert-subscriptions/webhooks/{id}

GET /alert-subscriptions/servicenow/{id}

PUT /alert-subscriptions/servicenow/{id}

PATCH /alert-subscriptions/servicenow/{id}

GET /alert-subscriptions/emails/{id}

PUT /alert-subscriptions/emails/{id}

DELETE /alert-subscriptions/emails/{id}

GET /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks

POST /alert-subscriptions/webhooks/:delete

GET /alert-subscriptions/servicenow



POST /alert-subscriptions/servicenow POST /alert-subscriptions/servicenow/:delete GET /alert-subscriptions/emails POST /alert-subscriptions/emails/ POST /alert-subscriptions/emails/{id}/:verify POST /alert-subscriptions/emails/:delete

#### alert-subscriptions:r

GET /alert-subscriptions/webhooks/{id} GET /alert-subscriptions/servicenow/{id} GET /alert-subscriptions/emails/{id} GET /alert-subscriptions/webhooks GET /alert-subscriptions/servicenow GET /alert-subscriptions/emails

#### app

GET /applications
GET /applications/{id}/clients/top{n}
GET /applications/top{n}

# application:r

GET /applications
GET /applications/{id}/clients/top{n}
GET /applications/top{n}

# 13-address-profile

GET /l3-address-profiles/{id} PUT /l3-address-profiles/{id} DELETE /l3-address-profiles/{id} GET /l3-address-profiles POST /l3-address-profiles

#### 13-address-profile:r

GET /13-address-profiles/{id} GET /13-address-profiles



# vlan-profile

GET /vlan-profiles POST /vlan-profiles/:delete POST /vlan-profiles/:delete GET /vlan-profiles/{id} DELETE /vlan-profiles/{id} PATCH /vlan-profiles/{id}

#### vlan-profile:r

GET /vlan-profiles GET /vlan-profiles/{id}

#### enduser

PUT /endusers/{id}
DELETE /endusers/{id}
GET /endusers
POST /endusers
POST /endusers/{id}/:regenerate-password

#### enduser:r

GET /endusers

# radius-client-object

GET /radius-client-objects/{id} PUT /radius-client-objects/{id} DELETE /radius-client-objects/{id} GET /radius-client-objects POST /radius-client-objects

#### radius-client-object:r

GET /radius-client-objects/{id} GET /radius-client-objects

#### **Idap-server**



GET /ldap-servers/{id} PUT /ldap-servers/{id} DELETE /ldap-servers/{id} GET /ldap-servers POST /ldap-servers

#### Idap-server:r

GET /ldap-servers/{id} GET /ldap-servers

#### email-template

GET /email-templates

#### email-template:r

GET /email-templates

#### certificate

GET /certificates

#### certificate:r

GET /certificates

#### radio-profile

GET /radio-profiles/{id}

PUT /radio-profiles/{id}

DELETE /radio-profiles/{id}

GET /radio-profiles/wmm-qos/{id}

PUT /radio-profiles/wmm-qos/{id}

GET /radio-profiles/sensor-scan/{id}

PUT /radio-profiles/sensor-scan/{id}

GET /radio-profiles/radio-usage-opt/{id}

PUT /radio-profiles/radio-usage-opt/{id}

GET /radio-profiles/neighborhood-analysis/{id}

PUT /radio-profiles/neighborhood-analysis/{id}

GET /radio-profiles/miscellaneous/{id}

PUT /radio-profiles/miscellaneous/{id}

GET /radio-profiles/mac-ouis/{id}



PUT /radio-profiles/mac-ouis/{id}
DELETE /radio-profiles/mac-ouis/{id}
GET /radio-profiles/channel-selection/{id}
PUT /radio-profiles/channel-selection/{id}
GET /radio-profiles
POST /radio-profiles
GET /radio-profiles/mac-ouis
POST /radio-profiles/mac-ouis

# radio-profile:r

GET /radio-profiles/{id}

GET /radio-profiles/wmm-qos/{id}

GET /radio-profiles/sensor-scan/{id}

GET /radio-profiles/radio-usage-opt/{id}

GET /radio-profiles/neighborhood-analysis/{id}

GET /radio-profiles/miscellaneous/{id}

GET /radio-profiles/mac-ouis/{id}

GET /radio-profiles/channel-selection/{id}

GET /radio-profiles

GET /radio-profiles/mac-ouis

### iot-profile

GET /iot-profiles/{id} PUT /iot-profiles/{id} DELETE /iot-profiles/{id} GET /iot-profiles POST /iot-profiles

#### iot-profile:r

GET /iot-profiles/{id} GET /iot-profiles

#### client-monitor-profile

GET /client-monitor-profiles/{id} PUT /client-monitor-profiles/{id} DELETE /client-monitor-profiles/{id} GET /client-monitor-profiles POST /client-monitor-profiles



#### client-monitor-profile:r

GET /client-monitor-profiles/{id}

GET /client-monitor-profiles

#### copilot-connectivity-wired:r

GET /copilot/connectivity/wired/quality-index

GET /copilot/connectivity/wired/locations/hardware

GET /copilot/connectivity/wired/hardware

GET /copilot/connectivity/wired/experience

GET /copilot/connectivity/wired/events

#### copilot-connectivity-wireless:r

GET /copilot/connectivity/wireless/views

GET /copilot/connectivity/wireless/time-to-connect

GET /copilot/connectivity/wireless/quality-index

GET /copilot/connectivity/wireless/performance

GET /copilot/connectivity/wireless/locations/time-to-connect

GET /copilot/connectivity/wireless/locations/quality-index

GET /copilot/connectivity/wireless/locations/performance

GET /copilot/connectivity/wireless/locations/events

GET /copilot/connectivity/wireless/experience

GET /copilot/connectivity/wireless/events

GET /copilot/connectivity/wireless/apps

#### copilot-anomalies:r

GET /copilot/anomalies/wifi-efficiency/stats

GET /copilot/anomalies/wifi-efficiency/client-list

GET /copilot/anomalies/wifi-capacity/stats

GET /copilot/anomalies/wifi-capacity/client-list

GET /copilot/anomalies/report

GET /copilot/anomalies/port-efficiency/stats

GET /copilot/anomalies/port-efficiency/speed-duplex-stats

GET /copilot/anomalies/poeflapping/trends

GET /copilot/anomalies/poeflapping/stats

GET /copilot/anomalies/poeflapping/lldp-cdp-info

GET /copilot/anomalies/notifications

GET /copilot/anomalies/missing-vlan/count

GET /copilot/anomalies/locations

GET /copilot/anomalies/hardware-health/stats



GET /copilot/anomalies/hardware-health/cpu-mem-stats

GET /copilot/anomalies/hardware-health/client-list

GET /copilot/anomalies/excluded-vlans-list

GET /copilot/anomalies/dfs-recurrence/count-stats

GET /copilot/anomalies/dfs-recurrence/channel-stats

GET /copilot/anomalies/devices-with-locations

GET /copilot/anomalies/devices-by-location

GET /copilot/anomalies/anomalies-by-category

GET /copilot/anomalies/adverse-traffic/packet-counts

GET /copilot/anomalies/adverse-traffic/device-stats

#### licenses

Permission not used

#### licenses:r

Permission not used

# copilot-assurance-scans:r

GET /copilot/assurance-scans/overview

#### packet-capture

GET /packetcaptures POST /packetcaptures POST /packetcaptures/{id}/:upload POST /packetcaptures/{id}/:stop GET /packetcaptures/{id} DELETE /packetcaptures/{id}

GET /packetcaptures/files

#### packet-capture:r

GET /packetcaptures

GET /packetcaptures/{id}

GET /packetcaptures/files

#### country

GET /countries

GET /countries/{countryCode}/:validate



# GET /countries/{countryAlpha2Code}/states country:r GET /countries GET /countries/{countryCode}/:validate GET /countries/{countryAlpha2Code}/states cas Permission not used cas:r Permission not used cas-policies Permission not used cas-policies:r Permission not used cas-metadata:r Permission not used cns-subscriptions Permission not used cns-subscriptions:r Permission not used hotspot-profile GET /hotspot-profiles/{id} PUT /hotspot-profiles/{id} DELETE /hotspot-profiles/{id}

GET /hotspot-profiles



# POST /hotspot-profiles

# hotspot-profile:r

GET /hotspot-profiles/{id} GET /hotspot-profiles

# hotspot-service-provider-profile

GET /hotspot-service-provider-profiles/{id} PUT /hotspot-service-provider-profiles/{id} DELETE /hotspot-service-provider-profiles/{id} GET /hotspot-service-provider-profiles POST /hotspot-service-provider-profiles

# hotspot-service-provider-profile:r

GET /hotspot-service-provider-profiles/{id} GET /hotspot-service-provider-profiles