

ASUS > Support > FAQ

FAQ

Create MyASUS in WinRE For USB

Last Update: 2025/01/23 14:19



Related Topics

[Notebook] System Diagnostics within MyASUS in WinRE - Introduction

Cloud Recovery in UEFI BIOS - Introduction

Create MyASUS in WinRE For USB

Table of Contents

About MyASUS in WinRE For USB

Hardware Requirements

Download the Toolkit

Create MyASUS in WinRE For USB tool

Perform System Diagnostics via MyASUS in WinRE for USB

About tool MyASUS in WinRE For USB

This tool creates a bootable USB drive to enable the system to boot into MyASUS in WinRe Environment.

Hardware Requirements


USB Flash Drive (Capacity suggestion is higher than 2GB and with FAT32 format).

Download the Toolkit


How to get MyASUS in WinRE For USB toolkit, please refer to ASUS official website [How to search and download Drivers, Utilities, BIOS, and User Manuals].

*The product must support the Cloud Recovery feature (Check if your product supports Cloud Recovery) to use this tool.

*If you do not find the Toolkit in the product download center, it means that this product model does not support temporarily.




After toolkit downloaded, please put the file into your This PC or USB Drive.




[Back to Content]

Create MyASUS in WinRE For USB tool


Please executing the toolkit (EXE file) with mouse left-click twice.




Select the language to use during the installation, then click [OK] to start.




Click [Next] to continue MyASUS in WinRE for USB tool installation.




Please read the following License Agreement. You must accept the terms of this agreement before continuing with the installation.



Confirm destination location and then click [Next] to continue.



Click [Install] to continue with MyASUS in WinRE For USB tool installation.



The toolkit will run automatically to completed, then click [Finish] to exit setup.



Perform System Diagnostics via MyASUS in WinRE for USB

Please insert the USB flash drive with the tool installed into your laptop and use [Boot the system from USB flash drive] through the boot menu. After booting through the USB flash drive, the computer will enter System Diagnostics within MyASUS in WinRE. Please refer to [System Diagnostics within MyASUS in WinRE-Introduction] to complete the Diagnostics.

[Back to Content]



Contact Support

Please contact with us if the above information cannot resolve your problem



- Above information might be partly or entirely quoted from exterior websites or sources. please refer to the information based on the source that we noted. Please directly contact or inquire the sources if there is any further question and note that ASUS is neither relevant nor responsible for its content/service
- This information may not suitable for all the products from the same category/series. Some of the screen shots and operations could be different from the software versions.
- ASUS provides the above information for reference only. If you have any questions about the content, please contact the above product vendor directly. Please note that ASUS is not responsible for the content or service provided by the above product vendor.
- · Brand and product names mentioned are trademarks of their respective companies.

/SUS > Support	
Product Line	+
Inquiry service	+
Support service	+
Contact Us	+
You f YOU	
ASUSTEK Computer Inc. All rights reserved. Terms of Use Notice Privacy Policy Export Control and Sanctions Compliance Cookie Settings	∰ Global / English