
For immediate assistance call: 206-221-5000, Option 9
For general requests email: help@uw.edu
OR go to: www.washington.edu/uwit/cte



### Turn on the data projector:

1) Select [Power]. The projector will begin to warm-up, which will take about 60 seconds.

### **Adjust Volume:**

1) All volume for source selections can be controlled by the [UP], [DOWN], and [Mute Volume] buttons.

### Laptop:

- 1) Connect either the VGA cable or the HDMI cable
- 2) Select [Computer] or [HDMI] based on which cable you are using. This will automatically send your source to the projection screen.

## **DVD/VCR:**

- 1) Select [Video]
- 2) Use the controls to navigate the media as needed

# **Wireless Microphone:**

1) The wireless microphone is located in the drawer of the podium. You will need an IOFA key to access this. The power button is located on the **TOP** of the transmitter pack. A **GREEN** LED will indicate the mic is on.

CTE may not support the use of personal audio/video or network devices. CTE does not warrant or guarantee that third-party audio/video or network devices will be compatible with the technology installed in this building. If you would like to test your personal equipment in this room, please contact our office to schedule an equipment tutorial. For more information, please visit: http://goo.gl/NaTFkY