## **Embedded Systems**

Chips with power of whole computer systems now in many applications:

- Mobile Phones
- PDA's
- Smart Cards
- On-board controllers of HW

Characterisation of those systems:

- Fewer resources available: memory, storage space
- Often real-time applications necessary (on-board controllers)

Nick Blundell, Eike Ritter Operating Systems with C/C++ 2010/11



## Real-time Operating Systems

Have two different kinds of real-time

- 1.) Hard real-time: completion required within a guaranteed amount of time
- cannot be met by normal time-sharing systems; needs dedicated HW and adaptations to SW
- 2.) soft real-time: critical processes receive priority. Requires
  - pre-emptive priority scheduling (plus sufficient resources to avoid starvation)
  - short dispatch latency (time between arrival of process and start of execution)
    - Problem: context switch normally only after syscall-completion or when I/O takes place way out: make kernel pre-emptible (eg Solaris 2, newer versions of Linux)
  - Priority inversion: increase priority of process if resources required by high-priority process

Nick Blundell, Eike Ritter Operating Systems with C/C++ 2010/11 3



## Limited Resources

Not so much of a problem in general: OS's designed for this case Only issue: potentially missing MMU

⇒ virtual memory and protection of processes against each other not implementable

Also paging not available

Nick Blundell, Eike Ritter Operating Systems with C/C++ 2010/11 2 2

