SH2702 Nuclear Reactor Technology

Project work Task 4


Project work

Topic numbers	Topics
1	Design, operation and safety features of NuSCALE
2	Design, operation and safety features of ABWR
3	Design, operation and safety features of ESBWR
4	Design, operation and safety features of EPR
5	Design, operation and safety features of AP1000


- Task 1 General design specification of the nuclear power plant with selected reactor type
- Task 2 Operational principles of the power plant
- Task 3 Safety features of the power plant
- Task 4 Calculation of selected core parameters
- Task 5 Calculation of CHF margins in a hot channel
- Task 6 Calculation of the maximum cladding and fuel pellet Temperature

Task 4

- 1. Data collection
 - Tables are recommended
- 2. core-averaged thermal-hydraulic calculations
 - Axial enthalpy/temperature distribution
 - Axial void fraction distribution
 - BWRs, from subcooled to saturated
 - Axial pressure distribution
 - Inlet orifices pressure loss, BWRs (50%), PWRs (25%)
 - Flow characteristic of the core (-dp)=f(G)
 - 0%, 50%, 100%, 150% power
 - 1% to 150% flow




Task 4



- Inlet orifices pressure loss
 - BWRs (50% at nominal operating conditions)
 - PWRs (25% at nominal operating conditions)

$$\Delta p = p_{out} - p_{in} = \Delta p_{FuelChannel} + \Delta p_{Orifice}$$

$$\left| \Delta p_{Orifice} \right| = \xi_{Orifice} \frac{\rho U^2}{2} = \xi_{Orifice} \frac{G^2}{2\rho}$$



Task 4 Nodalization and numerical solution

- for j = 2 to nk
 - $-i(j) = i(j-1) + q_cell(j-1) / W$ (energy balance)
- end for
- while p not converged
 - p(1) = pin + dpInletOrifice
 - for j = 2 to nk
 - xe(j), xa(j), alpha(j) (void fraction model)
 - dpf_cell(j-1), dpg_cell(j-1), dpa_cell(j-1), dpl_cell(j-1)
 - dp_cell(j-1) (pressure drop calculation)
 - $p(j) = p(j-1) + dp_cell(j-1)$
 - end for
- end while p
- T(j)
 - f(p(j), i(j)) for subcooled water
 - Tsat(j) for saturated water
- Inlet orifices pressure loss coefficient (designed for nominal condition)
- Flow characteristic of the core (-dp)=f(G)


Thermal Power Distribution in Fission Reactors

•Distribution of thermal power density in nuclear reactors depends on the shape of the reactor:

-Finite cylindrical with radius R and height H:

-Sphere with radius R:


Compendium, Appendix B $q'''(r,z) = q_0''' J_0 \left(\frac{2.405r}{\widetilde{R}} \right) \cos \left(\frac{\pi z}{\widetilde{H}} \right)$



$$q'''(r) = q_0'''\left(\frac{\widetilde{R}}{\pi}\right) \frac{\sin\frac{\pi r}{\widetilde{R}}}{r}$$

Note: dimensions with tilde are so-called extrapolated dimensions to avoid zero flux at reactor boundary

Rectangularparallelepiped with sidesa, b, c:



$$q'''(x, y, z) = q_0''' \cos\left(\frac{\pi x}{\widetilde{a}}\right) \cos\left(\frac{\pi y}{\widetilde{b}}\right) \cos\left(\frac{\pi z}{\widetilde{c}}\right)$$

 $J_0(x)$ – Bessel function of first


kind and zero order. See

 q_0''' - power density at the core centre; r=0, z=0

Isolated Sub-channel Model

 Cross-section over a square lattice with fuel pins

- Heat transfer calculations are performed in an averaged, representative "sub-channel"
- Heat conduction is considered in each rod separately
- Main assumption: no flow of mass, momentum and energy through sub-channel "walls"




Basic Parameters Describing Isolated Subchannel (1)

Hydraulic diameter
 Flow area
 Wetted perimeter

$$D_h = \frac{4A}{P_w}$$

A - channel cross-section area

 P_w – channel wetted perimeter




Square lattice

$$D_{h} = \begin{cases} d_{r} \left[\frac{4}{\pi} \left(\frac{p}{d_{r}} \right)^{2} - 1 \right] & \text{for square lattice} \\ d_{r} \left[\frac{2\sqrt{3}}{\pi} \left(\frac{p}{d_{r}} \right)^{2} - 1 \right] & \text{for triangular lattice} \end{cases} \qquad p - \text{lattice pitch}$$

$$d_{r} - \text{rod diameter}$$

Basic Parameters Describing Isolated Subchannel (2)


Heated diameter Flow area Heated perimeter



A - channel cross-section area

 P_H – sub-channel heated perimeter

Flow subchannel



Square lattice

subchannels with all heated rods we have:

For

$$D_{H} = \begin{cases} d_{r} \left[\frac{4}{\pi} \left(\frac{p}{d_{r}} \right)^{2} - 1 \right] & \text{for square lattice} \\ d_{r} \left[\frac{2\sqrt{3}}{\pi} \left(\frac{p}{d_{r}} \right)^{2} - 1 \right] & \text{for triangular lattice} \end{cases}$$

$$p - \text{lattice pitch}$$

$$d_{r} - \text{rod diameter}$$

Triangular lattice

Whole-Assembly Model

Water rod

This model is suitable to BWR Box wall in fuel assemblies

Fuel rods

Basic parameters:

• hydraulic diameter
$$D_h$$
 $D_h \equiv \frac{4A}{P_w} = \frac{4w^2 - N\pi d_r^2}{4w + N\pi d_r}$

wetted perimeter P_w

$$P_{w} = 4w + N\pi d_{r}$$

heated diameter D_H

$$D_H \equiv \frac{4A}{P_H} = \frac{4w^2 - N\pi d_r^2}{N_{FR}\pi d_r}$$

heated perimeter P_H

$$P_H = N_{FR} \pi d_r$$

 N_{FR}, N_{WR} – nr of fuel /water rods

$$N = N_{FR} + N_{WR}$$

N – total number of rods


A – cross-section flow area

w – assembly width

 d_r – rod diameter

p – lattice pitch

Flow and Heat Transfer Regimes in a Boiling Channel




Coolant Enthalpy Distribution in Heated Channels (1)

- Assume a heated channel as shown in the figure to the right. The channel is uniformly heated along its length with heat flux q" [W/m²], it has a flow cross-section area A and heated perimeter P_H.
- The energy balance for a portion of channel dz is as follows:

$$W \cdot i_l(z) + q''(z) \cdot P_H(z) \cdot dz = W \cdot [i_l(z) + di_l]$$

$$\frac{di_l(z)}{dz} = \frac{q''(z) \cdot P_H(z)}{W}$$

$$W = G*A$$




Coolant Enthalpy Distribution in Heated Channels (2)

 Thus, the enthalpy distribution of coolant is described by the following differential equation:

$$\frac{di_l(z)}{dz} = \frac{q''(z) \cdot P_H(z)}{W}$$

Integration yields

$$i_{l}(z) = i_{li} + \frac{1}{W} \int_{-H/2}^{z} q''(z) \cdot P_{H}(z) \cdot dz$$



Coolant Enthalpy Distribution in Heated Channels (3)

 Assuming constant specific heat (calorically perfect fluid) the enthalpy increase can be expressed in terms of the temperature increase as follows:

$$di = c_p * dT$$


• Using W = G A and assuming a constant channel cross-section area and heat flux distribution, the coolant temperature can be found as, $\rho_l c_{pl} v_l T_l dA$

$$T_{lb}(z) = T_{lbi} + \frac{q''P_H(z+H/2)}{c_pGA} \qquad T_{lb} = \frac{\frac{A}{\int \rho_l c_{pl} v_l dA}}{\int \rho_l c_{pl} v_l dA} \qquad \text{Definition of the bulk liquid temperature}$$

Coolant Enthalpy Distribution in Heated Channels (4)

- The temperature is thus linearly distributed between the inlet and the exit of the assembly
- The exit temperature becomes

$$T_{lbex} = T_{lbi} + \frac{q'' P_H H}{c_p G A}$$



Coolant Enthalpy Distribution in Heated Channels (5)

 Usually the axial power distribution is non-uniform. In a cylindrical reactor the axial power distribution is given by the cosine function:

$$q''(z) = q_0'' \cdot \cos\left(\frac{\pi z}{\widetilde{H}}\right)$$

The differential equation for the enthalpy (temperature) distribution is now

$$z=H/2$$
 $z=H/2$
 $z=H/2$

$$\frac{di_{l}(z)}{dz} = \frac{q_{0}'' \cdot P_{H}(z)}{W} \cos\left(\frac{\pi z}{\widetilde{H}}\right), \quad \text{or} \quad \frac{dT_{lb}(z)}{dz} = \frac{q_{0}'' \cdot P_{H}(z)}{W \cdot c_{p}} \cos\left(\frac{\pi z}{\widetilde{H}}\right)$$

Coolant Enthalpy Distribution in Heated

• After integration, (P_H=const) the coolant enthalpy (temperature)


distribution is as follows
$$i_{l}(z) = \frac{q_{0}'' \cdot P_{H}}{W} \cdot \frac{\widetilde{H}}{\pi} \left[\sin \left(\frac{\pi z}{\widetilde{H}} \right) + \sin \left(\frac{\pi H}{2\widetilde{H}} \right) \right] + i_{li}, \quad or$$

$$T_{lb}(z) = \frac{q_0'' \cdot P_H}{W \cdot c} \cdot \frac{\widetilde{H}}{\pi} \left[\sin \left(\frac{\pi z}{\widetilde{H}} \right) + \sin \left(\frac{\pi H}{2\widetilde{H}} \right) \right] + T_{lbi}$$


The exit enthalpy (temperature) can be found as:

$$i_{lex} = i_l(H/2) = \frac{2q_0'' \cdot P_H \cdot \widetilde{H}}{\pi \cdot W} \sin\left(\frac{\pi H}{2\widetilde{H}}\right) + i_{li}, \text{ or}$$

$$T_{lbex} = T_{lb}(H/2) = \frac{2q_0'' \cdot P_H \cdot \widetilde{H}}{\pi \cdot W \cdot c_p} \sin\left(\frac{\pi H}{2\widetilde{H}}\right) + T_{lbi}$$




PWR Fuel Assembly






Top nozzle



Cross section

Bottom nozzle with debris filter





Pressure Drop Calculation

- Calculation of pressure drop in single phase flows, including
 - Friction pressure losses
 - Local losses from the spacer grids
 - Local losses at the assembly inlet and exit
 - Local losses due to flow area change
 - Elevation pressure drop
- The total pressure drop in a vertical channel with length H and hydraulic diameter D_h can be calculated from the following equation (G = const)

$$-\Delta p_{tot} = -\Delta p_{fric} - \Delta p_{loc} - \Delta p_{elev} = \left(\frac{4C_f H}{D_h} + \sum_i \xi_i\right) \frac{G|G|}{2\rho} + H\rho g$$

Hydraulic Design

Friction Pressure Losses (1)

 Friction pressure losses in a channel with length H and hydraulic diameter D_h is calculated as:

$$-\Delta p_{fric} = \frac{4C_f H}{D_h} \frac{G|G|}{2\rho}$$

 where C_f is the (Fanning) friction coefficient, which depends on the Reynolds number and wall roughness, defined as

$$C_f \equiv \frac{\tau_w}{\frac{1}{2}\rho U^2}$$
 τ_w – wall shear stress, $U = G/\rho$ – flow velocity

Friction Pressure Losses (2)

Friction coefficient for pipes

$$C_f = \frac{16}{\text{Re}}$$

$$C_f = \frac{0.0791}{\text{Re}^{0.25}}$$

Turbulent flow in commercial rough tubes (Colebrook formula)

$$\frac{1}{\sqrt{C_f}} = -4.0 \log_{10} \left(\frac{k/D_h}{3.7} + \frac{1.255}{\text{Re}\sqrt{C_f}} \right)$$

k – wall roughness [m],

 D_h – hydraulic diameter [m]

Friction Pressure Losses (3)

- Friction coefficient for pipes, cont'ed
 - Colebrook formula can be replaced with the Haaland formula (which does not require iterations)

$$\frac{1}{\sqrt{C_f}} = -3.6 \log_{10} \left[\left(\frac{k / D_h}{3.7} \right)^{1.11} + \frac{6.9}{\text{Re}} \right]$$

k – wall roughness [m], D_h – hydraulic diameter [m]

Friction Pressure Losses (4)

 In fuel assemblies, friction coefficients are obtained experimentally and are in general expressed in the following form:

$$C_f = a \operatorname{Re}^{-b}$$

a, b > 0 – coefficients that depend on the fuel assembly design

Friction Pressure Losses (5)

• For triangular lattice with $1.0 < p/d_r < 1.5$ the following correlation can be used:


$$C_{f,b} = \frac{0.25 \left(0.96 \frac{p}{d_r} + 0.63\right)}{\left(1.82 \log_{10} \text{Re} - 1.64\right)^2}$$
 Re > 4000


Local Losses Due to Spacer Grids

- Spacer local pressure loss
 - Geometry-dependent
 - In general, the pressure loss can be calculated as

$$\xi_{spac} = a_1 + a_2 \cdot \text{Re}^{-b}$$


Constants a₁, a₂ and b are usually obtained from experiments






Local Losses Due to Area Changes


Exit from fuel assembly



$$-\Delta p_I = \xi_{ex} \cdot \frac{G^2}{2\rho}; \qquad \xi_{ex} = 1.0$$


Inlet to fuel assembly






$$-\Delta p_I = \xi_{in} \cdot \frac{G|G|}{2\rho}; \qquad \xi_{in} = 0.5$$

Area change due to part-length rods



$$-\Delta p_I = \left(1 - \frac{A_1}{A_2}\right)^2 \cdot \frac{G_1|G_1|}{2\rho}; \qquad \xi_{enl} = \left(1 - \frac{A_1}{A_2}\right)^2$$

Loss Distribution in Fuel Assembly



Pressure Drop in Two-Phase Flows

Steady-state momentum equation for a homogeneous two-phase mixture flow in a channel can be written as,

$$-\frac{dp}{dz} = \left(\frac{dp}{dz}\right)_{w} + \rho_{m}g\sin\varphi + \frac{1}{A}\frac{d}{dz}\left(\frac{G^{2}A}{\rho_{M}}\right)$$

- Where two definitions of mixture density are introduced:
 - Mixture static density

$$\rho_m = \sum_k \rho_k \alpha_k$$

- Mixture dynamic density
$$\rho_M = \left(\sum_k \frac{x_k^2}{\rho_k \alpha_k}\right)^{-1}$$

Local Pressure Loss in Two-Phase Flows

 Local pressure losses in two-phase flows are calculated as:

$$-\Delta p_{loc} = \phi_{lo,d}^2 \xi \frac{G^2}{2\rho_f}$$

Here:

G - total mass flux, kg/m².s

 ξ - local (single-phase) loss coefficient

$$\phi_{lo,d}^2 = \left[1 + \left(\frac{\rho_f}{\rho_g} - 1\right)x\right]$$
 - HEM local two-phase multipl.

Friction pressure loss in two-phase flows

 It can be shown that the ratio of two-phase friction loss to single-phase friction loss is as follows,

$$\left(\frac{dp}{dz}\right)_{w,tp} / \left(\frac{dp}{dz}\right)_{w,lo} = \frac{C_{f,tp}}{C_{f,lo}} \frac{\rho_l}{\rho_m}$$

 The above ratio is called a two-phase friction multiplier and is as follows

$$\phi_{lo}^{2} = \left(\frac{dp}{dz}\right)_{w,tp} / \left(\frac{dp}{dz}\right)_{w,lo} = \frac{C_{f,tp}}{C_{f,lo}} \frac{\rho_{l}}{\rho_{m}}$$

It should be noted that it is a local variable

Two-Phase Friction Multiplier using HEM

 For Homogeneous Equilibrium Model, it can be shown that the two-phase friction multiplier is the following function of the local equilibrium quality:

$$\phi_{lo}^2 = \left[1 + \left(\frac{\mu_f}{\mu_g} - 1\right)x\right]^{-0.25} \left[1 + \left(\frac{\rho_f}{\rho_g} - 1\right)x\right]$$

where it is assumed that mixture viscosity is given as:

$$\frac{1}{\mu_m} = \frac{x}{\mu_g} + \frac{1-x}{\mu_f}$$

 it should be noted that other models of mixture viscosity are used as well (see Compendium in Thermal-Hydraulics)

Rod Bundle Correlations for ϕ_{lo}^2

- Local two-phase friction multiplier in general depends on local conditions (pressure, mass flux, heat flux) and geometry (pipe, bundle)
- For a rod bundle geometry the following correlation has been obtained (FRIGG)

$$\phi_{lo}^2 = 1 + \left(2234 - 0.348G\right)\left(\frac{x}{p}\right)^{0.96}$$
 x -quality p - pressure (bar) G - mass flux (kg/m²s)

To capture the effect of heating:

$$\frac{\left(\phi_{lo}^{2}\right)_{diabatic}}{\left(\phi_{lo}^{2}\right)_{adiabatic}} = 1 + C\left(\frac{q''}{G}\right)^{0.7}$$

$$C - constant coefficient q'' - heat flux (W/m^{2})$$

$$G - mass flux (kg/m^{2}s)$$

EPRI Correlation for ϕ_{lo}^2

$$\phi_{lo}^2 = \left[1 + x \left(\frac{\rho_f}{\rho_g} - 1 \right) C \right]$$

$$C = \begin{cases} 1.02x^{-0.175}G_R^{-0.45} & \text{for} & p > 4.137 \text{ MPa} \\ 0.357(1+p_R)x^{-0.175}G_R^{-0.45} & \text{for} & 2.068$$

$$p_{R} = \frac{p}{p_{cr}}; G_{R} = \frac{G}{1356.2}$$

$$x - \text{ equilibrium quality}$$

$$p - \text{ pressure (Pa)}$$

$$G - \text{ mass flux (kg/m²s)}$$

$$p_{cr} - \text{ critical pressure (22.1 MPa)}$$

Parameter range: 2.068 MPa; <math>0 < x < 1; 475 < G < 4475 kg/m²s; 5.08 < d < 15.24 mm; 127 < L < 2540 mm; geometry: round tubes and vertical upflow; based on 1533 experimental points; RMS error: 9.7%

Mean Value of ϕ_{lo}^2 Over Channel Length

• Integration of ϕ_{lo}^2 along a channel length gives

$$r_{3} = \frac{1}{L} \int_{0}^{L} \phi_{lo}^{2} dz \qquad \phi_{lo}^{2} = \left[1 + \left(\frac{\mu_{f}}{\mu_{g}} - 1 \right) x \right]^{-0.25} \left[1 + \left(\frac{\rho_{f}}{\rho_{g}} - 1 \right) x \right]$$

- The integral to calculate r_3 is thus a function of the quality distribution along the channel.
- In particular, if x = const (unheated channel):

$$r_3 = \phi_{lo}^2$$

Enthalpy and Quality in Heated Channel

For heated channel, we have:

$$di = \frac{q''(z)P_{H}dz}{W} \Longrightarrow d\left(\frac{i - i_{f}}{i_{fg}}\right) \equiv dx = \frac{q''(z)P_{H}dz}{Wi_{fg}}$$

thus, assuming z = 0 at the inlet:

$$x(z) - x_{in} = \frac{P_H}{Wi_{fg}} \int_0^z q''(z') dz'$$

For uniformly heated channel:

$$x(z) = x_{in} + \frac{P_H q''}{W i_{fg}} z$$

Total Pressure Drop in Boiling Channel

 Integration of the momentum eq. gives the total pressure drop for two-phase flows in channel with length L as:

$$-\Delta p = r_3 C_{f,lo} \frac{4L}{D} \frac{G^2}{2\rho_f} + \underbrace{r_4 L \rho_f g \sin \varphi}_{gravity} + \underbrace{r_2 \frac{G^2}{\rho_f}}_{acceleration} + \underbrace{\left(\sum_{i=1}^N \phi_{lo,d,i}^2 \xi_i\right) \frac{G^2}{2\rho_f}}_{local}$$

- where:
 - friction multiplier: $r_3 = \frac{1}{L} \int_0^L \phi_{lo}^2 dz$
 - gravity multiplier: $r_4 = \frac{1}{L\rho_f} \int_0^L \left[\alpha \rho_g + (1-\alpha)\rho_f \right] dz$
 - acceleration multiplier: $r_2 = \rho_f \int_0^L \frac{d}{dz} \left[\frac{x^2}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)\rho_f} \right] dz = \left[\frac{x^2 \rho_f}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)} \right]_{ex} \left[\frac{x^2 \rho_f}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)} \right]_{in}$

Friction Loss in BWR Fuel Assembly

Thus to find friction pressure drop in heated fuel assembly:


Find the location of the onset of two-phase flow. If HEM is used,

it will be at location where x = 0

• Let $z = \lambda = z_{SUB}$ where x = 0

$$-\Delta p_{fric} = -\int_{0}^{L} \left(\frac{dp}{dz}\right)_{fric} dz =$$

$$-\int_{0}^{\lambda} \left(\frac{dp}{dz}\right)_{fric} dz - \int_{\lambda}^{L} \left(\frac{dp}{dz}\right)_{fric} dz$$



Friction Loss in BWR Fuel Assembly

• Thus:
$$-\Delta p_{fric} = \left(\frac{4C_f \lambda}{D_h} + \frac{4C_{f,lo}}{D_h} \int_{\lambda}^{L} \phi_{lo}^2 dz\right) \frac{G^2}{2\rho_f} = \left[\frac{4C_f \lambda}{D_h} + r_3 \frac{4C_{f,lo}(L - \lambda)}{D_h}\right] \frac{G^2}{2\rho_f}$$

where

$$r_3 = \frac{1}{L - \lambda} \int_{\lambda}^{L} \phi_{lo}^2 dz$$

where
$$x_{ex} = x_{in} + \frac{q''P_H}{Wi_{fg}}L$$

Assuming uniform power distributions with q"=const
$$r_{3} = \int_{0}^{1} \frac{1 + x_{ex} \left(\frac{\rho_{f}}{\rho_{g}} - 1\right) \zeta}{\left[1 + x_{ex} \left(\frac{\mu_{f}}{\mu_{g}} - 1\right) \zeta\right]^{0.25}} d\zeta$$
 where
$$x_{ex} = x_{in} + \frac{q'' P_{H}}{W_{i}} L$$

is the exit quality and x_{in} is the inlet quality

Gravity Pressure Drop

The gravity pressure drop multiplier is given as:

$$r_4 = \frac{1}{L\rho_f} \int_0^L \left[\alpha \rho_g + (1 - \alpha) \rho_f \right] dz \qquad \text{where using HEM}$$

the local void fraction is obtained as:

$$\alpha = \frac{1}{1 + \frac{\rho_g}{\rho_f} \cdot \left(\frac{1 - x}{x}\right)} \quad \text{for} \quad 0 < x < 1$$

The integral to calculate r_4 is thus a function of the quality distribution along the channel.

Gravity Pressure Drop in BWR Fuel Assembly

- Thus to find the gravity pressure drop in a heated fuel assembly:
 - Find the location of the onset of two-phase flow. If HEM is used,

it will be at location where x = 0

• Let $z = \lambda$ where x = 0

$$-\Delta p_{grav} = -\int_{0}^{L} \left(\frac{dp}{dz}\right)_{grav} dz =$$

$$\int_{0}^{\lambda} (dp) \int_{0}^{L} (dp) dz$$

$$-\int_{0}^{\lambda} \left(\frac{dp}{dz}\right)_{grav} dz - \int_{\lambda}^{L} \left(\frac{dp}{dz}\right)_{grav} dz$$

Two-phase flow

Single-phase flow

Gravity Pressure Drop in BWR Fuel Assembly

Thus:

$$-\Delta p_{grav} = \int_{0}^{\lambda} \rho_{l} g \sin \varphi dz + \int_{\lambda}^{L} \left[\alpha \rho_{g} + (1 - \alpha) \rho_{f} \right] g \sin \varphi dz =$$
$$\lambda \rho_{l} g \sin \varphi + r_{4} (L - \lambda) \rho_{f} \sin \varphi$$

where:
$$r_4 = \frac{1}{(L-\lambda)\rho_f} \int_{\lambda}^{L} \left[\alpha \rho_g + (1-\alpha)\rho_f \right] dz$$

assuming uniform power distribution:


$$r_4 = 1 - x_{ex} \int_0^1 \frac{\zeta}{\rho_g / (\rho_f - \rho_g) + x_{ex} \zeta} d\zeta$$

where x_{ex} is the exit quality

Gravity Pressure Drop Multiplier

$$r_4 = 1 - x_{ex} \int_0^1 \frac{\zeta}{\rho_g / (\rho_f - \rho_g) + x_{ex}}$$

This graph can be used to find the value of the r_4 multiplier for known exit quality and system pressure in uniformly heated channel and x_{in} =0



The gravity pressure drop is then found as:

$$-\Delta p_{grav} = \lambda \rho_f g \sin \varphi + r_4 (L - \lambda) \rho_f \sin \varphi$$

Acceleration Pressure Drop in Two-Phase Flows

For channel with subcooled water at inlet, the acceleration multiplier can be calculated as:

$$r_2 \equiv \rho_f \int_0^L \frac{d}{dz} \left[\frac{x^2}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)\rho_f} \right] dz = \rho_f \int_0^\lambda \frac{d}{dz} \left[\frac{x^2}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)\rho_f} \right] dz +$$

$$\rho_{f} \int_{\lambda}^{L} \frac{d}{dz} \left[\frac{x^{2}}{\alpha \rho_{g}} + \frac{(1-x)^{2}}{(1-\alpha)\rho_{f}} \right] dz = \left[\frac{x^{2} \rho_{f}}{\alpha \rho_{g}} + \frac{(1-x)^{2}}{(1-\alpha)} \right]_{ex} - \left[\underbrace{\frac{x^{2} \rho_{f}}{\alpha \rho_{g}}}_{0} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} \right]_{ex} = \left[\underbrace{\frac{x^{2} \rho_{f}}{\alpha \rho_{g}}}_{0} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} \right]_{ex} - \underbrace{\frac{x^{2} \rho_{f}}{\alpha \rho_{g}}}_{0} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} \right]_{ex} - \underbrace{\frac{x^{2} \rho_{f}}{\alpha \rho_{g}}}_{0} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} \right]_{ex} - \underbrace{\frac{x^{2} \rho_{f}}{\alpha \rho_{g}}}_{0} + \underbrace{\frac{(1-x)^{2}}{(1-\alpha)}}_{1} + \underbrace{\frac$$

$$\left[\frac{x^2 \rho_f}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)}\right]_{ex} - 1$$

Thus:
$$r_2 = \left[\frac{x^2 \rho_f}{\alpha \rho_g} + \frac{(1-x)^2}{(1-\alpha)} \right]_{ex} - 1$$

Void Fraction Calculation

- Prediction of void fraction is important because it affects the moderator density, thus, it affects power generation in nuclear reactors
- Two models are widely used in saturated region:
 - Homogeneous Equilibrium Model (HEM)
 - Drift-Flux Model (DFM)
- Void fraction in subcooled region
 - Onset of Nucleate Boiling (ONB)
 - Onset of Significant Void (OSV)
 - Actual quality model

Void Fraction - HEM (1)

- In HEM, it is assumed that both phases are in the thermodynamic equilibrium and flow with the same speed
- Void fraction is calculated in two steps:
 - first the value of the equilibrium quality (x_e) is found as $x_e(z) = \frac{i(z) i_f}{i_{fo}}$
 - next the value of void fraction is calculated from the following equation:

$$\alpha(z) = \begin{cases} 0 & \text{for } x_e \le 0\\ \frac{1}{1 + \frac{\rho_g}{\rho_f} \cdot \left(\frac{1 - x_e(z)}{x_e(z)}\right)} & \text{for } 0 < x_e < 1\\ 1 & \text{for } x_e \ge 1 \end{cases}$$

Void Fraction - DFM

- Drift flux model allows for:
 - different velocities for both phases
 - thermodynamic equilibrium/non-equilibrium
- The void fraction is calculated from the following relationship:

$$J_{v} = \frac{G_{v}}{\rho_{v}} = \frac{xG}{\rho_{v}}$$

$$J_{v} = \frac{G_{v}}{\rho_{v}} = \frac{xG}{\rho_{v}}$$

$$J_{l} = \frac{G_{l}}{\rho_{l}} = \frac{(1-x)G}{\rho_{l}}$$


- here C_0 and U_{vj} are the <u>distribution parameter</u> and the <u>drift</u> <u>velocity</u>, respectively. They are flow-regime dependent.
- J_{v} and J are <u>superficial velocities</u> for vapor and for the mixture, respectively

DFM in Thermodynamic Equilibrium

Flow pattern	Distribution parameter	Drift velocity
Bubbly	$\int_{0.5p/p_{cr}} 1-0.5p/p_{cr} \qquad D \ge 0.05m_{1}$	$U_{vj} = 1.41 \left(\frac{\sigma g(\rho_l - \rho_v)}{\rho_v^2} \right)^{0.25}$
$0 < \alpha \le 0.25$	$C_0 = \begin{cases} 1.2 & p/p_{cr} < 0.5 \\ 1.4 - 0.4p/p_{cr} & p/p_{cr} \ge 0.5 \end{cases} D < 0.05m$	ρ_l^2
Slug/churn	$C_0 = 1.15$	$U_{vj} = 0.35 \left(\frac{gD(\rho_l - \rho_v)}{\rho_l} \right)^{0.5}$
$0.25 < \alpha \le 0.75$		ρ_l
Annular	$C_0 = 1.05$	$U_{vj} = 23 \left(\frac{\mu_l j_l}{\rho_v D_b} \right)^{0.5} \frac{(\rho_l - \rho_v)}{\rho_l}$
$0.75 < \alpha \le 0.95$		(PvD_h) P_l
Mist	$C_0 = 1.0$	$U_{vj} = 1.53 \left(\frac{\sigma g(\rho_l - \rho_v)}{\rho_v^2} \right)^{0.25}$
$0.95 < \alpha < 1$		` ''

 p_{σ} – critical pressure σ - surface tension $D=D_h$ – hydraulic diameter

Void Fraction in Subcooled Region



Void Fraction – Subcooled Boiling (1)

- It can be assumed that void fraction is negligible up to the Onset of Significant Void (OSV) point.
- This point occurs at the location, where equilibrium quality becomes (Saha-Zuber model):

$$x_{e,OSV} = \begin{cases} -0.0022 \frac{q'' \cdot D_h \cdot c_{pf}}{i_{fg} \cdot \lambda_f} & \text{for} \\ -154 \frac{q''}{G \cdot i_{fg}} & \text{for} \end{cases}$$
 Pe < 70000

– here Pe is the Peclet number, defined as:

$$Pe = Re \cdot Pr = \frac{G \cdot D_h \cdot c_{pf}}{\lambda_f}$$

q" – heat flux, W/m²
D_h – hydraulic diameter, m

 c_{pf} – fluid spec. heat, J/kgK

 λ_f – thermal conduct. W/mK

Void Fraction – Subcooled Boiling (2)

The actual quality is approximated as (Levy's model):

$$x_a(z) = x_e(z) - x_e(z_{OSV}) \cdot e^{\frac{x_e(z)}{x_e(z_{OSV})} - 1}$$

The void fraction is then found as:

$$\alpha = \frac{J_{v}}{C_0 J + U_{vj}}$$

$$J_v = \frac{x_a G}{\rho_g}$$
 superficial velocity of vapour

- where
$$C_0 = \beta \left[1 + \left(\frac{1}{\beta} \right)^b \right]$$

$$J_{l} = \frac{(1-x_{a})G}{\rho_{f}}$$
 Superficial velocity of liquid

$$\beta = \frac{1}{1 + \frac{\rho_g}{\rho_f} \frac{1 - x_a(z)}{x_a(z)}}$$

$$b = \left(\frac{\rho_g}{\rho_f}\right)^{0.1}$$

$$\beta = \frac{1}{1 + \frac{\rho_g}{\rho_f} \frac{1 - x_a(z)}{x_a(z)}} \qquad b = \left(\frac{\rho_g}{\rho_f}\right)^{0.1} \qquad U_{vj} = 2.9 \left(\frac{\sigma g \left(\rho_f - \rho_g\right)}{\rho_f^2}\right)^{0.25} \quad \text{o - surface tension, N/m}$$