## PRODUCT SPECIFICATION

MODEL NAME: THD-AIR1

### **VERSION HISTORY**

Ver	Changes Description	Date	Prepared By	Checked By	Approved By
A/0	Draft	Otc 14,2013			
	<u>. =                                   </u>		_		
		á			

#### **INDEX**

1,	Cover
2,	Index2
3,	ID Drawing
4、	Button Introduction
5、	Wireles Range
6,	RC Pairing8
7、	Air-mouse9
8,	Full Key Board9
9、	Button Code10
0	FCC Statement11

3. ID Drawing







#### 4. Remote Control Button introduction: Total 44 buttons

Item	Buttons	Туре	Function Description	
01	Power	IR	Power on/off the target device	
02	Mute	IR	Switch remote to send Mute command to the target	
03	Play/Pause	IR	Play / pause program	
04	Stop	IR	Stop program	
05	Fast Forward	IR	Fast go to next program	
06	Fast Backward	IR	Fast go to last program	
07	PLEX	IR	customize	
08	You Tube	IR	customize	
09	NETFLIX	IR	customize	
10	Skype	IR	customize	
11	Mouse on/off	RF	turn on/off the mouse function	
12	Mouse Left	RF	Mouse's left button function	
13	Mouse Right	RF	Mouse's right button function	
14	OK	IR	Confirms the current selection/mouse left	
15	Up	IR	Move to up	
16	Down	IR	Move to down	
17	Left	IR	Move to left	
18	Right	IR	Move to right	
19	Vol +	IR	Increases the volume of the device	
20	Vol -	IR	Decreases the volume of the device	
21	PG+	IR	Last page	
22	PG-	IR	next program	

23	BACK	IR	Back to last menu	
24	MENU	IR	Go to homepage	
25	Number 1	IR	Input number 1	
26	Number 2	IR	Input number 2	
27	Number 3	IR	Input number 3	
28	Number 4	IR	Input number 4	
29	Number 5	IR	Input number 5	
30	Number 6	IR	Input number 6	
31	Number 7	IR	Input number 7	
32	Number 8	IR	Input number 8	
33	Number 9	IR	Input number 9	
34	Number 0	IR	Input number 0	
35	SETUP	IR	Go to setup page	
36	EPG	IR	customize	
37	DISP	IR	customize	
38	EXIT	IR	Exit current page/menu	
39	RES	IR	customize	
40	DEL	IR	customize	
41	Red	IR	Programmable button - links to a page or function in the	
42	Green	IR	Programmable button - links to a page or function in the	
43	Yellow	IR	Programmable button - links to a page or function in the	
44	Blue	IR	Programmable button - links to a page or function in the	

#### 5. RF and IR Range

The remote control can support a transmission range of 16 meters in direct line-of-sight, 10 meters when not line-of-sight by RF.

RF Range		IR Range		
Direct line- of-sight	16m	Direct line- of-sight	10m	
Not line-of- sight	10m	Angles IR distance	8m with the angle 15degree  TV  15° Remote unit  ≥8M  TV  15° Remote	

#### 6. RC Pairing

Before operating the remote control, user have to pair the target device with the remote control, the remote should be paired with the target (Usb dongle) as steps below.

Pairing Process:

- First be sure that the device is power on, then press and hold "1" button and "9" button at the same time.
- LED of the remote control will turn on to indicate that it is now in pairing mode.
- Remote control will search the target device (USB Dongle) automatically.
- Remote control sends pairing request to the device (USB Dongle).
- LED of remote control will blink three times slowly (blink one time each second) if pairing procedure finish successfully.

#### 7. Air-mouse Mode

#### 7.1 \ Air-mouse Introduction

Two gyros produce the initial delta x and delta y data. This can be accomplished because the gyros measure the amount of angular velocity in their corresponding axis.

The pointer follows the user's motions (no matter what the motion are, circular, horizontal, vertical, fast, slow, etc.). The pointer works smoothly and doesn't produce any unwanted movements or delays. The pointer can go precisely where the user wants it to.

#### 7.2 Air-mouse Usage

10.2.1 User can press the mouse on/off button to switch between the air mouse mode and the non-air mouse mode.

10.2.2 Air-mouse only can work on the mode of Remote control.

10.2.3 When Air-mouse is turn on and no any action to Remote Control within 30 seconds, the Air mouse will enter the sleeping mode, after that, if you use Remote control again, Air-mouse will wakeup automatically.

#### 8. Full Key Board

Full keyboard mode will turn on automatically when user make remote control full keyboard face up; Full keyboard mode will turn off automatically when user make remote control full keyboard face down.

#### 9, Button Code

9.1 Remote control Button Code



Page 9 of 11

#### 9.2 Full-key board Button Code



#### Remark:

- A. Button"mouse on/off"no button code.
- B. Button ".com" Code: 37 06 12 10
- C. Button "www" Code: 1a 1a 1a

#### Basic button code

29	1d	04	14
39	1b	16	1a
ALT	06	07	08
2c	19	09	15
2c	05	0a	17
2c	11	0b	1c
36	10	0d	18
50	37	0e	0 c
51	52	0f	12
4 <b>f</b>	28	2a	13

#### Up button code

29	022e	0238	1e
39	2d	021e	1f
ALT	2е	0220	20
2 c	38	0221	21
2 c	022d	0222	22
2 c	0234	0224	23
33	34	0225	24
www	0233	0226	25
021f	52	0227	26
.com	28	002a	27

#### 10. FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.