# HIDE AND SEEK TOY

# **OPERATING INSTRUCTIONS**



#### Contents:

- 1 Plush Head
- 1 Plush Bone

### TO OPERATE AND REPLACE BATTERY:

- 1. Carefully remove the product from the packaging.
- 2. Open the plastic fastener and remove the battery case cover (located at the back of unit) by using Phillips-head screwdriver (not included).
- 3. Install 2 "AAA" batteries (not included) following the polarity markings in the battery case.
- 4. Replace and secure the battery cover.
- 5. Slide the ON/OFF switch (located on the side of battery case) to ON position .
- 6. Repeat above step to install both plush head and plush bone and switch ON before operating.
- 7. You will hear frequency continuous "BEE" sound from the plush head which is ready for playing.
- 8. Hide the plush bone on desired position.
- 9. Use the plush head to locate the hided plush bone.
- 10. The plush head distance with the plush bone which "BEE" sound will be become fast and faster to represent the more close between on the right position.
- 11. The "BEE" sound repeat frequency time should be 2's, 1's, 0.5's, 0.25's and 0.125's represent the distance between the hided unit. The faster the "BEE" sound, the plush head will be close to the plush bone.
- 12. To extend the battery life, always switch the unit "OFF" when not in use.

TO CLEAN: Wipe surface with a damp cloth.

## TECHNICAL SPECIFICATION:

- Frequency 2.4GHz and field strength is 94dBµV/m at 3 m.
- Reflective detection range approx. 65 Feet (20 Meter) in open area.

## NOTICE:

- If out of detection range or either one side is power OFF. Product will be auto power OFF on both units after approx. 30 minutes.
- If auto power OFF of product. Press both weak up button from the plush dog head's nose and plush bone's blue icon to functions again.
- To prevent lost either unit. Always place both plush dog head and plush bone at same location when not to playing.
- Complex environment (e.g. at estate or commercial area which consists a lot of WIFI device) will affect the performance.
- Real situation may be varies from different environment and the user practice (e.g. the pick up angle, the bone cover material...etc.)

### WARNING:

The bone should not cover by metal or organic material (e.g. human body), otherwise the performance will be degraded.

<u>PLEASE NOTE</u>: For best results, always use alkaline batteries. Be sure to check the expiration date because fresh batteries will ensure uninterrupted usage/enjoyment of the product. Remove the batteries if the product will not be used for an extended period. If the product does not perform as expected, check for proper battery charge and correct battery installation, or try a fresh set of batteries.

CAUTION: BATTERIES SHOULD BE REMOVED AND REPLACED BY ADULTS ONLY. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge standard or alkaline batteries. Be sure to insert batteries with the correct polarities and always follow the product and battery manufacturer's instructions. Remove batteries and store them in a cool, dry place when not in use. Always remove old and dead batteries from the product. The supply terminals are not to be short-circuited.

## CAUTION:

- For Indoor Use Only.
- Please save these instructions for future use.
- Do not mount or place the product near gas or electric heaters, fireplaces, candles or any flammable sources.
- Never place product in or near wet locations.

WARNING: Do not use rechargeable batteries.

WARNING: Small children should not be left unsupervised

## **FCC Warning**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

# **IC Warning**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, meme si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.