Instruction manual

Welcome to choose my company product "iBUD"BLUETOOTH SPEAKER. The product is a portable audio with Bluetooth receiver. You can store the songs in mobile phone or device with Bluetooth playback, and then transmit to this product for music playback via Bluetooth.


Read the instruction manual quickly before use.

A. Main features and Technical Parameters

- 1. Bluetooth audio player
- Handfree function
- 3. Φ 3.5mm audio input interface
- 4. Touch sensor keys5. Audio Max power: 5W*1

- 7. Power supplied: built-in rechargeable lithium battery
 8. Connect external USB 5VDC power source to charge the unit
- 9. Charging time: around 3-4 hours
 10. Continue play music about 4-5 hours when built-in lithium battery is fully charged.
- 11.LED Bluetooth indicator & power charge indicator

B. Product Illustration



C. Key functions

No	Current mode	Function operating	Button	Operation	Indicator
1	Power off	Power on	ON/OFF	Switch the key "ON/OFF" to "ON"	blue lights flashing rapidly
2	Power on	Power off	ON/OFF	Switch the key "ON/OFF" to "OFF"	blue light are off
3	Power on	Bluetooth pairing		Automatically paired	blue lights flashing rapidly
4	Power on	Bluetooth pair successfully		Automatically paired	blue lights flashing slowly
5	Power on	Bluetooth disconnect	Hands free	Long touch for 3 seconds	blue lights flashing rapidly
6	Power on	Call back	Hands free	Double click twice	
7	Call mode	Answer calls	Hands free	Short touch once	
8	Talk mode	End calls	Hands free	Short touch once	
9	Any mode	Volume up	Volume + key	Short touch or long touch	
10	Any mode	Volume down	Volume - key	Short touch or long touch	
11	Bluetooth mode	Previous song	Previous song key	Short touch on key	
12	Bluetooth mode	Next song	Next song key	Short touch on key	
13	Bluetooth mode	pause/play	Hands free	Short press circle	
14	AUX mode	Mute, ON/OFF	Hands free	Short press circle	
15	Any mode	Charging			Red LED is ON
16	Any mode	Battery is full			Red light is Off Green light is on
17	Bluetooth mode	Low battery alarm			Blue light flash continuously
18	Bluetooth mode	Audio input		Audio cable is plug on audio input	Blue light is ON
19	Audio mode	Bluetooth mode		Unplug audio cable	blue light is flashing slowly

D. Bluetooth playback

- Switch the power to "ON", Bluetooth indicator is on, producing a start-up sound, Bluetooth indicator is flashing rapidly.
 Turn on your cell phone or Bluetooth device on the Bluetooth function, search for devices in the Bluetooth menu.
 When "Hiting" appears on the Bluetooth devices list, select "Hiting" establish pairing and connection (if asked for a passkey, orter (2002). When the priving and connection is guestiful. enter 0000). When the pairing and connection is successful, it produces a connected tone, and Bluetooth indicator changes to slow flash, the speaker is ready for playing music.
- 4. When the connection is successful pairing, touch the key

- "Play/Pause"three seconds, you can disconnect the current Bluetooth devices, and the indicator is flashing alternately again, the Bluetooth speaker is ready for pairing with the other
- 5. When the connection between the mobile and the speaker is 5. When the connection between the mobile and the speaker is successful, and the speaker is playing music, the music will be stopped when incoming call is reaching and the speaker will play incoming call alert, short touch 'Play/Pause' switch to answer the call, others' speech will be broadcast via the speaker, Short touch 'volume +/- ' switch to adjust desire volume for conversation. Short touch 'Play/Pause' switch to hang up the phone. The speaker is automatically restored before playback music

To reject the incoming call, long touch 'Play/Pause' switch for 2 seconds to reject the incoming call.

To redial the previous call number, short touch 'Play/Pause' switch 2 times for redial the last call.

6. If the pairing is overtime or no flash for indicator light, please repeat step 1 to 3 for re-connection.

- 1. Please insert 3.5mm audio cable into the audio input port of the product, with MP3, IPOD, cell phone or other audio connections, audio music playback, adjust the audio output volume to achieve the best sound, and the blue indicator is on
- (instead of flashing).

 2. Pls pull out the audio cable to disconnect the devices,the speaker will switch back to the Bluetooth mood, the indicator is flashing again, and the product will automatically pair back with the last device.

F. Power supply

- 1. Connect DC 5V adapter with the product for power supply and charging the built-in rechargeable lithium battery synchronously, the red power indicator is on. After the full charge, the red indicator is off, and the blue indicator is on. Disconnect the adapter, all the power charging indicators are
- off.

 2. The speaker is powered by the built-in rechargeable battery,

G. Troublesh

G. 1 roubleshooting					
Failure Manifest	Solutions				
Bluetooth playback interrupt and produce a sound	Lower battery, please charge				
Music intermittent in Bluetooth playback	Try to move the bluetooth device close to the product or charge the audio or equipment location				
Bluetootii playback	Repair				
	Lower battry , please charge				
	Try to move the Bluetooth device closer to the speaker				
	Turn off & restart				
	Device of the computer has Bluetooth function or not				
Equimpment cannot pair	Try repeating this product Bluetooth playback and set				
with Bluetooth audio	up steps				
connection	You can play the music in one device, cancel				
	equipmentand unused pairs (see the documents for help), in accordance with the procedure set pairing				
	new devices				
	Bluetooth name is not correct, confirm whether "Hiting".				
No call function	Repair				
No can function	Check the setting of the phone(see the phone manual)				
	Lower battery, please charge				
Key failure	Turn off & restart				
	Please use the original adapter for this item.				
Weak sound	Touch "Volume+" key to the suitable level				

H. Packing Accessories

1. One audio cable

2. An adapter (optional) 4. USB cable

3. Instruction manual

- The product avoids rain and damp, in order to avoid damage.
 The product should be kept away from fire, high temperature environment to avoid the product does not work normally and
- 3. When the product is playing music via Bluetooth technology, the music may caused intermittent or noise because of the environment or the source device (such as mobile phones)
- environment or the source device (such as mobile phones) interference or software incompatibilities etc... Please adjust the distance between the music device and the unit, or restart the unit's power supply or restart the music device or change to other music source to have better sound performance.

 4. When the product is during a call via Bluetooth technology, the conversation may be intermittent or noise, or phone off because of the environment or the network signal interference or poor etc... Please adjust the distance between the phone and the unit, or change to other calling device, or restart the unit's power supply etc..to improve the calling quality.

 5. Do not touch the speaker or the speaker collision with other objects to avoid damaging the speakers.

- 5. Do not total the speaker of the speaker consists with other objects to avoid damaging the speakers.
 6. The power supply output 5V and current 1A or more.
 7. If stop use, turn off the power to avoid power loss.
 8. The product built-in rechargeable lithium battery, please do not pollute the environment when discarded, try to classify recycling. recycling.
- 9. The product should be used for the first time after the battery is fully charged.

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.