LEEDARSON We Build Your Success in 10T




Music Downlight Quick Start Guide Specification

Specification


| Item | Spec. |
|-------------------|-------------------|
| Model | DL-N35A13FR1 |
| Function | ON/OFF/Play Music |
| Power (W) | 7.5W(LED)+3W(spk) |
| Voltage (V) | 120 |
| PF | >0.9 |
| Lumen (lm) | 650 |
| CCT (K) | 2700 |
| CRI | 90 |
| Beam Angle | 100° |
| Dimensions (mm) | Ф126 |
| Lifetime (H) | 35,000 |
| Bluetooth Version | 2.1+EDR |
| Range (m) | 10 |

Instruction


1. Install the downlight, and turn the switch on. Downlight wil**l** light up and emit Bluetooth signal about 10m.



- 2. Open the Bluetooth in your mobile device, searching for music lamp.
- 3. Pair the downlight with your mobile device, and light will notice you by sound after connect successfully.



- 4. Play the music on your phone, the sound will embrace your home by our lamp.
- 5. Music downlight can't work without power, if switch off the light, the signal will be cut off also.



FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.