# TS-200BC Halo Wireless Speaker & Lighting USER MANUAL (Read before proceeding)

#### **Power Supply**

1. Insert the USB cable to the micro socket of the unit. Connect to a 5V power switch for power supply.

(Both USB cable and power switch are included.)

#### Switch on/off & Connect/disconnect

- 1. To turn on/off the unit, switch the power button to "ON" or "OFF" position.
- 2. Long press the "Bluetooth" button to switch on Bluetooth function, the blue and red LED lights are flashing alternately.
- 3. The unit will automatically try to reconnect to the last Bluetooth device first. If not found, it will be seen by other Bluetooth devices.
- 4. On the Bluetooth device, switch on Bluetooth and search for "TS-200BC". For the first-time connection, select "TS-200BC" to start connection. If necessary, enter the pass code 0000 or 1234. Once connected successfully, the blue light is always on.
- 5. To disconnect "TS-200BC" from current Bluetooth device, switch off Bluetooth from current Bluetooth device. Or press and hold "Bluetooth" button for 2 seconds to disconnect and search for another Bluetooth device.
- 6. After Bluetooth connected, long press "Bluetooth" button to switch off Bluetooth function.
- 7. If "TS-200BC" is not in used for a long time, it will turn off automatically.

## Play music

- 1. After successful connection, start music play on the Bluetooth device. You can listen to music from "TS-200BC" wirelessly (< 33 ft.). The music streaming may be interrupted by obstacles between the device and the unit, such as walls, metallic casing that covers the device, or other devices nearby that operate in the same frequency.
- 2. Long press "+" or "-" to switch forwards or backwards to skip songs.
- 3. Short press "+" or "-" to control the volume.

## **LED lighting**

- 1. When the unit is power on, touch the "Lighting Power" button on the top middle part to select different light modes as following order: White light mode Selecting color normal mode Selecting color dancing mode Selecting color breathing mode Gradually changing color mode Switch off light.
- 2. On the White light mode and Selecting color normal mode, touch and hold the Circular Dotted Area on the top middle part to dimmer the light.
- 3. On select color mode, the lighting color can be selected by touch the top colorful circle.

## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.