I.I Keys and connectors

This product meets applicable national SAR limits of I.6 W/kg. The specific maximum SAR values can be found on page 23 of this

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 15 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

PROTECT YOUR HEARING

5.1 Consulting your contacts

You can access this function using the following options:

Select from the widget bar, and then enter the sub-menu

When you press "Options", you can have access to View. Send

message, Save to Contacts, Edit before call, Add to blacklist,

Press the send key from the Home screen.

5.2 Adding a contact

Select from the main menu.

6.2 Available options

Add to whitelist, Delete, etc.

"Add contact"

6.1 Access

You can access this function by selecting "Contacts" from the main


You can add a new contact to your phone or SIM card by selecting

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

Ouick Start Guide



ALCATEL onetouch.



connector

Facebook is a social media application that connects people with friends

and others who work, study and live around them. It provides a number

Twitter

Twitter is a social networking and microblogging service that has gained

notability and popularity worldwide. This feature enables phone users

to exchange news updates and ideas with a community in the form of

messages or posts. Posts are displayed on the author's profile page and

Apps store is an online software store where you can download and

delivered to the author's subscribers or followers.

install applications and games to your phone.

To open an account online, please go to: http://m.twitter.com.

of features with which users interact, such as Wall, Pokes, etc.

To open an account online, please go to: http://m.facebook.com/.

Your mobile

Press to go left/right/up/down Press to confirm an option

Left softkey

 Unlock keypad Access main menu

 Answer/Send a call Press: Enter Call log

Right softkey

Access contacts

From home screen

In Edit mode:

Press and hold: Change input methods

• Press: #

· Press: Change input methods

Your mobile phone is fitted with a camera for taking photos and recording videos that you can use in different ways:

send them directly by MMS, Bluetooth. customize your Home screen.

transfer them by data cable or microSD card to your computer.

You can access this feature from the main menu by selecting "Music You will have full flexibility of managing music both on your mobile and

A library links to the images (stored in "Photos") in phone or SD card to multi-mark, set as wallpaper, power on/off display and incoming cal image or sent by MMS, Bluetooth.

1.2 Status bar icons (1)

Battery charge level

Headset connected

Keypad locked

Bluetooth status (Activated

Vibrate alert: your phone vibrates, but does not ring

Bluetooth status (Connected to an audio device)

Call forwarding activated: your calls are forwarded

Alarm or appointments programmed

Level of network reception

Voicemail message received

or beep with the exception of the alarm

In 2045M:

Contains all video clips (stored in "Videos") on your phone or SD card Enables you to download games to your phone. and enables you to play, send, delete, rename, etc.

Recorder

Allows to make voice or sound recordings

You will have an access to all audio and visual files stored on phone or SD card in My files. You can access a number of items with this option: Answer machine, Audio, MRE, My Music, Photos, etc.

GPRS connection status (Activated)

Silence mode: your phone does not ring been or

(Flickering) Message list is full: your phone cannot

accept any new messages. You must access the message

list and delete at least one message on your SIM card.

vibrate with the exception of the alarm

GPRS connecting

Music activated

Sending an MMS

Incoming MMS message

Unread SMS message

Unread MMS message

Your mobile phone has a built-in alarm clock with a snooze feature.

Calculator.....

Enter a number, select the type of operation to be performed using the navigation keys, and enter the second number, then select "=" to display

Once you enter this menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

1.3 Home screen

I.3.1 Widget bar

Widgets are convenient shortcuts for quick access from the Hom-


You can customize the widget bar by going to "Settings/Phone settings/Widget bar".

1.3.2 Change wallpaper

You can select an image to set as the wallpaper by selecting "Options/ Use as/Wallpaper".

Getting started.....

2. | Set-up



Charging the battery

Connect the charger to your phone and wall outlet respectively.

To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Bluetooth or background-running applications when not in use; reduce the backlight time, etc.

2.2 Power on your phone Hold down the <u>\$\rightarrow\$\$</u> key until the telephone powers on.

2.3 Power off your phone Hold down the _____ key from the Home screen.

Making a call

Dial the desired number then press the send key to place the call. The number you entered can be saved to Contacts by selecting "Ontions Save to contacts". If you make a mistake, press the Right softkey to delete the incorrect numbers.

To hang up the call, press the _____ key.

Access from the main menu by selecting "Messages".

Select [7] from the widget bar, and then enter the sub-menu you prefer.

You can select "Messages\Create SMS" from the main menu or access from the widget to write text/multimedia message. One or more recipients can be added from the contact list. Press "Contacts" through key to multi-select recipients from Contacts. An SMS will be converted to MMS automatically when images, videos, audio, slides, or attachments are inserted; or if the message contains more than 8 pages of text.



An SMS message of more than a certain number of characters (the number of characters depends on your language) will be charged as several SMS messages. An MMS message containing photos and/or sounds may also be billed as more than one message. Specific letters (accent) will increase the size of the SMS messages, this may cause multiple SMS messages to be sent to your recipient.

With this menu, you can personalize ringtones for different events and times until the desired letter is highlighted. When you release the key the highlighted character is inserted into the text.

> and is used under license by TCL Communication Ltd.

TCL Communication Ltd.

TCL Communication Ltd. reserves the right to alter material or technical specification

without prior notice.

that particular area.

Depending on your service provider and marke

(i) The quality of the radio depends on the coverage of the radio station in (ii) You need to download the application to your phone for the first time

May cause additional network charges for data flow to download this

English - CIB184T02AAA

(i) Depending on your service provider

Manage your downloaded applications and games.

Apps mgr.....

Press: End a call

Return to the Home screen

Press and hold: Power on/off

Press and hold: Access your voicemail

Press: 0 Press and hold: "+/P/W"

In Edit mode Press: space

Press and hold: 0

From Idle screen Press: *

Press: Access symbols table

From Idle screen

Press and hold: Activate/deactivate Meeting mode In Edit mode

store them as your creations in SD card or phone send them in a multimedia message (MMS) to a mobile phone

select them as incoming call image to a contact in your Contacts.

(i) The icons and illustrations in this guide are provided for informational

Your phone is equipped with a radio (1) with RDS (2) functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display, if you tune to stations that offer Visual Radio service. You can listen to it while running other applications.

Access this feature by selecting "Calculator" from the main menu

You can create a note in text format by accessing "Notes" from the Bluetooth™ *

You can transfer data, such as music, to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

This function enables you to do conversion of weights and lengths.

Converter

With this menu, you can create a voice file and set it as the alarm.

politely escape from social situations at any. This call can be rejected by pressing ______. Activate a fake call by "Fake call mode\Enable".

Enable blacklist: all callers on the list will be automatically blocked. Enable whitelist: only callers on the list can be connected. Flashlight.....

Access Wap options: Homepage, Bookmarks, Search or input

URL, Last wap address, Recent pages, Stored pages, Settings.

This program enables you to call yourself by simulating a caller This Web browser allows you to visit Websites when you are Contact your service provider to check service availability number/name and ringtone at a scheduled time. It helps you to connected to the internet.

Settings

rom the main menu, select the menu icon 🔯 and select the function

of your choice in order to customize your telephone: Phone

settings, Call settings, Network, Connectivity, Security,

Regulatory & Safety, Rights manager, Restore default (1), etc.

This mode allows you to type a message by choosing a letter or sequence of characters associated with a key. Press the key several

ALCATEL is a trademark of Alcatel-Lucent

All rights reserved © Copyright 2015

(I) Reset the phone settings to its default value. End-user data will not be erased. Enter its default password 0000 to confirm to restore and reboot

4.1 Access

You can access this menu using the following options:

4.2 Write message







Safety and use

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein.

TRAFFIC SAFFTY:

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked

When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas. When switched on, your phone emits electromagnetic waves that

can interfere with the vehicle's electronic systems such as ABS antilock brakes or airbags. To ensure that there is no problem: - do not place your phone on top of the dashboard or within an

- airbag deployment area, - check with your car dealer or the car manufacturer to make sure
- that the dashboard is adequately shielded from mobile phone RF energy.

· CONDITIONS OF USE:

You are advised to switch off the telephone from time to time to ontimise its performance

Switch the phone off before boarding an aircraft. Switch the phone off when you are in health care facilities, except

in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive When the phone is switched on, it should be kept at least 15 cm

from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any,

your ear. Also move the handset away from your ear while using the "handsee" mode because the amplified volume might cause hearing damage. Do not let children use the phone and/or play with the telephone and ccessories without supervision

Please note that your phone is a unibody device, the back cover and hattery are not removable. Do not attempt to disassemble your phone. If you disassemble your phone the warranty will not apply. Also disassembling the phone may damage the battery, and may cause leakage of substances that could create an allergic reaction. Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating mperature range is -10°C to +45°C

At over 45°C the legibility of the phone's display may be impaired, though this is temporary and not serious. Emergency call numbers may not be reachable on all cellular networks.

You should never rely only on your phone for emergency calls Oo not open, dismantle or attempt to repair your mobile phone yourself.

Do not use the phone if the glass made screen, is damaged, cracked or broken to avoid any injury.

Do not drop, throw or bend your mobile phone

Do not paint it Use only batteries, battery chargers, and accessories which are

recommended by TCL Communication Ltd. and its affiliates and are ompatible with your phone model. TCL Communication Ltd. and its affiliates disclaim any liability for damage caused by the use of other chargers or hatteries

Remember to make back-up copies or keep a written record of all important information stored in your phone

me people may suffer epileptic seizures or blackouts when exposed o flashing lights, or when playing video games. These seizures or plackouts may occur even if a person never had a previous seizure or plackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature

To avoid hearing impairment, pick up the call before holding your phone to Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All

of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety - Do not play or use a flashing-lights feature if you are tired or need sleep.

Play in a room in which all lights are on

playing, stop the game and see a doctor.

and rest for several hours before playing again.

tunnel syndrome or other musculoskeletal disorders

PROTECT YOUR HEARING

Take a minimum of a 15-minute break hourly

- If your hands, wrists, or arms become tired or sore while playing, stop

- If you continue to have sore hands, wrists, or arms during or after

When you play games on your phone, you may experience occasional

discomfort in your hands, arms, shoulders, neck, or other parts of your

body. Follow the instructions to avoid problems such as tendinitis, carpal

To prevent possible hearing damage, do not listen at high

volume levels for long periods. Exercise caution when holding

your device near your ear while the loudspeaker is in use.

Please note that you must respect the laws and regulations in force

n your jurisdiction or other jurisdiction(s) where you will use your

mobile phone regarding taking photographs and recording sounds

with your mobile telephone. Pursuant to such laws and regulations.

it may be strictly forbidden to take photographs and/or to record

the voices of other people or any of their personal attributes, and

duplicate or distribute them, as this may be considered to be an

nvasion of privacy. It is the user's sole responsibility to ensure that

rior authorisation be obtained, if necessary, in order to record private

or confidential conversations or take a photograph of another person:

the manufacturer, the seller or vendor of your mobile phone (including

Please note your phone is a unibody device, the back cover and battery

are not removable. Observe the following precautions:

the operator) disclaim any liability which may result from the improper

persons should discontinue use and consult a doctor if any of the

following symptoms occur: convulsion, eye or muscle twitching, loss

Play at the farthest distance possible from the screen.

This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life: Proof of compliance with international standards (ICNIRP) or with - Municipal waste disposal centres with specific bins for Furopean Directive 1999/5/EC (R&TTE) is required of all mobile phone

these items of equipment

- Do not attempt to open the back cover.

it at temperature above 60°C.

- Do not attempt to eject, replace and open batters

- Do not punctuate the back cover of your phone.

with locally applicable environmental regulations.

Collection bins at points of sale. health and safety for the user and any other person is an essential

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused. In European Union countries:

Do not burn or dispose of your phone in household rubbish or store

Phone and battery as a unibody device must be disposed of in accordance

These collection points are accessible free of charge

All products with this sign must be brought to these collection points. In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if your jurisdiction or your region has suitable recycling and collection facilities: instead they are to be taken to collection points for them to be recycled

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED as the Specific Absorption Rate, or SAR. The SAR limit for mobile BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

CHARGERS

hey should be used for this purpose only

equirement of these standards or this directive

afety of all persons, regardless of age and health.

GSM 850

The chargers designed for your mobile phone meet with the standard

or safety of information technology equipment and office equipment

use. They are also compliant to the ecodesign directive 2009/125/

FC Due to different applicable electrical specifications, a charger you

urchased in one jurisdiction may not work in another jurisdiction.

models before they can be put on the market. The protection of the

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR

Your mobile device is a radio transmitter and receiver. It is designed

not to exceed the limits for exposure to radio waves (radio frequency

guidelines were developed by an independent scientific organization

(ICNIRP) and include a substantial safety margin designed to assure the

The radio wave exposure guidelines use a unit of measurement known

Tests for SAR are conducted using standard operating positions with

the device transmitting at its highest certified power level in all tested

frequency bands. The highest SAR values under the ICNIRP guidelines

Maximum SAR for this model and conditions under which it

0.50 W/kg

0.89 W/kg

electromagnetic fields) recommended by international guidelines. The

of: 0°C to 40°C.

RADIO WAVES:

devices is 1 6 W/kg

Head SAR

2045Y

22

for this device model are:

Body-worn SAR PCS 1900

EXPOSURE TO RADIO WAVES

Mains powered chargers will operate within the temperature range below the values stated above. This is because for purposes of system

efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value. Rody-worn SAR testing has been carried out at a separation distance

of 15 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away

If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from the body izations such as the World Health Organization and the US Food

and Drug Administration have statesd that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of time spent on the phone For more information you can go to www alcatelonetouch com-

Additional information about electromagnetic fields and public health are available on the following site: http://www.who.int/peh-emf. Your telephone is equipped with a built-in antenna. For optimal operation, you should avoid touching it or degrading it.

As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or usb data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 15 mm away from the body

During use, the actual SAR values for this device are usually well • LICENCES



microSD Logo is a trademark.



The Bluetooth word mark and logos are owned by the Bluetooth SIG. Inc. and any use of such marks by TCI Communication Ltd. and its affiliates is under license. Other trademarks and trade names are those of their respective owners.

ALCATEL ONETOUCH 2045X Bluetooth Declaration ID D024874



acebook and the f Logo are trademarks of Facebook, Inc., and are used under license.

Twitter and the T Logo are trademarks of Twitter, Inc., and are used under license.

General information

- Internet address: www.alcatelonetouch.com
- Hot Line Number: see "TCL Communication Services" leaflet or go to our website Address: Room 1910-12A, Tower 3, China HK City, 33 Canton Road. materials in this handset are provided "as is" without warranty of any
- Tsimshatsui. Kowloon, Hong Kong

On our website, you will find our FAQ (Frequently Asked Questions section. You can also contact us by e-mail to ask any questions you

An electronic version of this user guide is available in English and other languages according to availability on our server

www.alcatelonetouch.com Your telephone is a transceiver that operates on GSM 850/900/ 1800/1900 MHz and UMTS 850/2100MHz. FCC ID: 2ACC|B038

This equipment is in compliance with the essential requirements and

other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatelonetouch.com Protection against theft (1)

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the phone's memory. We recommend th you note the number the first time you use your telephone by enter * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it even with a different SIM card Disclaimer

There may be certain differences between the user manual description

and the phone's operation, depending on the software release of your telephone or specific operator services

and Third Party Materials.

Warranty.....

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original invoice.

Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your original invoice.

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase If the defect is confirmed, your phone or part thereof will be either

replaced or repaired, as appropriate. Repaired phone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality This warranty covers the cost of parts and labor but excludes any

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation)

technical and safety standards applicable in the geographical area where your phone is used. 2) Connection to any equipment not supplied or not recommended by

Modification or repair performed by individuals not authorised by

) Modification, adjustment or alteration of software or hardware performed by individuals not authorized by TCL Communication

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered

There are no express warranties, whether written, oral or implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

Before contacting the service centre, you are advised to follow the

You are advised to fully charge () the battery for optimal

Avoid storing large amounts of data in your phone as this may affect

phone formatting or software upgrading, (to reset User Data format, data and profile via PC suite before doing formatting and upgrading.

before you want to format

My phone is frozen or cannot switch on Check the battery power level, charge for at least 20 minutes

- If it still does not work, please use User Data Format (1) to reset the
- phone or Mobile Upgrade to upgrade software

My phone has not responded for several minutes

Restart your phone by pressing and holding the — key If it still does not work, please use User Data Format (1) to reset the phone or Mobile Upgrade to upgrade software

User Data Format ALL user phone data: Contacts, messages

and files will be lost permanently. Please store phone data in SIM card

My phone turns off by itself Check whether your phone is locked when not in use and make sure

- you don't accidentally turn off your phone when locking it by pressing the power key
- Check the battery charge level
- If it still does not work, please use User Data Format (1) to reset the phone or Mobile Upgrade to upgrade software

My phone cannot charge properly

- Make sure that your battery is not completely discharged; if the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the screen.
- (0°C to +40°C) When abroad, check that the voltage input is compatible

My phone cannot connect to a network or "No service" is

- Try connecting in another location.

- Try connecting at a later time if the network is overloaded

- printed on your warranty card or box
- Make sure that the internet access service of your SIM card is
- Make sure you are in a place with network coverage

Invalid SIM card

- Make sure the chip on your SIM card is not damaged or scratched

- Make sure your phone is connected to a network, and the network
- is not overloaded or unavailable

- (check for overloaded or unavailable network)
- card valid, etc.)
- Make sure you have not forwarded incoming calls
- Make sure that you have not harred certain calls

- Your caller has concealed his/her name or number

I cannot find my contacts

- Make sure your SIM card is not broken

Make sure that your phone is not in flight mode

Unable to receive incoming calls

You can adjust the volume during a call by pressing the navigation key Check the network strength

I am unable to use the features described in the manual

- Check with your operator to make sure that your subscription
- Make sure this feature does not require an ALCATEL ONETOUCH

When I select a number from my contacts, the number cannot be dialed

(i) Contact your network operator for service availability

I am unable to add a contact in my contacts

or save the files in the phone contacts

I cannot access my voicemail

Try later if the network is busy

I am unable to send and receive MMS

"Messages\Voicemail"

check MMS parameters

Unblocking Key) Make sure that you have selected the country prefix when calling

- Make sure that your SIM card contacts are not full; delete some files

Make sure that you're using the right cable from the box

- Make sure there is sufficient phone memory for your download

Check your subscription status with your operator

Make sure that Bluetooth is turned on and your phone is visible

How to make your battery last longer

- After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain
 - Switch on the backlight upon request

The warranty period may vary depending on your country.

purchase and for approximately 200 more recharges.

The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after

Non-compliance with the instructions for use or installation, or with

TCI Communication Ltd TCL Communication Ltd. or its affiliates or your vendor

5) Inclement weather, lightning, fire, humidity, infiltration of liquids or foods, chemical products, download of files, crash, high voltage,

use of the mobile phone.

In no event shall TCL Communication Ltd. or any of its affiliates be

Troubleshooting.....

instructions below

Use User Data Format (1) and the Mobile Upgrade tool to perform hold down # while simultaneously pressing the power on/off key under power off mode). ALL User phone data: contacts, photos, messages and files, downloaded applications like MRE games will be lost permanently. It is strongly advised to fully backup the phone

and carry out the following checks:

- Verify the network coverage with your operator
- Check with your operator that your SIM card is valid Try selecting the available network(s) manually

My phone cannot connect to the Internet • Check that the IMEI number (press *#06#) is the same as the one • Make sure your phone is switched on and connected to a network

- Check your phone's Internet connecting settings
- Try connecting at a later time or another location
- Make sure the SIM card has been correctly inserted

Make sure charging is carried out under normal conditions Make sure the service of your SIM card is available Unable to make outgoing calls

- Make sure you have dialed a valid number and press the send key For international calls, check the country and area codes
- Check your subscription status with your operator (credit, SIM) card valid, etc.)
- Make sure you have not barred outgoing calls

- Check your subscription status with your operator (credit SIM

Make sure that your phone is not in flight mode

- The caller's name/number does not appear when a call is
- · Check that you have subscribed to this service with your operator

Make sure your SIM card is inserted properly Import all contacts stored in SIM card to phone

The sound quality of the calls is poor

- Make sure that the receiver connector or speaker on your phone
- includes this service

Make sure that you have correctly recorded the number in your file

My callers are unable to leave messages on my voicemail

Contact your network operator to check service availability

Check your phone memory availability as it might be full

The server centre may be swamped, try again later

some of them or archive them in the phone memory

Contact your network operator to check service availability and

Verify the server centre number or your MMS profile with your

You have saved too many short messages on your SIM card; delete

The flickering icon is displayed on my standby screen

I am unable to connect my phone to my computer a foreign country

Install ALCATEL ONETOUCH PC suite first of all

Check that your computer meets the requirements for ALCATEL ONETOUCH PC Suite installation

TCL Communication shall not be held legally responsible for such

responsibility shall be borne by the operator exclusively. This

handset may contain materials, including applications and software in

executable or source code form, which is submitted by third parties

for inclusion in this handset ("Third Party Materials"). All third party

kind, whether express or implied, including the implied warranties of

merchantability, fitness for a particular purpose or use/third party

application, interoperability with other materials or applications of

the purchaser and non-infringement of copyright. The purchaser

obligations incumbent upon it as a manufacturer of mobile devices

and handsets in complying with Intellectual Property rights. TCL

Communication will at no stage be responsible for the inability

or failure of the Third Party Materials to operate on this handset

or in interaction with any other devices of the purchaser. To the

maximum extent permitted by law TCI. Communication disclaims

all liability for any claims demands suits or actions and more

specifically - but not limited to - tort law actions, under any theory

of liability, arising out of the use, by whatever means, or attempts to

use, such Third Party Materials. Moreover, the present Third Party

Materials, which are provided free of charge by TCL Communication.

may be subject to paid updates and upgrades in the future: TCL

Communication waives any responsibility regarding such additional

costs, which shall be borne exclusively by the purchaser. The

availability of the applications may vary depending on the countries

and the operators where the handset is used; in no event shall the

list of possible applications and software provided with the handsets

he considered as an undertaking from TCI Communication: it

shall remain merely as information for the purchaser. Therefore,

TCL Communication shall not be held responsible for the lack of

availability of one or more applications wished for by the purchaser,

as its availability depends on the country and the operator of the

purchaser TCI Communication reserves the right at any time to

add or remove Third Party Materials from its handsets without prior

notice: in no event shall TCL Communication be held responsible by

the purchaser for any consequences that such removal may have on

the purchaser regarding the use or attempt to use such applications

Contact your network operator to obtain the PUK code (Personal

undertakes that TCL Communication has complied with all quality

differences if any nor for their potential consequences which

- I am unable to download new files
- Select the microSD card as the location to store downloaded files

Make sure your operator's voicemail number is correctly entered in The phone cannot be detected by others via Bluetooth

to other users Make sure that the two phones are within Bluetooth's detection

· Make sure you follow the complete charge time (minimum 3 hours)

an exact indication

Deactivate Bluetooth when not in use