



Smart Plug P1 (US) Quick Start Guide

Read before use

Know your new plug

Button & LED Product label

Setup

Install app
Configure plug

More functions & more fun

Timing task

Period task

Delay task

Customize icon

Voice control

Push notification

Authorize other users

Energy monitoring

Feedback

Delete the plug

FAQ


Contact



Know your new plug

Button & LED







Status: Power LED is **ON**.

Description: The smart plug is

OΝ



Status: Power LED is OFF.

Description: The smart plug is



Status: WiFi LED is ON.

Description: Configuration

successful.


Status: WiFi LED is OFF.

is **Description**: Configuration is failed.

Product label

You can find the product label on the back of the smart plug, please pay attention to the Maximum current and power!

The QR Code is used for adding the plug. The Password is required for manual configuration.



Tips:

When WiFi LED is flashing, it indicates that the smart plug is waiting for configuration.



Setup

Install app

Search "Reco" in Apple Store or Google

Play



App icon

Scan it

Tips:

You can scan the QR Code on the box for access to the download pages.

Configure plug

Before configuration, please get the items ready as follows:

P1 (US) Smart Plug ×1 Smart Phone (iOS/Android) ×1 WiFi Router ×1







Smart-Link configuration

STEP 1



- Make sure that the working frequency of the router is 2.4GHz.
- 2 Make sure that the SSID of the router is visible.
- 8 Make sure that the router is encrypted.

STEP 2



When the plug is connected to power supply, long press the Power button till all LEDs flash once, wait about 5 seconds WiFi LED begins to flash

It indicates that the smart plug is resetting and turned to default connection mode.

STEP 3



Next,connect Reco4Life smart plug to the network,please ensure:

- WiFi LED is flashing
- The smart phone is connected to Internet via
 WiFi

STEP 5



WiFi LED is constantly on Configuration successful,start to use Reco now.

STEP 4



Input the password of the current WiFi network

Requirements for the router?>


yingzhenTP

Password

If Smart-Link configuration failed, please try manual configuration.

Manual configuration

STEP 1



When the plug is connected to power supply, if the WiFi LED is flashing, please press the WiFi button to cancel the flashing status.

STEP 2



Next,connect Reco4Life smart plug to the network,please ensure:

WiFi LED of Reco4Life smart plug is off

STEP 3



1.Click "settings" and enable "WIFI".

✓ Reco123456789 💎

Select the network of your
 Reco4Life smart plug.



3.The password is the same as the password on the back of the plug.

 Connection completed, return to this interface and click the button to continue.

Tips:

Please contact us if you cannot configure the plug successfully for several times.



Congratulations, configuration successful!

More functions & more fun

Timing task

Login your Reco account, click "Task" -> Click "+" on the top right corner -> Click "Timing".

You can turn on/off the appliances at the set time. E.g. turn off the light at 9:00 am.



Period task



Login your Reco account, click "Task" -> Click "+" on the top right corner -> Click "Period".

You can turn on/off the appliances at the set duration. E.g. turn off the light during 9:00 am. —17:00 pm.

Delay task

Login your Reco account, click "Task" -> Click "+" on the top right corner -> Click "Delay".


You can turn on/off the appliances after a period of time.

E.g. turn off the light after 30 minutes.



Customize icon

Login your Reco account, long press the device and click "Edit" -> Choose the icon and edit the name -> Click "Save" on the top right corner.



You could modify the name of connected device as well.



Voice control

You can control Reco App by voice command.

Please notice that:

"Turn on the light" ("light" is the device name, if the device you edited is "floor lamp", you need to say "turn on the floor lamp")

You can also command like this: "turn the light on"




Push notification

Login your Reco account, click "Device Details" -> Click "Settings" -> Set the push notification that you need.



Authorize other users

Login your Reco account, click "Device Details" -> Click "Settings" -> Click "+"marked -> Fill in the usernames of your families or friends, then they will get the permissions to control and monitor your plug.





Energy monitoring

Login your Reco account.

Click the device to view the current power and cost.


Click the blue area to view the historical data.

Feedback

Login your Reco account.

Click "Mine" -> Click "About Reco".

Click "Feedback".



Delete the plug



iOS

Tips:
With Android App, you can long press to edit the device.

Reco

Pevice
Task
Me

Reco Smart Plug

Reco Smart Plug

Edit

Android

Delete Cancel

FAQ

(Q): What's Reco account?

A:

With a registered account, you are able to control the smart plug remotely, experience all functions and further push notifications for upgrade. All other smart products by Reco4life can be added to this account, enjoy your smart life with one account.

O: How to change the password of the account?

(A):

Login your Reco account, click "Me"-> click your username -> click "password" -> fill in the new password twice, and click the "save" button on the top right corner.

①: The icon of the smart plug is grey, and the plug is unavailable.

A:

- 1. First, please check whether the smart plug is connected well to the power supply, and you can try to pull out the smart plug, then re-plug it.
- 2. Please try to close the App, and restart it later
- 3. It might be caused by network error, please have a check whether you can access the Internet via your router.
- 4. The configuration might be unsuccessful, please try to configure the smart plug again.

①: How to reset the password?

A:

Start Reco App, and click "Forget password?"

You can reset the password via e-mail: Fill in the bound e-mail -> Check the e-mail sent to your e-mail address -> Click the URL and reset the password in the pop-up webpage.

O: How many tasks can I set for the smart plug?

A:

There is no limit on the amount of tasks.

①: What to do when I am informed that "no response of the device"

A:

Step 1: Please try to close the App, and restart it later. Please move to step 2 if you still have the problem.

Step 2: Please try to pull out the smart plug and then re-plug it to the power supply. Please move to step 3 if you still have the problem.

Step 3: Please try to configure the smart plug again.

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons.