











Q1: Why does the device can't be connected?

A1, There are 2 modes to setup, 'Smartconfig' setup mode and

- 'AP' setup mode. User can long press device's Wi-Fi button for 5 seconds to switch between this 2 modes. Indicator light rapidly blink twice per second is 'Smartconfig' setup mode, user should
- click 'Confirm indicator rapidly blink' button in APP to setup. push alarm within 1 minute. Indicator light slowly blink once per 2 seconds is 'AP' setup 5. Maybe in APP-Device-Notice-Detection Alarm is disable. mode, user should click 'AP Mode' in the APP to setup
 - Pls enable it 6. Maybe in APP-Profile-Settings-Push Notification is
 - disable. Pls enable it.
- phone to receive push notification of this APP. Pls check 4, Maybe your router haven't open DHCP. Pls open DHCP in your phone's notification center to enable receiving push
- 5. Maybe device is too far away from the Wi-Fi router. Pls put 8 Maybe you use Android tablet device don't support
- device close to router or add Wi-Fi repeater. Android tablet which will close Wi-Fi if screen closed. 6, Maybe your router's WiFi have special settings, pls reset
- Q2. Why I can't receive push notification alarm or miss some

- nush notification alarm?

2. Maybe you are using 5Ghz WiFi router, device don't support

5Ghz WIFL user should use 2.4GHz WiFi router to connect.

- A1, Maybe you use Android smart phone and you are in China mainland but you register other country or Hong Kong APP user account then you can't receive push notification. You should register APP China mainland user account when you
- are in China mainland for Android smartphone 2, Maybe you use Android smart phone and register China mainland user account but you have stop APP in the smart

notification. Android smart phone APP China mainland user account should keep APP running at Android smart phone's background to receive push notification alarm. 3. Maybe device is too far away from the Wi-Fi router. Pls put

phones' background, then you can't receive push

- device close to router or add Wi-Fi repeater. 4. Device will only send push notification alarm every
- minute to save battery. After 1 push notification it will not
- 7. Maybe when you install the APP you haven't allowed smart
- notification of this APP
- 9. Maybe you had turn off your phone's 3G/4G network then you might miss some push notification alarm when battery is low or WiFi is intermittently disconnected. You should always turn on 3G/4G network to be receive push notification all the time.

1pc CR123A 3V dry battery.

Specification

(Note: Rechargable battery RCR123A 4.2V is forbidden.) WiFi frequency: Standby Time: About 2 years if no detection

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.