





open app"VeryFitPro"





4. Working Time





1.2.1 Data Reading Sub-Mode

1.3 Heart Rate Mode

234
STEP

34.5
STEP

34.5
STEP


AND

AND


Click the touch key] to enter the next sub-mode


Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode


measure BPM BPM BPM





	12:34:56	
	Average pace Pace/Speed Pm	
ouch key for 2s] to enter the	[Click the touch key] to enter the next sub-mode of "Sports Underway"[Press and hold the touch key fo to enter any interface of Data Reading, press and h to exit the sports mode.	
to enter the next sports mode; and in		
ner sports modes, it will go back to the	Note: The speed and distance of riding can be displayed, but to be connected and the riding and App needs to start at the s	
s mode can be selected in App (App		
f track recording sports and 10 types	1.5.3 Sports Stop Mode	
	If the sports last less than 1 minute, the user will be reminded of not saving the data.	SI
e countdown interface of 3-2-1-GO ports underway mode.	[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)	trai ses Not













1.5.5 Abnormal operations during activity The reminder will be available soon

mode for low-battery

PLS
CHARGE
Note: The reminder will occur when a user tried to start
the sports mode with the battery of device is in low.

2) Message Reminder

~

•

 Camera mode control 3) Alarm Clock Alarm Clock: The relevant settings need to done in the App. Entry mode: Start the camera entry by App, and the device will get in the camera mode successfully.

Photo taking Photo taking methods: shake/wrist lifting/click the touch key

Alarm Clock Types: Modes of exit:

1. Press and hold the touch key to exit from the camera mode

2. Exit through App will make the wrist strap quit from the camera mode. Wake up Medicine taking Sleeping Party 2. More modes of reminders Appointment Exercise Meeting 1) Call Reminder Click the touch key to remove the call reminder Press and hold the touch key to hang up the call Note: The call reminder in the App needs to be set open. 4)Long Sitting Reminder

Alarm Clock Reminder: The relevant settings need to done in the App.. Click the touch key: It will remove the reminder. 5) Target completion reminder eat together at night there is no time ... In case of pages of messages, Click the touch key to read the remained ones.

Note: The relevant settings need to done in the App.

When some goals are achieved, shake the wrist strap to get the interface of target completion reminde displayed Click the touch key to quit from the reminder strap to get the interface of target completion reminder displayed Click the touch key to quit from the reminder

6) Low battery reminder Low-Battery! Please recharge timely! 7) Device Error Notification Note: When the device is detected with an abnormality, the interface herein will be displayed each time the device is opened.

Status Code:
-01 means the abnormality of acceleration sensor
-02 means the abnormality of heart rate sensor
-03 means the abnormality of touch key IC
-04 means the abnormality of flash

Model No.: ID131HR

Battery Capacity: 65mAh

Host weight: about 30g

Working temperature: -10 ℃ - 45 ℃

Product frequency band: 2402-2480MHz

Maximum transmit power: 0.97dBm

Working Voltage: 3.7V

Sync: Bluetooth 4.0

Waterproof: IP67

Working Time: 8days

Basic Specifications

The device meets the EU ROHS criterion.
Please refer to IEC 62321, EU ROHS Directive
2011/65/EU and revised directive. ◆ Failed to find the device when pairing ① Make sure the Bluetooth of smart phone is ON, and smart phone OS Android 4.4 & Above, iOS 7.0 & Above. ② Make sure the distance between phone and device is within 0.5meter, device is among the normal Bluetooth communication distance range(within 10meter) after pairing finished. ③ Make sure the device is not under low battery. If there is still a problem after fully charged, please contact us.

13

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help. RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE ◆ Failed to connect with Bluetooth occasionally ① Caused by the abnormality of Bluetooth service when it restarted on the phone. TO THE INSTRUCTIONS $\ensuremath{ \mathbb{Z}}$ Reboot mobile phone or re-start the Bluetooth service, then it works normal. How to restore factory defaults Make sure the device is connected with smart phone, go in the App, enter "device-- System setting", and choose "reboot device".

DISPOSE OF USED BATTERIES ACCORDING Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances. 14

This device complies with Part 15 of the FCC Rules. Operation is subject

(2) this device must accept any interference received, including interference

to the following two conditions:
(1) this device may not cause harmful interference, and

that may cause undesired operation.