
Wireless Charging Equipment Quick Guide


Wireless Resonant Power & Charging



Device And Accessories



Specifications



CFS011
Wireless Charging Transmitter

| Model | CFS011 |
|-----------------------|---------------------------------|
| Name | Wireless Charging Transmitter |
| Power Transfer | 6.78MHz |
| Bluetooth | BLE4.0 |
| Adaptor | DC 15V/1.5A |
| PTU Matching | CJT111/CJT211(Recommended) |
| Dimensions | 258mm*200mm*6.5mm |
| Charging Area | 250mm*162mm |
| Charging Distance | 50mm matching PTU CJT111/CJT211 |
| PRU Quantity | 2 |
| Weight | 300g |
| Operating Temperature | 0°C to 50°C |
| Storage | -40°C to +80°C |

Specifications



CJT111 Wireless Charging Receiver

| Model | CJT111 |
|-----------------------|----------------------------|
| Name | Wireless Charging Receiver |
| Connector Type | Apple Lighting |
| Power Transfer | 6.78MHz |
| Output Current | DC 1A |
| Output Voltage | DC 5V |
| Bluetooth | BLE4.0 |
| PTU Matching | CFS011 |
| Dimensions | φ64mm*8.2mm(Recommended) |
| Charging Area | φ60mm |
| Charging Distance | 50mm matching PTU CFS011 |
| Weight | 38g |
| Operating Temperature | 0°C to 50°C |
| Storage | -40°C to +80°C |


Specifications




CJT211 Wireless Charging Receiver

| Model | CJT211 |
|-----------------------|----------------------------|
| Name | Wireless Charging Receiver |
| Connector Type | MicroUSB |
| Power Transfer | 6.78MHz |
| Output Current | DC 1A |
| Output Voltage | DC 5V |
| Bluetooth | BLE4.0 |
| PTU Matching | CFS011 |
| Dimensions | φ64mm*8.2mm(Recommended) |
| Charging Area | φ60mm |
| Charging Distance | 50mm matching PTU CFS011 |
| Weight | 38g |
| Operating Temperature | 0°C to 50°C |
| Storage | -40°C to +80°C |


Charging




1. Plug in power.




3. Put PRU on the PTU, and the phone will be charged.



Connect PRU to smart phone with PRU right side facing up.



4. PTU can also be put underneath the table. Repeat step 1 to 3, and the phone will be charged.



Note: The mobile phone should be placed in the wireless charging area which is shown in the shadow

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this

equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help