

LED Lighting Speaker Instruction

技术参数

光源类型 无级调光LED灯 传输类型 无线传输 V4.2 音响尺寸 ø 110 x 267mm

音 响 重 量 : 500g 充 电 接 口

: DC 5V-1A Micro USB 额 定 功 率

200 Hz ~ 20 kHz 频 率 响 应

电池充电时间: 4小时 音乐播放时间:5小时 蓝牙发射机功率。5dBm

蓝牙发射频率。2402~2480 MHz

传输距离 : < 10米(传输距离因环境因素和 手机蓝牙设备不同而有所差异)



使用说明

LED灯

按一下光源开关,LED灯亮起,旋转明暗调节器可呈现不同亮度

音响

1. 长按3秒音响开关待发出提示音即可开机

2. 将你的蓝牙设备打开,接着连接"Candle Light"装置,连接成功 后会发出提示音

3. 如果在连接装置的时候提示你输入密码,请输入"0000"就可以 进入配对状态声

充电提示音: 当电量不足时,会有提示音,提醒你需要充电

指示灯状态表示

● – LED灯关闭时橘灯长亮。 LED灯开启时橘灯熄灭, 按扭长按时,橘灯也会熄灭

◀ - 红灯常亮,充电中


□ - 绿灯常亮,充满电

■ - 蓝灯常亮,蓝牙设备连接成功 LED灯开关/ ★ = 蓝灯闪烁,播放音乐中



音响开关/

请勿将任何明火火源,如点燃的蜡烛放在产品之上或附近



LED油燈音響使用說明書

技術參數 光源類型 無級調光LED燈 藍牙版本 無線傳輸 V2.1+EDR 音響尺寸 : Ø 110 x 267mm 音響重量 充 電 介 面 : DC 5V-1A Micro USB 額 定 功 率 5W 频率响应 200 Hz ~ 20 kHz 電池規格 鋰聚合物電池 3.7V 1800mA 電池充電時間 4小時 音樂播放時間:5小時 藍牙發射機功率 5dBm 藍牙發射頻率 2402~2480 MHz 傳輸距離: < 10米(傳輸距離因環境因素和 手機藍牙設備不同而有所差異)

(附電源線)

便由说明

LED燈

按一下光源開闢,LED燈亮起,旋轉明暗調節器可呈現不同亮度

音響

- 1. 長按3秒音響開關待發出提示音即可開機
- 2. 將你的藍牙設備打開,接著連接"Candle Light"裝置,連接成功 後會發出提示音
- 3. 如果在連接裝置的時候提示你輸入密碼,請輸入"0000"就可以 進入配對狀態聲

充電提示音: 當電量不足時,會有提示音,提醒你需要充電


指示燈狀態表示

● - LED燈關閉時橋燈長亮 LED 燈開啟時橘燈熄滅, 按扭長按時,橘燈也會熄滅

■ - 紅燈常亮,充電中

🗗 🗕 綠燈常亮,充滿電 ■ - 藍燈常亮,藍牙設備連接成功 LED燈開闢/

其 - 藍燈閃爍,播放音樂中 → 二 一 紅藍交互閃爍,藍牙設備連接失敗



TECHNICAL SPECIFICATION

Light Source Transmission Type Dimensions

BT V4.2 ø 110 x 267mm

Charging Interface Power Consumption Frequency Response

DC 5V-1A Micro USB 200 Hz ~ 20 kHz Li-ion Rechargeable

Battery 3.7V 1700mA


Dimmable LED

Battery Battery Charge Time 4 hours

RF Power Control Range Operating Frequency Transmission Distance

Normal Volume Playing Time 5 hours

2402-2480 MHz < 10M (Transmission distance depend on the environmental factors with your phone or



HOW TO USE

LED

Press the light switch to turn on the light, and use the dimmer knob to control brightness

SPEAKER

- 1. Press and hold speaker button for 3 seconds until the beep sound is turned on
- 2. Turn on the Bluetooth device, then pair to the "Candle Light" device, the connection is successful when hear up the beep sound.
- 3. If the Bluetooth device is reminded to enter a password, please enter" 0000 "to connect

Low battery warning: There will be a beep sound, please charge device

INDICATOR STATUS


 When the LED ON, the indicator went off. When the LED OFF, the indicator stayed on Hold down to turn off the indicator

Charging, RED ☐ Charged, GREEN

 for Bluetooth device to connect. Connect successed, BLUE.

Flashing in BLUE, playing music Light switch/ Speaker switch/ indicator indicator = Flashing in RED and BLUE is failed

CRASSAV



CAUTION

Please do not place near fire (e.g. lighted candle) The light source of this fixture is irreplaceable



圖解

