





#### Data parameter

## Basic:

Data transmission: 1Mbps Frequency: 2402MHZ-2480MHZ

Channel: 16
Engine: Optical
Distance: 30m
Voltage: 3V
Current: 4mA

Key life: 500W Above Size: 115x78x38mm Weight: 95g

## **Step current:**

Working current = 4mA

Standby current = 1.3mA

Dormancy current = 50uA

No receiver state = 10-25uA

# Tracking performance:

Resolution: 1000-1600-2000-2400DPI

Rate of return: 250-500Hz Max. acceler ation: 20G

## System requirement:

- ▶ IBM or compatible computer
- Windows: 2000/ ME/ XP(x64) / Vista / 7/ 8
- ► Mac OS X(More than V10.4)
- ▶ Workable USB port

#### § 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### § 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.