# Security System High Security for Galaxy Watch(Small) INSTALLATION MANUAL

<u>Kumoh</u>

Please carefully read the installation manual before installation work, and please do the installation following to manual. Please keep the manual for future reference.

#### ▶ Before installing, Please check up the parts





#### ! CAUTION -When attaching the double-sided adhesive tape.

- 1. Take care to ensure that the adhesive surface stays clean after you remove the protective film from the double-sided adhesive tape.
- If touching the tape with a hand or foreign materials get on it, its adhesive strength can be significantly deteriorated.

  2. The adhesive tape will have full adhesive strength after the 24 hours from its placement. Please do not use the products right after its installation.

#### Installation Guide - High Security for Galaxy Watch(Small)

### How to assemble



With the Galaxy Watch(Small) strap buckle facing upward, assemble Galaxy Watch(Small) according to the shape of cradle(a) head.

\*\*Make sure to use the Galaxy Watch 'Small' product, Galaxy Watch 'Large' Product can not be assembled.



Assemble the security cover(f b) to the groove on the cradle(f a) head, and then assemble the screw(f f) using the triangle wrench(f g).





Assemble the security cover(b) in the same way as No. 2. 3

Assemble the triangle wrench( $\bigcirc$ ) and the hexagonal wrench( $\bigcirc$ ) and fasten the screws (4) firmly again to prevent the screws fixing the security cover from becoming If this step is omitted, the screw may become loose easily










Remove the sealing sheet(h) from the protective film and attach it to the assembled screw (4 places) firmly. \*\*Attach the sealing sheet (h) to

the screw and press it strongly for more than 30 seconds.

Fasten the loosened strap using a buckle as shown in the figure.







- ① Assemble 2 full threaded bolts(d) to the bottom surface of the cradle(a) along the hole on the table
- ② At first, insert the charging & security cable( connector into the groove on the table, and then place 2 full threaded bolts( d) assembled to the bottom surface of the cradle along the hole on the table.




- ① Assemble the washer(k) to the full threaded bolts(d) assembled to the cradle at the bottom surface of the table and fix the cradle firmly to prevent it from moving by rotating the butterfly nut(a). \*\* Process all 2 full threaded bolts equally. by rotating the butterfly nut(e).
- ② Connect the charging & security cable( ) connector to the control box and turn

Remove all 4 sealing sheets (n) attached to the screw, loosen all screws using the triangle wrench (n) and the hexagonal wrench (n) and separate the security










#### ► How to separate the High Security for Galaxy Watch(Small)

#### st Before separating the charging & security cable connector, make sure to turn off the control box.









#### Safety warning

Control box

- Do not expose the product to fire or other electric heaters!
   This creates the risk of fire or damage to the product.
   Do not disassemble, repair, or remodel the product!
   This creates the risk of injury.
- Do not forcibly bend or pull the cable!
   This creates the risk of damage to the product or injury to the user.
   When the cable is disconnected or breaks away, do not touch the cable with bare hands,
- but always wear protective hand gloves!

   The disconnected part of the cable is sharp, thus, may cause injury
- Do not use the cable for purposes other than as a security alarm device, and do not allow access to children!
- Winding the cable around your neck or body may result in death or serious injury.
   Do not touch the cable when there is lightning and thunder!
- This creates the risk of electric shock
- The cable is a consumable product, so free repair service is not provided even within the warranty period in the event of damage or failure due to excessive use or intentional misuse.
- \*\* The specifications and design(& color) of the product may be modified without prior notice for the improvement of product performance.

#### **▶** Information

#### Limited warranty

Item	Warranty Period
High Security for Galaxy Watch(Small)	One year from shipment date.

#### Manufacturer Information

Manufacturer	KUMOH Electronics Co.,Ltd
Address	35, Gilju-ro 444beon-gil, Bucheon-si, Gyeonggi-do (Seoul 14556 Korea)
Tel / Fax	82-32-662-2000 / 82-32-662-9312
E-mail	sale@kumohec.co.kr

## ■ For detailed information about our service support, please contact us by email at sale@kumohec.co.kr or by phoning +82-32-662-2000

We will provide repair services (including delivery charge)free of charge according to the our company's regulations for any failure or damage occurring during normal use according to the directions in the instruction manual within the warranty period. Free repair If the warranty period has expired, repairs can be provided for a fee. Furthermore, even during the warranty period the free repair service will not be provided in the following circumstances:

Charged repair

• When damage has occurred due to the negligence or carelessness

- When damage has occurred due to the regigions of the user.
  When failure or damage have occurred due to an arbitrary repair, structural or performance modification by the consumer.
  When failure or damage have occurred due to force majeure or fire.

#### FCC Warning Statement

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 10cm between the radiator and your body.

#### IC Warning Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence, L'exploitation est autorisée aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### IC Radiation Exposure Statement

This equipment complies with IC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 10cm between the radiator and your body.

Cet equipment est conforme aux limites établies par Industrie Canada en matière d'exposition aux radiofréquences dans un environnement non contrôlé. Cet appareil et son antenne ne doivent pas être colocalisés ou

fonctionner en conjonction avec tout autre antenne ou émetteur. Cet équipement doit être installé et utilisé avec une distance minimale de 10cm entre le radiateur et votre corps

### **► MEMO**